

Proxmox VE Administration Guide

Release 9.2.22



November 24, 2026

Proxmox Server Solutions GmbH

www.proxmox.com

Copyright © 2026 Proxmox Server Solutions GmbH

Permission is granted to copy, distribute and/or modify this document under the terms of the GNU Free Documentation License, Version 1.3 or any later version published by the Free Software Foundation; with no Invariant Sections, no Front-Cover Texts, and no Back-Cover Texts.

A copy of the license is included in the section entitled "GNU Free Documentation License".

Contents

1 Introduction **1**

1.1 Central Management . . . 2
1.2 Flexible Storage . . . 3
1.3 Integrated Backup and Restore . . . 3
1.4 High Availability Cluster . . . 4
1.5 Flexible Networking . . . 4
1.6 Integrated Firewall . . . 4
1.7 Hyper-converged Infrastructure . . . 4
1.7.1 Benefits of a Hyper-Converged Infrastructure (HCI) with Proxmox VE . . . 4
1.7.2 Hyper-Converged Infrastructure: Storage . . . 5
1.8 Why Open Source . . . 5
1.9 Your Benefits with Proxmox VE . . . 5
1.10 Getting Help . . . 6
1.10.1 Proxmox VE Wiki . . . 6
1.10.2 Community Support Forum . . . 6
1.10.3 Mailing Lists . . . 6
1.10.4 Commercial Support . . . 6
1.10.5 Bug Tracker . . . 6
1.11 Project History . . . 7
1.12 Improving the Proxmox VE Documentation . . . 8
1.13 Translating Proxmox VE . . . 8
1.13.1 Translating with git . . . 8
1.13.2 Translating without git . . . 9
1.13.3 Testing the Translation . . . 9
1.13.4 Sending the Translation . . . 9

2 Installing Proxmox VE **10**
2.1 System Requirements . . . 10
2.1.1 Minimum Requirements, for Evaluation . . . 10
2.1.2 Recommended System Requirements . . . 11
2.1.3 64-bit ARM (arm64) Support . . . 11
2.1.4 Simple Performance Overview . . . 12
2.1.5 Supported Web Browsers for Accessing the Web Interface . . . 12
2.2 Prepare Installation Media . . . 12
2.2.1 Prepare a USB Flash Drive as Installation Medium . . . 13
2.2.2 Instructions for GNU/Linux . . . 13
2.2.3 Instructions for macOS . . . 14
2.2.4 Instructions for Windows . . . 14
2.3 Using the Proxmox VE Installer . . . 15
2.3.1 Accessing the Management Interface Post-Installation . . . 23
2.3.2 Advanced LVM Configuration Options . . . 24
2.3.3 Advanced ZFS Configuration Options . . . 25
2.3.4 Advanced BTRFS Configuration Options . . . 26
2.3.5 Advanced Network Configuration Options . . . 26
2.3.6 ZFS Performance Tips . . . 27
2.3.7 Adding the `nomodeset` Kernel Parameter . . . 27
2.4 Unattended Installation . . . 27
2.5 Install Proxmox VE on Debian . . . 28

3 Host System Administration **29**
3.1 Package Repositories . . . 29
3.1.1 Repositories in Proxmox VE . . . 29
3.1.2 Debian Base Repositories . . . 31
3.1.3 Proxmox VE Enterprise Repository . . . 31
3.1.4 Proxmox VE No-Subscription Repository . . . 32
3.1.5 Proxmox VE Test Repository . . . 32
3.1.6 Proxmox VE Debug Symbol Repository . . . 32
3.1.7 Ceph Repositories . . . 33
3.1.8 Debian Firmware Repository . . . 35
3.1.9 SecureApt . . . 35
3.2 System Software Updates . . . 36
3.3 Firmware Updates . . . 36

3.3.1 Persistent Firmware . . . 37
3.3.2 Runtime Firmware Files . . . 37
3.3.3 CPU Microcode Updates . . . 37
3.4 Network Configuration . . . 40
3.4.1 Apply Network Changes . . . 40
3.4.2 Naming Conventions . . . 41
3.4.3 Choosing a network configuration . . . 44
3.4.4 Default Configuration Using a Bridge . . . 45
3.4.5 Routed Configuration . . . 46
3.4.6 Masquerading (NAT) with `iptables` . . . 47
3.4.7 Linux Bond . . . 48
3.4.8 VLAN 802.1Q . . . 51
3.4.9 Disabling IPv6 on the Node . . . 54
3.4.10 Disabling MAC Learning on a Bridge . . . 55
3.5 Time Synchronization . . . 55
3.5.1 Using Custom NTP Servers . . . 55
3.6 External Metric Server . . . 57
3.6.1 Graphite server configuration . . . 57
3.6.2 Influxdb plugin configuration . . . 58
3.7 Disk Health Monitoring . . . 58
3.8 Logical Volume Manager (LVM) . . . 59
3.8.1 Hardware . . . 60
3.8.2 Bootloader . . . 60
3.8.3 Creating a Volume Group . . . 60
3.8.4 Creating an extra LV for `/var/lib/vz` . . . 61
3.8.5 Resizing the thin pool . . . 61
3.8.6 Create a LVM-thin pool . . . 62
3.9 ZFS on Linux . . . 62
3.9.1 Hardware . . . 63
3.9.2 Installation as Root File System . . . 63
3.9.3 ZFS RAID Level Considerations . . . 64
3.9.4 ZFS dRAID . . . 65
3.9.5 Bootloader . . . 66
3.9.6 ZFS Administration . . . 66
3.9.7 Configure E-Mail Notification . . . 71

3.9.8 Limit ZFS Memory Usage . . . 71
3.9.9 SWAP on ZFS . . . 72
3.9.10 Encrypted ZFS Datasets . . . 73
3.9.11 Compression in ZFS . . . 74
3.9.12 ZFS Special Device . . . 75
3.9.13 ZFS Pool Features . . . 76
3.10 BTRFS . . . 76
3.10.1 Installation as Root File System . . . 77
3.10.2 BTRFS Administration . . . 78
3.11 Proxmox Node Management . . . 80
3.11.1 Wake-on-LAN . . . 80
3.11.2 Task History . . . 81
3.11.3 Bulk Guest Power Management . . . 81
3.11.4 First Guest Boot Delay . . . 81
3.11.5 Bulk Guest Migration . . . 82
3.11.6 RAM Usage Target for Ballooning . . . 82
3.12 Certificate Management . . . 82
3.12.1 Certificates for Intra-Cluster Communication . . . 82
3.12.2 Certificates for API and Web GUI . . . 82
3.12.3 Upload Custom Certificate . . . 83
3.12.4 Trusted certificates via Let's Encrypt (ACME) . . . 83
3.12.5 ACME HTTP Challenge Plugin . . . 85
3.12.6 ACME DNS API Challenge Plugin . . . 86
3.12.7 Automatic renewal of ACME certificates . . . 87
3.12.8 ACME Examples with `pvenode` . . . 87
3.13 Host Bootloader . . . 90
3.13.1 Partitioning Scheme Used by the Installer . . . 91
3.13.2 Synchronizing the content of the ESP with `proxmox-boot-tool` . . . 91
3.13.3 Determine which Bootloader is Used . . . 94
3.13.4 GRUB . . . 95
3.13.5 Systemd-boot . . . 95
3.13.6 Editing the Kernel Commandline . . . 96
3.13.7 Override the Kernel-Version for next Boot . . . 96
3.13.8 Secure Boot . . . 97
3.14 Kernel Samepage Merging (KSM) . . . 100
3.14.1 Implications of KSM . . . 100
3.14.2 Disabling KSM . . . 101

4 Graphical User Interface 102
4.1 Features . . . 102
4.2 Login . . . 103
4.3 GUI Overview . . . 103
4.3.1 Header . . . 104
4.3.2 My Settings . . . 104
4.3.3 Resource Tree . . . 105
4.3.4 Log Panel . . . 105
4.4 Content Panels . . . 106
4.4.1 Datacenter . . . 106
4.4.2 Nodes . . . 107
4.4.3 Guests . . . 109
4.4.4 Storage . . . 110
4.4.5 Pools . . . 111
4.5 Tags . . . 112
4.5.1 Style Configuration . . . 113
4.5.2 Permissions . . . 113
4.6 Consent Banner . . . 114

5 Cluster Manager 115
5.1 Requirements . . . 115
5.2 Preparing Nodes . . . 116
5.3 Create a Cluster . . . 117
5.3.1 Create via Web GUI . . . 117
5.3.2 Create via the Command Line . . . 117
5.3.3 Multiple Clusters in the Same Network . . . 117
5.4 Adding Nodes to the Cluster . . . 118
5.4.1 Join Node to Cluster via GUI . . . 118
5.4.2 Join Node to Cluster via Command Line . . . 119
5.4.3 Adding Nodes with Separated Cluster Network . . . 120
5.5 Remove a Cluster Node . . . 120
5.5.1 Prerequisites . . . 121
5.5.2 Remove the Cluster Node . . . 121
5.5.3 Cleanup Steps After Node Removal . . . 123
5.6 Separate a Node Without Reinstalling . . . 123
5.7 Cluster ID . . . 125

5.8 Quorum . . . 126
5.9 Cluster Network . . . 126
5.9.1 Network Requirements . . . 127
5.9.2 Corosync Over Bonds . . . 127
5.9.3 Separate Cluster Network . . . 128
5.9.4 Corosync Addresses . . . 131
5.10 Corosync Redundancy . . . 132
5.10.1 Adding Redundant Links To An Existing Cluster . . . 132
5.11 Role of SSH in Proxmox VE Clusters . . . 134
5.11.1 SSH setup . . . 134
5.11.2 Pitfalls due to automatic execution of `.bashrc` and siblings . . . 135
5.12 Corosync External Vote Support . . . 135
5.12.1 QDevice Technical Overview . . . 135
5.12.2 Supported Setups . . . 136
5.12.3 QDevice-Net Setup . . . 136
5.12.4 Frequently Asked Questions . . . 137
5.13 Corosync Configuration . . . 138
5.13.1 Edit corosync.conf . . . 138
5.13.2 Changing the Token Coefficient . . . 139
5.13.3 Troubleshooting . . . 140
5.13.4 Corosync Configuration Glossary . . . 141
5.14 Cluster Cold Start . . . 141
5.15 Guest VMID Auto-Selection . . . 141
5.16 Guest Migration . . . 142
5.16.1 Migration Type . . . 142
5.16.2 Migration Network . . . 143

6 Proxmox Cluster File System (pmxcfs) 145
6.1 POSIX Compatibility . . . 145
6.2 File Access Rights . . . 146
6.3 Technology . . . 146
6.4 File System Layout . . . 146
6.4.1 Files . . . 146
6.4.2 Symbolic links . . . 147
6.4.3 Special status files for debugging (JSON) . . . 148
6.4.4 Enable/Disable debugging . . . 148
6.5 Recovery . . . 148
6.5.1 Remove Cluster Configuration . . . 148
6.5.2 Recovering/Moving Guests from Failed Nodes . . . 148

7 Proxmox VE Storage **150**

7.1 Storage Types . . . 150
7.1.1 Thin Provisioning . . . 151
7.2 Storage Configuration . . . 152
7.2.1 Storage Pools . . . 152
7.2.2 Common Storage Properties . . . 153
7.2.3 Volume Types of Guests . . . 155
7.3 Volumes . . . 155
7.3.1 Volume Ownership . . . 156
7.4 Using the Command-line Interface . . . 156
7.4.1 Examples . . . 156
7.5 Directory Backend . . . 158
7.5.1 Configuration . . . 159
7.5.2 File naming conventions . . . 159
7.5.3 Storage Features . . . 160
7.5.4 Examples . . . 160
7.6 NFS Backend . . . 160
7.6.1 Configuration . . . 161
7.6.2 Storage Features . . . 161
7.6.3 Examples . . . 162
7.7 CIFS Backend . . . 162
7.7.1 Configuration . . . 162
7.7.2 Storage Features . . . 163
7.7.3 Examples . . . 164
7.8 Proxmox Backup Server . . . 164
7.8.1 Configuration . . . 164
7.8.2 Storage Features . . . 165
7.8.3 Encryption . . . 166
7.8.4 Example: Add Storage over CLI . . . 167
7.9 Local ZFS Pool Backend . . . 167
7.9.1 Configuration . . . 167
7.9.2 File naming conventions . . . 168
7.9.3 Storage Features . . . 168
7.9.4 Encryption . . . 169
7.9.5 Examples . . . 169

7.10 LVM Backend . . . 169
7.10.1 Configuration . . . 169
7.10.2 File naming conventions . . . 171
7.10.3 Storage Features . . . 171
7.10.4 Examples . . . 172
7.11 LVM thin Backend . . . 172
7.11.1 Configuration . . . 172
7.11.2 File naming conventions . . . 173
7.11.3 Storage Features . . . 173
7.11.4 Examples . . . 173
7.12 Open-iSCSI initiator . . . 173
7.12.1 Configuration . . . 174
7.12.2 File naming conventions . . . 174
7.12.3 Storage Features . . . 175
7.12.4 Examples . . . 175
7.13 User Mode iSCSI Backend . . . 175
7.13.1 Configuration . . . 175
7.13.2 Storage Features . . . 176
7.14 Multipath . . . 176
7.14.1 Prerequisites . . . 176
7.14.2 Setting Up Shared LVM . . . 177
7.14.3 Adding Another LUN . . . 178
7.14.4 Growing a LUN . . . 178
7.14.5 Removing a LUN . . . 178
7.14.6 Checking Path Failures . . . 179
7.14.7 Multipath Entries . . . 180
7.14.8 Array Settings and Existing Configurations . . . 181
7.15 NVMe over Fabrics Backend . . . 181
7.15.1 Prerequisites . . . 181
7.15.2 Setting Up Shared LVM . . . 182
7.15.3 Configuration . . . 183
7.15.4 Checking and Disconnecting Paths . . . 184
7.15.5 Limits . . . 184
7.16 Ceph RADOS Block Devices (RBD) . . . 185
7.16.1 Configuration . . . 185

7.16.2 Authentication . . . 186
7.16.3 Ceph client configuration (optional) . . . 187
7.16.4 Storage Features . . . 187
7.17 Ceph Filesystem (CephFS) . . . 187
7.17.1 Configuration . . . 188
7.17.2 Authentication . . . 189
7.17.3 Storage Features . . . 189
7.18 BTRFS Backend . . . 190
7.18.1 Configuration . . . 190
7.18.2 Snapshots . . . 190
7.19 ZFS over ISCSI Backend . . . 190
7.19.1 Configuration . . . 191
7.19.2 Storage Features . . . 192

8 Deploy Hyper-Converged Ceph Cluster 194
8.1 Introduction . . . 194
8.2 Terminology . . . 195
8.3 Recommendations for a Healthy Ceph Cluster . . . 195
8.4 Initial Ceph Installation & Configuration . . . 198
8.4.1 Using the Web-based Wizard . . . 198
8.4.2 CLI Installation of Ceph Packages . . . 200
8.4.3 Initial Ceph configuration via CLI . . . 200
8.5 Ceph Monitor . . . 201
8.5.1 Create Monitors . . . 201
8.5.2 Destroy Monitors . . . 202
8.6 Ceph Manager . . . 202
8.6.1 Create Manager . . . 202
8.6.2 Destroy Manager . . . 202
8.7 Ceph OSDs . . . 203
8.7.1 Create OSDs . . . 203
8.7.2 Destroy OSDs . . . 205
8.8 Ceph Configuration . . . 205
8.9 Ceph Pools . . . 206
8.9.1 Create and Edit Pools . . . 207
8.9.2 Erasure Coded Pools . . . 208
8.9.3 Destroy Pools . . . 212

8.9.4 PG Autoscaler . . . 212
8.10 Ceph CRUSH & Device Classes . . . 213
8.11 Cephx Authentication . . . 215
8.11.1 Keyring Locations . . . 215
8.11.2 Encrypted OSD Lockbox Keys . . . 215
8.12 Ceph Client . . . 216
8.13 CephFS . . . 216
8.13.1 Metadata Server (MDS) . . . 217
8.13.2 Create CephFS . . . 218
8.13.3 Destroy CephFS . . . 218
8.14 Ceph Maintenance . . . 219
8.14.1 Replace OSDs . . . 219
8.14.2 Trim/Discard . . . 220
8.14.3 Scrub & Deep Scrub . . . 220
8.14.4 Mute a Health Check . . . 220
8.14.5 Migrate Cephx Keys from `aes` to `aes256k` . . . 220
8.14.6 Shutdown Proxmox VE + Ceph HCI Cluster . . . 227
8.14.7 Network Changes . . . 228
8.15 Ceph Monitoring and Troubleshooting . . . 231
8.15.1 Troubleshooting . . . 232

9 Storage Replication 234
9.1 Supported Storage Types . . . 234
9.2 Schedule Format . . . 235
9.3 Error Handling . . . 235
9.3.1 Possible issues . . . 235
9.3.2 Migrating a guest in case of Error . . . 235
9.3.3 Example . . . 235
9.4 Managing Jobs . . . 236
9.5 Network . . . 237
9.6 Command-line Interface Examples . . . 237

10 QEMU/KVM Virtual Machines 238
10.1 Emulated devices and paravirtualized devices . . . 238
10.2 Virtual Machines Settings . . . 239
10.2.1 General Settings . . . 239

10.2.2 OS Settings . . . 240
10.2.3 System Settings . . . 240
10.2.4 Hard Disk . . . 242
10.2.5 CPU . . . 244
10.2.6 Memory . . . 251
10.2.7 Memory Encryption . . . 252
10.2.8 Network Device . . . 254
10.2.9 Display . . . 256
10.2.10 USB Passthrough . . . 257
10.2.11 BIOS and UEFI . . . 258
10.2.12 Trusted Platform Module (TPM) . . . 259
10.2.13 Inter-VM shared memory . . . 260
10.2.14 Audio Device . . . 260
10.2.15 VirtIO RNG . . . 261
10.2.16 Virtiofs . . . 261
10.2.17 Device Boot Order . . . 263
10.2.18 Automatic Start and Shutdown of Virtual Machines . . . 263
10.2.19 QEMU Guest Agent . . . 264
10.2.20 SPICE Enhancements . . . 267
10.3 Migration . . . 268
10.3.1 Online Migration . . . 269
10.3.2 Offline Migration . . . 270
10.4 Copies and Clones . . . 270
10.5 Virtual Machine Templates . . . 271
10.6 VM Generation ID . . . 272
10.7 Importing Virtual Machines . . . 272
10.7.1 Import Wizard . . . 273
10.7.2 Import OVF/OVA Through CLI . . . 275
10.8 Cloud-Init Support . . . 276
10.8.1 Preparing Cloud-Init Templates . . . 277
10.8.2 Deploying Cloud-Init Templates . . . 279
10.8.3 Custom Cloud-Init Configuration . . . 279
10.8.4 Cloud-Init on Windows . . . 280
10.8.5 Preparing Cloudbase-Init Templates . . . 280
10.8.6 Cloudbase-Init and Sysprep . . . 281

10.8.7 Cloud-Init specific Options . . . 282
10.9 PCI(e) Passthrough . . . 283
10.9.1 General Requirements . . . 284
10.9.2 Host Device Passthrough . . . 286
10.9.3 SR-IOV . . . 289
10.9.4 Mediated Devices (vGPU, GVT-g) . . . 289
10.9.5 Usage in Clusters . . . 290
10.9.6 vIOMMU (emulated IOMMU) . . . 290
10.10 Hookscripts . . . 291
10.11 Hibernation . . . 291
10.12 Resource Mapping . . . 292
10.13 Managing Virtual Machines with qm . . . 295
10.13.1 CLI Usage Examples . . . 295
10.14 Configuration . . . 296
10.14.1 File Format . . . 296
10.14.2 Snapshots . . . 296
10.14.3 Meta Information . . . 297
10.14.4 Options . . . 298
10.15 Locks . . . 326

11 Proxmox Container Toolkit 327
11.1 Technology Overview . . . 328
11.2 Supported Distributions . . . 328
11.2.1 Alpine Linux . . . 328
11.2.2 Arch Linux . . . 328
11.2.3 CentOS, Almalinux, Rocky Linux . . . 329
11.2.4 Debian . . . 329
11.2.5 Devuan . . . 330
11.2.6 Fedora . . . 330
11.2.7 Gentoo . . . 330
11.2.8 OpenSUSE . . . 330
11.2.9 Ubuntu . . . 330
11.3 Container Images . . . 331
11.3.1 System Container Templates . . . 331
11.3.2 Open Container Initiative (OCI) Images . . . 332
11.3.3 Obtaining OCI Images . . . 332

11.4 Container Settings . . . 333
11.4.1 General Settings . . . 333
11.4.2 CPU . . . 334
11.4.3 Memory . . . 335
11.4.4 Mount Points . . . 336
11.4.5 Network . . . 339
11.4.6 Automatic Start and Shutdown of Containers . . . 341
11.4.7 Hookscripts . . . 342
11.5 Security Considerations . . . 342
11.5.1 AppArmor . . . 342
11.5.2 Control Groups (*cgroup*) . . . 342
11.6 Guest Operating System Configuration . . . 343
11.7 Container Storage . . . 345
11.7.1 FUSE Mounts . . . 345
11.7.2 Using Quotas Inside Containers . . . 346
11.7.3 Using ACLs Inside Containers . . . 346
11.7.4 Backup of Container mount points . . . 346
11.7.5 Replication of Containers mount points . . . 347
11.8 Backup and Restore . . . 347
11.8.1 Container Backup . . . 347
11.8.2 Restoring Container Backups . . . 347
11.9 Managing Containers with `pct` . . . 348
11.9.1 CLI Usage Examples . . . 348
11.9.2 Obtaining Debugging Logs . . . 349
11.10 Migration . . . 350
11.11 Configuration . . . 350
11.11.1 File Format . . . 351
11.11.2 Snapshots . . . 351
11.11.3 Meta Information . . . 351
11.11.4 Options . . . 352
11.12 Locks . . . 359

12 Software-Defined Network 360

12.1 Introduction . . . 360
12.2 Support Status . . . 360
12.2.1 History . . . 360
12.2.2 Current Status . . . 361
12.3 Installation . . . 361
12.3.1 SDN Core . . . 361
12.3.2 DHCP IPAM . . . 361
12.3.3 FRRouting . . . 362
12.4 Configuration Overview . . . 362
12.5 Technology & Configuration . . . 362
12.6 Zones . . . 363
12.6.1 Common Options . . . 363
12.6.2 Simple Zones . . . 363
12.6.3 VLAN Zones . . . 366
12.6.4 QinQ Zones . . . 366
12.6.5 VXLAN Zones . . . 367
12.6.6 EVPN Zones . . . 367
12.7 VNets . . . 368
12.8 Subnets . . . 369
12.9 Controllers . . . 370
12.9.1 EVPN Controller . . . 370
12.9.2 BGP Controller . . . 372
12.9.3 ISIS Controller . . . 373
12.10 Fabrics . . . 374
12.10.1 Installation . . . 374
12.10.2 Permissions . . . 374
12.10.3 Configuration . . . 375
12.10.4 Fabrics in a Zone VRF . . . 376
12.10.5 OpenFabric . . . 376
12.10.6 OSPF . . . 379
12.10.7 WireGuard . . . 381
12.10.8 Status Reporting . . . 383
12.11 Prefix Lists and Route Maps . . . 385
12.11.1 Prefix Lists . . . 385

12.11.2 Route Maps . . . 386
12.11.3 Where Prefix Lists and Route Maps Are Used . . . 387
12.11.4 Examples . . . 387
12.11.5 BGP . . . 388
12.12 IPAM . . . 390
12.12.1 PVE IPAM Plugin . . . 390
12.12.2 NetBox IPAM Plugin . . . 390
12.12.3 phpIPAM Plugin . . . 391
12.13 DNS . . . 391
12.13.1 PowerDNS Plugin . . . 391
12.14 DHCP . . . 392
12.14.1 Configuration . . . 392
12.14.2 Plugins . . . 393
12.15 Firewall Integration . . . 393
12.15.1 VNets and Subnets . . . 394
12.15.2 IPAM . . . 395
12.16 Examples . . . 395
12.16.1 Simple Zone Example . . . 395
12.16.2 Source NAT Example . . . 396
12.16.3 VLAN Setup Example . . . 396
12.16.4 QinQ Setup Example . . . 397
12.16.5 VXLAN Setup Example . . . 398
12.16.6 EVPN Setup Example . . . 399
12.16.7 WireGuard Setup Example . . . 400
12.17 Notes . . . 403
12.17.1 Multiple EVPN Exit Nodes . . . 403
12.17.2 VXLAN IPSEC Encryption . . . 403

13 Proxmox VE Firewall **405**
13.1 Directions & Zones . . . 405
13.1.1 Directions . . . 405
13.1.2 Zones . . . 406
13.2 Configuration Files . . . 406
13.2.1 Cluster Wide Setup . . . 406
13.2.2 Host Specific Configuration . . . 408
13.2.3 VM/Container Configuration . . . 410

13.2.4 VNet Configuration . . . 411
13.3 Firewall Rules . . . 412
13.4 Security Groups . . . 414
13.5 IP Aliases . . . 414
13.5.1 Standard IP Alias `local_network` . . . 414
13.6 IP Sets . . . 415
13.6.1 Standard IP set `management` . . . 415
13.6.2 Standard IP set `blacklist` . . . 415
13.6.3 Standard IP set `ipfilter-net*` . . . 415
13.7 Services and Commands . . . 416
13.8 Default firewall rules . . . 416
13.8.1 Datacenter incoming/outgoing DROP/REJECT . . . 416
13.8.2 VM/CT incoming/outgoing DROP/REJECT . . . 417
13.9 Logging of firewall rules . . . 417
13.9.1 Logging of user defined firewall rules . . . 418
13.10 Tips and Tricks . . . 418
13.10.1 How to allow FTP . . . 418
13.10.2 Suricata IPS integration . . . 419
13.11 Notes on IPv6 . . . 419
13.12 Ports used by Proxmox VE . . . 419
13.13 nftables . . . 420
13.13.1 Installation and Usage . . . 420
13.13.2 Usage . . . 421
13.13.3 Helpful Commands . . . 421

14 User Management **423**
14.1 Users . . . 423
14.1.1 System administrator . . . 424
14.2 Groups . . . 424
14.3 API Tokens . . . 424
14.3.1 Token Policy . . . 424
14.4 Resource Pools . . . 425
14.5 Authentication Realms . . . 426
14.5.1 Linux PAM Standard Authentication . . . 426
14.5.2 Proxmox VE Authentication Server . . . 427
14.5.3 LDAP . . . 427

14.5.4 Microsoft Active Directory (AD) . . . 428
14.5.5 Syncing LDAP-Based Realms . . . 429
14.5.6 OpenID Connect . . . 431
14.6 Two-Factor Authentication . . . 433
14.6.1 Available Second Factors . . . 433
14.6.2 Realm Enforced Two-Factor Authentication . . . 434
14.6.3 Limits and Lockout of Two-Factor Authentication . . . 434
14.6.4 User Configured TOTP Authentication . . . 435
14.6.5 TOTP . . . 436
14.6.6 WebAuthn . . . 436
14.6.7 Recovery Keys . . . 436
14.6.8 Server Side Webauthn Configuration . . . 437
14.6.9 Server Side U2F Configuration . . . 437
14.6.10 Activating U2F as a User . . . 438
14.7 Permission Management . . . 438
14.7.1 Roles . . . 438
14.7.2 Privileges . . . 439
14.7.3 Objects and Paths . . . 441
14.7.4 Pools . . . 442
14.7.5 Which Permissions Do I Need? . . . 442
14.8 Command-line Tool . . . 443
14.9 Real World Examples . . . 444
14.9.1 Administrator Group . . . 444
14.9.2 Auditors . . . 444
14.9.3 Delegate User Management . . . 445
14.9.4 Limited API Token for Monitoring . . . 445
14.9.5 Resource Pools . . . 445

15 High Availability **447**
15.1 Requirements . . . 448
15.2 Resources . . . 449
15.3 Management Tasks . . . 449
15.4 How It Works . . . 450
15.4.1 Service States . . . 451
15.4.2 Local Resource Manager . . . 452
15.4.3 Cluster Resource Manager . . . 453

15.5 HA Simulator . . . 454
15.6 Configuration . . . 455
15.6.1 Resources . . . 455
15.6.2 Groups . . . 457
15.6.3 Rules . . . 460
15.6.4 Rule Conflicts and Errors . . . 464
15.7 Fencing . . . 465
15.7.1 How Proxmox VE Fences . . . 465
15.7.2 Configure Hardware Watchdog . . . 465
15.7.3 Recover Fenced Services . . . 466
15.7.4 Fencing & Watchdog Status . . . 466
15.8 Start Failure Policy . . . 467
15.9 Error Recovery . . . 467
15.10 Package Updates . . . 467
15.11 Node Maintenance . . . 468
15.11.1 Maintenance Mode . . . 468
15.11.2 Shutdown Policy . . . 469
15.12 Disarming HA for Cluster Maintenance . . . 471
15.13 Cluster Resource Scheduling . . . 473
15.13.1 CRS Scheduling Mode . . . 473
15.13.2 CRS Scheduling Points . . . 474
15.13.3 CRS Load Balancer . . . 475

16 Backup and Restore **477**
16.1 Backup Modes . . . 477
16.1.1 VM Backup Fleecing . . . 479
16.1.2 CT Change Detection Mode . . . 479
16.2 Backup File Names . . . 480
16.3 Backup File Compression . . . 480
16.4 Backup Encryption . . . 481
16.5 Backup Jobs . . . 481
16.6 Backup Retention . . . 483
16.6.1 Prune Simulator . . . 484
16.6.2 Retention Settings Example . . . 484
16.7 Backup Protection . . . 485
16.8 Backup Notes . . . 485

16.9 Restore . . . 486
16.9.1 Bandwidth Limit . . . 486
16.9.2 Live-Restore . . . 487
16.9.3 Single File Restore . . . 487
16.9.4 Failed Restores . . . 488
16.10 Guest Identity . . . 488
16.10.1 Identity Values . . . 489
16.10.2 Reading the Identity . . . 489
16.10.3 Lifecycle . . . 490
16.10.4 Restore Over an Existing Guest . . . 491
16.10.5 Retrying a Failed Restore . . . 491
16.10.6 Migration to Another Cluster . . . 492
16.10.7 Mixed Versions in a Cluster . . . 492
16.11 Configuration . . . 493
16.12 Hook Scripts . . . 497
16.13 File Exclusions . . . 497
16.14 Examples . . . 498

17 Notifications **499**
17.1 Overview . . . 499
17.2 Notification Targets . . . 499
17.2.1 Sendmail . . . 499
17.2.2 SMTP . . . 501
17.2.3 Gotify . . . 502
17.2.4 Webhook . . . 503
17.3 Notification Matchers . . . 505
17.3.1 Match Rules . . . 506
17.3.2 Matcher Configuration Options . . . 506
17.3.3 Match Expression Reference . . . 507
17.4 Notification Events . . . 509
17.5 Notification Queue . . . 510
17.6 System Mail Forwarding . . . 510
17.7 Permissions . . . 511
17.8 Notification Mode . . . 511
17.9 Overriding Notification Templates . . . 511

18 Important Service Daemons **512**
18.1 pvedaemon - Proxmox VE API Daemon . . . 512
18.1.1 Number of Workers . . . 512
18.2 pveproxy - Proxmox VE API Proxy Daemon . . . 512
18.2.1 Host based Access Control . . . 513
18.2.2 Listening IP Address . . . 513
18.2.3 SSL Cipher Suite . . . 514
18.2.4 Supported TLS versions . . . 514
18.2.5 Diffie-Hellman Parameters . . . 515
18.2.6 Alternative HTTPS certificate . . . 515
18.2.7 Response Compression . . . 515
18.2.8 Real Client IP Logging . . . 516
18.2.9 Number of Workers . . . 516
18.3 pvestatd - Proxmox VE Status Daemon . . . 516
18.4 spiceproxy - SPICE Proxy Service . . . 517
18.4.1 Host based Access Control . . . 517
18.5 pvescheduler - Proxmox VE Scheduler Daemon . . . 517

19 Useful Command-line Tools **518**
19.1 pvesubscription - Subscription Management . . . 518
19.2 pveperf - Proxmox VE Benchmark Script . . . 518
19.3 Shell interface for the Proxmox VE API . . . 519
19.3.1 EXAMPLES . . . 519

20 Frequently Asked Questions **520**

21 Bibliography **524**
21.1 Books about Proxmox VE . . . 524
21.2 Books about related technology . . . 524
21.3 Books about related topics . . . 525

A Command-line Interface **526**
A.1 General . . . 526
A.2 Output format options `[FORMAT_OPTIONS]` . . . 526
A.3 **pvesm** - Proxmox VE Storage Manager . . . 527
A.4 **pvesubscription** - Proxmox VE Subscription Manager . . . 545
A.5 **pveperf** - Proxmox VE Benchmark Script . . . 546

A.6 **pveceph** - Manage CEPH Services on Proxmox VE Nodes . . . 546
A.7 **pvenode** - Proxmox VE Node Management . . . 554
A.8 **pvesh** - Shell interface for the Proxmox VE API . . . 563
A.9 **qm** - QEMU/KVM Virtual Machine Manager . . . 565
A.10 **qmrestore** - Restore QemuServer `vzdump` Backups . . . 613
A.11 **pct** - Proxmox Container Toolkit . . . 614
A.12 **pveam** - Proxmox VE Appliance Manager . . . 641
A.13 **pvecm** - Proxmox VE Cluster Manager . . . 642
A.14 **pvesr** - Proxmox VE Storage Replication . . . 646
A.15 **pveum** - Proxmox VE User Manager . . . 650
A.16 **vzdump** - Backup Utility for VMs and Containers . . . 667
A.17 **ha-manager** - Proxmox VE HA Manager . . . 670

B Service Daemons **678**
B.1 **pve-firewall** - Proxmox VE Firewall Daemon . . . 678
B.2 **pvedaemon** - Proxmox VE API Daemon . . . 679
B.3 **pveproxy** - Proxmox VE API Proxy Daemon . . . 680
B.4 **pvestatd** - Proxmox VE Status Daemon . . . 681
B.5 **spiceproxy** - SPICE Proxy Service . . . 681
B.6 **pmxcfs** - Proxmox Cluster File System . . . 682
B.7 **pve-ha-crm** - Cluster Resource Manager Daemon . . . 683
B.8 **pve-ha-lrm** - Local Resource Manager Daemon . . . 683
B.9 **pvescheduler** - Proxmox VE Scheduler Daemon . . . 684

C Configuration Files **685**
C.1 General . . . 685
C.1.1 Casing of Property Names . . . 685
C.2 Datacenter Configuration . . . 685
C.2.1 File Format . . . 685
C.2.2 Options . . . 686

D Calendar Events **693**
D.1 Schedule Format . . . 693
D.2 Detailed Specification . . . 693
D.2.1 Examples: . . . 694

E QEMU vCPU List **696**

E.1 Introduction . . . 696

E.2 Intel CPU Types . . . 696

E.3 AMD CPU Types . . . 697

F Firewall Macro Definitions **698**

G Markdown Primer **711**

G.1 Markdown Basics . . . 711

G.1.1 Headings . . . 711

G.1.2 Emphasis . . . 711

G.1.3 Links . . . 712

G.1.4 Lists . . . 712

G.1.5 Tables . . . 713

G.1.6 Block Quotes . . . 713

G.1.7 Code and Snippets . . . 713

H GNU Free Documentation License **715**

Chapter 1

Introduction

Proxmox VE is a platform for running virtual machines and containers. It is based on Debian GNU/Linux and completely open source. For maximum flexibility, Proxmox VE provides two virtualization technologies—Kernel-based Virtual Machine (KVM) and Linux Containers (LXC).

A core design goal is to make administration as easy as possible. You can use Proxmox VE on a single node, or assemble a cluster of many nodes. All management tasks can be done through the web-based management interface, and even a novice user can set up and install Proxmox VE within minutes.



1.1 Central Management

While many people start with a single node, Proxmox VE can scale out to a large set of clustered nodes. The cluster stack is fully integrated and ships with the default installation.

Unique Multi-Master Design
Every node in a Proxmox VE cluster can perform all management tasks. There is no single-point-of-failure central management server—any node can manage the entire cluster. This multi-master architecture keeps the cluster manageable even if individual nodes are temporarily unavailable.

Proxmox Cluster File System (pmxcfs)
Proxmox VE uses the Proxmox Cluster File System (pmxcfs), a database-driven file system for storing configuration files. It can store the configuration of thousands of virtual machines. Corosync replicates these files in real time to all cluster nodes. The file system stores all data inside a persistent database on disk, while a copy resides in RAM, providing a maximum storage size of 128 MiB—more than enough for thousands of VMs.

Proxmox VE is the only virtualization platform using this cluster file system.

Web-based Management Interface
Proxmox VE is simple to use. The included web-based interface, built on the ExtJS JavaScript framework, provides a clean overview of all KVM guests and Linux containers, and full control over all cluster resources. You can manage VMs, containers, storage, and networking from the GUI, including history and syslog viewing for each node, running backup or restore jobs, live migration, and HA-triggered activities. There is no need to install a separate management tool or additional management node.

Command Line
For advanced users who prefer the comfort of a Unix shell or Windows PowerShell, Proxmox VE provides a command-line interface to manage all components of the virtual environment. This command-line interface has intelligent tab completion and full documentation in the form of man pages.

REST API
Proxmox VE uses a RESTful API with JSON as the primary data format. The entire API is formally defined using JSON Schema, enabling fast and easy integration for third-party management tools such as custom hosting environments.

Role-based Administration
You can define granular access for all objects (such as VMs, storage, and nodes) by using role-based user and permission management. Each permission specifies a subject (a user or group) and a role (set of privileges) on a specific path, following the access control list model.

Authentication Realms
Proxmox VE supports multiple authentication sources, including Microsoft Active Directory, LDAP, Linux PAM standard authentication, and the built-in Proxmox VE authentication server.

1.2 Flexible Storage

The Proxmox VE storage model is very flexible. Virtual machine images can be stored on one or several local storages, or on shared storage such as NFS or SAN. You may configure as many storage definitions as you like, using all storage technologies available for Debian GNU/Linux.

One major benefit of storing VMs on shared storage is the ability to live-migrate running machines without any downtime, as all nodes in the cluster have direct access to VM disk images.

The following network storage types are supported:

- LVM group (network backing with iSCSI targets or NVMe over Fabrics)
- iSCSI target
- iSCSI LUNs (direct use)
- NVMe over Fabrics subsystem
- NFS share
- CIFS share
- Ceph RBD
- CephFS
- Proxmox Backup Server

The following local storage types are supported:

- LVM group (local backing devices such as block devices, Fibre Channel devices, and DRBD)
- Directory (storage on existing file system)
- ZFS

1.3 Integrated Backup and Restore

The integrated backup tool (`vzdump`) creates consistent snapshots of running containers and KVM guests. It creates an archive of the VM or container data, including the configuration files.

Additionally, the Proxmox Backup Server integration provides advanced features, including the ability to combine full backups and data deduplication, perform client-side encryption, back up to tape or S3 object storage, and sync with other offsite Proxmox Backup Server installations.

KVM live backup works for all storage types including VM images on NFS, CIFS, iSCSI LUN, and Ceph RBD. The backup format is optimized for storing VM backups efficiently—using sparse files, out-of-order data, and minimized I/O.

1.4 High Availability Cluster

A multi-node Proxmox VE HA cluster enables highly available virtual machines and containers. The integrated High Availability (HA) manager automatically detects node failures using watchdog-based fencing and restarts affected services on healthy nodes. No external tools like Pacemaker are needed—the HA stack ships with Proxmox VE and is configured entirely through the web interface or command line.

1.5 Flexible Networking

Proxmox VE uses a bridged networking model. All VMs can share one bridge as if virtual network cables from each guest were all plugged into the same switch. For connecting VMs to the outside world, bridges are attached to physical network cards and assigned a TCP/IP configuration.

For further flexibility, Virtual LANs (VLANs, IEEE 802.1q) and network bonding/aggregation are available, allowing you to build complex, flexible virtual networks for the Proxmox VE hosts and leverage the full power of the Linux network stack.

For larger or multi-tenant environments, the Software Defined Network (SDN) stack provides zone-based network isolation and supports protocols such as VXLAN and EVPN. SDN is fully integrated into the web interface and installed by default.

1.6 Integrated Firewall

The integrated firewall allows you to filter network packets on any VM or container interface. Common sets of firewall rules can be grouped into “security groups”.

1.7 Hyper-converged Infrastructure

Proxmox VE is a virtualization platform that tightly integrates compute, storage and networking resources, manages highly available clusters, backup/restore as well as disaster recovery. All components are software-defined and compatible with one another.

Therefore it is possible to administrate them like a single system via the centralized web management interface. These capabilities make Proxmox VE an ideal choice to deploy and manage an open source hyper-converged infrastructure.

1.7.1 Benefits of a Hyper-Converged Infrastructure (HCI) with Proxmox VE

A hyper-converged infrastructure (HCI) is especially useful for deployments in which a high infrastructure demand meets a low administration budget, for distributed setups such as remote and branch office environments or for virtual private and public clouds.

HCI provides the following advantages:

- Scalability: seamless expansion of compute, network and storage devices (i.e. scale up servers and storage quickly and independently from each other).

- Low cost: Proxmox VE is open source and integrates all components you need such as compute, storage, networking, backup, and management center. It can replace an expensive compute/storage infrastructure.
- Data protection and efficiency: services such as backup and disaster recovery are integrated.
- Simplicity: easy configuration and centralized administration.
- Open Source: No vendor lock-in.

1.7.2 Hyper-Converged Infrastructure: Storage

Proxmox VE has tightly integrated support for deploying a hyper-converged storage infrastructure. You can, for example, deploy and manage the following two storage technologies by using the web interface only:

- **Ceph**: a self-healing and self-managing shared, reliable and highly scalable storage system. Check out how to manage Ceph services on Proxmox VE nodes
- **ZFS**: a combined file system and logical volume manager with extensive protection against data corruption, various RAID modes, fast and cheap snapshots - among other features. Find out how to leverage the power of ZFS on Proxmox VE nodes.

Besides above, Proxmox VE has support to integrate a wide range of additional storage technologies. You can find out about them in the Storage Manager chapter.

1.8 Why Open Source

Proxmox VE uses a Linux kernel and is based on the Debian GNU/Linux distribution. The source code of Proxmox VE is released under the GNU Affero General Public License, version 3. This means that you are free to inspect the source code at any time or contribute to the project yourself.

Proxmox is committed to using open source software whenever possible. Open source software guarantees full access to all functionality—as well as high security and reliability. Everybody should have the right to access the source code of software to run it, build on it, or submit changes back to the project. Everybody is encouraged to contribute while Proxmox ensures the product always meets professional quality criteria.

Open source software also helps to keep costs low and makes core infrastructure independent from a single vendor.

1.9 Your Benefits with Proxmox VE

- Open source software
- No vendor lock-in
- Linux kernel
- Fast installation and easy to use
- Web-based management interface

- REST API
- Huge active community
- Low administration costs and simple deployment

1.10 Getting Help

1.10.1 Proxmox VE Wiki

The primary source of information is the Proxmox VE Wiki. It combines the reference documentation with user contributed content.

1.10.2 Community Support Forum

Proxmox VE itself is fully open source, so we always encourage our users to discuss and share their knowledge using the Proxmox VE Community Forum. The forum is moderated by the Proxmox support team, and has a large user base from all around the world. Needless to say, such a large forum is a great place to get information.

1.10.3 Mailing Lists

This is a fast way to communicate with the Proxmox VE community via email.

- Mailing list for users: Proxmox VE User List

Proxmox VE is fully open source and contributions are welcome! The primary communication channel for developers is the:

- Mailing list for developers: Proxmox VE development discussion

1.10.4 Commercial Support

Proxmox Server Solutions GmbH also offers enterprise support available as Proxmox VE Subscription Service Plans. All users with a subscription get access to the Proxmox VE Enterprise Repository, and—with a Basic, Standard or Premium subscription—also to the Proxmox Customer Portal. The customer portal provides help and support with guaranteed response times from the Proxmox VE developers.

For volume discounts, or more information in general, please contact sales@proxmox.com.

1.10.5 Bug Tracker

Proxmox runs a public bug tracker at https://bugzilla.proxmox.com. If an issue appears, file your report there. An issue can be a bug as well as a request for a new feature or enhancement. The bug tracker helps to keep track of the issue and will send a notification once it has been solved.

1.11 Project History

The project started in 2007, followed by a first stable version in 2008. At the time, it used OpenVZ for containers and KVM for virtual machines. The clustering features were limited, and the user interface was simple (a server-generated web page).

The project quickly developed new features using the Corosync cluster stack, and the introduction of the Proxmox Cluster File System (pmxcfs) was a big step forward, because it completely hides the cluster complexity from the user. Managing a cluster of 16 nodes is as simple as managing a single node.

The introduction of the REST API, with a complete declarative specification written in JSON Schema, enabled other people to integrate Proxmox VE into their infrastructure and made it easy to provide additional services.

The REST API also made it possible to replace the original user interface with a modern client-side single-page application using JavaScript. The old Java-based VNC console code was replaced with noVNC, so only a web browser is needed to manage VMs.

The support for various storage types is another big achievement. Notably, Proxmox VE was the first distribution to ship ZFS on Linux by default in 2014. Another milestone was the ability to run and manage Ceph storage on the hypervisor nodes. Such setups are extremely cost effective.

When the project started, Proxmox was among the first companies providing commercial support for KVM. The KVM project itself continuously evolved and is now a widely used hypervisor. New features arrive with each release. The KVM live backup feature, developed by Proxmox, makes it possible to create snapshot backups on any storage type.

The most notable change with version 4.0 was the move from OpenVZ to LXC. Containers are now deeply integrated, and they can use the same storage and network features as virtual machines. At the same time, the easy-to-use High Availability (HA) manager was introduced, simplifying the configuration and management of highly available setups.

During the development of Proxmox VE 5, asynchronous storage replication as well as automated certificate management using ACME/Let's Encrypt were introduced, among many other features.

The Software Defined Network (SDN) stack was developed in cooperation with the community. It was integrated into the web interface as an experimental feature in version 6.2, simplifying the management of sophisticated network configurations. Since version 8.1, the SDN integration is fully supported and installed by default.

2020 marked the release of a new project, the Proxmox Backup Server, written in the Rust programming language. Proxmox Backup Server is deeply integrated with Proxmox VE and significantly improves backup capabilities by implementing incremental backups, deduplication, and much more.

Another new tool, the Proxmox Offline Mirror, was released in 2022, enabling subscriptions for systems which have no connection to the public internet.

The highly requested dark theme for the web interface was introduced in 2023. Later that year, version 8.0 integrated access to the Ceph enterprise repository. Access to the most stable Ceph repository is included with any Proxmox VE subscription.

Automated and unattended installation for the official ISO installer was introduced in version 8.2, significantly simplifying large deployments of Proxmox VE.

With the import wizard, equally introduced in version 8.2, users can easily and efficiently migrate guests directly from other hypervisors like VMware ESXi [1]. Additionally, archives in Open Virtualization Format (OVF/OVA) can now be directly imported from file-based storages in the web interface.

[1] Migrate to Proxmox VE https://pve.proxmox.com/wiki/Migrate_to_Proxmox_VE

1.12 Improving the Proxmox VE Documentation

Contributions and improvements to the Proxmox VE documentation are always welcome. There are several ways to contribute.

If you find errors or other room for improvement in this documentation, please file a bug at the Proxmox bug tracker to propose a correction.

If you want to propose new content, choose one of the following options:

- The wiki: For specific setups, how-to guides, or tutorials the wiki is the right option to contribute.
- The reference documentation: For general content that will be helpful to all users please propose your contribution for the reference documentation. This includes all information about how to install, configure, use, and troubleshoot Proxmox VE features. The reference documentation is written in the asciidoc format. To edit the documentation you need to clone the git repository at `git://git.proxmox.com/git/pve-docs` then follow the README.adoc document.

Note
If you are interested in working on the Proxmox VE codebase, the Developer Documentation wiki article will show you where to start.

1.13 Translating Proxmox VE

The Proxmox VE user interface is in English by default. However, thanks to the contributions of the community, translations to other languages are also available. We welcome any support in adding new languages, translating the latest features, and improving incomplete or inconsistent translations.

We use gettext for the management of the translation files. Tools like Poedit offer a nice user interface to edit the translation files, but you can use whatever editor you're comfortable with. No programming knowledge is required for translating.

1.13.1 Translating with git

The language files are available as a git repository. If you are familiar with git, please contribute according to our Developer Documentation.

You can create a new translation by doing the following (replace <LANG> with the language ID):

```
# git clone git://git.proxmox.com/git/proxmox-i18n.git
# cd proxmox-i18n
# make init-<LANG>.po
```

Or you can edit an existing translation, using the editor of your choice:

```
# poedit <LANG>.po
```

1.13.2 Translating without git

Even if you are not familiar with git, you can help translate Proxmox VE. To start, you can download the language files here. Find the language you want to improve, then right click on the "raw" link of this language file and select *Save Link As...*. Make your changes to the file, and then send your final translation directly to office(at)proxmox.com, together with a signed contributor license agreement.

1.13.3 Testing the Translation

In order for the translation to be used in Proxmox VE, you must first translate the `.po` file into a `.js` file. You can do this by invoking the following script, which is located in the same repository:

```
# ./po2js.pl -t pve xx.po >pve-lang-xx.js
```

The resulting file `pve-lang-xx.js` can then be copied to the directory `/usr/share/pve-i18n`, on your proxmox server, in order to test it out.

Alternatively, you can build a deb package by running the following command from the root of the repository:

```
# make deb
```



Important
For either of these methods to work, you need to have the following perl packages installed on your system. For Debian/Ubuntu:

```
# apt-get install perl liblocale-po-perl libjson-perl
```

1.13.4 Sending the Translation

You can send the finished translation (`.po` file) to the Proxmox team at the address office(at)proxmox.com, along with a signed contributor license agreement. Alternatively, if you have some developer experience, you can send it as a patch to the Proxmox VE development mailing list. See Developer Documentation.

Chapter 2

Installing Proxmox VE

Proxmox VE is based on Debian GNU/Linux. The install disk images (ISO files) provided by Proxmox include a complete Debian system as well as all necessary Proxmox VE packages.

Tip
See the support table in the FAQ for the relationship between Proxmox VE releases and Debian releases.

The installer guides you through the setup, allowing you to partition the local disk(s), apply basic system configurations (for example, timezone, language, network), and install all required packages. This process should not take more than a few minutes. Installing with the provided ISO is the recommended method for new and existing users.

Alternatively, Proxmox VE can be installed on top of an existing Debian system. This option is only recommended for advanced users because detailed knowledge about Proxmox VE is required.

2.1 System Requirements

We recommend using high quality server hardware, when running Proxmox VE in production. To further decrease the impact of a failed host, you can run Proxmox VE in a cluster with highly available (HA) virtual machines and containers.

Proxmox VE can use local storage (DAS), SAN, NAS, and distributed storage like Ceph RBD. For details see chapter storage.

2.1.1 Minimum Requirements, for Evaluation

These minimum requirements are for evaluation purposes only and should not be used in production.

- CPU: 64-bit x86 (Intel 64 or AMD64). Alternatively, 64-bit ARM (arm64, aarch64) with an ARMv8-A or newer CPU, see 64-bit ARM (arm64) Support.
- For x86 hosts, an Intel VT or AMD-V capable CPU and motherboard for KVM full virtualization support. On the supported arm64 platforms, KVM hardware-assisted virtualization needs no equivalent CPU flag.

- RAM: 1 GB RAM, plus additional RAM needed for guests
- Hard drive
- One network card (NIC)

2.1.2 Recommended System Requirements

- Intel 64 or AMD64 with an Intel VT or AMD-V CPU flag. Alternatively, a 64-bit ARM host with an ARMv9-A or newer CPU, see 64-bit ARM (arm64) Support.
- Memory: Minimum 2 GB for the OS and Proxmox VE services, plus designated memory for guests. For Ceph and ZFS, additional memory is required; approximately 1GB of memory for every TB of used storage.
- Fast and redundant storage, best results are achieved with SSDs.
- OS storage: Use a hardware RAID with battery protected write cache ("BBU") or non-RAID with ZFS (optional SSD for ZIL).
- VM storage:
  - For local storage, use either a hardware RAID with battery backed write cache (BBU) or non-RAID for ZFS and Ceph. Neither ZFS nor Ceph are compatible with a hardware RAID controller.
  - Shared and distributed storage is possible.
  - SSDs with Power-Loss-Protection (PLP) are recommended for good performance. Using consumer SSDs is discouraged.
- Redundant (Multi-)Gbit NICs, with additional NICs depending on the preferred storage technology and cluster setup.
- For PCI(e) passthrough, the CPU and motherboard need to support an input/output memory management unit (IOMMU): Intel VT-d or AMD-Vi on x86, or a System Memory Management Unit (SMMU) on arm64.

Tip
IOMMU usually also needs to be enabled in the BIOS/UEFI. See the PCI(e) Passthrough chapter for details.

2.1.3 64-bit ARM (arm64) Support

Proxmox VE supports native 64-bit ARM (arm64, aarch64) on the NVIDIA Grace Hopper and NVIDIA Vera platforms. On other UEFI-based ARMv9-A or newer hardware, support is best-effort. Device-tree-only single-board computers, such as the Raspberry Pi, are not supported.

An arm64 host must boot through UEFI and describe its hardware through ACPI (Advanced Configuration and Power Interface). Proxmox VE does not support device-tree-only or legacy BIOS boot on arm64.

Several x86-specific features are not available on arm64:

- Virtual machines cannot use SeaBIOS. On arm64, guests always boot through UEFI, provided by the ARM build of OVMF, also known as AAVMF.

- AMD SEV (Secure Encrypted Virtualization) memory encryption and Intel's GVT-g mediated vGPUs are x86-only.
- There is no operating-system-level CPU microcode package, unlike `intel-microcode` and `amd64-microc` on x86.

A cluster can contain both x86 and arm64 nodes, but guests cannot move between nodes of different architectures while running:

- Live migration is only possible between nodes of the same architecture, because a running guest's CPU state cannot be transferred across architectures.
- A guest, whether a virtual machine or a container, only runs on a node whose architecture matches the guest. Offline migration, backup and restore, or shared storage can move a guest's data to a node of a different architecture, but the guest still needs to be reinstalled or reconfigured for that architecture before it starts.

2.1.4 Simple Performance Overview

To get an overview of the CPU and hard disk performance on an installed Proxmox VE system, run the included `pveperf` tool.

Note
This is just a very quick and general benchmark. More detailed tests are recommended, especially regarding the I/O performance of your system.

2.1.5 Supported Web Browsers for Accessing the Web Interface

To access the web-based user interface, we recommend using one of the following browsers:

- Firefox, a release from the current year, or the latest Extended Support Release
- Chrome, a release from the current year
- Microsoft's currently supported version of Edge
- Safari, a release from the current year

When accessed from a mobile device, Proxmox VE will show a lightweight, touch-based interface.

2.2 Prepare Installation Media

Download the installer ISO image from: https://www.proxmox.com/en/downloads/proxmox-virtual-environment/-iso

The Proxmox VE installation media is a hybrid ISO image. It works in two ways:

- An ISO image file ready to burn to a CD or DVD.
- A raw sector (IMG) image file ready to copy to a USB flash drive (USB stick).

Using a USB flash drive to install Proxmox VE is the recommended way because it is the faster option.

2.2.1 Prepare a USB Flash Drive as Installation Medium

The flash drive needs to be larger than the ISO image.

Note
Do not use UNetbootin. It does not work with the Proxmox VE installation image.



Important
Make sure that the USB flash drive is not mounted and does not contain any important data.

2.2.2 Instructions for GNU/Linux

On Unix-like operating system use the `dd` command to copy the ISO image to the USB flash drive. First find the correct device name of the USB flash drive (see below). Then run the `dd` command.

```
# dd bs=1M conv=fdatasync if=./proxmox-ve_*.iso of=/dev/XYZ
```

Note
Be sure to replace /dev/XYZ with the correct device name and adapt the input filename (*if*) path.



Caution
Be very careful, and do not overwrite the wrong disk!

Find the Correct USB Device Name

There are two ways to find out the name of the USB flash drive. The first one is to compare the last lines of the `dmesg` command output before and after plugging in the flash drive. The second way is to compare the output of the `lsblk` command. Open a terminal and run:

```
# lsblk
```

Then plug in your USB flash drive and run the command again:

```
# lsblk
```

A new device will appear. This is the one you want to use. To be on the extra safe side check if the reported size matches your USB flash drive.

2.2.3 Instructions for macOS

Open the terminal (query Terminal in Spotlight).

Convert the `.iso` file to `.dmg` format using the convert option of `hdiutil`, for example:

```
# hdiutil convert proxmox-ve_*.iso -format UDRW -o proxmox-ve_*.dmg
```

Tip
macOS tends to automatically add *.dmg* to the output file name.

To get the current list of devices run the command:

```
# diskutil list
```

Now insert the USB flash drive and run this command again to determine which device node has been assigned to it. (e.g., /dev/diskX).

```
# diskutil list
# diskutil unmountDisk /dev/diskX
```

Note
replace X with the disk number from the last command.

```
# sudo dd if=proxmox-ve_*.dmg bs=1M of=/dev/rdiskX
```

Note
rdiskX, instead of *diskX*, in the last command is intended. It will increase the write speed.

2.2.4 Instructions for Windows

Using Etcher

Etcher works out of the box. Download Etcher from https://etcher.io. It will guide you through the process of selecting the ISO and your USB flash drive.

Using Rufus

Rufus is a more lightweight alternative, but you need to use the **DD mode** to make it work. Download Rufus from https://rufus.ie/. Either install it or use the portable version. Select the destination drive and the Proxmox VE ISO file.



Important
Once you *Start* you have to click *No* on the dialog asking to download a different version of GRUB. In the next dialog select the *DD* mode.

2.3 Using the Proxmox VE Installer

The installer ISO image includes the following:

- Complete operating system (Debian GNU/Linux, 64-bit)
- The Proxmox VE installer, which partitions the local disk(s) with ext4, XFS, BTRFS (technology preview), or ZFS and installs the operating system
- Proxmox VE Linux kernel with KVM and LXC support
- Complete toolset for administering virtual machines, containers, the host system, clusters, and all necessary resources
- Web-based management interface

Note
All existing data on the selected drives will be removed during the installation process. The installer does not add boot menu entries for other operating systems.

Please insert the prepared installation media (for example, USB flash drive or CD-ROM) and boot from it.

Tip
Make sure that booting from the installation medium (for example, USB) is enabled in your server's firmware settings. Secure boot needs to be disabled when booting an installer prior to Proxmox VE version 8.1.



After choosing the correct entry (for example, *Boot from USB*), the Proxmox VE menu appears and you can select one of the following options:

Install Proxmox VE (Graphical)
: Starts the normal installation.

Tip

It's possible to use the installation wizard with a keyboard only. Buttons can be clicked by pressing the `ALT` key combined with the underlined character from the respective button. For example, `ALT + N` to press a `Next` button.

Install Proxmox VE (Terminal UI)
: Starts the terminal-mode installation wizard. It provides the same overall installation experience as the graphical installer, but has generally better compatibility with very old and very new hardware.

Install Proxmox VE (Terminal UI, Serial Console)
: Starts the terminal-mode installation wizard, additionally setting up the Linux kernel to use the (first) serial port of the machine for in- and output. This can be used if the machine is completely headless and only has a serial console available.



Both modes use the same code base for the actual installation process to benefit from more than a decade of bug fixes and ensure feature parity.

Tip

The *Terminal UI* option can be used in case the graphical installer does not work correctly, for example due to driver issues. See also adding the nomodeset kernel parameter.

Advanced Options: Install Proxmox VE (Graphical, Debug Mode)

Starts the installation in debug mode. A console will be opened at several installation steps. This helps to debug the situation if something goes wrong. To exit a debug console, press `CTRL-D`. This option can be used to boot a live system with all basic tools available. You can use it, for example, to repair a degraded ZFS rpool or fix the bootloader for an existing Proxmox VE setup.

Advanced Options: Install Proxmox VE (Terminal UI, Debug Mode)

Same as the graphical debug mode, but preparing the system to run the terminal-based installer instead.

Advanced Options: Install Proxmox VE (Serial Console Debug Mode)

Same as the terminal-based debug mode, but additionally sets up the Linux kernel to use the (first) serial port of the machine for in- and output.

Advanced Options: Install Proxmox VE (Automated)

Starts the installer in unattended mode, even if the ISO has not been appropriately prepared for an automated installation. This option can be used to gather hardware details or might be useful to debug an automated installation setup. See Unattended Installation for more information.

Advanced Options: Rescue Boot

With this option you can boot an existing installation. It searches all attached hard disks. If it finds an existing installation, it boots directly into that disk using the Linux kernel from the ISO. This can be useful if there are problems with the bootloader (GRUB/`systemd-boot`) or the BIOS/UEFI is unable to read the boot block from the disk.

Advanced Options: Test Memory (memtest86+)

Runs `memtest86+`. This is useful to check if the memory is functional and free of errors. Secure Boot must be turned off in the UEFI firmware setup utility to run this option.

Note

This entry is available on x86 installation media only, as `memtest86+` does not support arm64.

You normally select **Install Proxmox VE (Graphical)** to start the installation.



The first step is to read the EULA (End User License Agreement). Following this, you can select the target hard disk(s) for the installation.

Caution

By default, the whole server is used and all existing data is removed. Make sure there is no important data on the server before proceeding with the installation.

The `Options` button lets you select the target file system, which defaults to `ext4`. The installer uses LVM if you select `ext4` or `xfs` as a file system, and offers additional options to restrict LVM space (see below).

Proxmox VE can also be installed on ZFS. As ZFS offers several software RAID levels, this is an option for systems that don't have a hardware RAID controller. The target disks must be selected in the `Options` dialog. More ZFS-specific settings can be changed under Advanced Options.

Warning
ZFS on top of any hardware RAID is not supported and can result in data loss.



The next page asks for basic configuration options like your location, time zone, and keyboard layout. The location is used to select a nearby download server, in order to increase the speed of updates. The installer is usually able to auto-detect these settings, so you only need to change them in rare situations when auto-detection fails, or when you want to use a keyboard layout not commonly used in your country.



You must also specify the password of the superuser (`root`) and an email address. The password must consist of at least 8 characters. It's highly recommended to use a stronger password. Some guidelines are:

- Use a minimum password length of at least 12 characters.
- Include lowercase and uppercase alphabetic characters, numbers, and symbols.
- Avoid character repetition, keyboard patterns, common dictionary words, letter or number sequences, usernames, relative or pet names, romantic links (current or past), and biographical information (for example ID numbers, ancestors' names or dates).

The email address is used to send notifications to the system administrator. For example:

- Information about available package updates.
- Error messages from periodic *cron* jobs.



The system sends all notification emails to the specified address.

The last step is the network configuration. Network interfaces that are *UP* show a filled circle in front of their name in the drop-down menu. Please note that during installation you can either specify an IPv4 or IPv6 address, but not both. To configure a dual-stack node, add additional IP addresses after the installation.

The `Advanced Options` button lets you pin the names of the network interfaces, set up a bond for the management network, and tag the management network with a VLAN, see Advanced Network Configuration Options.



The next step shows a summary of the previously selected options. Please re-check every setting and use the `Previous` button if a setting needs to be changed.

After clicking `Install`, the installer begins to format the disks and copy packages to the target disk(s). Please wait until this step has finished; then remove the installation medium and restart your system.



Copying the packages usually takes several minutes, mostly depending on the speed of the installation medium and the target disk performance.

When copying and setting up the packages has finished, you can reboot the server. This will be done automatically after a few seconds by default.

Installation Failure

If the installation failed, check out specific errors on the second TTY (*CTRL + ALT + F2*) and ensure that the system meets the minimum requirements.

If the installation is still not working, look at the how to get help chapter.

2.3.1 Accessing the Management Interface Post-Installation



After a successful installation and reboot of the system you can use the Proxmox VE web interface for further configuration.

1. Point your browser to the IP address given during the installation and port 8006, for example: https://youripadd
2. Log in using the `root` (realm *PAM*) username and the password chosen during installation.
3. Upload your subscription key to gain access to the Enterprise repository. Otherwise, you will need to set up one of the public, less tested package repositories to get updates for security fixes, bug fixes, and new features.
4. Check the IP configuration and hostname.
5. Check the timezone.
6. Check your Firewall settings.

2.3.2 Advanced LVM Configuration Options

The installer creates a Volume Group (VG) called `pve`, and additional Logical Volumes (LVs) called `root`, `data`, and `swap`, if `ext4` or `xfs` is used. To control the size of these volumes use:

`hdsize`
Defines the total hard disk size to be used. This way you can reserve free space on the hard disk for further partitioning (for example for an additional PV and VG on the same hard disk that can be used for LVM storage).

`swapsize`
Defines the size of the `swap` volume. The default is the size of the installed memory, minimum 4 GB and maximum 8 GB. The resulting value cannot be greater than one eighth of the size of the hard drive (`hdsize / 8`).

> **Note**
> If set to `0`, no `swap` volume will be created.

`maxroot`
Defines the maximum size of the `root` volume, which stores the operating system. With more than 48 GiB storage available, the default is a quarter of the size of the hard drive (`hdsize / 4`) with a maximum of 96 GiB. With less than 48 GiB of storage available, the root volume size is at least half the size of the hard drive (`hdsize / 2`).

`maxvz`
Defines the maximum size of the `data` volume. The actual size of the `data` volume is:

```
datasize = hdsize - rootsize - swapsize - minfree
```

Where `datasize` cannot be bigger than `maxvz`.

Note
In case of LVM thin, the `data` pool will only be created if `datasize` is bigger than 4GB.

Note
If set to `0`, no `data` volume will be created and the storage configuration will be adapted accordingly.

`minfree`
Defines the amount of free space that should be left in the LVM volume group `pve`. With more than 128GB storage available, the default is 16GB, otherwise `hdsize/8` will be used.

Note
LVM requires free space in the VG for snapshot creation (not required for lvmthin snapshots).

2.3.3 Advanced ZFS Configuration Options

The installer creates the ZFS pool `rpool`, if ZFS is used. No swap space is created but you can reserve some unpartitioned space on the install disks for swap. You can also create a swap zvol after the installation, although this can lead to problems (see ZFS swap notes).

`ashift`
Defines the `ashift` value for the created pool. The `ashift` needs to be set at least to the sector-size of the underlying disks (2 to the power of `ashift` is the sector-size), or any disk which might be put in the pool (for example the replacement of a defective disk).

`compress`
Defines whether compression is enabled for `rpool`.

`checksum`
Defines which checksumming algorithm should be used for `rpool`.

`copies`
Defines the `copies` parameter for `rpool`. Check the `zfs(8)` manpage for the semantics, and why this does not replace redundancy on disk-level.

`ARC max size`
Defines the maximum size the ARC can grow to and thus limits the amount of memory ZFS will use. See also the section on how to limit ZFS memory usage for more details.

`hdsize`
Defines the total hard disk size to be used. This is useful to save free space on the hard disk(s) for further partitioning (for example to create a swap-partition). `hdsize` applies to every disk of the pool, as the installer sets up all of them as bootable disks.

2.3.4 Advanced BTRFS Configuration Options

No swap space is created when BTRFS is used but you can reserve some unpartitioned space on the install disks for swap. You can either create a separate partition, BTRFS subvolume or a swapfile using the `btrfs filesystem mkswapfile` command.

`compress`
Defines whether compression is enabled for the BTRFS subvolume. Different compression algorithms are supported: *on* (equivalent to *zlib*), *zlib*, *lzo* and *zstd*. Defaults to *off*.

`hdsize`
Defines the total hard disk size to be used. This is useful to save free space on the hard disk(s) for further partitioning (for example, to create a swap partition).

2.3.5 Advanced Network Configuration Options

The `Advanced Options` dialog of the network configuration step provides the following settings for the management network.

`Interface Name Pinning`
Assigns fixed names to the network interfaces, based on their MAC addresses, so that the names do not change after kernel or firmware updates, or hardware changes that keep the MAC addresses. By default, the interfaces are named `nic0`, `nic1`, and so on, but you can enter other names. Names of the form `bond<N>`, `vlan<N>` and `vmbr<N>` are reserved for bonds, VLANs and bridges. To pin the names after the installation, for example for a replacement interface with a different MAC address, see Overriding Network Device Names.

`Management Bond`
Combines two or more of the `Bond Interfaces` into the bond `bond0`, which then connects the bridge `vmbr0` to the network instead of a single interface. This keeps the host reachable if one of the interfaces or its link fails. The `Bond Mode` defaults to *active-backup*, which works without any configuration on the switch, while the *802.3ad* mode requires switch ports configured for LACP. The `Hash Policy` applies to the *802.3ad* and *balance-xor* modes, and the optional `Primary Interface` to the *active-backup* mode, where it is preferred as the active interface. Enter the primary interface by its name as listed under `Bond Interfaces`. See Linux Bond for a description of the modes.

> **Note**
> The *balance-alb* and *balance-tlb* modes are not suitable if guests use the bridge on top of the bond, as they overwrite the source MAC address of frames sent over an interface other than the active one.

`Management VLAN`
Tags the management network with the given `VLAN Tag`, for networks that are only reachable tagged. The bridge `vmbr0` then becomes VLAN-aware and the host address is configured on the

interface `vlan<tag>` on top of it, so that guests can still use other VLANs on the bridge. Valid tags are 2 to 4094, as the VLAN-aware bridge sends VLAN 1 untagged. Leave the VLAN setup disabled for an untagged management network.

Tip
The installer proposes the network settings it obtained via DHCP on the untagged network. If the management network is only reachable tagged, boot the installer with the `proxmox-vlan=<tag>` kernel parameter, so that it obtains them on that VLAN and preselects its tag. See adding the nomodeset kernel parameter for how to add a kernel parameter.

2.3.6 ZFS Performance Tips

ZFS works best with a lot of memory. If you intend to use ZFS make sure to have enough RAM available for it. A good calculation is 4GB plus 1GB RAM for each TB RAW disk space.

ZFS can use a dedicated drive as write cache, called the ZFS Intent Log (ZIL). Use a fast drive (SSD) for it. It can be added after installation with the following command:

```
# zpool add <pool-name> log </dev/path_to_fast_ssd>
```

2.3.7 Adding the `nomodeset` Kernel Parameter

Problems may arise on very old or very new hardware due to graphics drivers. If the installation hangs during boot, you can try adding the `nomodeset` parameter. This prevents the Linux kernel from loading any graphics drivers and forces it to continue using the BIOS/UEFI-provided framebuffer.

On the Proxmox VE bootloader menu, navigate to *Install Proxmox VE (Terminal UI)* and press `e` to edit the entry. Using the arrow keys, navigate to the line starting with `linux`, move the cursor to the end of that line and add the parameter `nomodeset`, separated by a space from the pre-existing last parameter.

Then press `Ctrl-X` or `F10` to boot the configuration.

2.4 Unattended Installation

The automated installation method allows installing Proxmox VE in an unattended manner. This enables you to fully automate the setup process on bare-metal. Once the installation is complete and the host has booted up, automation tools like Ansible can be used to further configure the installation.

The necessary options for the installer must be provided in an answer file. This file allows using filter rules to determine which disks and network cards should be used.

To use the automated installation, first choose a source from which to fetch the answer file and then prepare an installation ISO with that choice.

Once the ISO is prepared, its initial boot menu will show a new boot entry named *Automated Installation* which gets automatically selected after a 10-second timeout.

Visit the wiki for more details and information on the unattended installation.

2.5 Install Proxmox VE on Debian

Proxmox VE ships as a set of Debian packages and can be installed on top of a standard Debian installation. After configuring the repositories you need to run the following commands:

```
# apt-get update
# apt-get install proxmox-ve
```

Installing on top of an existing Debian installation looks easy, but it presumes that the base system has been installed correctly and that you know how you want to configure and use the local storage. You also need to configure the network manually.

In general, this is not trivial, especially when LVM or ZFS is used.

A detailed step-by-step how-to can be found on the wiki.

Chapter 3

Host System Administration

The following sections will focus on common virtualization tasks and explain the Proxmox VE specifics regarding the administration and management of the host machine.

Proxmox VE is based on Debian GNU/Linux with additional repositories to provide the Proxmox VE related packages. This means that the full range of Debian packages is available including security updates and bug fixes. Proxmox VE provides its own Linux kernel based on the Ubuntu kernel. It has all the necessary virtualization and container features enabled and includes ZFS and several extra hardware drivers.

For other topics not included in the following sections, please refer to the Debian documentation. The Debian Administrator's Handbook is available online, and provides a comprehensive introduction to the Debian operating system (see [Hertzog13]).

3.1 Package Repositories

Proxmox VE uses APT as its package management tool like any other Debian-based system.

Proxmox VE automatically checks for package updates on a daily basis. The `root@pam` user is notified via email about available updates. From the GUI, the *Changelog* button can be used to see more details about a selected update.

3.1.1 Repositories in Proxmox VE

Repositories are a collection of software packages, they can be used to install new software, but are also important to get new updates.

Note
You need valid Debian and Proxmox repositories to get the latest security updates, bug fixes and new features.

APT Repositories are defined in the file `/etc/apt/sources.list` in the legacy single-line format and in `.sources` files placed in `/etc/apt/sources.list.d/` for the modern deb822 multi-line format, see Repository Formats for details.

Repository Management



Since Proxmox VE 7, you can check the repository state in the web interface. The node summary panel shows a high level status overview, while the separate *Repository* panel shows in-depth status and list of all configured repositories.

Basic repository management, for example, activating or deactivating a repository, is also supported.

The available packages from a repository are acquired by running `apt update`. Updates can be installed directly using `apt`, or via the GUI (Node → Updates).

Repository Formats

Package repositories can be configured in the source list */etc/apt/sources.list* and the files contained in */etc/apt/sources.list.d/*.

There are two formats supported:

single line
: In a single-line `sources.list` file, each line defines a package repository. Empty lines are ignored. A # character anywhere on a line marks the remainder of that line as a comment. This is the legacy format. Since Debian 13 Trixie apt will complain about using this format. You can automatically migrate most repositories using the `apt modernize-sources` command.

deb822
: In the multi-line format `repo.sources` file each entry consists of multiple lines of key-value pairs. A file can include multiple entries by separating each group with a blank line. This is the modern format.

Available Repositories

Proxmox VE provides three different package repositories in addition to requiring the base Debian repositories.

3.1.2 Debian Base Repositories

File /etc/apt/sources.list.d/debian.sources

```
Types: deb deb-src
URIs: http://deb.debian.org/debian/
Suites: trixie trixie-updates
Components: main non-free-firmware
Signed-By: /usr/share/keyrings/debian-archive-keyring.gpg

Types: deb deb-src
URIs: http://security.debian.org/debian-security/
Suites: trixie-security
Components: main non-free-firmware
Signed-By: /usr/share/keyrings/debian-archive-keyring.gpg
```

3.1.3 Proxmox VE Enterprise Repository

This is the recommended repository and available for all Proxmox VE subscription users. It contains the most stable packages and is suitable for production use. The `pve-enterprise` repository is enabled by default:

File /etc/apt/sources.list.d/pve-enterprise.sources

```
Types: deb
URIs: https://enterprise.proxmox.com/debian/pve
Suites: trixie
Components: pve-enterprise
Signed-By: /usr/share/keyrings/proxmox-archive-keyring.gpg
```

Please note that you need a valid subscription key to access the `pve-enterprise` repository. We offer different support levels, which you can find further details about at https://proxmox.com/en/proxmox-virtual-environment/pricing.

Note
Subscription keys are bound to the host architecture. An arm64 host needs a dedicated arm64 subscription key; an x86 key is not valid on it, and vice versa.

Note
You can disable this repository by adding an `Enabled: no` line to the relevant entry in the file. This will prevent error messages if your host does not have a subscription key. In that case, please configure the `pve-no-subscription` repository.

3.1.4 Proxmox VE No-Subscription Repository

As the name suggests, you do not need a subscription key to access this repository. It can be used for testing and non-production use. It's not recommended to use this on production servers, as these packages are not always as heavily tested and validated.

We recommend to configure this repository in `/etc/apt/sources.list.d/proxmox.sources`.

File /etc/apt/sources.list.d/proxmox.sources

```
Types: deb
URIs: http://download.proxmox.com/debian/pve
Suites: trixie
Components: pve-no-subscription
Signed-By: /usr/share/keyrings/proxmox-archive-keyring.gpg
```

Note
Remember that you will always need the base Debian repositories in addition to a Proxmox VE Proxmox repository.

3.1.5 Proxmox VE Test Repository

This repository contains the latest packages and is primarily used by developers to test new features. To configure it, add the following stanza to the file `/etc/apt/sources.list.d/proxmox.sources`:

File /etc/apt/sources.list.d/proxmox.sources

```
Types: deb
URIs: http://download.proxmox.com/debian/pve
Suites: trixie
Components: pve-test
Signed-By: /usr/share/keyrings/proxmox-archive-keyring.gpg
```



Warning
The `pve-test` repository should (as the name implies) only be used for testing new features or bug fixes.

3.1.6 Proxmox VE Debug Symbol Repository

Debug symbol packages, named `<package>-dbgsym`, contain the detached debug information for the matching binary package. They are not needed for normal operation, but let tools such as `gdb`, `systemd-cored` or `crash` produce useful backtraces when analyzing a crash or hang. They are provided in a dedicated repository, separate from the regular ones, for the Debian Bookworm and Trixie based Proxmox VE releases (and newer).

File /etc/apt/sources.list.d/pve-dbgsym.sources

```
Types: deb
URIs: https://dbgsym.proxmox.com/debian/pve
Suites: trixie
Components: pve-dbgsym
Signed-By: /usr/share/keyrings/proxmox-archive-keyring.gpg
```

After enabling the repository, install the `-dbgsym` package that matches the binary you want to debug.

3.1.7 Ceph Repositories

Ceph-related packages are kept up to date with a preconfigured Ceph enterprise repository. Preinstalled packages enable connecting to an external Ceph cluster and adding its RBD or CephFS pools as storage. You can also build a hyper-converged infrastructure (HCI) by running Ceph on top of the Proxmox VE cluster.

Information from this chapter is helpful in the following cases:

Installing Ceph to build an HCI
: Decide on a below described repository and recent Ceph release, which you can then select in the web-based wizard or the CLI tool.

Already running the HCI and want to upgrade to the succeeding *Ceph* major release
: Please follow the related Ceph upgrade guide.

Already running the HCI and want to upgrade to the succeeding *Proxmox VE* major release
: In an HCI each Proxmox VE major release requires a corresponding minimum Ceph major release, please follow the related Proxmox VE upgrade guide.

Not running an HCI but using an external Ceph cluster
: To install newer packages used to connect to Ceph, apply available system updates, decide on a repository and Ceph release listed below, add it to your node via the *Repository* panel, apply newly available system updates, verify the result by running `ceph --version` and disable the old Ceph repository.

Ceph releases available in Proxmox VE 9

To read the latest version of the admin guide for your Proxmox VE release, make sure that all system updates are installed and that this page has been reloaded.

	Estimated End-of-Life	`enterprise`	`no-subscription`	`test`
`ceph-tentacle`	2027-11 (v20.2)	recommended	available	available
`ceph-squid`	2026-09 (v19.2)	available	available	available

Ceph repositories for Proxmox VE 9

The content of the `ceph.sources` file below serves as a reference (prior to Proxmox VE 9 the file `ceph.list` was used). To make changes, please follow the case that applies to your situation as described at the beginning of this subchapter. If you have disabled a repository in the web UI and also want to delist it, you can manually remove the corresponding entry from the file.

`enterprise`

This repository is recommended for production use and contains the most stable package versions. It is accessible if the Proxmox VE node has a valid subscription of any level. For details and included customer support levels visit:

https://proxmox.com/en/proxmox-virtual-environment/pricing

File /etc/apt/sources.list.d/ceph.sources

```
Types: deb
URIs: https://enterprise.proxmox.com/debian/ceph-tentacle
Suites: trixie
Components: enterprise
Signed-By: /usr/share/keyrings/proxmox-archive-keyring.gpg
```

`no-subscription`

This repository is suitable for testing and for non-production use. It is freely accessible and does not require a valid subscription. After some time, its package versions are also made available in the enterprise repository.

File /etc/apt/sources.list.d/ceph.sources

```
Types: deb
URIs: http://download.proxmox.com/debian/ceph-tentacle
Suites: trixie
Components: no-subscription
Signed-By: /usr/share/keyrings/proxmox-archive-keyring.gpg
```

`test`

This repository contains the latest package versions and is primarily used by developers to test new features and bug fixes.

File /etc/apt/sources.list.d/ceph.sources

```
Types: deb
URIs: http://download.proxmox.com/debian/ceph-tentacle
Suites: trixie
Components: test
Signed-By: /usr/share/keyrings/proxmox-archive-keyring.gpg
```



Warning
The Ceph **`test`** repository should (as the name implies) only be used for testing new features or bug fixes.

3.1.8 Debian Firmware Repository

Starting with Debian Bookworm (Proxmox VE 8) non-free firmware (as defined by DFSG) has been moved to the newly created Debian repository component `non-free-firmware`.

Since Proxmox VE 9 this repository is enabled by default for new installations to ensure they can get Early OS Microcode Updates.

You can also acquire need additional Runtime Firmware Files not already included in the pre-installed package `pve-firmware`.

To be able to install packages from this component, run `editor /etc/apt/sources.list`, append `non-free-firmware` to the end of each `.debian.org` repository line and run `apt update`.

If you upgraded your Proxmox VE 9 install from a previous version of Proxmox VE and have modernized your package repositories to the new deb822-style, you will need to adapt `/etc/apt/sources.list.d/debian` instead. Run `editor /etc/apt/sources.list.d/debian.sources` and add `non-free-firmwa` to the lines starting with `Components:` of each stanza.

Note
Modernizing your package repositories is recommended. Otherwise, `apt` on Debian Trixie will complain. You can run `apt modernize-sources` to do so.

3.1.9 SecureApt

The *Release* files in the repositories are signed with GnuPG. APT is using these signatures to verify that all packages are from a trusted source.

If you install Proxmox VE from an official ISO image, the key for verification is already installed.

If you install Proxmox VE on top of Debian, download and install the key with the following commands:

```
# wget https://enterprise.proxmox.com/debian/proxmox-archive-keyring- ↩
   trixie.gpg -O /usr/share/keyrings/proxmox-archive-keyring.gpg
```

Note
The `wget` command above adds the keyring for Proxmox releases based on Debian Trixie. Once the `proxmox-archive-keyring` package is installed, it will manage this file. At that point, the hashes below may no longer match the hashes of this file, as keys for new Proxmox releases get added or removed. This is intended, `apt` will ensure that only trusted keys are being used. **Modifying this file is discouraged once `proxmox-archive-keyring` is installed.**

Verify the checksum afterwards with the `sha512sum` CLI tool:

```
# sha256sum /usr/share/keyrings/proxmox-archive-keyring.gpg
 136673be77aba35dcce385b28737689ad64fd785a797e57897589aed08db6e45 /usr/ ↩
   share/keyrings/proxmox-archive-keyring.gpg
```

or the `md5sum` CLI tool:

```
# md5sum /usr/share/keyrings/proxmox-archive-keyring.gpg
77c8b1166d15ce8350102ab1bca2fcbf /usr/share/keyrings/proxmox-archive- ↩
   keyring.gpg
```

Note
Make sure the path you install the key to matches the `Signed-By:` lines in your repository stanzas.

3.2 System Software Updates

Proxmox provides updates on a regular basis for all repositories. To install updates use the web-based GUI or the following CLI commands:

```
# apt update
# apt full-upgrade
```



Warning
As Proxmox VE uses a rolling release model on top of Debian, performing an `apt upgrade` may result in a partially upgraded or broken package state. This is because `apt full-upgrade` can also remove existing packages to satisfy dependencies if needed, while `apt upgrade` cannot.

For occasionally upgrading Ceph to its succeeding major release, see Ceph Repositories.

Note
The APT package management system is very flexible and provides many features, see `man apt`, or [Hertzog13] for additional information.

Tip
Regular updates are essential to get the latest patches and security related fixes. Major system upgrades are announced in the Proxmox VE Community Forum.

3.3 Firmware Updates

Firmware updates from this chapter should be applied when running Proxmox VE on a bare-metal server. Whether configuring firmware updates is appropriate within guests, e.g. when using device pass-through, depends strongly on your setup and is therefore out of scope.

In addition to regular software updates, firmware updates are also important for reliable and secure operation.

When obtaining and applying firmware updates, a combination of available options is recommended to get them as early as possible or at all.

The term firmware is usually divided linguistically into microcode (for CPUs) and firmware (for other devices).

3.3.1 Persistent Firmware

This section is suitable for all devices. Updated microcode, which is usually included in a BIOS/UEFI update, is stored on the motherboard, whereas other firmware is stored on the respective device. This persistent method is especially important for the CPU, as it enables the earliest possible regular loading of the updated microcode at boot time.



Caution
With some updates, such as for BIOS/UEFI or storage controller, the device configuration could be reset. Please follow the vendor's instructions carefully and back up the current configuration.

Please check with your vendor which update methods are available.

- Convenient update methods for servers can include Dell's Lifecycle Manager or Service Packs from HPE.
- Sometimes there are Linux utilities available as well. Examples are *mlxup* for NVIDIA ConnectX or *bnxtnvm*/*niccli* for Broadcom network cards.
- LVFS is also an option if there is a cooperation with the hardware vendor and supported hardware in use. The technical requirement for this is that the system was manufactured after 2014 and is booted via UEFI.

Proxmox VE ships its own version of the `fwupd` package to enable Secure Boot Support with the Proxmox signing key. This package consciously dropped the dependency recommendation for the `udisks2` package, due to observed issues with its use on hypervisors.

Tip
If the update instructions require a host reboot, make sure that it can be done safely. See also Node Maintenance.

3.3.2 Runtime Firmware Files

This method stores firmware on the Proxmox VE operating system and will pass it to a device if its persisted firmware is less recent. It is supported by devices such as network and graphics cards, but not by those that rely on persisted firmware such as the motherboard and hard disks.

In Proxmox VE the package `pve-firmware` is already installed by default. Therefore, with the normal system updates (APT), included firmware of common hardware is automatically kept up to date.

An additional Debian Firmware Repository exists, but is not configured by default.

If you try to install an additional firmware package but it conflicts, APT will abort the installation. Perhaps the particular firmware can be obtained in another way.

3.3.3 CPU Microcode Updates

Note
CPU microcode updates as described in this section are specific to x86 hosts. There is no equivalent operating-system-level microcode package for arm64.

Microcode updates are intended to fix found security vulnerabilities and other serious CPU bugs. While the CPU performance can be affected, a patched microcode is usually still more performant than an unpatched microcode where the kernel itself has to do mitigations. Depending on the CPU type, it is possible that performance results of the flawed factory state can no longer be achieved without knowingly running the CPU in an unsafe state.

To get an overview of present CPU vulnerabilities and their mitigations, run `lscpu`. Current real-world known vulnerabilities can only show up if the Proxmox VE host is up to date, its version not end of life, and has at least been rebooted since the last kernel update.

Besides the recommended microcode update via persistent BIOS/UEFI updates, there is also an independent method via **Early OS Microcode Updates**. It is convenient to use and also quite helpful when the motherboard vendor no longer provides BIOS/UEFI updates. Regardless of the method in use, a reboot is always needed to apply a microcode update.

Set up Early OS Microcode Updates

To set up microcode updates that are applied early on boot by the Linux kernel, you need to:

1. Enable the Debian Firmware Repository
2. Get the latest available packages `apt update` (or use the web interface, under Node → Updates)
3. Install the CPU-vendor specific microcode package:
   - For Intel CPUs: `apt install intel-microcode`
   - For AMD CPUs: `apt install amd64-microcode`
4. Reboot the Proxmox VE host

Any future microcode update will also require a reboot to be loaded.

Microcode Version

To get the current running microcode revision for comparison or debugging purposes:

```
# grep microcode /proc/cpuinfo | uniq
microcode       : 0xf0
```

A microcode package has updates for many different CPUs. But updates specifically for your CPU might not come often. So, just looking at the date on the package won't tell you when the company actually released an update for your specific CPU.

If you've installed a new microcode package and rebooted your Proxmox VE host, and this new microcode is newer than both, the version baked into the CPU and the one from the motherboard's firmware, you'll see a message in the system log saying "microcode updated early".

```
# dmesg | grep microcode
[    0.000000] microcode: microcode updated early to revision 0xf0, date =  ↩
   2021-11-12
[    0.896580] microcode: Microcode Update Driver: v2.2.
```

Troubleshooting

For debugging purposes, the set up Early OS Microcode Update applied regularly at system boot can be temporarily disabled as follows:

1. make sure that the host can be rebooted safely
2. reboot the host to get to the GRUB menu (hold `SHIFT` if it is hidden)
3. at the desired Proxmox VE boot entry press `E`
4. go to the line which starts with `linux` and append separated by a space **`dis_ucode_ldr`**
5. press `CTRL-X` to boot this time without an Early OS Microcode Update

If a problem related to a recent microcode update is suspected, a package downgrade should be considered instead of package removal (`apt purge <intel-microcode|amd64-microcode>`). Otherwise, a too old persisted microcode might be loaded, even though a more recent one would run without problems.

A downgrade is possible if an earlier microcode package version is available in the Debian repository, as shown in this example:

```
# apt list -a intel-microcode
Listing... Done
intel-microcode/stable-security,now 3.20230808.1~deb12u1 amd64 [installed]
intel-microcode/stable 3.20230512.1 amd64
```

```
# apt install intel-microcode=3.202305*
...
Selected version '3.20230512.1' (Debian:12.1/stable [amd64]) for 'intel- ↩
   microcode'
...
dpkg: warning: downgrading intel-microcode from 3.20230808.1~deb12u1 to  ↩
   3.20230512.1
...
intel-microcode: microcode will be updated at next boot
...
```

Make sure (again) that the host can be rebooted safely. To apply an older microcode potentially included in the microcode package for your CPU type, reboot now.

Tip

It makes sense to hold the downgraded package for a while and try more recent versions again at a later time. Even if the package version is the same in the future, system updates may have fixed the experienced problem in the meantime.

```
# apt-mark hold intel-microcode
intel-microcode set on hold.
```

```
# apt-mark unhold intel-microcode
# apt update
# apt full-upgrade
```

3.4 Network Configuration

Proxmox VE is using the Linux network stack. This provides a lot of flexibility on how to set up the network on the Proxmox VE nodes. The configuration can be done either via the GUI, or by manually editing the file `/etc/network/interfaces`, which contains the whole network configuration. The `interfaces(5)` manual page contains the complete format description. All Proxmox VE tools try hard to keep direct user modifications, but using the GUI is still preferable, because it protects you from errors.

A Linux bridge interface (commonly called *vmbrX*) is needed to connect guests to the underlying physical network. It can be thought of as a virtual switch which the guests and physical interfaces are connected to. This section provides some examples on how the network can be set up to accommodate different use cases like redundancy with a bond, vlans or routed and NAT setups.

The Software Defined Network is an option for more complex virtual networks in Proxmox VE clusters.



Warning
It's discouraged to use the traditional Debian tools `ifup` and `ifdown` if unsure, as they have some pitfalls like interrupting all guest traffic on `ifdown vmbrX` but not reconnecting those guest again when doing `ifup` on the same bridge later.

3.4.1 Apply Network Changes

Proxmox VE does not write changes directly to `/etc/network/interfaces`. Instead, we write into a temporary file called `/etc/network/interfaces.new`, this way you can do many related changes at once. This also allows to ensure your changes are correct before applying, as a wrong network configuration may render a node inaccessible.

Live-Reload Network with ifupdown2

With the recommended *ifupdown2* package (default for new installations since Proxmox VE 7.0), it is possible to apply network configuration changes without a reboot. If you change the network configuration via the GUI, you can click the *Apply Configuration* button. This will move changes from the staging `interfaces.new` file to `/etc/network/interfaces` and apply them live.

If you made manual changes directly to the `/etc/network/interfaces` file, you can apply them by running `ifreload -a`

Note
If you installed Proxmox VE on top of Debian, or upgraded to Proxmox VE 7.0 from an older Proxmox VE installation, make sure *ifupdown2* is installed: `apt install ifupdown2`

Reboot Node to Apply

Another way to apply a new network configuration is to reboot the node. In that case the systemd service `pvenetcommit` will activate the staging `interfaces.new` file before the `networking` service will apply that configuration.

3.4.2 Naming Conventions

We currently use the following naming conventions for device names:

- Ethernet devices: `en*`, systemd network interface names. This naming scheme is used for new Proxmox VE installations since version 5.0.
- Ethernet devices: `eth[N]`, where 0 ≤ N (`eth0`, `eth1`, ...) This naming scheme is used for Proxmox VE hosts which were installed before the 5.0 release. When upgrading to 5.0, the names are kept as-is.
- Bridge names: Commonly `vmbr[N]`, where 0 ≤ N ≤ 4094 (`vmbr0` - `vmbr4094`), but you can use any alphanumeric string that starts with a character and is at most 10 characters long.
- Bonds: `bond[N]`, where 0 ≤ N (`bond0`, `bond1`, ...)
- VLANs: Simply add the VLAN number to the device name, separated by a period (`eno1.50`, `bond1.30`)

This makes it easier to debug networks problems, because the device name implies the device type.

Systemd Network Interface Names

Systemd defines a versioned naming scheme for network device names. The scheme uses the two-character prefix `en` for Ethernet network devices. The next characters depends on the device driver, device location and other attributes. Some possible patterns are:

- `o<index>[n<phys_port_name>|d<dev_port>]` — devices on board
- `s<slot>[f<function>][n<phys_port_name>|d<dev_port>]` — devices by hotplug id
- `[P<domain>]p<bus>s<slot>[f<function>][n<phys_port_name>|d<dev_port>]` — devices by bus id
- `x<MAC>` — devices by MAC address

Some examples for the most common patterns are:

- `eno1` — is the first on-board NIC
- `enp3s0f1` — is function 1 of the NIC on PCI bus 3, slot 0

For a full list of possible device name patterns, see the systemd.net-naming-scheme(7) manpage.

A new version of systemd may define a new version of the network device naming scheme, which it then uses by default. Consequently, updating to a newer systemd version, for example during a major Proxmox VE upgrade, can change the names of network devices and require adjusting the network configuration. To avoid name changes due to a new version of the naming scheme, you can manually pin a particular naming scheme version (see below).

However, even with a pinned naming scheme version, network device names can still change due to kernel or driver updates. In order to avoid name changes for a particular network device altogether, you can manually override its name using a link file (see below).

For more information on network interface names, see Predictable Network Interface Names.

Pinning a specific naming scheme version

You can pin a specific version of the naming scheme for network devices by adding the `net.naming-scheme=<` parameter to the kernel command line. For a list of naming scheme versions, see the systemd.net-naming-scheme(7) manpage.

For example, to pin the version `v252`, which is the latest naming scheme version for a fresh Proxmox VE 8.0 installation, add the following kernel command-line parameter:

```
net.naming-scheme=v252
```

See also this section on editing the kernel command line. You need to reboot for the changes to take effect.

Overriding Network Device Names

Using the pve-network-interface-pinning Tool

Proxmox VE provides a tool for automatically generating .link files for overriding the name of network devices. It also automatically replaces the occurences of the old interface name in the following files:

- `/etc/network/interfaces`
- `/etc/pve/nodes/<nodename>/host.fw`
- `/etc/pve/sdn/controllers.cfg`
- `/etc/pve/sdn/fabrics.cfg`

Note
Since the generated mapping is local to the node it is generated on, interface names contained in the Firewall Datacenter configuration (`/etc/pve/firewall/cluster.fw`) are **not** automatically updated.

The generated link files are stored in `/usr/local/lib/systemd/network`. For the configuration files a new file will be generated in the same place with a `.new` suffix. This way you can inspect the changes made to the configuration by using diff (or another diff viewer of your choice):

```
diff -y /etc/network/interfaces /etc/network/interfaces.new
```

If you see any problematic changes or want to revert the changes made by the pinning tool **before rebooting**, simply delete all `.new` files and the respective link files from `/usr/local/lib/systemd/network`.

The following command will generate a .link file for all physical network interfaces that do not yet have a .link file and update selected Proxmox VE configuration files (see above). The generated names will use the default prefix `nic`, so the resulting interface names will be `nic1`, `nic2`, ...

```
pve-network-interface-pinning generate
```

You can override the default prefix with the `--prefix` flag:

```
pve-network-interface-pinning generate --prefix myprefix
```

It is also possible to pin only a specific interface:

```
pve-network-interface-pinning generate --interface enp1s0
```

When pinning a specific interface, you can specify the exact name that the interface should be pinned to:

```
pve-network-interface-pinning generate --interface enp1s0 --target-name  ↩
   if42
```

In order to apply the changes made by `pve-network-interface-pinning` to the network configuration, the node needs to be rebooted.

Manually Creating .Link Files

You can manually assign a name to a particular network device using a custom systemd.link file. This overrides the name that would be assigned according to the latest network device naming scheme. This way, you can avoid naming changes due to kernel updates, driver updates or newer versions of the naming scheme.

Custom link files should be placed in `/etc/systemd/network/` and named `<n>-<id>.link`, where `n` is a priority smaller than `99` and `id` is some identifier. A link file has two sections: `[Match]` determines which interfaces the file will apply to; `[Link]` determines how these interfaces should be configured, including their naming.

To assign a name to a particular network device, you need a way to uniquely and permanently identify that device in the `[Match]` section. One possibility is to match the device's MAC address using the `MACAddress` option, as it is unlikely to change.

The `[Match]` section should also contain a `Type` option to make sure it only matches the expected physical interface, and not bridge/bond/VLAN interfaces with the same MAC address. In most setups, `Type` should be set to `ether` to match only Ethernet devices, but some setups may require other choices. See the systemd.link(5) manpage for more details.

Then, you can assign a name using the `Name` option in the `[Link]` section.

Link files are copied to the `initramfs`, so it is recommended to refresh the `initramfs` after adding, modifying, or removing a link file:

```
# update-initramfs -u -k all
```

For example, to assign the name `enwan0` to the Ethernet device with MAC address `aa:bb:cc:dd:ee:ff`, create a file `/etc/systemd/network/10-enwan0.link` with the following contents:

```
[Match]
MACAddress=aa:bb:cc:dd:ee:ff
Type=ether

[Link]
Name=enwan0
```

Do not forget to adjust `/etc/network/interfaces` to use the new name, and refresh your `initramfs` as described above. You need to reboot the node for the change to take effect.

Note
It is recommended to assign a name starting with `en` or `eth` so that Proxmox VE recognizes the interface as a physical network device which can then be configured via the GUI. Also, you should ensure that the name will not clash with other interface names in the future. One possibility is to assign a name that does not match any name pattern that systemd uses for network interfaces (see above), such as `enwan0` in the example above.

For more information on link files, see the systemd.link(5) manpage.

3.4.3 Choosing a network configuration

Depending on your current network organization and your resources you can choose either a bridged, routed, or masquerading networking setup.

Proxmox VE server in a private LAN, using an external gateway to reach the internet

The **Bridged** model makes the most sense in this case, and this is also the default mode on new Proxmox VE installations. Each of your Guest system will have a virtual interface attached to the Proxmox VE bridge. This is similar in effect to having the Guest network card directly connected to a new switch on your LAN, the Proxmox VE host playing the role of the switch.

Proxmox VE server at hosting provider, with public IP ranges for Guests

For this setup, you can use either a **Bridged** or **Routed** model, depending on what your provider allows.

Proxmox VE server at hosting provider, with a single public IP address

In that case the only way to get outgoing network accesses for your guest systems is to use **Masquerading**. For incoming network access to your guests, you will need to configure **Port Forwarding**.

For further flexibility, you can configure VLANs (IEEE 802.1q) and network bonding, also known as "link aggregation". That way it is possible to build complex and flexible virtual networks.

3.4.4 Default Configuration Using a Bridge



Bridges are like physical network switches implemented in software. All virtual guests can share a single bridge, or you can create multiple bridges to separate network domains. Each host can have up to 4094 bridges.

The installation program creates a single bridge named `vmbr0`, which is connected to the management interface selected during the installation. The corresponding configuration in `/etc/network/interfaces` might look like this:

```
auto lo
iface lo inet loopback

iface eno1 inet manual

auto vmbr0
iface vmbr0 inet static
        address 192.168.10.2/24
        gateway 192.168.10.1
        bridge-ports eno1
        bridge-stp off
        bridge-fd 0
```

If you set up a bond during the installation, the bridge is connected to the bond `bond0` instead. With a VLAN tag for the management network, the bridge is VLAN-aware and the host address is configured on a VLAN interface on top of it. See Advanced Network Configuration Options.

Virtual machines behave as if they were directly connected to the physical network. The network, in turn, sees each virtual machine as having its own MAC, even though there is only one network cable connecting all of these VMs to the network.

3.4.5 Routed Configuration

Most hosting providers do not support the above setup. For security reasons, they disable networking as soon as they detect multiple MAC addresses on a single interface.

Tip
Some providers allow you to register additional MACs through their management interface. This avoids the problem, but can be clumsy to configure because you need to register a MAC for each of your VMs.

You can avoid the problem by "routing" all traffic via a single interface. This makes sure that all network packets use the same MAC address.



A common scenario is that you have a public IP (assume `198.51.100.5` for this example), and an additional IP block for your VMs (`203.0.113.16/28`). We recommend the following setup for such situations:

```
auto lo
iface lo inet loopback

auto eno0
iface eno0 inet static
        address  198.51.100.5/29
        gateway  198.51.100.1
        post-up echo 1 > /proc/sys/net/ipv4/ip_forward
        post-up echo 1 > /proc/sys/net/ipv4/conf/eno0/proxy_arp


auto vmbr0
iface vmbr0 inet static
```

```
        address  203.0.113.17/28
        bridge-ports none
        bridge-stp off
        bridge-fd 0
```

The `vmbr0` address `203.0.113.17` is the first usable host address of the `203.0.113.16/28` block; the block's network address `203.0.113.16` cannot be assigned to an interface.

3.4.6 Masquerading (NAT) with `iptables`

Masquerading allows guests having only a private IP address to access the network by using the host IP address for outgoing traffic. Each outgoing packet is rewritten by `iptables` to appear as originating from the host, and responses are rewritten accordingly to be routed to the original sender.

```
auto lo
iface lo inet loopback

auto eno1
#real IP address
iface eno1 inet static
        address  198.51.100.5/24
        gateway  198.51.100.1

auto vmbr0
#private sub network
iface vmbr0 inet static
        address  10.10.10.1/24
        bridge-ports none
        bridge-stp off
        bridge-fd 0

        post-up   echo 1 > /proc/sys/net/ipv4/ip_forward
        post-up   iptables -t nat -A POSTROUTING -s '10.10.10.0/24' -o eno1 ↩
            -j MASQUERADE
        post-down iptables -t nat -D POSTROUTING -s '10.10.10.0/24' -o eno1 ↩
            -j MASQUERADE
```

Note
In some masquerade setups with firewall enabled, conntrack zones might be needed for outgoing connections. Otherwise the firewall could block outgoing connections since they will prefer the `POSTROUTING` of the VM bridge (and not `MASQUERADE`).

Adding these lines in the `/etc/network/interfaces` can fix this problem:

```
post-up   iptables -t raw -I PREROUTING -i fwbr+ -j CT --zone 1
post-down iptables -t raw -D PREROUTING -i fwbr+ -j CT --zone 1
```

For more information about this, refer to the following links:

Netfilter Packet Flow

Patch on netdev-list introducing conntrack zones

Blog post with a good explanation by using TRACE in the raw table

3.4.7 Linux Bond

Bonding (also called NIC teaming or Link Aggregation) is a technique for binding multiple NIC's to a single network device. It is possible to achieve different goals, like make the network fault-tolerant, increase the performance or both together.

High-speed hardware like Fibre Channel and the associated switching hardware can be quite expensive. By doing link aggregation, two NICs can appear as one logical interface, resulting in double speed. This is a native Linux kernel feature that is supported by most switches. If your nodes have multiple Ethernet ports, you can distribute your points of failure by running network cables to different switches and the bonded connection will failover to one cable or the other in case of network trouble.

Aggregated links can improve live-migration delays and improve the speed of replication of data between Proxmox VE Cluster nodes.

There are 7 modes for bonding:

- **Round-robin (balance-rr):** Transmit network packets in sequential order from the first available network interface (NIC) slave through the last. This mode provides load balancing and fault tolerance.
- **Active-backup (active-backup):** Only one NIC slave in the bond is active. A different slave becomes active if, and only if, the active slave fails. The single logical bonded interface's MAC address is externally visible on only one NIC (port) to avoid distortion in the network switch. This mode provides fault tolerance.
- **XOR (balance-xor):** Transmit network packets based on [(source MAC address XOR'd with destination MAC address) modulo NIC slave count]. This selects the same NIC slave for each destination MAC address. This mode provides load balancing and fault tolerance.
- **Broadcast (broadcast):** Transmit network packets on all slave network interfaces. This mode provides fault tolerance.
- **IEEE 802.3ad Dynamic link aggregation (802.3ad)(LACP):** Creates aggregation groups that share the same speed and duplex settings. Utilizes all slave network interfaces in the active aggregator group according to the 802.3ad specification.
- **Adaptive transmit load balancing (balance-tlb):** Linux bonding driver mode that does not require any special network-switch support. The outgoing network packet traffic is distributed according to the current load (computed relative to the speed) on each network interface slave. Incoming traffic is received by one currently designated slave network interface. If this receiving slave fails, another slave takes over the MAC address of the failed receiving slave.
- **Adaptive load balancing (balance-alb):** Includes balance-tlb plus receive load balancing (rlb) for IPV4 traffic, and does not require any special network switch support. The receive load balancing is achieved by ARP negotiation. The bonding driver intercepts the ARP Replies sent by the local system on their way out and overwrites the source hardware address with the unique hardware address of one of the NIC slaves in the single logical bonded interface such that different network-peers use different MAC addresses for their network packet traffic.

If your switch supports the LACP (IEEE 802.3ad) protocol, then we recommend using the corresponding bonding mode (802.3ad). Otherwise you should generally use the active-backup mode.



Warning
The bond modes *balance-alb* and *balance-tlb* are not suitable when the local addresses are not known to the host. These bond modes should not be used when a Linux bridge with guests is used in combination with the bond.

For the cluster network (Corosync) we recommend configuring it with multiple networks. Corosync does not need a bond for network redundancy as it can switch between networks by itself, if one becomes unusable. Some bond modes are known to be problematic for Corosync, see Corosync over Bonds.

The following bond configuration can be used as distributed/shared storage network. The benefit would be that you get more speed and the network will be fault-tolerant.

Example: Use bond with fixed IP address

```
auto lo
iface lo inet loopback

iface eno1 inet manual

iface eno2 inet manual

iface eno3 inet manual

auto bond0
iface bond0 inet static
      bond-slaves eno1 eno2
      address  192.168.1.2/24
      bond-miimon 100
      bond-mode 802.3ad
      bond-xmit-hash-policy layer2+3

auto vmbr0
iface vmbr0 inet static
        address  10.10.10.2/24
        gateway  10.10.10.1
        bridge-ports eno3
        bridge-stp off
        bridge-fd 0
```



Another possibility is to use the bond directly as the bridge port. This can be used to make the guest network fault-tolerant.

Example: Use a bond as the bridge port

```
auto lo
iface lo inet loopback

iface eno1 inet manual

iface eno2 inet manual

auto bond0
iface bond0 inet manual
      bond-slaves eno1 eno2
      bond-miimon 100
      bond-mode 802.3ad
      bond-xmit-hash-policy layer2+3

auto vmbr0
iface vmbr0 inet static
        address  10.10.10.2/24
        gateway  10.10.10.1
        bridge-ports bond0
        bridge-stp off
        bridge-fd 0
```

3.4.8 VLAN 802.1Q

A virtual LAN (VLAN) is a broadcast domain that is partitioned and isolated in the network at layer two. So it is possible to have multiple networks (4096) in a physical network, each independent of the other ones.

Each VLAN network is identified by a number often called *tag*. Network packages are then *tagged* to identify which virtual network they belong to.

VLAN for Guest Networks

Proxmox VE supports this setup out of the box. You can specify the VLAN tag when you create a VM. The VLAN tag is part of the guest network configuration. The networking layer supports different modes to implement VLANs, depending on the bridge configuration:

- **VLAN awareness on the Linux bridge:** In this case, each guest's virtual network card is assigned to a VLAN tag, which is transparently supported by the Linux bridge. Trunk mode is also possible, but that makes configuration in the guest necessary.
- **"traditional" VLAN on the Linux bridge:** In contrast to the VLAN awareness method, this method is not transparent and creates a VLAN device with associated bridge for each VLAN. That is, creating a guest on VLAN 5 for example, would create two interfaces eno1.5 and vmbr0v5, which would remain until a reboot occurs.
- **Open vSwitch VLAN:** This mode uses the OVS VLAN feature.
- **Guest configured VLAN:** VLANs are assigned inside the guest. In this case, the setup is completely done inside the guest and can not be influenced from the outside. The benefit is that you can use more than one VLAN on a single virtual NIC.
- **SDN configured VLAN:** It is also possible to configure VLANs in SDN by creating a VLAN zone on the bridge and then creating VNets for every VLAN tag. In this case, it is also recommended to use a VLAN-aware bridge.

Example: SDN VLAN Zones with VLAN-aware bridges

This is the preferred solution if users have a small number of VLANs inside their cluster. On every node, users should configure a VLAN-aware bridge with the respective carrier for their VLANs:

```
auto vmbr0
iface vmbr0 inet manual
        bridge-ports nic0
        bridge-stp off
        bridge-fd 0
        bridge-vlan-aware yes
        bridge-vids 2-4094
```

Then create an SDN zone on top of that bridge:

```
vlan: vlanz
        bridge vmbr0
        ipam pve
```

Then, for each VLAN they want to use, create a VNet:

```
vnet: vnet1234
        zone vlanz
        tag 1234
```

After applying the SDN configuration, users can then select vnet1234 in the network device configuration of their guests. This method does not allow to configure an IP for the host directly on a VNet - but it can be done manually by adding an entry for the VNet to /etc/network/interfaces:

```
auto vnet1234
iface vnet1234 inet static
        address 192.0.2.1/24
```

Note
On a VLAN-aware bridge, a VNet uses `vmbr0.<tag>` as its bridge port. Do not configure a host address on that interface for a tag that has a VNet, configure it on the VNet instead.

VLAN on the Host

To allow host communication with an isolated network. It is possible to apply VLAN tags to any network device (NIC, Bond, Bridge). In general, you should configure the VLAN on the interface with the least abstraction layers between itself and the physical NIC. But it would still be best to configure the VLAN on a bridge instead of a bond or the NIC directly to avoid some of the issues mentioned here.

For example, in a default configuration where you want to place the host management address on a separate VLAN.

Example: Use VLAN 5 for the Proxmox VE management IP with VLAN-aware Linux bridge

```
auto lo
iface lo inet loopback

iface eno1 inet manual

auto vmbr0
iface vmbr0 inet manual
        bridge-ports eno1
        bridge-stp off
        bridge-fd 0
        bridge-vlan-aware yes
        bridge-vids 2-4094

auto vmbr0.5
iface vmbr0.5 inet static
        address  10.10.10.2/24
        gateway  10.10.10.1
```

Guests can then reference the VLAN tag directly in their network configuration. Compared to an SDN-configured solution, this has the disadvantage that specific VLANs cannot be named, but the advantage that each VLAN does not have to be configured individually.

```
net0: bridge=vmbr0,tag=5,...
```

The next example is the same setup but a bond is used to make this network fail-safe.

Example: Use VLAN 5 with bond0 for the Proxmox VE management IP with VLAN-aware Linux bridge

```
auto lo
iface lo inet loopback

iface eno1 inet manual

iface eno2 inet manual

auto bond0
iface bond0 inet manual
      bond-slaves eno1 eno2
      bond-miimon 100
      bond-mode 802.3ad
      bond-xmit-hash-policy layer2+3

auto vmbr0
iface vmbr0 inet manual
        bridge-ports bond0
        bridge-vlan-aware yes
        bridge-vids 2-4094
        bridge-stp off
        bridge-fd 0

auto vmbr0.5
iface vmbr0.5 inet static
        address 10.10.10.2/24
        gateway 10.10.10.1
```

Common Issues

Issue: Host not reachable on VLAN interface after guest start

A management IP can be configured in a VLAN interface whose underlying interface is a bridge port, for example on nic0.5 or bond0.5. If the bridge the underlying interface is on is not VLAN-aware, the IP stops working as soon as a guest on that bridge and VLAN is started. Stopping the guest will not rectify this problem, the host has to be rebooted. To fix this, the VLAN interface must be removed, and the management IP configured on the bridge VLAN interface, as well as making the bridge VLAN-aware. This example shows how to do this.

Issue: ifupdown2 fails after configuring gateway on NIC

When configuring a default gateway on the VLAN interface, where the underlying interface is part of a VLAN-aware bridge, ifupdown2 will not be able to configure the default gateway and fail with a similar error:

```
error: nic0.1337: cmd '/bin/ip route replace default via 192.0.2.1 proto  ↩
   kernel
dev nic0.1337 onlink' failed: returned 2 (Error: Nexthop device is not up.)
```

To avoid this issue, configure the address and default gateway on a VLAN interface of the bridge, for example `vmbr0.5`, as shown in this example.

Issue: Limited number of tags when VLAN offloading to NIC

Certain NICs only support VLAN filter offloading for a reduced number of tags. In these cases it's best to either reduce the tag range on the VLAN-aware bridge or disable offloading altogether. To determine if offloading is enabled, use `ethtool`, replacing `nic0` with the name of your interface:

```
ethtool -k nic0 | grep rx-vlan-filter
```

If the output contains "[fixed]", the value cannot be changed. Otherwise, use a `post-up` command to disable offloading, so that the setting persists across reboots:

```
iface nic0 inet manual
        post-up ethtool -K nic0 rx-vlan-filter off
```

Troubleshooting

There are some helpful commands that can be utilized when debugging such issues:

```
$ bridge -compressvlans vlan show
```

This prints a list of bridges and their ports, as well as the VLANs that are currently configured for them:

```
port              vlan-id
nic0              1 PVID Egress Untagged
                  2-4094
vmbr0             1 PVID Egress Untagged
veth100i0         1234 PVID Egress Untagged
```

```
$ bridge fdb show
```

This prints a list of the current forwarding database entries of all bridges. The bridge decides how to forward a given packet based on this table. An entry of the fdb generally looks like this:

```
aa:aa:aa:d8:36:7c dev nic0 vlan 49 master vmbr0 permanent
```

This means that packets arriving on vmbr0, that have VLAN Tag 49 set and destination MAC address aa:aa:aa:d8:36:7c will not be forwarded, but be terminated locally.

3.4.9 Disabling IPv6 on the Node

Proxmox VE works correctly in all environments, irrespective of whether IPv6 is deployed or not. We recommend leaving all settings at the provided defaults.

Should you still need to disable support for IPv6 on your node, do so by creating an appropriate `sysctl.conf (5)` snippet file and setting the proper sysctls, for example adding `/etc/sysctl.d/disable-ipv6.conf` with content:

```
net.ipv6.conf.all.disable_ipv6 = 1
net.ipv6.conf.default.disable_ipv6 = 1
```

This method is preferred to disabling the loading of the IPv6 module on the kernel commandline.

3.4.10 Disabling MAC Learning on a Bridge

By default, MAC learning is enabled on a bridge to ensure a smooth experience with virtual guests and their networks.

But in some environments this can be undesired. Since Proxmox VE 7.3 you can disable MAC learning on the bridge by setting the ‘bridge-disable-mac-learning 1` configuration on a bridge in `/etc/network/interfaces’, for example:

```
# ...

auto vmbr0
iface vmbr0 inet static
        address  10.10.10.2/24
        gateway  10.10.10.1
        bridge-ports ens18
        bridge-stp off
        bridge-fd 0
        bridge-disable-mac-learning 1
```

Once enabled, Proxmox VE will manually add the configured MAC address from VMs and Containers to the bridges forwarding database to ensure that guest can still use the network - but only when they are using their actual MAC address.

3.5 Time Synchronization

The Proxmox VE cluster stack itself relies heavily on the fact that all the nodes have precisely synchronized time. Some other components, like Ceph, also won’t work properly if the local time on all nodes is not in sync.

Time synchronization between nodes can be achieved using the “Network Time Protocol” (`NTP`). As of Proxmox VE 7, `chrony` is used as the default NTP daemon, while Proxmox VE 6 uses `systemd-timesyncd`. Both come preconfigured to use a set of public servers.



Important
If you upgrade your system to Proxmox VE 7, it is recommended that you manually install either `chrony`, `ntp` or `openntpd`.

3.5.1 Using Custom NTP Servers

In some cases, it might be desired to use non-default NTP servers. For example, if your Proxmox VE nodes do not have access to the public internet due to restrictive firewall rules, you need to set up local NTP servers and tell the NTP daemon to use them.

For systems using chrony:

Specify which servers `chrony` should use in `/etc/chrony/chrony.conf`:

```
server ntp1.example.com iburst
server ntp2.example.com iburst
server ntp3.example.com iburst
```

Restart `chrony`:

```
# systemctl restart chronyd
```

Check the journal to confirm that the newly configured NTP servers are being used:

```
# journalctl --since -1h -u chrony
```

```
...
Aug 26 13:00:09 node1 systemd[1]: Started chrony, an NTP client/server.
Aug 26 13:00:15 node1 chronyd[4873]: Selected source 10.0.0.1 (ntp1.example ↩
   .com)
Aug 26 13:00:15 node1 chronyd[4873]: System clock TAI offset set to 37  ↩
   seconds
...
```

For systems using systemd-timesyncd:

Specify which servers `systemd-timesyncd` should use in `/etc/systemd/timesyncd.conf`:

```
[Time]
NTP=ntp1.example.com ntp2.example.com ntp3.example.com ntp4.example.com
```

Then, restart the synchronization service (`systemctl restart systemd-timesyncd`), and verify that your newly configured NTP servers are in use by checking the journal (`journalctl --since -1h -u systemd-timesyncd`):

```
...
Oct 07 14:58:36 node1 systemd[1]: Stopping Network Time Synchronization...
Oct 07 14:58:36 node1 systemd[1]: Starting Network Time Synchronization...
Oct 07 14:58:36 node1 systemd[1]: Started Network Time Synchronization.
Oct 07 14:58:36 node1 systemd-timesyncd[13514]: Using NTP server  ↩
   10.0.0.1:123 (ntp1.example.com).
Oct 07 14:58:36 node1 systemd-timesyncd[13514]: interval/delta/delay/jitter ↩
   /drift 64s/-0.002s/0.020s/0.000s/-31ppm
...
```

3.6 External Metric Server



In Proxmox VE, you can define external metric servers, which will periodically receive various stats about your hosts, virtual guests and storages.

Currently supported are:

- Graphite (see https://graphiteapp.org)
- InfluxDB (see https://www.influxdata.com/time-series-platform/influxdb/)
- OpenTelemetry (see https://opentelemetry.io/)

The external metric server definitions are saved in */etc/pve/status.cfg*, and can be edited through the web interface.

3.6.1 Graphite server configuration



The default port is set to **2003** and the default graphite path is **proxmox**.

By default, Proxmox VE sends the data over UDP, so the graphite server has to be configured to accept this. Here the maximum transmission unit (MTU) can be configured for environments not using the standard **1500** MTU.

You can also configure the plugin to use TCP. In order not to block the important `pvestatd` statistic collection daemon, a timeout is required to cope with network problems.

3.6.2 Influxdb plugin configuration



Proxmox VE sends the data over UDP, so the influxdb server has to be configured for this. The MTU can also be configured here, if necessary.

Here is an example configuration for influxdb (on your influxdb server):

```
[[udp]]
   enabled = true
   bind-address = "0.0.0.0:8089"
   database = "proxmox"
   batch-size = 1000
   batch-timeout = "1s"
```

With this configuration, your server listens on all IP addresses on port 8089, and writes the data in the **proxmox** database

Alternatively, the plugin can be configured to use the http(s) API of InfluxDB 2.x. InfluxDB 1.8.x does contain a forwards compatible API endpoint for this v2 API.

To use it, set *influxdbproto* to *http* or *https* (depending on your configuration). By default, Proxmox VE uses the organization *proxmox* and the bucket/db *proxmox* (They can be set with the configuration *organization* and *bucket* respectively).

Since InfluxDB's v2 API is only available with authentication, you have to generate a token that can write into the correct bucket and set it.

In the v2 compatible API of 1.8.x, you can use *user:password* as token (if required), and can omit the *organization* since that has no meaning in InfluxDB 1.x.

You can also set the HTTP Timeout (default is 1s) with the *timeout* setting, as well as the maximum batch size (default 25000000 bytes) with the *max-body-size* setting (this corresponds to the InfluxDB setting with the same name).

3.7 Disk Health Monitoring

Although a robust and redundant storage is recommended, it can be very helpful to monitor the health of your local disks.

Starting with Proxmox VE 4.3, the package smartmontools [1] is installed and required. This is a set of tools to monitor and control the S.M.A.R.T. system for local hard disks.

You can get the status of a disk by issuing the following command:

```
# smartctl -a /dev/sdX
```

where /dev/sdX is the path to one of your local disks.

If the output says:

```
SMART support is: Disabled
```

you can enable it with the command:

```
# smartctl -s on /dev/sdX
```

For more information on how to use smartctl, please see `man smartctl`.

By default, the smartmontools daemon smartd is active and enabled, and scans any devices matching

- `/dev/sd[a-z]`
- `/dev/sd[a-z][a-z]`
- `/dev/hd[a-t]`
- or `/dev/nvme[0-99]`

every 30 minutes for errors and warnings, and sends an e-mail to root if it detects a problem.

For more information about how to configure smartd, please see `man smartd` and `man smartd.conf`.

If you use your hard disks with a hardware raid controller, there are most likely tools to monitor the disks in the raid array and the array itself. For more information about this, please refer to the vendor of your raid controller.

3.8 Logical Volume Manager (LVM)

Most people install Proxmox VE directly on a local disk. The Proxmox VE installation CD offers several options for local disk management, and the current default setup uses LVM. The installer lets you select a single disk for such setup, and uses that disk as physical volume for the **V**olume **G**roup (VG) `pve`. The following output is from a test installation using a small 8GB disk:

```
# pvs
  PV         VG   Fmt  Attr PSize PFree
  /dev/sda3  pve  lvm2 a--  7.87g 876.00m

# vgs
  VG   #PV #LV #SN Attr   VSize VFree
  pve    1   3   0 wz--n- 7.87g 876.00m
```

The installer allocates three **L**ogical **V**olumes (LV) inside this VG:

[1] smartmontools homepage https://www.smartmontools.org

```
# lvs
  LV   VG   Attr       LSize   Pool Origin Data%  Meta%
  data pve  twi-a-tz--   4.38g             0.00   0.63
  root pve  -wi-ao----   1.75g
  swap pve  -wi-ao---- 896.00m
```

root
Formatted as `ext4`, and contains the operating system.

swap
Swap partition

data
This volume uses LVM-thin, and is used to store VM images. LVM-thin is preferable for this task, because it offers efficient support for snapshots and clones.

For Proxmox VE versions up to 4.1, the installer creates a standard logical volume called “data”, which is mounted at `/var/lib/vz`.

Starting from version 4.2, the logical volume “data” is a LVM-thin pool, used to store block based guest images, and `/var/lib/vz` is simply a directory on the root file system.

3.8.1 Hardware

We highly recommend to use a hardware RAID controller (with BBU) for such setups. This increases performance, provides redundancy, and make disk replacements easier (hot-pluggable).

LVM itself does not need any special hardware, and memory requirements are very low.

3.8.2 Bootloader

We install two boot loaders by default. The first partition contains the standard GRUB boot loader. The second partition is an **E**FI **S**ystem **P**artition (ESP), which makes it possible to boot on EFI systems and to apply persistent firmware updates from the user space.

3.8.3 Creating a Volume Group

Let’s assume we have an empty disk `/dev/sdb`, onto which we want to create a volume group named “vmdata”.



Caution
Please note that the following commands will destroy all existing data on `/dev/sdb`.

First create a partition.

```
# sgdisk -N 1 /dev/sdb
```

Create a **P**hysical **V**olume (PV) without confirmation and 250K metadatasize.

```
# pvcreate --metadatasize 250k -y -ff /dev/sdb1
```

Create a volume group named “vmdata” on `/dev/sdb1`

```
# vgcreate vmdata /dev/sdb1
```

3.8.4 Creating an extra LV for `/var/lib/vz`

This can be easily done by creating a new thin LV.

```
# lvcreate -n <Name> -V <Size[M,G,T]> <VG>/<LVThin_pool>
```

A real world example:

```
# lvcreate -n vz -V 10G pve/data
```

Now a filesystem must be created on the LV.

```
# mkfs.ext4 /dev/pve/vz
```

At last this has to be mounted.



Warning
be sure that `/var/lib/vz` is empty. On a default installation it’s not.

To make it always accessible add the following line in `/etc/fstab`.

```
# echo '/dev/pve/vz /var/lib/vz ext4 defaults 0 2' >> /etc/fstab
```

3.8.5 Resizing the thin pool

Resize the LV and the metadata pool with the following command:

```
# lvresize --size +<size[\M,G,T]> --poolmetadatasize +<size[\M,G]> < ↩
  VG>/<LVThin_pool>
```

Note
When extending the data pool, the metadata pool must also be extended.

3.8.6 Create a LVM-thin pool

A thin pool has to be created on top of a volume group. How to create a volume group see Section LVM.

```
# lvcreate -L 80G -T -n vmstore vmdata
```

3.9 ZFS on Linux

ZFS is a combined file system and logical volume manager designed by Sun Microsystems. Starting with Proxmox VE 3.4, the native Linux kernel port of the ZFS file system is introduced as optional file system and also as an additional selection for the root file system. There is no need for manually compile ZFS modules - all packages are included.

By using ZFS, its possible to achieve maximum enterprise features with low budget hardware, but also high performance systems by leveraging SSD caching or even SSD only setups. ZFS can replace cost intense hardware raid cards by moderate CPU and memory load combined with easy management.

GENERAL ZFS ADVANTAGES

- Easy configuration and management with Proxmox VE GUI and CLI.
- Reliable
- Protection against data corruption
- Data compression on file system level
- Snapshots
- Copy-on-write clone
- Various raid levels: RAID0, RAID1, RAID10, RAIDZ-1, RAIDZ-2, RAIDZ-3, dRAID, dRAID2, dRAID3
- Can use SSD for cache
- Self healing
- Continuous integrity checking
- Designed for high storage capacities
- Asynchronous replication over network
- Open Source
- Encryption
- ...

3.9.1 Hardware

ZFS depends heavily on memory, so you need at least 8GB to start. In practice, use as much as you can get for your hardware/budget. To prevent data corruption, we recommend the use of high quality ECC RAM.

If you use a dedicated cache and/or log disk, you should use an enterprise class SSD. This can increase the overall performance significantly.



Important
Do not use ZFS on top of a hardware RAID controller which has its own cache management. ZFS needs to communicate directly with the disks. An HBA adapter or something like an LSI controller flashed in “IT” mode is more appropriate.

If you are experimenting with an installation of Proxmox VE inside a VM (Nested Virtualization), don’t use `virtio` for disks of that VM, as they are not supported by ZFS. Use IDE or SCSI instead (also works with the `virtio` SCSI controller type).

3.9.2 Installation as Root File System

When you install using the Proxmox VE installer, you can choose ZFS for the root file system. You need to select the RAID type at installation time:

RAID0	Also called “striping”. The capacity of such volume is the sum of the capacities of all disks. But RAID0 does not add any redundancy, so the failure of a single drive makes the volume unusable.
RAID1	Also called “mirroring”. Data is written identically to all disks. This mode requires at least 2 disks with the same size. The resulting capacity is that of a single disk.
RAID10	A combination of RAID0 and RAID1. Requires at least 4 disks.
RAIDZ-1	A variation on RAID-5, single parity. Requires at least 3 disks.
RAIDZ-2	A variation on RAID-5, double parity. Requires at least 4 disks.
RAIDZ-3	A variation on RAID-5, triple parity. Requires at least 5 disks.

The installer automatically partitions the disks, creates a ZFS pool called `rpool`, and installs the root file system on the ZFS subvolume `rpool/ROOT/pve-1`.

Another subvolume called `rpool/data` is created to store VM images. In order to use that with the Proxmox VE tools, the installer creates the following configuration entry in `/etc/pve/storage.cfg`:

```
zfspool: local-zfs
        pool rpool/data
        sparse
        content images,rootdir
```

After installation, you can view your ZFS pool status using the `zpool` command:

```
# zpool status
  pool: rpool
 state: ONLINE
  scan: none requested
config:
```

```
        NAME         STATE     READ WRITE CKSUM
        rpool        ONLINE       0     0     0
          mirror-0   ONLINE       0     0     0
            sda2     ONLINE       0     0     0
            sdb2     ONLINE       0     0     0
          mirror-1   ONLINE       0     0     0
            sdc      ONLINE       0     0     0
            sdd      ONLINE       0     0     0

errors: No known data errors
```

The `zfs` command is used to configure and manage your ZFS file systems. The following command lists all file systems after installation:

```
# zfs list
NAME                USED  AVAIL  REFER  MOUNTPOINT
rpool              4.94G  7.68T    96K  /rpool
rpool/ROOT          702M  7.68T    96K  /rpool/ROOT
rpool/ROOT/pve-1    702M  7.68T   702M  /
rpool/data           96K  7.68T    96K  /rpool/data
rpool/swap         4.25G  7.69T    64K  -
```

3.9.3 ZFS RAID Level Considerations

There are a few factors to take into consideration when choosing the layout of a ZFS pool. The basic building block of a ZFS pool is the virtual device, or `vdev`. All vdevs in a pool are used equally and the data is striped among them (RAID0). Check the `zpoolconcepts(7)` manpage for more details on vdevs.

Performance

Each `vdev` type has different performance behaviors. The two parameters of interest are the IOPS (Input/Output Operations per Second) and the bandwidth with which data can be written or read.

A *mirror* vdev (RAID1) will approximately behave like a single disk in regard to both parameters when writing data. When reading data the performance will scale linearly with the number of disks in the mirror.

A common situation is to have 4 disks. When setting it up as 2 mirror vdevs (RAID10) the pool will have the write characteristics as two single disks in regard to IOPS and bandwidth. For read operations it will resemble 4 single disks.

A *RAIDZ* of any redundancy level will approximately behave like a single disk in regard to IOPS with a lot of bandwidth. How much bandwidth depends on the size of the RAIDZ vdev and the redundancy level.

A *dRAID* pool should match the performance of an equivalent *RAIDZ* pool.

For running VMs, IOPS is the more important metric in most situations.

Size, Space usage and Redundancy

While a pool made of *mirror* vdevs will have the best performance characteristics, the usable space will be 50% of the disks available. Less if a mirror vdev consists of more than 2 disks, for example in a 3-way mirror. At least one healthy disk per mirror is needed for the pool to stay functional.

The usable space of a *RAIDZ* type vdev of N disks is roughly N-P, with P being the RAIDZ-level. The RAIDZ-level indicates how many arbitrary disks can fail without losing data. A special case is a 4 disk pool with RAIDZ2. In this situation it is usually better to use 2 mirror vdevs for the better performance as the usable space will be the same.

Another important factor when using any RAIDZ level is how ZVOL datasets, which are used for VM disks, behave. For each data block the pool needs parity data which is at least the size of the minimum block size defined by the `ashift` value of the pool. With an ashift of 12 the block size of the pool is 4k. The default block size for a ZVOL is 8k. Therefore, in a RAIDZ2 each 8k block written will cause two additional 4k parity blocks to be written, 8k + 4k + 4k = 16k. This is of course a simplified approach and the real situation will be slightly different with metadata, compression and such not being accounted for in this example.

This behavior can be observed when checking the following properties of the ZVOL:

- `volsize`
- `refreservation` (if the pool is not thin provisioned)
- `used` (if the pool is thin provisioned and without snapshots present)

```
# zfs get volsize,refreservation,used <pool>/vm-<vmid>-disk-X
```

`volsize` is the size of the disk as it is presented to the VM, while `refreservation` shows the reserved space on the pool which includes the expected space needed for the parity data. If the pool is thin provisioned, the `refreservation` will be set to 0. Another way to observe the behavior is to compare the used disk space within the VM and the `used` property. Be aware that snapshots will skew the value.

There are a few options to counter the increased use of space:

- Increase the `volblocksize` to improve the data to parity ratio
- Use *mirror* vdevs instead of *RAIDZ*
- Use `ashift=9` (block size of 512 bytes)

The `volblocksize` property can only be set when creating a ZVOL. The default value can be changed in the storage configuration. When doing this, the guest needs to be tuned accordingly and depending on the use case, the problem of write amplification is just moved from the ZFS layer up to the guest.

Using `ashift=9` when creating the pool can lead to bad performance, depending on the disks underneath, and cannot be changed later on.

Mirror vdevs (RAID1, RAID10) have favorable behavior for VM workloads. Use them, unless your environment has specific needs and characteristics where RAIDZ performance characteristics are acceptable.

3.9.4 ZFS dRAID

In a ZFS dRAID (declustered RAID) the hot spare drive(s) participate in the RAID. Their spare capacity is reserved and used for rebuilding when one drive fails. This provides, depending on the configuration, faster rebuilding compared to a RAIDZ in case of drive failure. More information can be found in the official OpenZFS documentation. [2]

[2] OpenZFS dRAID https://openzfs.github.io/openzfs-docs/Basic%20Concepts/dRAID%20Howto.html

Note
dRAID is intended for more than 10-15 disks in a dRAID. A RAIDZ setup should be better for a lower amount of disks in most use cases.

Note
The GUI requires one more disk than the minimum (i.e. dRAID1 needs 3). It expects that a spare disk is added as well.

- `dRAID1` or `dRAID`: requires at least 2 disks, one can fail before data is lost
- `dRAID2`: requires at least 3 disks, two can fail before data is lost
- `dRAID3`: requires at least 4 disks, three can fail before data is lost

Additional information can be found on the manual page:

```
# man zpoolconcepts
```

Spares and Data

The number of `spares` tells the system how many disks it should keep ready in case of a disk failure. The default value is 0 `spares`. Without spares, rebuilding won't get any speed benefits.

`data` defines the number of devices in a redundancy group. The default value is 8. Except when `disks - parity - spares` equal something less than 8, the lower number is used. In general, a smaller number of `data` devices leads to higher IOPS, better compression ratios and faster resilvering, but defining fewer data devices reduces the available storage capacity of the pool.

3.9.5 Bootloader

Proxmox VE uses proxmox-boot-tool to manage the bootloader configuration. See the chapter on Proxmox VE host bootloaders for details.

3.9.6 ZFS Administration

This section gives you some usage examples for common tasks. ZFS itself is really powerful and provides many options. The main commands to manage ZFS are `zfs` and `zpool`. Both commands come with great manual pages, which can be read with:

```
# man zpool
# man zfs
```

Create a new zpool

To create a new pool, at least one disk is needed. The `ashift` should have the same sector-size (2 power of `ashift`) or larger as the underlying disk.

```
# zpool create -f -o ashift=12 <pool> <device>
```

Tip
Pool names must adhere to the following rules:

- begin with a letter (a-z or A-Z)
- contain only alphanumeric, `-`, `_`, `.`, `:` or ` ` (space) characters
- must **not begin** with one of `mirror`, `raidz`, `draid` or `spare`
- must not be `log`

To activate compression (see section Compression in ZFS):

```
# zfs set compression=lz4 <pool>
```

Create a new pool with RAID-0

Minimum 1 disk

```
# zpool create -f -o ashift=12 <pool> <device1> <device2>
```

Create a new pool with RAID-1

Minimum 2 disks

```
# zpool create -f -o ashift=12 <pool> mirror <device1> <device2>
```

Create a new pool with RAID-10

Minimum 4 disks

```
# zpool create -f -o ashift=12 <pool> mirror <device1> <device2> mirror < ↩
   device3> <device4>
```

Create a new pool with RAIDZ-1

Minimum 3 disks

```
# zpool create -f -o ashift=12 <pool> raidz1 <device1> <device2> <device3>
```

Create a new pool with RAIDZ-2

Minimum 4 disks

```
# zpool create -f -o ashift=12 <pool> raidz2 <device1> <device2> <device3> ↩
   <device4>
```

Please read the section for ZFS RAID Level Considerations to get a rough estimate on how IOPS and bandwidth expectations before setting up a pool, especially when wanting to use a RAID-Z mode.

Extend RAIDZ-N

Note
This feature only works starting with Proxmox VE 9 (ZFS 2.3.3).

Assuming you have an existing `<pool>` with a RAIDZ-N `<raidzN-M>` vdev, you can add a new physical disk `<device>` using the following syntax:

```
zpool attach <pool> <raidzN-M> <device>
```

You can verify general success by running `zpool status <pool>` and get verbose output for all attached disks by running `zpool list <pool> -v`. To inspect the new capacity of your pool run `zfs list <pool>`.

Create a new pool with cache (L2ARC)

It is possible to use a dedicated device, or partition, as second-level cache to increase the performance. Such a cache device will especially help with random-read workloads of data that is mostly static. As it acts as additional caching layer between the actual storage, and the in-memory ARC, it can also help if the ARC must be reduced due to memory constraints.

Create ZFS pool with a on-disk cache

```
# zpool create -f -o ashift=12 <pool> <device> cache <cache-device>
```

Here only a single `<device>` and a single `<cache-device>` was used, but it is possible to use more devices, like it's shown in Create a new pool with RAID.

Note that for cache devices no mirror or raid modi exist, they are all simply accumulated.

If any cache device produces errors on read, ZFS will transparently divert that request to the underlying storage layer.

Create a new pool with log (ZIL)

It is possible to use a dedicated drive, or partition, for the ZFS Intent Log (ZIL), it is mainly used to provide safe synchronous transactions, so often in performance critical paths like databases, or other programs that issue `fsync` operations more frequently.

The pool is used as default ZIL location, diverting the ZIL IO load to a separate device can, help to reduce transaction latencies while relieving the main pool at the same time, increasing overall performance.

For disks to be used as log devices, directly or through a partition, it's recommend to:

- use fast SSDs with power-loss protection, as those have much smaller commit latencies.
- Use at least a few GB for the partition (or whole device), but using more than half of your installed memory won't provide you with any real advantage.

Create ZFS pool with separate log device

```
# zpool create -f -o ashift=12 <pool> <device> log <log-device>
```

In the example above, a single `<device>` and a single `<log-device>` is used, but you can also combine this with other RAID variants, as described in the Create a new pool with RAID section.

You can also mirror the log device to multiple devices, this is mainly useful to ensure that performance doesn't immediately degrade if a single log device fails.

If all log devices fail the ZFS main pool itself will be used again, until the log device(s) get replaced.

Add cache and log to an existing pool

If you have a pool without cache and log you can still add both, or just one of them, at any time.

For example, let's assume you got a good enterprise SSD with power-loss protection that you want to use for improving the overall performance of your pool.

As the maximum size of a log device should be about half the size of the installed physical memory, it means that the ZIL will most likely only take up a relatively small part of the SSD, the remaining space can be used as cache.

First you have to create two GPT partitions on the SSD with `parted` or `gdisk`.

Then you're ready to add them to a pool:

Add both, a separate log device and a second-level cache, to an existing pool

```
# zpool add -f <pool> log <device-part1> cache <device-part2>
```

Just replace `<pool>`, `<device-part1>` and `<device-part2>` with the pool name and the two `/dev/disk/by-id/` paths to the partitions.

You can also add ZIL and cache separately.

Add a log device to an existing ZFS pool

```
# zpool add <pool> log <log-device>
```

Adding a hot spare drive to an existing pool

ZFS supports hot spare drives which allow the system to automatically replace a failed disk with the spare without manual intervention.

Add a hot spare to an existing pool

```
# zpool add <pool> spare <spare-device>
```

Changing a failed device

```
# zpool replace -f <pool> <old-device> <new-device>
```

Changing a failed bootable device

Depending on how Proxmox VE was installed it is either using `systemd-boot` or GRUB through `proxmox-boo` [3] or plain GRUB as bootloader (see Host Bootloader). You can check by running:

```
# proxmox-boot-tool status
```

The first steps of copying the partition table, reissuing GUIDs and replacing the ZFS partition are the same. To make the system bootable from the new disk, different steps are needed which depend on the bootloader in use.

```
# sgdisk <healthy bootable device> -R <new device>
# sgdisk -G <new device>
# zpool replace -f <pool> <old zfs partition> <new zfs partition>
```

Note
Use the `zpool status -v` command to monitor how far the resilvering process of the new disk has progressed.

With proxmox-boot-tool:

```
# proxmox-boot-tool format <new disk's ESP>
# proxmox-boot-tool init <new disk's ESP> [grub]
```

Note
`ESP` stands for EFI System Partition, which is set up as partition #2 on bootable disks when using the Proxmox VE installer since version 5.4. For details, see Setting up a new partition for use as synced ESP.

Note
Make sure to pass *grub* as mode to `proxmox-boot-tool init` if `proxmox-boot-tool status` indicates your current disks are using GRUB, especially if Secure Boot is enabled!

[3] Systems installed with Proxmox VE 6.4 or later, EFI systems installed with Proxmox VE 5.4 or later

With plain GRUB:

```
# grub-install <new disk>
```

Note
Plain GRUB is only used on systems installed with Proxmox VE 6.3 or earlier, which have not been manually migrated to use `proxmox-boot-tool` yet.

3.9.7 Configure E-Mail Notification

ZFS comes with an event daemon `ZED`, which monitors events generated by the ZFS kernel module. The daemon can also send emails on ZFS events like pool errors. Newer ZFS packages ship the daemon in a separate `zfs-zed` package, which should already be installed by default in Proxmox VE.

You can configure the daemon via the file `/etc/zfs/zed.d/zed.rc` with your favorite editor. The required setting for email notification is `ZED_EMAIL_ADDR`, which is set to `root` by default.

```
ZED_EMAIL_ADDR="root"
```

Please note Proxmox VE forwards mails to `root` to the email address configured for the root user.

3.9.8 Limit ZFS Memory Usage

ZFS uses *10 %* of the host memory, clamped to a maximum of `16 GiB`, for the **A**daptive **R**eplacement **C**ache (ARC) by default. This value is written to `/etc/modprobe.d/zfs.conf` during installation. See the manual `man 4 zfs` for more information about ZFS kernel module parameters.

Before Proxmox VE 8.1, the ARC usage limit was not set during installation and matched ZFS' default value which was either 62.5% starting on ZFS 2.3.0 or 50% for older versions. For existing installations that predate Proxmox VE 8.1, manual steps would have to be performed in order to lower the usage limit as described below.

Allocating enough memory for the ARC is crucial for IO performance, so reduce it with caution. As a general rule of thumb, allocate at least `2 GiB Base + 1 GiB/TiB-Storage`. For example, if you have a pool with `8 TiB` of available storage space then you should use `10 GiB` of memory for the ARC.

ZFS also enforces a minimum value of `64 MiB`.

You can change the ARC usage limit for the current boot (a reboot resets this change again) by writing to the `zfs_arc_max` module parameter directly:

```
 echo "$[10 * 1024*1024*1024]" >/sys/module/zfs/parameters/zfs_arc_max
```

To **permanently change** the ARC limits, add (or change if already present) the following line to `/etc/modprobe`

```
options zfs zfs_arc_max=8589934592
```

This example setting limits the usage to 8 GiB ($8 * 2^{30}$).



Important
In case your desired `zfs_arc_max` value is lower than or equal to `zfs_arc_min` (which defaults to 1/32 of the system memory), `zfs_arc_max` will be ignored unless you also set `zfs_arc_min` to at most `zfs_arc_max - 1`.

```
echo "$[8 * 1024*1024*1024 - 1]" >/sys/module/zfs/parameters/zfs_arc_min
echo "$[8 * 1024*1024*1024]" >/sys/module/zfs/parameters/zfs_arc_max
```

This example setting (temporarily) limits the usage to 8 GiB ($8 * 2^{30}$) on systems with more than 256 GiB of total memory, where simply setting `zfs_arc_max` alone would not work.



Important
If your root file system is ZFS, you must update your initramfs every time this value changes:

```
# update-initramfs -u -k all
```

You **must reboot** to activate these changes.

3.9.9 SWAP on ZFS

Swap-space created on a zvol may generate some troubles, like blocking the server or generating a high IO load, often seen when starting a Backup to an external Storage.

We strongly recommend to use enough memory, so that you normally do not run into low memory situations. Should you need or want to add swap, it is preferred to create a partition on a physical disk and use it as a swap device. You can leave some space free for this purpose in the advanced options of the installer. Additionally, you can lower the "swappiness" value. A good value for servers is 10:

```
# sysctl -w vm.swappiness=10
```

To make the swappiness persistent, create a new file `/etc/sysctl.d/99-swappiness.conf` with an editor of your choice and add the following line:

```
vm.swappiness = 10
```

Table 3.3: Linux kernel `swappiness` parameter values

Value	Strategy
`vm.swappiness = 0`	The kernel will swap only to avoid an *out of memory* condition
`vm.swappiness = 1`	Minimum amount of swapping without disabling it entirely.
`vm.swappiness = 10`	This value is sometimes recommended to improve performance when sufficient memory exists in a system.
`vm.swappiness = 60`	The default value.
`vm.swappiness = 100`	The kernel will swap aggressively.

3.9.10 Encrypted ZFS Datasets

Warning

Native ZFS encryption in Proxmox VE is experimental. Known limitations and issues include Replication with encrypted datasets [a], as well as checksum errors when using Snapshots or ZVOLs. [b]

[a] https://bugzilla.proxmox.com/show_bug.cgi?id=2350
[b] https://github.com/openzfs/zfs/issues/11688

ZFS on Linux version 0.8.0 introduced support for native encryption of datasets. After an upgrade from previous ZFS on Linux versions, the encryption feature can be enabled per pool:

```
# zpool get feature@encryption tank
NAME  PROPERTY            VALUE             SOURCE
tank  feature@encryption  disabled          local

# zpool set feature@encryption=enabled

# zpool get feature@encryption tank
NAME  PROPERTY            VALUE             SOURCE
tank  feature@encryption  enabled          local
```

Warning

There is currently no support for booting from pools with encrypted datasets using GRUB, and only limited support for automatically unlocking encrypted datasets on boot. Older versions of ZFS without encryption support will not be able to decrypt stored data.

Note

It is recommended to either unlock storage datasets manually after booting, or to write a custom unit to pass the key material needed for unlocking on boot to `zfs load-key`.

Warning

Establish and test a backup procedure before enabling encryption of production data. If the associated key material/passphrase/keyfile has been lost, accessing the encrypted data is no longer possible.

Encryption needs to be setup when creating datasets/zvols, and is inherited by default to child datasets. For example, to create an encrypted dataset `tank/encrypted_data` and configure it as storage in Proxmox VE, run the following commands:

```
# zfs create -o encryption=on -o keyformat=passphrase tank/encrypted_data
Enter passphrase:
Re-enter passphrase:

# pvesm add zfspool encrypted_zfs -pool tank/encrypted_data
```

All guest volumes/disks create on this storage will be encrypted with the shared key material of the parent dataset.

To actually use the storage, the associated key material needs to be loaded and the dataset needs to be mounted. This can be done in one step with:

```
# zfs mount -l tank/encrypted_data
Enter passphrase for 'tank/encrypted_data':
```

It is also possible to use a (random) keyfile instead of prompting for a passphrase by setting the `keylocation` and `keyformat` properties, either at creation time or with `zfs change-key` on existing datasets:

```
# dd if=/dev/urandom of=/path/to/keyfile bs=32 count=1

# zfs change-key -o keyformat=raw -o keylocation=file:///path/to/keyfile ↩
  tank/encrypted_data
```



Warning
When using a keyfile, special care needs to be taken to secure the keyfile against unauthorized access or accidental loss. Without the keyfile, it is not possible to access the plaintext data!

A guest volume created underneath an encrypted dataset will have its `encryptionroot` property set accordingly. The key material only needs to be loaded once per encryptionroot to be available to all encrypted datasets underneath it.

See the `encryptionroot`, `encryption`, `keylocation`, `keyformat` and `keystatus` properties, the `zfs load-key`, `zfs unload-key` and `zfs change-key` commands and the `Encryption` section from `man zfs` for more details and advanced usage.

3.9.11 Compression in ZFS

When compression is enabled on a dataset, ZFS tries to compress all **new** blocks before writing them and decompresses them on reading. Already existing data will not be compressed retroactively.

When creating a pool on Proxmox VE using the Web UI or the ISO installer, compression is enabled by default. To enable it manually or to change the compression algorithm, you can use the following:

```
# zfs set compression=<algorithm> <dataset>
```

We recommend using the `lz4` algorithm, because it adds very little CPU overhead. Other algorithms like `lzjb` and `gzip-N`, where `N` is an integer from `1` (fastest) to `9` (best compression ratio), are also available. Depending on the algorithm and how compressible the data is, having compression enabled can even increase I/O performance.

You can disable compression at any time with:

```
# zfs set compression=off <dataset>
```

Again, only new blocks will be affected by this change.

3.9.12 ZFS Special Device

Since version 0.8.0 ZFS supports `special` devices. A `special` device in a pool is used to store metadata, deduplication tables, and optionally small file blocks.

A `special` device can improve the speed of a pool consisting of slow spinning hard disks with a lot of metadata changes. For example workloads that involve creating, updating or deleting a large number of files will benefit from the presence of a `special` device. ZFS datasets can also be configured to store whole small files on the `special` device which can further improve the performance. Use fast SSDs for the `special` device.



Important
The redundancy of the `special` device should match the one of the pool, since the `special` device is a point of failure for the whole pool.



Warning
Adding a `special` device to a pool cannot be undone!

Create a pool with special device and RAID-1:

```
# zpool create -f -o ashift=12 <pool> mirror <device1> <device2> special  ↩
   mirror <device3> <device4>
```

Add a special device to an existing pool with RAID-1:

```
# zpool add <pool> special mirror <device1> <device2>
```

ZFS datasets expose the `special_small_blocks=<size>` property. `size` can be `0` to disable storing small file blocks on the `special` device or a power of two in the range between `512B` to `1M`. After setting the property new file blocks smaller than `size` will be allocated on the `special` device.



Important
If the value for `special_small_blocks` is greater than or equal to the `recordsize` (default `128K`) of the dataset, **all** data will be written to the `special` device, so be careful!

Setting the `special_small_blocks` property on a pool will change the default value of that property for all child ZFS datasets (for example all containers in the pool will opt in for small file blocks).

Opt in for all file smaller than 4K-blocks pool-wide:

```
# zfs set special_small_blocks=4K <pool>
```

Opt in for small file blocks for a single dataset:

```
# zfs set special_small_blocks=4K <pool>/<filesystem>
```

Opt out from small file blocks for a single dataset:

```
# zfs set special_small_blocks=0 <pool>/<filesystem>
```

3.9.13 ZFS Pool Features

Changes to the on-disk format in ZFS are only made between major version changes and are specified through **features**. All features, as well as the general mechanism are well documented in the `zpool-features(` manpage.

Since enabling new features can render a pool not importable by an older version of ZFS, this needs to be done actively by the administrator, by running `zpool upgrade` on the pool (see the `zpool-upgrade(8)` manpage).

Unless you need to use one of the new features, there is no upside to enabling them.

In fact, there are some downsides to enabling new features:

- A system with root on ZFS, that still boots using GRUB will become unbootable if a new feature is active on the rpool, due to the incompatible implementation of ZFS in GRUB.
- The system will not be able to import any upgraded pool when booted with an older kernel, which still ships with the old ZFS modules.
- Booting an older Proxmox VE ISO to repair a non-booting system will likewise not work.



Important
Do **not** upgrade your rpool if your system is still booted with GRUB, as this will render your system unbootable. This includes systems installed before Proxmox VE 5.4, and systems booting with legacy BIOS boot (see how to determine the bootloader).

Enable new features for a ZFS pool:

```
# zpool upgrade <pool>
```

3.10 BTRFS



Warning
BTRFS integration is currently a **technology preview** in Proxmox VE.

BTRFS is a modern copy on write file system natively supported by the Linux kernel, implementing features such as snapshots, built-in RAID and self healing via checksums for data and metadata. Starting with Proxmox VE 7.0, BTRFS is introduced as optional selection for the root file system.

GENERAL BTRFS ADVANTAGES

- Main system setup almost identical to the traditional ext4 based setup
- Snapshots
- Data compression on file system level
- Copy-on-write clone
- RAID0, RAID1 and RAID10
- Protection against data corruption
- Self healing
- Natively supported by the Linux kernel

CAVEATS

- RAID levels 5/6 are experimental and dangerous, see BTRFS Status

3.10.1 Installation as Root File System

When you install using the Proxmox VE installer, you can choose BTRFS for the root file system. You need to select the RAID type at installation time:

RAID0	Also called “striping”. The capacity of such volume is the sum of the capacities of all disks. But RAID0 does not add any redundancy, so the failure of a single drive makes the volume unusable.
RAID1	Also called “mirroring”. Data is written identically to all disks. This mode requires at least 2 disks with the same size. The resulting capacity is that of a single disk.
RAID10	A combination of RAID0 and RAID1. Requires at least 4 disks.

The installer automatically partitions the disks and creates an additional subvolume at `/var/lib/pve/local-`
In order to use that with the Proxmox VE tools, the installer creates the following configuration entry in `/etc/pve/storage.cfg`:

```
dir: local
        path /var/lib/vz
        content iso,vztmpl,backup
        disable

btrfs: local-btrfs
        path /var/lib/pve/local-btrfs
        content iso,vztmpl,backup,images,rootdir
```

This explicitly disables the default `local` storage in favor of a BTRFS specific storage entry on the additional subvolume.

The `btrfs` command is used to configure and manage the BTRFS file system, After the installation, the following command lists all additional subvolumes:

```
# btrfs subvolume list /
ID 256 gen 6 top level 5 path var/lib/pve/local-btrfs
```

3.10.2 BTRFS Administration

This section gives you some usage examples for common tasks.

Creating a BTRFS file system

To create BTRFS file systems, `mkfs.btrfs` is used. The `-d` and `-m` parameters are used to set the profile for metadata and data respectively. With the optional `-L` parameter, a label can be set.

Generally, the following modes are supported: `single`, `raid0`, `raid1`, `raid10`.

Create a BTRFS file system on a single disk `/dev/sdb` with the label `My-Storage`:

```
# mkfs.btrfs -m single -d single -L My-Storage /dev/sdb
```

Or create a RAID1 on the two partitions `/dev/sdb1` and `/dev/sdc1`:

```
# mkfs.btrfs -m raid1 -d raid1 -L My-Storage /dev/sdb1 /dev/sdc1
```

Mounting a BTRFS file system

The new file-system can then be mounted either manually, for example:

```
# mkdir /my-storage
# mount /dev/sdb /my-storage
```

A BTRFS can also be added to `/etc/fstab` like any other mount point, automatically mounting it on boot. It's recommended to avoid using block-device paths but use the `UUID` value the `mkfs.btrfs` command printed, especially there is more than one disk in a BTRFS setup.

For example:

File /etc/fstab

```
# ... other mount points left out for brevity

# using the UUID from the mkfs.btrfs output is highly recommended
UUID=e2c0c3ff-2114-4f54-b767-3a203e49f6f3 /my-storage btrfs defaults 0 0
```

Tip
If you do not have the UUID available anymore you can use the `blkid` tool to list all properties of block-devices.

Afterwards you can trigger the first mount by executing:

```
mount /my-storage
```

After the next reboot this will be automatically done by the system at boot.

Adding a BTRFS file system to Proxmox VE

You can add an existing BTRFS file system to Proxmox VE via the web interface, or using the CLI, for example:

```
pvesm add btrfs my-storage --path /my-storage
```

Creating a subvolume

Creating a subvolume links it to a path in the BTRFS file system, where it will appear as a regular directory.

```
# btrfs subvolume create /some/path
```

Afterwards `/some/path` will act like a regular directory.

Deleting a subvolume

Contrary to directories removed via `rmdir`, subvolumes do not need to be empty in order to be deleted via the `btrfs` command.

```
# btrfs subvolume delete /some/path
```

Creating a snapshot of a subvolume

BTRFS does not actually distinguish between snapshots and normal subvolumes, so taking a snapshot can also be seen as creating an arbitrary copy of a subvolume. By convention, Proxmox VE will use the read-only flag when creating snapshots of guest disks or subvolumes, but this flag can also be changed later on.

```
# btrfs subvolume snapshot -r /some/path /a/new/path
```

This will create a read-only "clone" of the subvolume on `/some/path` at `/a/new/path`. Any future modifications to `/some/path` cause the modified data to be copied before modification.

If the read-only (`-r`) option is left out, both subvolumes will be writable.

Enabling compression

By default, BTRFS does not compress data. To enable compression, the `compress` mount option can be added. Note that data already written will not be compressed after the fact.

By default, the rootfs will be listed in `/etc/fstab` as follows:

```
UUID=<uuid of your root file system> / btrfs defaults 0 1
```

You can simply append `compress=zstd`, `compress=lzo`, or `compress=zlib` to the `defaults` above like so:

```
UUID=<uuid of your root file system> / btrfs defaults,compress=zstd 0 1
```

This change will take effect after rebooting.

Checking Space Usage

The classic `df` tool may output confusing values for some BTRFS setups. For a better estimate use the `btrfs filesystem usage /PATH` command, for example:

```
# btrfs fi usage /my-storage
```

3.11 Proxmox Node Management

The Proxmox VE node management tool (`pvenode`) allows you to control node specific settings and resources.

Currently `pvenode` allows you to set a node's description, run various bulk operations on the node's guests, view the node's task history, and manage the node's SSL certificates, which are used for the API and the web GUI through `pveproxy`.

3.11.1 Wake-on-LAN

Wake-on-LAN (WoL) allows you to switch on a sleeping computer in the network, by sending a magic packet. At least one NIC must support this feature, and the respective option needs to be enabled in the computer's firmware (BIOS/UEFI) configuration. The option name can vary from *Enable Wake-on-Lan* to *Power On By PCIE Device*; check your motherboard's vendor manual, if you're unsure. `ethtool` can be used to check the WoL configuration of `<interface>` by running:

```
ethtool <interface> | grep Wake-on
```

`pvenode` allows you to wake sleeping members of a cluster via WoL, using the command:

```
pvenode wakeonlan <node>
```

This broadcasts the WoL magic packet on UDP port 9, containing the MAC address of `<node>` obtained from the `wakeonlan` property. The node-specific `wakeonlan` property can be set using the following command:

```
pvenode config set -wakeonlan XX:XX:XX:XX:XX:XX
```

The interface via which to send the WoL packet is determined from the default route. It can be overwritten by setting the `bind-interface` via the following command:

```
pvenode config set -wakeonlan XX:XX:XX:XX:XX:XX,bind-interface=<iface-name>
```

The broadcast address (default `255.255.255.255`) used when sending the WoL packet can further be changed by setting the `broadcast-address` explicitly using the following command:

```
pvenode config set -wakeonlan XX:XX:XX:XX:XX:XX,broadcast-address=< ↩
   broadcast-address>
```

3.11.2 Task History

When troubleshooting server issues, for example, failed backup jobs, it can often be helpful to have a log of the previously run tasks. With Proxmox VE, you can access the nodes's task history through the `pvenode task` command.

You can get a filtered list of a node's finished tasks with the `list` subcommand. For example, to get a list of tasks related to VM *100* that ended with an error, the command would be:

```
pvenode task list --errors --vmid 100
```

The log of a task can then be printed using its UPID:

```
pvenode task log UPID:pve1:00010D94:001CA6EA:6124E1B9:vzdump:100:root@pam:
```

3.11.3 Bulk Guest Power Management

In case you have many VMs/containers, starting and stopping guests can be carried out in bulk operations with the `startall` and `stopall` subcommands of `pvenode`. By default, `pvenode startall` will only start VMs/containers which have been set to automatically start on boot (see Automatic Start and Shutdown of Virtual Machines), however, you can override this behavior with the `--force` flag. Both commands also have a `--vms` option, which limits the stopped/started guests to the specified VMIDs.

For example, to start VMs *100*, *101*, and *102*, regardless of whether they have `onboot` set, you can use:

```
pvenode startall --vms 100,101,102 --force
```

To stop these guests (and any other guests that may be running), use the command:

```
pvenode stopall
```

Note
The stopall command first attempts to perform a clean shutdown and then waits until either all guests have successfully shut down or an overridable timeout (3 minutes by default) has expired. Once that happens and the force-stop parameter is not explicitly set to 0 (false), all virtual guests that are still running are hard stopped.

3.11.4 First Guest Boot Delay

In case your VMs/containers rely on slow-to-start external resources, for example an NFS server, you can also set a per-node delay between the time Proxmox VE boots and the time the first VM/container that is configured to autostart boots (see Automatic Start and Shutdown of Virtual Machines).

You can achieve this by setting the following (where `10` represents the delay in seconds):

```
pvenode config set --startall-onboot-delay 10
```

3.11.5 Bulk Guest Migration

In case an upgrade situation requires you to migrate all of your guests from one node to another, `pvenode` also offers the `migrateall` subcommand for bulk migration. By default, this command will migrate every guest on the system to the target node. It can however be set to only migrate a set of guests.

For example, to migrate VMs *100*, *101*, and *102*, to the node *pve2*, with live-migration for local disks enabled, you can run:

```
pvenode migrateall pve2 --vms 100,101,102 --with-local-disks
```

3.11.6 RAM Usage Target for Ballooning

The target percentage for automatic memory allocation defaults to 80%. You can customize this target per node by setting the `ballooning-target` property. For example, to target 90% host memory usage instead:

```
pvenode config set --ballooning-target 90
```

3.12 Certificate Management

3.12.1 Certificates for Intra-Cluster Communication

Each Proxmox VE cluster creates by default its own (self-signed) Certificate Authority (CA) and generates a certificate for each node which gets signed by the aforementioned CA. These certificates are used for encrypted communication with the cluster's `pveproxy` service and the Shell/Console feature if SPICE is used.

The CA certificate and key are stored in the Proxmox Cluster File System (pmxcfs).

To distribute the cluster CA to administrator workstations and avoid browser warnings, copy `/etc/pve/pve-roo` from any cluster node out of band (for example via `scp` or by reading it through an existing SSH session) and import it into the operating system or browser trust store. There is no API or web interface endpoint for downloading the file.

3.12.2 Certificates for API and Web GUI

The REST API and web GUI are provided by the `pveproxy` service, which runs on each node.

You have the following options for the certificate used by `pveproxy`:

1. By default the node-specific certificate in `/etc/pve/nodes/NODENAME/pve-ssl.pem` is used. This certificate is signed by the cluster CA and therefore not automatically trusted by browsers and operating systems.
2. use an externally provided certificate (e.g. signed by a commercial CA).
3. use ACME (Let's Encrypt) to get a trusted certificate with automatic renewal, this is also integrated in the Proxmox VE API and web interface.

For options 2 and 3 the file `/etc/pve/local/pveproxy-ssl.pem` (and `/etc/pve/local/pveproxy` which needs to be without password) is used.

Note
Keep in mind that `/etc/pve/local` is a node specific symlink to `/etc/pve/nodes/NODENAME`.

Certificates are managed with the Proxmox VE Node management command (see the `pvenode(1)` man-page).

Warning
Do not replace or manually modify the automatically generated node certificate files in `/etc/pve/local/pve-ssl.pem` and `/etc/pve/local/pve-ssl.key` or the cluster CA files in `/etc/pve/pve-root-ca.pem` and `/etc/pve/priv/pve-root-ca.key`.

3.12.3 Upload Custom Certificate

If you already have a certificate which you want to use for a Proxmox VE node you can upload that certificate simply over the web interface.



Note that the certificates key file, if provided, mustn't be password protected.

3.12.4 Trusted certificates via Let's Encrypt (ACME)

Proxmox VE includes an implementation of the **A**utomatic **C**ertificate **M**anagement **E**nvironment **ACME** protocol, allowing Proxmox VE admins to use an ACME provider like Let's Encrypt for easy setup of TLS certificates which are accepted and trusted on modern operating systems and web browsers out of the box.

Currently, the two ACME endpoints implemented are the Let's Encrypt (LE) production and its staging environment. Our ACME client supports validation of `http-01` challenges using a built-in web server and validation of `dns-01` challenges using a DNS plugin supporting all the DNS API endpoints acme.sh does.

ACME Account



You need to register an ACME account per cluster with the endpoint you want to use. The email address used for that account will serve as contact point for renewal-due or similar notifications from the ACME endpoint.

You can register and deactivate ACME accounts over the web interface `Datacenter -> ACME` or using the `pvenode` command-line tool.

```
pvenode acme account register account-name mail@example.com
```

Tip
Because of rate-limits you should use LE `staging` for experiments or if you use ACME for the first time.

ACME Plugins

The ACME plugins task is to provide automatic verification that you, and thus the Proxmox VE cluster under your operation, are the real owner of a domain. This is the basis building block for automatic certificate management.

The ACME protocol specifies different types of challenges, for example the `http-01` where a web server provides a file with a certain content to prove that it controls a domain. Sometimes this isn't possible, either because of technical limitations or if the address of a record to is not reachable from the public internet. The `dns-01` challenge can be used in these cases. This challenge is fulfilled by creating a certain DNS record in the domain's zone.



Proxmox VE supports both of those challenge types out of the box, you can configure plugins either over the web interface under `Datacenter -> ACME`, or using the `pvenode acme plugin add` command.

ACME Plugin configurations are stored in `/etc/pve/priv/acme/plugins.cfg`. A plugin is available for all nodes in the cluster.

Node Domains

Each domain is node specific. You can add new or manage existing domain entries under `Node -> Certificates`, or using the `pvenode config` command.



After configuring the desired domain(s) for a node and ensuring that the desired ACME account is selected, you can order your new certificate over the web interface. On success the interface will reload after 10 seconds.

Renewal will happen automatically.

3.12.5 ACME HTTP Challenge Plugin

There is always an implicitly configured `standalone` plugin for validating `http-01` challenges via the built-in webserver spawned on port 80.

Note
The name `standalone` means that it can provide the validation on it's own, without any third party service. So, this plugin works also for cluster nodes.

There are a few prerequisites to use it for certificate management with Let's Encrypts ACME.

- You have to accept the ToS of Let's Encrypt to register an account.
- **Port 80** of the node needs to be reachable from the internet.
- There **must** be no other listener on port 80.
- The requested (sub)domain needs to resolve to a public IP of the Node.

3.12.6 ACME DNS API Challenge Plugin

On systems where external access for validation via the `http-01` method is not possible or desired, it is possible to use the `dns-01` validation method. This validation method requires a DNS server that allows provisioning of `TXT` records via an API.

Configuring ACME DNS APIs for validation

Proxmox VE re-uses the DNS plugins developed for the `acme.sh` [4] project, please refer to its documentation for details on configuration of specific APIs.

The easiest way to configure a new plugin with the DNS API is using the web interface (`Datacenter -> ACME`).



Choose `DNS` as challenge type. Then you can select your API provider, enter the credential data to access your account over their API. The validation delay determines the time in seconds between setting the DNS record and prompting the ACME provider to validate it, as providers often need some time to propagate the record in their infrastructure.

Tip
See the acme.sh How to use DNS API wiki for more detailed information about getting API credentials for your provider.

[4] acme.sh https://github.com/acmesh-official/acme.sh

As there are many DNS providers and API endpoints Proxmox VE automatically generates the form for the credentials for some providers. For the others you will see a bigger text area, simply copy all the credentials KEY=VALUE pairs in there.

DNS Validation through CNAME Alias

A special alias mode can be used to handle the validation on a different domain/DNS server, in case your primary/real DNS does not support provisioning via an API. Manually set up a permanent CNAME record for _acme-challenge.domain1.example pointing to _acme-challenge.domain2.example and set the alias property on the corresponding acmedomainX key in the Proxmox VE node configuration file to domain2.example to allow the DNS server of domain2.example to validate all challenges for domain1.example.

Combination of Plugins

Combining http-01 and dns-01 validation is possible in case your node is reachable via multiple domains with different requirements / DNS provisioning capabilities. Mixing DNS APIs from multiple providers or instances is also possible by specifying different plugin instances per domain.

Tip
Accessing the same service over multiple domains increases complexity and should be avoided if possible.

3.12.7 Automatic renewal of ACME certificates

If a node has been successfully configured with an ACME-provided certificate (either via pvenode or via the GUI), the certificate will be automatically renewed by the pve-daily-update.service. Currently, renewal will be attempted if the certificate has expired already, or will expire in the next 30 days.

Note
If you are using a custom directory that issues short-lived certificates, disabling the random delay for the pve-daily-update.timer unit might be advisable to avoid missing a certificate renewal after a reboot.

3.12.8 ACME Examples with pvenode

Example: Sample pvenode invocation for using Let's Encrypt certificates

```
root@proxmox:~# pvenode acme account register default mail@example.invalid
Directory endpoints:
0) Let's Encrypt V2 (https://acme-v02.api.letsencrypt.org/directory)
1) Let's Encrypt V2 Staging (https://acme-staging-v02.api.letsencrypt.org/ ↩
   directory)
2) Custom
Enter selection: 1
```

```
Terms of Service: https://letsencrypt.org/documents/LE-SA-v1.2-November ↩
   -15-2017.pdf
Do you agree to the above terms? [y|N]y
...
Task OK
root@proxmox:~# pvenode config set --acme domains=example.invalid
root@proxmox:~# pvenode acme cert order
Loading ACME account details
Placing ACME order
...
Status is 'valid'!

All domains validated!
...
Downloading certificate
Setting pveproxy certificate and key
Restarting pveproxy
Task OK
```

Example: Setting up the OVH API for validating a domain

Note
the account registration steps are the same no matter which plugins are used, and are not repeated here.

Note
`OVH_AK` and `OVH_AS` need to be obtained from OVH according to the OVH API documentation

First you need to get all information so you and Proxmox VE can access the API.

```
root@proxmox:~# cat /path/to/api-token
OVH_AK=XXXXXXXXXXXXXXXX
OVH_AS=YYYYYYYYYYYYYYYYYYYYYYYYYYYYYYYY
root@proxmox:~# source /path/to/api-token
root@proxmox:~# curl -XPOST -H"X-Ovh-Application: $OVH_AK" -H "Content-type ↩
   : application/json" \
https://eu.api.ovh.com/1.0/auth/credential  -d '{
  "accessRules": [
    {"method": "GET","path": "/auth/time"},
    {"method": "GET","path": "/domain"},
    {"method": "GET","path": "/domain/zone/*"},
    {"method": "GET","path": "/domain/zone/*/record"},
    {"method": "POST","path": "/domain/zone/*/record"},
    {"method": "POST","path": "/domain/zone/*/refresh"},
    {"method": "PUT","path": "/domain/zone/*/record/"},
    {"method": "DELETE","path": "/domain/zone/*/record/*"}
]
}'
```

```
{"consumerKey":"ZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZ","state":" ↩
   pendingValidation","validationUrl":"https://eu.api.ovh.com/auth/? ↩
   credentialToken= ↩
   AAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAA"}

(open validation URL and follow instructions to link Application Key with  ↩
   account/Consumer Key)

root@proxmox:~# echo "OVH_CK=ZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZ" >> /path/to/ ↩
   api-token
```

Now you can setup the the ACME plugin:

```
root@proxmox:~# pvenode acme plugin add dns example_plugin --api ovh --data ↩
    /path/to/api_token
root@proxmox:~# pvenode acme plugin config example_plugin
&#x250c;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x252c;&#x
&#x2502; key    &#x2502; value                                    &#x2502;
&#x255e;&#x2550;&#x2550;&#x2550;&#x2550;&#x2550;&#x2550;&#x2550;&#x2550;&#x256a;&#x
&#x2502; api    &#x2502; ovh                                      &#x2502;
&#x251c;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x253c;&#x
&#x2502; data   &#x2502; OVH_AK=XXXXXXXXXXXXXXX                   &#x2502;
&#x2502;        &#x2502; OVH_AS=YYYYYYYYYYYYYYYYYYYYYYYYYYYYYYYY  &#x2502;
&#x2502;        &#x2502; OVH_CK=ZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZ  &#x2502;
&#x251c;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x253c;&#x
&#x2502; digest &#x2502; 867fcf556363ca1bea866863093fcab83edf47a1 &#x2502;
&#x251c;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x253c;&#x
&#x2502; plugin &#x2502; example_plugin                           &#x2502;
&#x251c;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x253c;&#x
&#x2502; type   &#x2502; dns                                      &#x2502;
&#x2514;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2500;&#x2534;&#x
```

At last you can configure the domain you want to get certificates for and place the certificate order for it:

```
root@proxmox:~# pvenode config set -acmedomain0 example.proxmox.com,plugin= ↩
   example_plugin
root@proxmox:~# pvenode acme cert order
Loading ACME account details
Placing ACME order
Order URL: https://acme-staging-v02.api.letsencrypt.org/acme/order ↩
   /11111111/22222222

Getting authorization details from 'https://acme-staging-v02.api. ↩
   letsencrypt.org/acme/authz-v3/33333333'
The validation for example.proxmox.com is pending!
[Wed Apr 22 09:25:30 CEST 2020] Using OVH endpoint: ovh-eu
[Wed Apr 22 09:25:30 CEST 2020] Checking authentication
[Wed Apr 22 09:25:30 CEST 2020] Consumer key is ok.
[Wed Apr 22 09:25:31 CEST 2020] Adding record
[Wed Apr 22 09:25:32 CEST 2020] Added, sleep 10 seconds.
Add TXT record: _acme-challenge.example.proxmox.com
Triggering validation
Sleeping for 5 seconds
```

```
Status is 'valid'!
[Wed Apr 22 09:25:48 CEST 2020] Using OVH endpoint: ovh-eu
[Wed Apr 22 09:25:48 CEST 2020] Checking authentication
[Wed Apr 22 09:25:48 CEST 2020] Consumer key is ok.
Remove TXT record: _acme-challenge.example.proxmox.com

All domains validated!

Creating CSR
Checking order status
Order is ready, finalizing order
valid!

Downloading certificate
Setting pveproxy certificate and key
Restarting pveproxy
Task OK
```

Example: Switching from the `staging` to the regular ACME directory

Changing the ACME directory for an account is unsupported, but as Proxmox VE supports more than one account you can just create a new one with the production (trusted) ACME directory as endpoint. You can also deactivate the staging account and recreate it.

Example: Changing the default ACME account from staging to directory using pvenode

```
root@proxmox:~# pvenode acme account deactivate default
Renaming account file from '/etc/pve/priv/acme/default' to '/etc/pve/priv/ ↩
   acme/_deactivated_default_4'
Task OK

root@proxmox:~# pvenode acme account register default example@proxmox.com
Directory endpoints:
0) Let's Encrypt V2 (https://acme-v02.api.letsencrypt.org/directory)
1) Let's Encrypt V2 Staging (https://acme-staging-v02.api.letsencrypt.org/ ↩
   directory)
2) Custom
Enter selection: 0

Terms of Service: https://letsencrypt.org/documents/LE-SA-v1.2-November ↩
   -15-2017.pdf
Do you agree to the above terms? [y|N]y
...
Task OK
```

3.13 Host Bootloader

Proxmox VE currently uses one of two bootloaders depending on the disk setup selected in the installer.

For EFI Systems installed with ZFS as the root filesystem `systemd-boot` is used, unless Secure Boot is enabled. All other deployments use the standard GRUB bootloader (this usually also applies to systems which are installed on top of Debian).

3.13.1 Partitioning Scheme Used by the Installer

The Proxmox VE installer creates 3 partitions on all disks selected for installation.

The created partitions are:

- a 1 MB BIOS Boot Partition (gdisk type EF02)
- a 512 MB EFI System Partition (ESP, gdisk type EF00)
- a third partition spanning the set `hdsize` parameter or the remaining space used for the chosen storage type

Systems using ZFS as root filesystem are booted with a kernel and initrd image stored on the 512 MB EFI System Partition. For legacy BIOS systems, and EFI systems with Secure Boot enabled, GRUB is used, for EFI systems without Secure Boot, `systemd-boot` is used. Both are installed and configured to point to the ESPs.

GRUB in BIOS mode (`--target i386-pc`) is installed onto the BIOS Boot Partition of all selected disks on all systems booted with GRUB [5].

Note
This applies to x86 hosts. On arm64, Proxmox VE boots through UEFI only, so there is no BIOS Boot Partition and no `i386-pc` GRUB target; GRUB is installed in EFI mode using the `arm64-efi` target instead.

3.13.2 Synchronizing the content of the ESP with `proxmox-boot-tool`

`proxmox-boot-tool` is a utility used to keep the contents of the EFI System Partitions properly configured and synchronized. It copies certain kernel versions to all ESPs and configures the respective bootloader to boot from the `vfat` formatted ESPs. In the context of ZFS as root filesystem this means that you can use all optional features on your root pool instead of the subset which is also present in the ZFS implementation in GRUB or having to create a separate small boot-pool [6].

In setups with redundancy all disks are partitioned with an ESP, by the installer. This ensures the system boots even if the first boot device fails or if the BIOS can only boot from a particular disk.

The ESPs are not kept mounted during regular operation. This helps to prevent filesystem corruption to the `vfat` formatted ESPs in case of a system crash, and removes the need to manually adapt `/etc/fstab` in case the primary boot device fails.

`proxmox-boot-tool` handles the following tasks:

- formatting and setting up a new partition

[5] These are all installs with root on `ext4` or `xfs` and installs with root on ZFS on non-EFI systems

[6] Booting ZFS on root with GRUB https://openzfs.github.io/openzfs-docs/Getting%20Started/Debian/-Debian%20Bookworm%20Root%20on%20ZFS.html

- copying and configuring new kernel images and initrd images to all listed ESPs
- synchronizing the configuration on kernel upgrades and other maintenance tasks
- managing the list of kernel versions which are synchronized
- configuring the boot-loader to boot a particular kernel version (pinning)

You can view the currently configured ESPs and their state by running:

```
# proxmox-boot-tool status
```

Setting up a new partition for use as synced ESP

To format and initialize a partition as synced ESP, e.g., after replacing a failed vdev in an rpool, or when converting an existing system that pre-dates the sync mechanism, `proxmox-boot-tool` from `proxmox-kernel` can be used.



Warning
the `format` command will format the `<partition>`, make sure to pass in the right device/partition!

For example, to format an empty partition `/dev/sda2` as ESP, run the following:

```
# proxmox-boot-tool format /dev/sda2
```

To setup an existing, unmounted ESP located on `/dev/sda2` for inclusion in Proxmox VE's kernel update synchronization mechanism, use the following:

```
# proxmox-boot-tool init /dev/sda2
```

or

```
# proxmox-boot-tool init /dev/sda2 grub
```

to force initialization with GRUB instead of `systemd-boot`, for example for Secure Boot support.

Afterwards `/etc/kernel/proxmox-boot-uuids` should contain a new line with the UUID of the newly added partition. The `init` command will also automatically trigger a refresh of all configured ESPs.

Updating the configuration on all ESPs

To copy and configure all bootable kernels and keep all ESPs listed in `/etc/kernel/proxmox-boot-uuids` in sync you just need to run:

```
# proxmox-boot-tool refresh
```

(The equivalent to running `update-grub` systems with `ext4` or `xfs` on root).

This is necessary should you make changes to the kernel commandline, or want to sync all kernels and initrds.

Note
Both `update-initramfs` and `apt` (when necessary) will automatically trigger a refresh.

Kernel Versions considered by proxmox-boot-tool

The following kernel versions are configured by default:

- the currently running kernel
- the version being newly installed on package updates
- the two latest already installed kernels
- the latest version of the second-to-last kernel series (e.g. 5.0, 5.3), if applicable
- any manually selected kernels

Manually keeping a kernel bootable

Should you wish to add a certain kernel and initrd image to the list of bootable kernels use `proxmox-boot-tool kernel add`.

For example run the following to add the kernel with ABI version `5.0.15-1-pve` to the list of kernels to keep installed and synced to all ESPs:

```
# proxmox-boot-tool kernel add 5.0.15-1-pve
```

`proxmox-boot-tool kernel list` will list all kernel versions currently selected for booting:

```
# proxmox-boot-tool kernel list
Manually selected kernels:
5.0.15-1-pve

Automatically selected kernels:
5.0.12-1-pve
4.15.18-18-pve
```

Run `proxmox-boot-tool kernel remove` to remove a kernel from the list of manually selected kernels, for example:

```
# proxmox-boot-tool kernel remove 5.0.15-1-pve
```

Note
It's required to run `proxmox-boot-tool refresh` to update all EFI System Partitions (ESPs) after a manual kernel addition or removal from above.

3.13.3 Determine which Bootloader is Used



The simplest and most reliable way to determine which bootloader is used, is to watch the boot process of the Proxmox VE node.

You will either see the blue box of GRUB or the simple black on white `systemd-boot`.



Determining the bootloader from a running system might not be 100% accurate. The safest way is to run the following command:

```
# efibootmgr -v
```

If it returns a message that EFI variables are not supported, GRUB is used in BIOS/Legacy mode.

If the output contains a line that looks similar to the following, GRUB is used in UEFI mode.

```
Boot0005* proxmox       [...] File(\EFI\proxmox\grubx64.efi)
```

If the active boot entry points to `\EFI\proxmox\shimx64.efi` like in the following example, GRUB is used in UEFI mode with Secure Boot enabled.

```
Boot0005* proxmox       [...] File(\EFI\proxmox\shimx64.efi)
```

If the output contains a line similar to the following, `systemd-boot` is used.

```
Boot0006* Linux Boot Manager    [...] File(\EFI\systemd\systemd-bootx64.efi ↩
   )
```

Note
The file names above are for x86 hosts. On arm64, the equivalent binaries are named `grubaa64.efi`, `shimaa64.efi`, and `systemd-bootaa64.efi`.

By running:

```
# proxmox-boot-tool status
```

you can find out if `proxmox-boot-tool` is configured, which is a good indication of how the system is booted.

3.13.4 GRUB

GRUB has been the de-facto standard for booting Linux systems for many years and is quite well documented [7].

Configuration

Changes to the GRUB configuration are done via the defaults file `/etc/default/grub` or config snippets in `/etc/default/grub.d`. To regenerate the configuration file after a change to the configuration run: [8]

```
# update-grub
```

3.13.5 Systemd-boot

`systemd-boot` is a lightweight EFI bootloader. It reads the kernel and initrd images directly from the EFI Service Partition (ESP) where it is installed. The main advantage of directly loading the kernel from the ESP is that it does not need to reimplement the drivers for accessing the storage. In Proxmox VE proxmox-boot-tool is used to keep the configuration on the ESPs synchronized.

[7] GRUB Manual https://www.gnu.org/software/grub/manual/grub/grub.html

[8] Systems using `proxmox-boot-tool` will call `proxmox-boot-tool refresh` upon `update-grub`.

Configuration

`systemd-boot` is configured via the file `loader/loader.conf` in the root directory of an EFI System Partition (ESP). See the `loader.conf(5)` manpage for details.

Each bootloader entry is placed in a file of its own in the directory `loader/entries/`

An example entry.conf looks like this (`/` refers to the root of the ESP):

```
title    Proxmox
version  5.0.15-1-pve
options   root=ZFS=rpool/ROOT/pve-1 boot=zfs
linux    /EFI/proxmox/5.0.15-1-pve/vmlinuz-5.0.15-1-pve
initrd   /EFI/proxmox/5.0.15-1-pve/initrd.img-5.0.15-1-pve
```

3.13.6 Editing the Kernel Commandline

You can modify the kernel commandline in the following places, depending on the bootloader used:

GRUB

The kernel commandline needs to be placed in the variable `GRUB_CMDLINE_LINUX_DEFAULT` in the file `/etc/default/grub`. Running `update-grub` appends its content to all `linux` entries in `/boot/grub/g`

Systemd-boot

The kernel commandline needs to be placed as one line in `/etc/kernel/cmdline`. To apply your changes, run `proxmox-boot-tool refresh`, which sets it as the `option` line for all config files in `loader/entries/proxmox-*.conf`.

A complete list of kernel parameters can be found at *https://www.kernel.org/doc/html/v<YOUR-KERNEL-VERSION>/admin-guide/kernel-parameters.html*. replace <YOUR-KERNEL-VERSION> with the major.minor version, for example, for kernels based on version 6.5 the URL would be: https://www.kernel.org/doc/html/-v6.5/admin-guide/kernel-parameters.html

You can find your kernel version by checking the web interface (*Node* → *Summary*), or by running

```
# uname -r
```

Use the first two numbers at the front of the output.

3.13.7 Override the Kernel-Version for next Boot

To select a kernel that is not currently the default kernel, you can either:

- use the boot loader menu that is displayed at the beginning of the boot process
- use the `proxmox-boot-tool` to `pin` the system to a kernel version either once or permanently (until pin is reset).

This should help you work around incompatibilities between a newer kernel version and the hardware.

Note
Such a pin should be removed as soon as possible so that all current security patches of the latest kernel are also applied to the system.

For example: To permanently select the version `5.15.30-1-pve` for booting you would run:

```
# proxmox-boot-tool kernel pin 5.15.30-1-pve
```

Tip
The pinning functionality works for all Proxmox VE systems, not only those using `proxmox-boot-tool` to synchronize the contents of the ESPs, if your system does not use `proxmox-boot-tool` for synchronizing you can also skip the `proxmox-boot-tool refresh` call in the end.

You can also set a kernel version to be booted on the next system boot only. This is for example useful to test if an updated kernel has resolved an issue, which caused you to `pin` a version in the first place:

```
# proxmox-boot-tool kernel pin 5.15.30-1-pve --next-boot
```

To remove any pinned version configuration use the `unpin` subcommand:

```
# proxmox-boot-tool kernel unpin
```

While `unpin` has a `--next-boot` option as well, it is used to clear a pinned version set with `--next-boot`. As that happens already automatically on boot, invoking it manually is of little use.

After setting, or clearing pinned versions you also need to synchronize the content and configuration on the ESPs by running the `refresh` subcommand.

Tip
You will be prompted to automatically do for `proxmox-boot-tool` managed systems if you call the tool interactively.

```
# proxmox-boot-tool refresh
```

3.13.8 Secure Boot

Since Proxmox VE 8.1, Secure Boot is supported out of the box via signed packages and integration in `proxmox-boot-tool`.

The following packages are required for secure boot to work. You can install them all at once by using the 'proxmox-secure-boot-support' meta-package.

- `shim-signed` (shim bootloader signed by Microsoft)
- `shim-helpers-amd64-signed` (fallback bootloader and MOKManager, signed by Proxmox)
- `grub-efi-amd64-signed` (GRUB EFI bootloader, signed by Proxmox)

- `proxmox-kernel-6.X.Y-Z-pve-signed` (Kernel image, signed by Proxmox)

Note
The `shim-helpers-amd64-signed` and `grub-efi-amd64-signed` package names are for x86 hosts. On arm64, the corresponding packages are `shim-helpers-arm64-signed` and `grub-efi-arm64-signed`.

Only GRUB is supported as bootloader out of the box, since other bootloader are currently not eligible for secure boot code-signing.

Any new installation of Proxmox VE will automatically have all of the above packages included.

More details about how Secure Boot works, and how to customize the setup, are available in our wiki.

Switching an Existing Installation to Secure Boot



Warning
This can lead to an unbootable installation in some cases if not done correctly. Reinstalling the host will setup Secure Boot automatically if available, without any extra interactions. **Make sure you have a working and well-tested backup of your Proxmox VE host!**

An existing UEFI installation can be switched over to Secure Boot if desired, without having to reinstall Proxmox VE from scratch.

First, ensure all your system is up-to-date. Next, install `proxmox-secure-boot-support`. GRUB automatically creates the needed EFI boot entry for booting via the default shim.

systemd-boot

If `systemd-boot` is used as a bootloader (see Determine which Bootloader is used), some additional setup is needed. This is only the case if Proxmox VE was installed with ZFS-on-root.

To check the latter, run:

```
# findmnt /
```

If the host is indeed using ZFS as root filesystem, the `FSTYPE` column should contain `zfs`:

```
TARGET SOURCE           FSTYPE OPTIONS
/      rpool/ROOT/pve-1 zfs    rw,relatime,xattr,noacl,casesensitive
```

Next, a suitable potential ESP (EFI system partition) must be found. This can be done using the `lsblk` command as following:

```
# lsblk -o +FSTYPE
```

The output should look something like this:

```
NAME   MAJ:MIN RM  SIZE RO TYPE MOUNTPOINTS FSTYPE
sda      8:0    0   32G  0 disk
&#x251c;&#x2500;sda1   8:1    0 1007K  0 part
&#x251c;&#x2500;sda2   8:2    0  512M  0 part             vfat
&#x2514;&#x2500;sda3   8:3    0 31.5G  0 part             zfs_member
sdb      8:16   0   32G  0 disk
&#x251c;&#x2500;sdb1   8:17   0 1007K  0 part
&#x251c;&#x2500;sdb2   8:18   0  512M  0 part             vfat
&#x2514;&#x2500;sdb3   8:19   0 31.5G  0 part             zfs_member
```

In this case, the partitions `sda2` and `sdb2` are the targets. They can be identified by the their size of 512M and their `FSTYPE` being `vfat`, in this case on a ZFS RAID-1 installation.

These partitions must be properly set up for booting through GRUB using `proxmox-boot-tool`. This command (using `sda2` as an example) must be run separately for each individual ESP:

```
# proxmox-boot-tool init /dev/sda2 grub
```

Afterwards, you can sanity-check the setup by running the following command:

```
# efibootmgr -v
```

This list should contain an entry looking similar to this:

```
[..]
Boot0009* proxmox       HD(2,GPT,..,0x800,0x100000)/File(\EFI\proxmox\ ↩
   shimx64.efi)
[..]
```

Note
The old `systemd-boot` bootloader will be kept, but GRUB will be preferred. This way, if booting using GRUB in Secure Boot mode does not work for any reason, the system can still be booted using `systemd-boot` with Secure Boot turned off.

Now the host can be rebooted and Secure Boot enabled in the UEFI firmware setup utility.

On reboot, a new entry named `proxmox` should be selectable in the UEFI firmware boot menu, which boots using the pre-signed EFI shim.

If, for any reason, no `proxmox` entry can be found in the UEFI boot menu, you can try adding it manually (if supported by the firmware), by adding the file `\EFI\proxmox\shimx64.efi` as a custom boot entry.

Note
Some UEFI firmwares are known to drop the `proxmox` boot option on reboot. This can happen if the `proxmox` boot entry is pointing to a GRUB installation on a disk, where the disk itself is not a boot option. If possible, try adding the disk as a boot option in the UEFI firmware setup utility and run `proxmox-boot-tool` again.

Tip
To enroll custom keys, see the accompanying Secure Boot wiki page.

Using DKMS/Third Party Modules With Secure Boot

On systems with Secure Boot enabled, the kernel will refuse to load modules which are not signed by a trusted key. The default set of modules shipped with the kernel packages is signed with an ephemeral key embedded in the kernel image which is trusted by that specific version of the kernel image.

In order to load other modules, such as those built with DKMS or manually, they need to be signed with a key trusted by the Secure Boot stack. The easiest way to achieve this is to enroll them as Machine Owner Key (`MOK`) with `mokutil`.

The `dkms` tool will automatically generate a keypair and certificate in `/var/lib/dkms/mok.key` and `/var/lib/dkms/mok.pub` and use it for signing the kernel modules it builds and installs.

You can view the certificate contents with

```
# openssl x509 -in /var/lib/dkms/mok.pub -noout -text
```

and enroll it on your system using the following command:

```
# mokutil --import /var/lib/dkms/mok.pub
input password:
input password again:
```

The `mokutil` command will ask for a (temporary) password twice, this password needs to be entered one more time in the next step of the process! Rebooting the system should automatically boot into the `MOKManager` EFI binary, which allows you to verify the key/certificate and confirm the enrollment using the password selected when starting the enrollment using `mokutil`. Afterwards, the kernel should allow loading modules built with DKMS (which are signed with the enrolled `MOK`). The `MOK` can also be used to sign custom EFI binaries and kernel images if desired.

The same procedure can also be used for custom/third-party modules not managed with DKMS, but the key/certificate generation and signing steps need to be done manually in that case.

3.14 Kernel Samepage Merging (KSM)

Kernel Samepage Merging (KSM) is an optional memory deduplication feature offered by the Linux kernel, which is enabled by default in Proxmox VE. KSM works by scanning a range of physical memory pages for identical content, and identifying the virtual pages that are mapped to them. If identical pages are found, the corresponding virtual pages are re-mapped so that they all point to the same physical page, and the old pages are freed. The virtual pages are marked as "copy-on-write", so that any writes to them will be written to a new area of memory, leaving the shared physical page intact.

3.14.1 Implications of KSM

KSM can optimize memory usage in virtualization environments, as multiple VMs running similar operating systems or workloads could potentially share a lot of common memory pages.

However, while KSM can reduce memory usage, it also comes with some security risks, as it can expose VMs to side-channel attacks. Research has shown that it is possible to infer information about a running VM via a second VM on the same host, by exploiting certain characteristics of KSM.

Thus, if you are using Proxmox VE to provide hosting services, you should consider disabling KSM, in order to provide your users with additional security. Furthermore, you should check your country's regulations, as disabling KSM may be a legal requirement.

3.14.2 Disabling KSM

KSM can be disabled on a node or on a per-VM basis.

Disable KSM on a Node

To see if KSM is active on a node, you can check the output of:

```
# systemctl status ksmtuned
```

If it is, it can be disabled immediately with:

```
# systemctl disable --now ksmtuned
```

Finally, to unmerge all the currently merged pages, run:

```
# echo 2 > /sys/kernel/mm/ksm/run
```

Disabe KSM for a Specific VM

The `allow-ksm` VM configuration option controls whether memory page merging is allowed for a given VM. The option defaults to true and can be disabled with:

```
# qm set <vmid> --allow-ksm 0
```

Chapter 4

Graphical User Interface

Proxmox VE is simple. There is no need to install a separate management tool, and everything can be done through your web browser (Latest Firefox or Google Chrome is preferred). A built-in HTML5 console is used to access the guest console. As an alternative, SPICE can be used.

Because we use the Proxmox cluster file system (pmxcfs), you can connect to any node to manage the entire cluster. Each node can manage the entire cluster. There is no need for a dedicated manager node.

You can use the web-based administration interface with any modern browser. When Proxmox VE detects that you are connecting from a mobile device, you are redirected to a simpler, touch-based user interface.

The web interface can be reached via https://youripaddress:8006 (default login is: *root*, and the password is specified during the installation process).

4.1 Features

- Seamless integration and management of Proxmox VE clusters
- AJAX technologies for dynamic updates of resources
- Secure access to all Virtual Machines and Containers via SSL encryption (https)
- Fast search-driven interface, capable of handling hundreds and probably thousands of VMs
- Secure HTML5 console or SPICE
- Role based permission management for all objects (VMs, storages, nodes, etc.)
- Support for multiple authentication sources (e.g. local, MS ADS, LDAP, . . .)
- Two-Factor Authentication (OATH, Yubikey)
- Based on ExtJS 7.x JavaScript framework

4.2 Login



When you connect to the server, you will first see the login window. Proxmox VE supports various authentication backends (*Realm*), and you can select the language here. The GUI is translated to more than 20 languages.

Note
You can save the user name on the client side by selecting the checkbox at the bottom. This saves some typing when you login next time.

4.3 GUI Overview



The Proxmox VE user interface consists of four regions.

Header	On top. Shows status information and contains buttons for most important actions.
Resource Tree	At the left side. A navigation tree where you can select specific objects.
Content Panel	Center region. Selected objects display configuration options and status here.
Log Panel	At the bottom. Displays log entries for recent tasks. You can double-click on those log entries to get more details, or to abort a running task.

Note
You can shrink and expand the size of the resource tree and log panel, or completely hide the log panel. This can be helpful when you work on small displays and want more space to view other content.

4.3.1 Header

On the top left side, the first thing you see is the Proxmox logo. Next to it is the current running version of Proxmox VE. In the search bar nearside you can search for specific objects (VMs, containers, nodes, . . .). This is sometimes faster than selecting an object in the resource tree.

The right part of the header contains four buttons:

Documentation	Opens a new browser window showing the reference documentation.
Create VM	Opens the virtual machine creation wizard.
Create CT	Open the container creation wizard.
User Menu	Displays the identity of the user you're currently logged in with, and clicking it opens a menu with user-specific options. In the user menu, you'll find the *My Settings* dialog, which provides local UI settings. Below that, there are shortcuts for *TFA* (Two-Factor Authentication) and *Password* self-service. You'll also find options to change the *Language* and the *Color Theme.* Finally, at the bottom of the menu is the *Logout* option.

4.3.2 My Settings



The *My Settings* window allows you to set locally stored settings. These include the *Dashboard Storages* which allow you to enable or disable specific storages to be counted towards the total amount visible in the datacenter summary. If no storage is checked the total is the sum of all storages, same as enabling every single one.

Below the dashboard settings you find the stored user name and a button to clear it as well as a button to reset every layout in the GUI to its default.

On the right side there are *xterm.js Settings*. These contain the following options:

Font-Family	The font to be used in xterm.js (e.g. Arial).
Font-Size	The preferred font size to be used.
Letter Spacing	Increases or decreases spacing between letters in text.
Line Height	Specify the absolute height of a line.

4.3.3 Resource Tree

This is the main navigation tree. On top of the tree you can select some predefined views, which change the structure of the tree below. The default view is the **Server View**, and it shows the following object types:

Datacenter	Contains cluster-wide settings (relevant for all nodes).
Node	Represents the hosts inside a cluster, where the guests run.
Guest	VMs, containers and templates.
Storage	Data Storage.
Pool	It is possible to group guests using a pool to simplify management.

The following view types are available:

Server View	Shows all kinds of objects, grouped by nodes.
Folder View	Shows all kinds of objects, grouped by object type.
Pool View	Show VMs and containers, grouped by pool.
Tag View	Show VMs and containers, grouped by tags.

4.3.4 Log Panel

The main purpose of the log panel is to show you what is currently going on in your cluster. Actions like creating an new VM are executed in the background, and we call such a background job a *task*.

Any output from such a task is saved into a separate log file. You can view that log by simply double-click a task log entry. It is also possible to abort a running task there.

Please note that we display the most recent tasks from all cluster nodes here. So you can see when somebody else is working on another cluster node in real-time.

Note
We remove older and finished task from the log panel to keep that list short. But you can still find those tasks within the node panel in the *Task History*.

Some short-running actions simply send logs to all cluster members. You can see those messages in the *Cluster log* panel.

4.4 Content Panels

When you select an item from the resource tree, the corresponding object displays configuration and status information in the content panel. The following sections provide a brief overview of this functionality. Please refer to the corresponding chapters in the reference documentation to get more detailed information.

4.4.1 Datacenter



On the datacenter level, you can access cluster-wide settings and information.

- **Search:** perform a cluster-wide search for nodes, VMs, containers, storage devices, and pools.
- **Summary:** gives a brief overview of the cluster's health and resource usage.
- **Cluster:** provides the functionality and information necessary to create or join a cluster.
- **Options:** view and manage cluster-wide default settings.
- **Storage:** provides an interface for managing cluster storage. **Add** opens a wizard for adding a storage, which also offers guided setups for shared LVM on iSCSI and Fibre Channel LUNs and on NVMe over Fabrics namespaces.

- **SAN:** shows the state of the SAN LUNs and NVMe namespaces on all nodes and manages the multipath configuration.
- **Backup:** schedule backup jobs. This operates cluster wide, so it doesn't matter where the VMs/containers are on your cluster when scheduling.
- **Replication:** view and manage replication jobs.
- **Permissions:** manage user, group, and API token permissions, and LDAP, MS-AD and Two-Factor authentication.
- **HA:** manage Proxmox VE High Availability.
- **ACME:** set up ACME (Let's Encrypt) certificates for server nodes.
- **Firewall:** configure and make templates for the Proxmox Firewall cluster wide.
- **Metric Server:** define external metric servers for Proxmox VE.
- **Notifications:** configurate notification behavior and targets for Proxmox VE.
- **Support:** display information about your support subscription.

4.4.2 Nodes



Nodes in your cluster can be managed individually at this level.

The top header has useful buttons such as *Reboot*, *Shutdown*, *Shell*, *Bulk Actions* and *Help*. *Shell* has the options *noVNC*, *SPICE* and *xterm.js*. *Bulk Actions* has the options *Bulk Start*, *Bulk Shutdown* and *Bulk Migrate*.

- **Search:** search a node for VMs, containers, storage devices, and pools.
- **Summary:** display a brief overview of the node's resource usage.
- **Notes:** write custom comments in Markdown syntax.
- **Shell:** access to a shell interface for the node.
- **System:** configure network, DNS and time settings, and access the syslog and the API access log.
- **Updates:** upgrade the system and see the available new packages.
- **Firewall:** manage the Proxmox Firewall for a specific node.
- **Disks:** get an overview of the attached disks, and manage how they are used.
- **SAN:** get an overview of the SAN LUNs and NVMe namespaces of the node, with their paths and usage. Below it, **iSCSI** shows the iSCSI targets and sessions, and **NVMe over Fabrics** the connected controllers.
- **Ceph:** is only used if you have installed a Ceph server on your host. In this case, you can manage your Ceph cluster and see the status of it here.
- **Replication:** view and manage replication jobs.
- **Task History:** see a list of past tasks.
- **Subscription:** upload a subscription key, and generate a system report for use in support cases.

4.4.3 Guests



There are two different kinds of guests and both can be converted to a template. One of them is a Kernel-based Virtual Machine (KVM) and the other is a Linux Container (LXC). Navigation for these are mostly the same; only some options are different.

To access the various guest management interfaces, select a VM or container from the menu on the left.

The header contains commands for items such as power management, migration, console access and type, cloning, HA, and help. Some of these buttons contain drop-down menus, for example, *Shutdown* also contains other power options, and *Console* contains the different console types: *SPICE*, *noVNC* and *xterm.js*.

The panel on the right contains an interface for whatever item is selected from the menu on the left.

The available interfaces are as follows.

- **Summary:** provides a brief overview of the VM's activity and a `Notes` field for Markdown syntax comments.
- **Console:** access to an interactive console for the VM/container.
- **(KVM)Hardware:** define the hardware available to the KVM VM.
- **(LXC)Resources:** define the system resources available to the LXC.
- **(LXC)Network:** configure a container's network settings.
- **(LXC)DNS:** configure a container's DNS settings.
- **Options:** manage guest options.

- **Task History:** view all previous tasks related to the selected guest.
- **(KVM) Monitor:** an interactive communication interface to the KVM process.
- **Backup:** create and restore system backups.
- **Replication:** view and manage the replication jobs for the selected guest.
- **Snapshots:** create and restore VM snapshots.
- **Firewall:** configure the firewall on the VM level.
- **Permissions:** manage permissions for the selected guest.

4.4.4 Storage



As with the guest interface, the interface for storage consists of a menu on the left for certain storage elements and an interface on the right to manage these elements.

In this view we have a two partition split-view. On the left side we have the storage options and on the right side the content of the selected option will be shown.

- **Summary:** shows important information about the storage, such as the type, usage, and content which it stores.

- **Content:** a menu item for each content type which the storage stores, for example, Backups, ISO Images, CT Templates.
- **Permissions:** manage permissions for the storage.

4.4.5 Pools



Again, the pools view comprises two partitions: a menu on the left, and the corresponding interfaces for each menu item on the right.

- **Summary:** shows a description of the pool.
- **Members:** display and manage pool members (guests and storage).
- **Permissions:** manage the permissions for the pool.

4.5 Tags



For organizational purposes, it is possible to set `tags` for guests. Currently, these only provide informational value to users. Tags are displayed in two places in the web interface: in the `Resource Tree` and in the status line when a guest is selected.

Tags can be added, edited, and removed in the status line of the guest by clicking on the `pencil` icon. You can add multiple tags by pressing the + button and remove them by pressing the − button. To save or cancel the changes, you can use the ✓ and `x` button respectively.

Tags can also be set via the CLI, where multiple tags are separated by semicolons. For example:

```
# qm set ID --tags 'myfirsttag;mysecondtag'
```

4.5.1 Style Configuration



By default, the tag colors are derived from their text in a deterministic way. The color, shape in the resource tree, and case-sensitivity, as well as how tags are sorted, can be customized. This can be done via the web interface under *Datacenter* → *Options* → *Tag Style Override*. Alternatively, this can be done via the CLI. For example:

```
# pvesh set /cluster/options --tag-style color-map=example:000000:FFFFFF
```

sets the background color of the tag `example` to black (#000000) and the text color to white (#FFFFFF).

4.5.2 Permissions



By default, users with the privilege `VM.Config.Options` on a guest (`/vms/ID`) can set any tags they

want (see Permission Management). If you want to restrict this behavior, appropriate permissions can be set under *Datacenter* → *Options* → *User Tag Access*:

- `free`: users are not restricted in setting tags (Default)
- `list`: users can set tags based on a predefined list of tags
- `existing`: like list but users can also use already existing tags
- `none`: users are restricted from using tags

The same can also be done via the CLI.

Note that a user with the `Sys.Modify` privileges on `/` is always able to set or delete any tags, regardless of the settings here. Additionally, there is a configurable list of `registered tags` which can only be added and removed by users with the privilege `Sys.Modify` on `/`. The list of registered tags can be edited under *Datacenter* → *Options* → *Registered Tags* or via the CLI.

For more details on the exact options and how to invoke them in the CLI, see Datacenter Configuration.

4.6 Consent Banner

A custom consent banner that has to be accepted before login can be configured in *Datacenter* → *Options* → *Consent Text*. If there is no content, the consent banner will not be displayed. The text will be stored as a base64 string in the `/etc/pve/datacenter.cfg` config file.

Chapter 5

Cluster Manager

The Proxmox VE cluster manager `pvecm` is a tool to create a group of physical servers. Such a group is called a **cluster**. We use the Corosync Cluster Engine for reliable group communication. There's no explicit limit for the number of nodes in a cluster. In practice, the actual possible node count may be limited by the host and network performance. Currently (2021), there are reports of clusters (using high-end enterprise hardware) with over 50 nodes in production.

`pvecm` can be used to create a new cluster, join nodes to a cluster, leave the cluster, get status information, and do various other cluster-related tasks. The **P**rox**m**o**x** **C**luster **F**ile **S**ystem ("pmxcfs") is used to transparently distribute the cluster configuration to all cluster nodes.

Grouping nodes into a cluster has the following advantages:

- Centralized, web-based management
- Multi-master clusters: each node can do all management tasks
- Use of `pmxcfs`, a database-driven file system, for storing configuration files, replicated in real-time on all nodes using `corosync`
- Easy migration of virtual machines and containers between physical hosts
- Fast deployment
- Cluster-wide services like firewall and HA

5.1 Requirements

- All nodes must be able to connect to each other via UDP ports 5405-5412 for corosync to work.
- Date and time must be synchronized.
- An SSH tunnel on TCP port 22 between nodes is required.
- If you are interested in High Availability, you need to have at least three nodes for reliable quorum. All nodes should have the same version.

Note
For smaller 2-node clusters, the QDevice can be used to provide a 3rd vote.

- We recommend a dedicated physical NIC for the cluster traffic.

Note
The Proxmox VE cluster communication uses the Corosync protocol. It needs consistent low latency but not a lot of bandwidth. A dedicated 1 Gbit NIC is enough in most situations. It helps to avoid situations where other services can use up all the available bandwidth. Which in turn would increase the latency for the Corosync packets.

- Additional links for cluster traffic offers redundancy in case the dedicated network is down.

Note
Corosync supports up to 8 links.

Note
To ensure reliable Corosync redundancy, it is essential to have at least another link on a different physical network. This enables Corosync to keep the cluster communication alive should the dedicated network be down.

Note
A single link backed by a bond can be problematic in certain failure scenarios, see Corosync Over Bonds.

- The root password of a cluster node is required for adding nodes.
- Online migration of virtual machines is only supported when nodes have CPUs from the same vendor. It might work otherwise, but this is never guaranteed.

5.2 Preparing Nodes

First, install Proxmox VE on all nodes. Make sure that each node is installed with the final hostname and IP configuration. Changing the hostname and IP is not possible after cluster creation.

While it's common to reference all node names and their IPs in `/etc/hosts` (or make their names resolvable through other means), this is not necessary for a cluster to work. It may be useful however, as you can then connect from one node to another via SSH, using the easier to remember node name (see also Link Address Types). Note that we always recommend referencing nodes by their IP addresses in the cluster configuration.

5.3 Create a Cluster

You can either create a cluster on the console (login via `ssh`), or through the API using the Proxmox VE web interface (*Datacenter* → *Cluster*).

Note
Use a unique name for your cluster. This name cannot be changed later. The cluster name follows the same rules as node names.

5.3.1 Create via Web GUI



Under *Datacenter* → *Cluster*, click on **Create Cluster**. Enter the cluster name and select a network connection from the drop-down list to serve as the main cluster network (Link 0). It defaults to the IP resolved via the node's hostname.

As of Proxmox VE 6.2, up to 8 fallback links can be added to a cluster. To add a redundant link, click the *Add* button and select a link number and IP address from the respective fields. Prior to Proxmox VE 6.2, to add a second link as fallback, you can select the *Advanced* checkbox and choose an additional network interface (Link 1, see also Corosync Redundancy).

Note
Ensure that the network selected for cluster communication is not used for any high traffic purposes, like network storage or live-migration. While the cluster network itself produces small amounts of data, it is very sensitive to latency. Check out full cluster network requirements.

5.3.2 Create via the Command Line

Login via `ssh` to the first Proxmox VE node and run the following command:

```
hp1# pvecm create CLUSTERNAME
```

To check the state of the new cluster use:

```
hp1# pvecm status
```

5.3.3 Multiple Clusters in the Same Network

It is possible to create multiple clusters in the same physical or logical network. In this case, each cluster must have a unique name to avoid possible clashes in the cluster communication stack. Furthermore, this helps avoid human confusion by making clusters clearly distinguishable.

While the bandwidth requirement of a corosync cluster is relatively low, the latency of packets and the packets per second (PPS) rate is the limiting factor. Different clusters in the same network can compete with each other for these resources, so it may still make sense to use separate physical network infrastructure for bigger clusters.

5.4 Adding Nodes to the Cluster

Caution

All existing configuration in `/etc/pve` is overwritten when joining a cluster. In particular, a joining node cannot hold any guests, since guest IDs could otherwise conflict, and the node will inherit the cluster's storage configuration. To join a node with existing guest, as a workaround, you can create a backup of each guest (using `vzdump`) and restore it under a different ID after joining. If the node's storage layout differs, you will need to re-add the node's storages, and adapt each storage's node restriction to reflect on which nodes the storage is actually available.

5.4.1 Join Node to Cluster via GUI



Log in to the web interface on an existing cluster node. Under *Datacenter* → *Cluster*, click the **Join Information** button at the top. Then, click on the button **Copy Information**. Alternatively, copy the string from the *Information* field manually.



Next, log in to the web interface on the node you want to add. Under *Datacenter* → *Cluster*, click on **Join Cluster**. Fill in the *Information* field with the *Join Information* text you copied earlier. Most settings required for joining the cluster will be filled out automatically. For security reasons, the cluster password has to be entered manually.

Note

To enter all required data manually, you can disable the *Assisted Join* checkbox.

After clicking the **Join** button, the cluster join process will start immediately. After the node has joined the cluster, its current node certificate will be replaced by one signed from the cluster certificate authority (CA). This means that the current session will stop working after a few seconds. You then might need to force-reload the web interface and log in again with the cluster credentials.

Now your node should be visible under *Datacenter* → *Cluster*.

5.4.2 Join Node to Cluster via Command Line

Log in to the node you want to join into an existing cluster via `ssh`.

```
# pvecm add IP-ADDRESS-CLUSTER
```

For `IP-ADDRESS-CLUSTER`, use the IP or hostname of an existing cluster node. An IP address is recommended (see Link Address Types).

By default, `pvecm add` authenticates against the existing cluster node's API, prompting for that node's `root@pam` password and verifying its SHA-256 certificate fingerprint. SSH password authentication is not required for this default flow, so administrators may keep `PasswordAuthentication no` set in `sshd_config`.

Pass `--use_ssh` to fall back to the legacy SSH-based join, which uses `ssh-copy-id` to merge the existing cluster's root key onto the new node. That flow does require root SSH login (with password or key) on the existing node.

To check the state of the cluster use:

```
# pvecm status
```

Cluster status after adding 4 nodes

```
 # pvecm status
Cluster information
~~~~~~~~~~~~~~~~~~~
Name:             prod-central
Config Version:   3
Transport:        knet
Secure auth:      on

Quorum information
~~~~~~~~~~~~~~~~~~
Date:             Tue Sep 14 11:06:47 2021
Quorum provider:  corosync_votequorum
Nodes:            4
Node ID:          0x00000001
Ring ID:          1.1a8
Quorate:          Yes

Votequorum information
~~~~~~~~~~~~~~~~~~~~~~
Expected votes:   4
Highest expected: 4
Total votes:      4
```

```
Quorum:           3
Flags:            Quorate

Membership information
~~~~~~~~~~~~~~~~~~~~~~
    Nodeid      Votes Name
0x00000001          1 192.168.15.91
0x00000002          1 192.168.15.92 (local)
0x00000003          1 192.168.15.93
0x00000004          1 192.168.15.94
```

If you only want a list of all nodes, use:

```
 # pvecm nodes
```

List nodes in a cluster

```
 # pvecm nodes

Membership information
~~~~~~~~~~~~~~~~~~~~~~
    Nodeid      Votes Name
         1          1 hp1
         2          1 hp2 (local)
         3          1 hp3
         4          1 hp4
```

5.4.3 Adding Nodes with Separated Cluster Network

When adding a node to a cluster with a separated cluster network, you need to use the *link0* parameter to set the nodes address on that network:

```
# pvecm add IP-ADDRESS-CLUSTER --link0 LOCAL-IP-ADDRESS-LINK0
```

If you want to use the built-in redundancy of the Kronosnet transport layer, also use the *link1* parameter.

Using the GUI, you can select the correct interface from the corresponding *Link X* fields in the **Cluster Join** dialog.

5.5 Remove a Cluster Node



Caution
Read the procedure carefully before proceeding, as it may not be what you want or need.

The following steps explain how to remove a node from a cluster that was also part of a Ceph cluster. If Ceph was not installed on your node, you can simply ignore the steps that mention it.

Note
If your configuration contains a QDevice, you will need to remove it before removing the cluster node, as outlined in the FAQ here.

5.5.1 Prerequisites

- Move all virtual machines and containers away from the node.
- Back up all local data on the node to be deleted.
- Make sure the node to be deleted is not part of any replication job anymore.



Caution
If you fail to remove replication jobs from a node before removing the node itself, the replication job will become irremovable. Note that replication automatically switches direction when a replicated VM is migrated. Therefore, migrating a replicated VM from a node that is going to be deleted will set up replication jobs to that node automatically.

- Ensure that the remaining Ceph cluster has sufficient storage space and that the OSDs are running (i.e. `up` and `in`). The destruction of any OSD, especially the last one on a node, will trigger a data rebalance in Ceph.

Note
Make sure that there are still enough nodes with OSDs available to satisfy the `size/min_size` parameters configured for the Ceph pools. If there are fewer than `size` (default: 3) nodes available, data redundancy will be degraded. If there are fewer than `min_size` (default: 2) nodes available, the I/O of the pools will be blocked until there are enough replicas available. Affected guests may crash if their I/O is blocked.

- Ensure that sufficient monitors, managers and, if using CephFS, metadata servers remain available in the Ceph cluster.

5.5.2 Remove the Cluster Node

Before a node can be removed from a cluster, you must ensure that it is no longer part of a Ceph cluster and that no Ceph resources or services are residing on it.

In the following example, the cluster node `node4` will be removed from both the Ceph-, and Proxmox VE corosync-cluster.

```
node4# pvecm nodes

Membership information
~~~~~~~~~~~~~~~~~~~~~~
    Nodeid      Votes Name
         1          1 node1
         2          1 node2
         3          1 node3
         4          1 node4 (local)
```

1. Start by removing the node from the Ceph cluster, this consists of multiple steps:

   a. Start by destroying the remaining Ceph OSDs on the node to be deleted, one after another.

   b. Wait until the CEPH status reaches `HEALTH_OK` again.

   c. If any exists, destroy the remaining Ceph metadata servers via the web interface at *Ceph* → *CephFS* or by running:

   ```
   node4# pveceph mds destroy node4
   ```

   d. Destroy the remaining Ceph monitor.

   e. Destroy the remaining Ceph manager.

   f. Finally, remove the now empty Ceph bucket (Proxmox VE node to be removed) from the CRUSH hierarchy.

   ```
   node4# ceph osd crush remove node4
   ```

2. Now, power off `node4` and ensure that it will not power on again in this network with its current configuration.

   

   Important
   As mentioned above, it is critical to power off the node **before** removal, and make sure that it will **not** power on again (in the existing cluster network) with its current configuration. If you power on the node as it is, the cluster could end up broken, and it could be difficult to restore it to a functioning state.

3. Log into one of the remaining cluster nodes and remove the node `node4` from the cluster.

   ```
   node1# pvecm delnode node4
   ```

   Note
   It is possible that you will receive an error message stating `could not kill node (error = cs_err_not_exist)`. This does not signify an actual failure in the deletion of the node, but rather a failure in Corosync trying to kill an offline node. Thus, it can be safely ignored.

4. Verify the node was successfully removed from the cluster

   ```
   node1# pvecm nodes

   Membership information
   ~~~~~~~~~~~~~~~~~~~~~~
       Nodeid      Votes Name
            1          1 node1 (local)
            2          1 node2
            3          1 node3
   ```

5.5.3 Cleanup Steps After Node Removal

- The configuration files of the removed node will still reside in */etc/pve/nodes/node4* in the cluster filesystem. Recover any configuration you still need and remove the directory afterwards.
- The SSH fingerprint of the removed node will still reside in the *known_hosts* file on the other nodes. If you receive an SSH error after rejoining a node with the same IP or hostname, run `pvecm updatecerts` once on the re-added node to update its fingerprint cluster wide.
- Existing high availability rules will still reference the deleted node, therefore remove the node from any existing rules.
- The public key of the removed node will still be listed in */etc/pve/priv/authorized_keys* and should be deleted if it is no longer needed.

Rejoin the same node again:

If you want the same server to join the same cluster again, you have to:

- Reinstall Proxmox VE on the server,
- then rejoin the node to the cluster

5.6 Separate a Node Without Reinstalling



Caution
This is **not** the recommended method, proceed with caution. Use the previous method if you're unsure.

You can also separate a node from a cluster without reinstalling it from scratch. But after removing the node from the cluster, it will still have access to any shared storage. This must be resolved before you start removing the node from the cluster. A Proxmox VE cluster cannot share the exact same storage with another cluster, as storage locking doesn't work over the cluster boundary. Furthermore, it may also lead to VMID conflicts.

It's suggested that you create a new storage, where only the node which you want to separate has access. This can be a new export on your NFS or a new Ceph pool, to name a few examples. It's just important that the exact same storage does not get accessed by multiple clusters. After setting up this storage, move all data and VMs from the node to it. Then you are ready to separate the node from the cluster.

Note
If your configuration contains a QDevice, you will need to remove it before removing the cluster node, as outlined in the FAQ here.



Warning
Ensure that all shared resources are cleanly separated! Otherwise you will run into conflicts and problems.

First, stop the corosync and pve-cluster services on the node:

```
systemctl stop pve-cluster
systemctl stop corosync
```

Start the cluster file system again in local mode:

```
pmxcfs -l
```

Delete the corosync configuration files:

```
rm /etc/pve/corosync.conf
rm -r /etc/corosync/*
```

Remove the cluster ID, if the cluster has one. Without this step, the node keeps the ID of its former cluster instead of generating its own when the file system starts again as a normal service:

```
rm /etc/pve/cluster-id
```

You can now start the file system again as a normal service:

```
killall pmxcfs
systemctl start pve-cluster
```

The node is now separated from the cluster. You can delete it from any remaining node of the cluster with:

```
pvecm delnode oldnode
```

If the command fails due to a loss of quorum in the remaining node, you can set the expected votes to 1 as a workaround:

```
pvecm expected 1
```

And then repeat the *pvecm delnode* command.

Now switch back to the separated node and delete all the remaining cluster files on it. This ensures that the node can be added to another cluster again without problems.

```
rm /var/lib/corosync/*
```

As the configuration files from the other nodes are still in the cluster file system, you may want to clean those up too. After making absolutely sure that you have the correct node name, you can simply remove the entire directory recursively from */etc/pve/nodes/NODENAME*.



Caution
The node's SSH keys will remain in the *authorized_key* file. This means that the nodes can still connect to each other with public key authentication. You should fix this by removing the respective keys from the */etc/pve/priv/authorized_keys* file.

5.7 Cluster ID

Since Proxmox VE 9.3, each cluster has a random cluster ID in the same format as the `uid` of a guest identity. A node that is not part of a cluster has an ID of its own. Guests in different clusters can have the same `uid`, for example after a migration to another cluster that kept the source guest. The cluster ID tells tools to which cluster the `uid` of a guest belongs.

The cluster ID is stored in `/etc/pve/cluster-id`:

```
# cat /etc/pve/cluster-id
```

Through the API, `/cluster/status` returns it in the `cluster-id` field of the entry of type `cluster`. On a node without a cluster, the field is on the node entry instead. Reading the cluster ID through the API requires the `Sys.Audit` privilege on `/`. Users with this privilege also see it in the web interface (*Datacenter* → *Summary*).

Proxmox VE generates the cluster ID and keeps it unchanged. Creating, changing, moving or removing `/etc/pve/cluster-id` fails with `Permission denied`. The only exception is removing or moving it away in local mode (`pmxcfs -l`), as described below. Nodes running a Proxmox VE version older than 9.3 do not protect the file.

A node without a cluster generates its ID when its cluster file system starts. If it cannot store the ID, for example because the root file system is full, it starts without one and generates it at the next start of the `pve-cluster` service. In a cluster, the online node with the lowest node ID generates the ID once all of the following apply:

- The cluster is quorate.
- More than half of the configured nodes are online.
- The cluster file systems of the online nodes are in sync.

If the node that generates the ID loses the connection to the other nodes at that moment, it reports its ID while the other nodes generate and report another one. When that node joins again, it normally adopts the ID of the others. Its own ID replaces theirs only if nothing in `/etc/pve` changed meanwhile and its clock is a few seconds ahead of theirs.

Until an ID exists, the API omits the field, and the file is missing or holds no valid ID. The API also omits the field if reading the file fails. An ID can be missing for the following reasons:

- The online node with the lowest node ID runs a Proxmox VE version older than 9.3. The cluster gets no ID as long as that is the case.
- The online node with the lowest node ID runs Proxmox VE 9.3 or later, but cannot generate the ID yet. Its `pve-cluster` service then logs the reason in a message starting with `not generating a cluster ID yet`.
- A directory takes up the path of the file, for example one created on a node with an older version. Proxmox VE then logs that `'cluster-id' is not a regular file`. Move the contents of the directory away and remove it with `rmdir /etc/pve/cluster-id`. A cluster then generates the ID within a few seconds. A node without a cluster generates it the next time the `pve-cluster` service starts, for example after `systemctl restart pve-cluster`.

Creating a cluster with `pvecm create` keeps the ID of the node, which then identifies the new cluster. A node that joins a cluster adopts the ID of the cluster, because joining replaces the configuration of the node in `/etc/pve`. A copy of an installation, such as a cloned disk or a copy of the cluster file system database, has the same ID as the original.

To give a node that is not part of a cluster a new ID, for example after cloning an installation, follow the steps below. To separate a node from its cluster, follow Separate a Node Without Reinstalling instead. That procedure includes the removal of the cluster ID.



Warning
Do not remove `/etc/pve/cluster-id` on a node that is still part of a cluster. When that node rejoins the cluster, the removal is either undone, or it reaches all nodes and the whole cluster gets a new ID.

1. Stop the cluster file system and start it again in local mode:

```
# systemctl stop pve-cluster
# pmxcfs -l
```

2. Remove the cluster ID file:

```
# rm /etc/pve/cluster-id
```

3. Stop the cluster file system and start it again as a normal service, which generates a new ID:

```
# killall pmxcfs
# systemctl start pve-cluster
```

5.8 Quorum

Proxmox VE use a quorum-based technique to provide a consistent state among all cluster nodes.

> A quorum is the minimum number of votes that a distributed transaction has to obtain in order to be allowed to perform an operation in a distributed system.
>
> — from Wikipedia *Quorum (distributed computing)*

In case of network partitioning, state changes requires that a majority of nodes are online. The cluster switches to read-only mode if it loses quorum.

Note
Proxmox VE assigns a single vote to each node by default.

5.9 Cluster Network

The cluster network is the core of a cluster. All messages sent over it have to be delivered reliably to all nodes in their respective order. In Proxmox VE this part is done by corosync, an implementation of a high performance, low overhead, high availability development toolkit. It serves our decentralized configuration file system (`pmxcfs`).

5.9.1 Network Requirements

The Proxmox VE cluster stack requires a reliable network with latencies under 5 milliseconds (LAN performance) between all nodes to operate stably. While on setups with a small node count a network with higher latencies *may* work, this is not guaranteed and gets rather unlikely with more than three nodes and latencies above around 10 ms.

The network should not be used heavily by other members, as while corosync does not use much bandwidth, it is sensitive to latency jitters; ideally corosync runs on its own physically separated network. Especially do not use a shared network for corosync and storage (except as a potential low-priority fallback in a redundant configuration).

Before setting up a cluster, it is good practice to check if the network is fit for that purpose. To ensure that the nodes can connect to each other on the cluster network, you can test the connectivity between them with the `ping` tool.

If the Proxmox VE firewall is enabled, ACCEPT rules for corosync will automatically be generated - no manual action is required.

Note
Corosync used Multicast before version 3.0 (introduced in Proxmox VE 6.0). Modern versions rely on Kronosnet for cluster communication, which, for now, only supports regular UDP unicast.



Caution
You can still enable Multicast or legacy unicast by setting your transport to `udp` or `udpu` in your corosync.conf, but keep in mind that this will disable all cryptography and redundancy support. This is therefore not recommended.

5.9.2 Corosync Over Bonds

Recommendations

We recommend at least one dedicated physical NIC for the primary Corosync link, see Requirements. Bonds may be used as additional links for increased redundancy. The following caveats apply **whenever a bond is used for Corosync traffic**:

- Bond mode **active-backup** may not provide the expected redundancy in certain failure scenarios, see below for details.
- We **advise against** using bond modes **balance-rr**, **balance-xor**, **balance-tlb**, or **balance-alb** for Corosync traffic. They are known to be problematic in certain failure scenarios, see below for details.
- **IEEE 802.3ad (LACP)**: If LACP bonds are used for corosync traffic, we strongly recommend setting `bond-lacp-rate fast` on the **Proxmox VE** node and the **switch**! With the default setting `bond-lacp-ra slow`, this mode is known to be problematic in certain failure scenarios, see below for details.

Background

Using a bond as a Corosync link can be problematic in certain failure scenarios. Consider the failure scenario where one of the bonded interfaces fails and stops transmitting packets, but its link state stays up, and there are no other Corosync links available. In this scenario, some bond modes may cause a state of asymmetric connectivity where cluster nodes can only communicate with different subsets of other nodes. Affected are bond modes that provide load balancing, as these modes may still try to send out a subset of packets via the failed interface. In case of asymmetric connectivity, Corosync may not be able to form a stable quorum in the cluster. If this state persists and HA is enabled, even nodes whose bond does not have any issues may fence themselves. In the worst case, the whole cluster may fence itself.

The bond mode **active-backup** will **not** cause asymmetric connectivity in the failure scenario described above. However, the bond with the interface failure may not switch over to the backup link. The node may lose connection to the cluster and, if HA is enabled, fence itself.

Bond modes **balance-rr**, **balance-xor**, **balance_tlb**, or **balance-alb** may cause asymmetric connectivity in the failure scenario above, which can lead to unexpected fencing if HA is enabled.

Bond mode **IEEE 802.3ad (LACP)** can cause asymmetric connectivity in the failure scenario above, but it can recover from this state, as each side of the bond (Proxmox VE node and switch) can stop using a bonded interface if it has not received three LACPDUs in a row on it. However, with default settings, LACPDUs are only sent every 30 seconds, yielding a failover time of 90 seconds. This is too long, as nodes with HA resources will fence themselves already after roughly one minute without a stable quorum. If LACP bonds are used for corosync traffic, we recommend setting `bond-lacp-rate fast` on the **Proxmox VE** node and the **switch**! Setting this option on one side requests the other side to send an LACPDU every second. Setting this option on both sides can reduce the failover time in the scenario above to 3 seconds and thus prevent fencing.

5.9.3 Separate Cluster Network

When creating a cluster without any parameters, the corosync cluster network is generally shared with the web interface and the VMs' network. Depending on your setup, even storage traffic may get sent over the same network. It's recommended to change that, as corosync is a time-critical, real-time application.

Setting Up a New Network

First, you have to set up a new network interface. It should be on a physically separate network. Ensure that your network fulfills the cluster network requirements.

Separate On Cluster Creation

This is possible via the *linkX* parameters of the *pvecm create* command, used for creating a new cluster.

If you have set up an additional NIC with a static address on 10.10.10.1/25, and want to send and receive all cluster communication over this interface, you would execute:

```
pvecm create test --link0 10.10.10.1
```

To check if everything is working properly, execute:

```
systemctl status corosync
```

Afterwards, proceed as described above to add nodes with a separated cluster network.

Separate After Cluster Creation

You can do this if you have already created a cluster and want to switch its communication to another network, without rebuilding the whole cluster. This change may lead to short periods of quorum loss in the cluster, as nodes have to restart corosync and come up one after the other on the new network.

Check how to edit the corosync.conf file first. Then, open it and you should see a file similar to:

```
logging {
  debug: off
  to_syslog: yes
}

nodelist {

  node {
    name: due
    nodeid: 2
    quorum_votes: 1
    ring0_addr: due
  }

  node {
    name: tre
    nodeid: 3
    quorum_votes: 1
    ring0_addr: tre
  }

  node {
    name: uno
    nodeid: 1
    quorum_votes: 1
    ring0_addr: uno
  }

}

quorum {
  provider: corosync_votequorum
}

totem {
  cluster_name: testcluster
  config_version: 3
  ip_version: ipv4-6
  secauth: on
  version: 2
  interface {
    linknumber: 0
  }

}
```

Note
`ringX_addr` actually specifies a corosync **link address**. The name "ring" is a remnant of older corosync versions that is kept for backwards compatibility.

The first thing you want to do is add the *name* properties in the node entries, if you do not see them already. Those **must** match the node name.

Then replace all addresses from the *ring0_addr* properties of all nodes with the new addresses. You may use plain IP addresses or hostnames here. If you use hostnames, ensure that they are resolvable from all nodes (see also Link Address Types).

In this example, we want to switch cluster communication to the 10.10.10.0/25 network, so we change the *ring0_addr* of each node respectively.

Note
The exact same procedure can be used to change other *ringX_addr* values as well. However, we recommend only changing one link address at a time, so that it's easier to recover if something goes wrong.

After we increase the *config_version* property, the new configuration file should look like:

```
logging {
  debug: off
  to_syslog: yes
}

nodelist {

  node {
    name: due
    nodeid: 2
    quorum_votes: 1
    ring0_addr: 10.10.10.2
  }

  node {
    name: tre
    nodeid: 3
    quorum_votes: 1
    ring0_addr: 10.10.10.3
  }

  node {
    name: uno
    nodeid: 1
    quorum_votes: 1
    ring0_addr: 10.10.10.1
  }

}

quorum {
```

```
  provider: corosync_votequorum
}

totem {
  cluster_name: testcluster
  config_version: 4
  ip_version: ipv4-6
  secauth: on
  version: 2
  interface {
    linknumber: 0
  }

}
```

Then, after a final check to see that all changed information is correct, we save it and once again follow the edit corosync.conf file section to bring it into effect.

The changes will be applied live, so restarting corosync is not strictly necessary. If you changed other settings as well, or notice corosync complaining, you can optionally trigger a restart.

On a single node execute:

```
systemctl restart corosync
```

Now check if everything is okay:

```
systemctl status corosync
```

If corosync begins to work again, restart it on all other nodes too. They will then join the cluster membership one by one on the new network.

5.9.4 Corosync Addresses

A corosync link address (for backwards compatibility denoted by *ringX_addr* in `corosync.conf`) can be specified in two ways:

- **IPv4/v6 addresses** can be used directly. They are recommended, since they are static and usually not changed carelessly.
- **Hostnames** will be resolved using `getaddrinfo`, which means that by default, IPv6 addresses will be used first, if available (see also `man gai.conf`). Keep this in mind, especially when upgrading an existing cluster to IPv6.



Caution
Hostnames should be used with care, since the addresses they resolve to can be changed without touching corosync or the node it runs on - which may lead to a situation where an address is changed without thinking about implications for corosync.

A separate, static hostname specifically for corosync is recommended, if hostnames are preferred. Also, make sure that every node in the cluster can resolve all hostnames correctly.

Since Proxmox VE 5.1, while supported, hostnames will be resolved at the time of entry. Only the resolved IP is saved to the configuration.

Nodes that joined the cluster on earlier versions likely still use their unresolved hostname in `corosync.conf`. It might be a good idea to replace them with IPs or a separate hostname, as mentioned above.

5.10 Corosync Redundancy

Corosync supports redundant networking via its integrated Kronosnet layer by default (it is not supported on the legacy udp/udpu transports). It can be enabled by specifying more than one link address, either via the *--linkX* parameters of `pvecm`, in the GUI as **Link 1** (while creating a cluster or adding a new node) or by specifying more than one *ringX_addr* in `corosync.conf`.

Note
To provide useful failover, every link should be on its own physical network connection.

The following examples assume that each cluster node has one static address in 10.10.10.0/25 and one static address in 10.20.20.0/25 configured.

Links are used according to a priority setting. You can configure this priority by setting *knet_link_priority* in the corresponding interface section in `corosync.conf`, or, preferably, using the *priority* parameter when creating your cluster with `pvecm`:

```
# pvecm create CLUSTERNAME --link0 10.10.10.1,priority=15 --link1  ↩
   10.20.20.1,priority=20
```

This would cause *link1* to be used first, since it has the higher priority.

If no priorities are configured manually (or two links have the same priority), links will be used in order of their number, with the lower number having higher priority.

Even if all links are working, only the one with the highest priority will see corosync traffic. Link priorities cannot be mixed, meaning that links with different priorities will not be able to communicate with each other.

Since lower priority links will not see traffic unless all higher priorities have failed, it becomes a useful strategy to specify networks used for other tasks (VMs, storage, etc.) as low-priority links. If worst comes to worst, a higher latency or more congested connection might be better than no connection at all.

5.10.1 Adding Redundant Links To An Existing Cluster

To add a new link to a running configuration, first check how to edit the corosync.conf file.

Then, add a new *ringX_addr* to every node in the `nodelist` section. Make sure that your *X* is the same for every node you add it to, and that it is unique for each node.

Lastly, add a new *interface*, as shown below, to your `totem` section, replacing *X* with the link number chosen above.

Assuming you added a link with number 1, the new configuration file could look like this:

```
logging {
  debug: off
  to_syslog: yes
}

nodelist {

  node {
    name: due
    nodeid: 2
    quorum_votes: 1
    ring0_addr: 10.10.10.2
    ring1_addr: 10.20.20.2
  }

  node {
    name: tre
    nodeid: 3
    quorum_votes: 1
    ring0_addr: 10.10.10.3
    ring1_addr: 10.20.20.3
  }

  node {
    name: uno
    nodeid: 1
    quorum_votes: 1
    ring0_addr: 10.10.10.1
    ring1_addr: 10.20.20.1
  }

}

quorum {
  provider: corosync_votequorum
}

totem {
  cluster_name: testcluster
  config_version: 4
  ip_version: ipv4-6
  secauth: on
  version: 2
  interface {
    linknumber: 0
  }
  interface {
    linknumber: 1
  }
}
```

The new link will be enabled as soon as you follow the last steps to edit the corosync.conf file. A restart

should not be necessary. You can check that corosync loaded the new link using:

```
journalctl -b -u corosync
```

It might be a good idea to test the new link by temporarily disconnecting the old link on one node and making sure that its status remains online while disconnected:

```
pvecm status
```

If you see a healthy cluster state, it means that your new link is being used.

5.11 Role of SSH in Proxmox VE Clusters

Proxmox VE utilizes SSH tunnels for various features.

- Proxying console/shell sessions (node and guests)

  When using the shell for node B while being connected to node A, connects to a terminal proxy on node A, which is in turn connected to the login shell on node B via a non-interactive SSH tunnel.

- VM and CT memory and local-storage migration in *secure* mode.

  During the migration, one or more SSH tunnel(s) are established between the source and target nodes, in order to exchange migration information and transfer memory and disk contents.

- Storage replication

5.11.1 SSH setup

On Proxmox VE systems, the following changes are made to the SSH configuration/setup:

- the `root` user's SSH client config gets setup to prefer `AES` over `ChaCha20`
- the `root` user's `authorized_keys` file gets linked to `/etc/pve/priv/authorized_keys`, merging all authorized keys within a cluster
- `sshd` is configured to allow logging in as root with a password

---

Note
Older systems might also have `/etc/ssh/ssh_known_hosts` set up as symlink pointing to `/etc/pve/priv/known_hosts`, containing a merged version of all node host keys. This system was replaced with explicit host key pinning in `pve-cluster <<INSERT VERSION>>`, the symlink can be deconfigured if still in place by running `pvecm updatecerts --unmerge-known-hosts`.

5.11.2 Pitfalls due to automatic execution of `.bashrc` and siblings

In case you have a custom `.bashrc`, or similar files that get executed on login by the configured shell, `ssh` will automatically run it once the session is established successfully. This can cause some unexpected behavior, as those commands may be executed with root permissions on any of the operations described above. This can cause possible problematic side-effects!

In order to avoid such complications, it's recommended to add a check in `/root/.bashrc` to make sure the session is interactive, and only then run `.bashrc` commands.

You can add this snippet at the beginning of your `.bashrc` file:

```
# Early exit if not running interactively to avoid side-effects!
case $- in
    *i*) ;;
      *) return;;
esac
```

5.12 Corosync External Vote Support

This section describes a way to deploy an external voter in a Proxmox VE cluster. When configured, the cluster can sustain more node failures without violating safety properties of the cluster communication.

For this to work, there are two services involved:

- A QDevice daemon which runs on each Proxmox VE node
- An external vote daemon which runs on an independent server

As a result, you can achieve higher availability, even in smaller setups (for example 2+1 nodes).

5.12.1 QDevice Technical Overview

The Corosync Quorum Device (QDevice) is a daemon which runs on each cluster node. It provides a configured number of votes to the cluster's quorum subsystem, based on an externally running third-party arbitrator's decision. Its primary use is to allow a cluster to sustain more node failures than standard quorum rules allow. This can be done safely as the external device can see all nodes and thus choose only one set of nodes to give its vote. This will only be done if said set of nodes can have quorum (again) after receiving the third-party vote.

Currently, only *QDevice Net* is supported as a third-party arbitrator. This is a daemon which provides a vote to a cluster partition, if it can reach the partition members over the network. It will only give votes to one partition of a cluster at any time. It's designed to support multiple clusters and is almost configuration and state free. New clusters are handled dynamically and no configuration file is needed on the host running a QDevice.

The only requirements for the external host are that it needs network access to the cluster and to have a corosync-qnetd package available. We provide a package for Debian based hosts, and other Linux distributions should also have a package available through their respective package manager.

Note
Unlike corosync itself, a QDevice connects to the cluster over TCP/IP. The daemon can also run outside the LAN of the cluster and isn't limited to the low latencies requirements of corosync.

5.12.2 Supported Setups

We support QDevices for clusters with an even number of nodes and recommend it for 2 node clusters, if they should provide higher availability. For clusters with an odd node count, we currently discourage the use of QDevices. The reason for this is the difference in the votes which the QDevice provides for each cluster type. Even numbered clusters get a single additional vote, which only increases availability, because if the QDevice itself fails, you are in the same position as with no QDevice at all.

On the other hand, with an odd numbered cluster size, the QDevice provides *(N-1)* votes — where *N* corresponds to the cluster node count. This alternative behavior makes sense; if it had only one additional vote, the cluster could get into a split-brain situation. This algorithm allows for all nodes but one (and naturally the QDevice itself) to fail. However, there are two drawbacks to this:

- If the QNet daemon itself fails, no other node may fail or the cluster immediately loses quorum. For example, in a cluster with 15 nodes, 7 could fail before the cluster becomes inquorate. But, if a QDevice is configured here and it itself fails, **no single node** of the 15 may fail. The QDevice acts almost as a single point of failure in this case.
- The fact that all but one node plus QDevice may fail sounds promising at first, but this may result in a mass recovery of HA services, which could overload the single remaining node. Furthermore, a Ceph server will stop providing services if only *((N-1)/2)* nodes or less remain online.

If you understand the drawbacks and implications, you can decide yourself if you want to use this technology in an odd numbered cluster setup.

5.12.3 QDevice-Net Setup

We recommend running any daemon which provides votes to corosync-qdevice as an unprivileged user. Proxmox VE and Debian provide a package which is already configured to do so. The traffic between the daemon and the cluster must be encrypted to ensure a safe and secure integration of the QDevice in Proxmox VE.

First, install the *corosync-qnetd* package on your external server

```
external# apt install corosync-qnetd
```

and the *corosync-qdevice* package on all cluster nodes

```
pve# apt install corosync-qdevice
```

After doing this, ensure that all the nodes in the cluster are online.

You can now set up your QDevice by running the following command on one of the Proxmox VE nodes:

```
pve# pvecm qdevice setup <QDEVICE-IP>
```

The SSH key from the cluster will be automatically copied to the QDevice.

Note
Make sure to setup key-based access for the root user on your external server, or temporarily allow root login with password during the setup phase. If you receive an error such as *Host key verification failed.* at this stage, running `pvecm updatecerts` could fix the issue.

After all the steps have successfully completed, you will see "Done". You can verify that the QDevice has been set up with:

```
pve# pvecm status

...

Votequorum information
~~~~~~~~~~~~~~~~~~~~~~
Expected votes:   3
Highest expected: 3
Total votes:      3
Quorum:           2
Flags:            Quorate Qdevice

Membership information
~~~~~~~~~~~~~~~~~~~~~~
    Nodeid      Votes    Qdevice Name
    0x00000001      1    A,V,NMW 192.168.22.180 (local)
    0x00000002      1    A,V,NMW 192.168.22.181
    0x00000000      1            Qdevice
```

QDevice Status Flags

The status output of the QDevice, as seen above, will usually contain three columns:

- `A` / `NA`: Alive or Not Alive. Indicates if the communication to the external `corosync-qnetd` daemon works.
- `V` / `NV`: If the QDevice will cast a vote for the node. In a split-brain situation, where the corosync connection between the nodes is down, but they both can still communicate with the external `corosync-qnetd` daemon, only one node will get the vote.
- `MW` / `NMW`: Master wins (`MV`) or not (`NMW`). Default is `NMW`, see [1].
- `NR`: QDevice is not registered.

Note
If your QDevice is listed as `Not Alive` (`NA` in the output above), ensure that port `5403` (the default port of the qnetd server) of your external server is reachable via TCP/IP!

5.12.4 Frequently Asked Questions

Tie Breaking

In case of a tie, where two same-sized cluster partitions cannot see each other but can see the QDevice, the QDevice chooses the partition which has the lowest node id and provides a vote to it. This behavior can be tuned with the configuration option `tie_breaker` (see `man corosync-qdevice` for more information) and requires a restart of `corosync-qdevice.service` on all nodes.

[1] `votequorum_qdevice_master_wins` manual page https://manpages.debian.org/stable/libvotequorum-dev/votequorum_qdevice_master_wins.3.en.html

Possible Negative Implications

For clusters with an even node count, there are no negative implications when using a QDevice. If it fails to work, it is the same as not having a QDevice at all.

Adding/Deleting Nodes After QDevice Setup

If you want to add a new node or remove an existing one from a cluster with a QDevice setup, you need to remove the QDevice first. After that, you can add or remove nodes normally. Once you have a cluster with an even node count again, you can set up the QDevice again as described previously.

Removing the QDevice

If you used the official `pvecm` tool to add the QDevice, you can remove it by running:

```
pve# pvecm qdevice remove
```

5.13 Corosync Configuration

The `/etc/pve/corosync.conf` file plays a central role in a Proxmox VE cluster. It controls the cluster membership and its network. For further information about it, check the corosync.conf man page:

```
man corosync.conf
```

For node membership, you should always use the `pvecm` tool provided by Proxmox VE. You may have to edit the configuration file manually for other changes. Here are a few best practice tips for doing this.

5.13.1 Edit corosync.conf

Editing the corosync.conf file is not always very straightforward. There are two on each cluster node, one in `/etc/pve/corosync.conf` and the other in `/etc/corosync/corosync.conf`. Editing the one in our cluster file system will propagate the changes to the local one, but not vice versa.

The configuration will get updated automatically, as soon as the file changes. This means that changes which can be integrated in a running corosync will take effect immediately. Thus, you should always make a copy and edit that instead, to avoid triggering unintended changes when saving the file while editing.

```
cp /etc/pve/corosync.conf /etc/pve/corosync.conf.new
```

Then, open the config file with your favorite editor, such as `nano` or `vim.tiny`, which come pre-installed on every Proxmox VE node.

Note
Always increment the *config_version* number after configuration changes; omitting this can lead to problems.

After making the necessary changes, create another copy of the current working configuration file. This serves as a backup if the new configuration fails to apply or causes other issues.

```
cp /etc/pve/corosync.conf /etc/pve/corosync.conf.bak
```

Then replace the old configuration file with the new one:

```
mv /etc/pve/corosync.conf.new /etc/pve/corosync.conf
```

You can check if the changes could be applied automatically, using the following commands:

```
systemctl status corosync
journalctl -b -u corosync
```

If the changes could not be applied automatically, you may have to restart the corosync service via:

```
systemctl restart corosync
```

On errors, check the troubleshooting section below.

5.13.2 Changing the Token Coefficient

The token coefficient can be configured in the `totem` section in `/etc/pve/corosync.conf`. If the token coefficient is not explicitly set, it defaults to 650 milliseconds. Since Proxmox VE 9.2, new clusters are created with a lower token coefficient of 125 milliseconds explicitly set in `/etc/pve/corosync.conf`. This reduces the time needed for reestablishing a new cluster membership after a node failure.

corosync uses the token coefficient to calculate several timeouts in relation to the cluster size [2], most importantly the token timeout and consensus timeout. corosync implements a token-passing protocol. The token timeout specifies how long a node waits for the token until it declares the token to be lost [3]. The consensus timeout [4] specifies the time nodes wait for a consensus on a new cluster membership. The sum of token and consensus timeouts defines the minimum time needed to reestablish a new cluster membership after a node goes offline.

Keeping the sum of token and consensus timeouts below 30 seconds reduces the time needed for reestablishing a new cluster membership after a node failure. When HA is enabled, it is especially important that this time stays below 45 seconds to ensure that a new cluster membership is formed before the watchdog timeout of 60 seconds expires, which would trigger a node fence. A safety margin below this 45 second limit is advisable so that transient timing variations do not push the cluster past the watchdog threshold. The recommended mechanism for lowering the token and consensus timeouts is lowering the token coefficient as explained below.

You can check the current token and consensus timeouts (in milliseconds) with the following command:

```
corosync-cmapctl | grep -Ew 'runtime.config.totem.token|runtime.config. ↩
   totem.consensus'
```

For example:

```
runtime.config.totem.consensus (u32) = 5940
runtime.config.totem.token (u32) = 4950
```

[2] `token_coefficient` in the corosync manual page https://manpages.debian.org/stable/corosync/corosync.conf.5.en.html#token_coefficient

[3] `token` in the corosync manual page https://manpages.debian.org/stable/corosync/corosync.conf.5.en.html#token

[4] `consensus` in the corosync manual page https://manpages.debian.org/stable/corosync/corosync.conf.5.en.html#consensus

The sum of these two values (10.89 seconds in the example) defines the minimum time needed to reestablish a new cluster membership after a node goes offline. Lowering the token coefficient is

- a suggested optimization if this value exceeds 30 seconds,
- recommended if it exceeds 40 seconds,
- strongly recommended if it exceeds 45 seconds.

To lower the token coefficient, first make sure your setup adheres to the network requirements, especially with regards to latency. Then:

- If the `token_coefficient` is not yet set explicitly to 125 milliseconds in corosync.conf, edit corosync.conf and add `token_coefficient: 125` to the `totem` section. Do not forget to increase the config_version.
- Otherwise, if 125 milliseconds is not low enough to keep the timeouts within the limits above, select a `token_coefficient` with which the token and consensus timeouts sum up to at most 45 seconds. By default, corosync computes the token and consensus timeouts (in milliseconds) according to the following formula:

```
token = 3000 + (number_of_nodes - 2) * token_coefficient
consensus = 1.2 * token
```

  Edit corosync.conf and set an appropriate `token_coefficient` option in the `totem` section. Do not forget to increase the config_version. Test your setup thoroughly for stability!

After adjusting the `token_coefficient` in `corosync.conf`, recent corosync versions will automatically adopt the new value for the cluster. For corosync versions below `3.1.10-pve1`, corosync needs to be restarted on all nodes for the change to take effect.

5.13.3 Troubleshooting

Issue: *quorum.expected_votes must be configured*

When corosync starts to fail and you get the following message in the system log:

```
[...]
corosync[1647]:  [QUORUM] Quorum provider: corosync_votequorum failed to  ↩
   initialize.
corosync[1647]:  [SERV  ] Service engine 'corosync_quorum' failed to load  ↩
   for reason
    'configuration error: nodelist or quorum.expected_votes must be  ↩
       configured!'
[...]
```

It means that the hostname you set for a corosync *ringX_addr* in the configuration could not be resolved.

Write Configuration When Not Quorate

If you need to change */etc/pve/corosync.conf* on a node with no quorum, and you understand what you are doing, use:

```
pvecm expected 1
```

This sets the expected vote count to 1 and makes the cluster quorate. You can then fix your configuration, or revert it back to the last working backup.

This is not enough if corosync cannot start anymore. In that case, it is best to edit the local copy of the corosync configuration in */etc/corosync/corosync.conf*, so that corosync can start again. Ensure that on all nodes, this configuration has the same content to avoid split-brain situations.

5.13.4 Corosync Configuration Glossary

ringX_addr
: This names the different link addresses for the Kronosnet connections between nodes.

5.14 Cluster Cold Start

It is obvious that a cluster is not quorate when all nodes are offline. This is a common case after a power failure.

Note
It is always a good idea to use an uninterruptible power supply (“UPS”, also called “battery backup”) to avoid this state, especially if you want HA.

On node startup, the `pve-guests` service is started and waits for quorum. Once quorate, it starts all guests which have the `onboot` flag set.

When you turn on nodes, or when power comes back after power failure, it is likely that some nodes will boot faster than others. Please keep in mind that guest startup is delayed until you reach quorum.

5.15 Guest VMID Auto-Selection

When creating new guests the web interface will ask the backend for a free VMID automatically. The default range for searching is `100` to `1000000` (lower than the maximal allowed VMID enforced by the schema).

Sometimes admins either want to allocate new VMIDs in a separate range, for example to easily separate temporary VMs with ones that choose a VMID manually. Other times its just desired to provided a stable length VMID, for which setting the lower boundary to, for example, `100000` gives much more room for.

To accommodate this use case one can set either lower, upper or both boundaries via the `datacenter.cfg` configuration file, which can be edited in the web interface under *Datacenter* → *Options*.

By default, the lowest free VMID in the range is suggested, so the VMIDs of destroyed guests get reused. This can be undesirable, for example, if external backup or monitoring systems identify guests by their VMID. With the `unique` option set, only VMIDs that have never been in use are suggested. For this, Proxmox VE records the VMID of every guest on creation and destruction in `/etc/pve/virtual-guest/used-guest-`, independent of whether `unique` is set. VMIDs of guests that were removed before Proxmox VE started recording them are not known and may still be suggested.

The range and the `unique` option only affect which VMID is suggested. Any other free VMID can still be chosen manually. With the `enforce` option set, they become a hard limit instead. New guests can then only use VMIDs from the range and, if `unique` is set as well, only VMIDs that have never been in use. Operations on existing guests, like destroying them or restoring a backup over them, are not restricted.

```
next-id: lower=10000,upper=20000,unique=1,enforce=1
```

Note
Consecutive VMIDs are stored as a single range, so the list of used VMIDs usually stays small. It only grows large if many VMIDs with gaps between them are used. If the list reaches 512 KiB, a warning is logged whenever it is updated. The list shrinks again as gaps get filled, since the ranges on both sides of a gap are merged into a single entry once all VMIDs in it have been used. With `unique` set, auto-selection suggests the lowest VMID that has never been used and thereby fills the gaps from the bottom up. To stay within the file size limit of the cluster file system, the smallest gaps between recorded VMIDs are marked as used once the list would exceed 768 KiB. As a result, they are no longer suggested with `unique` set and cannot be used for new guests anymore with `enforce` set as well.

5.16 Guest Migration

Migrating virtual guests to other nodes is a useful feature in a cluster. There are settings to control the behavior of such migrations. This can be done via the configuration file `datacenter.cfg` or for a specific migration via API or command-line parameters.

It makes a difference if a guest is online or offline, or if it has local resources (like a local disk).

For details about virtual machine migration, see the QEMU/KVM Migration Chapter.

For details about container migration, see the Container Migration Chapter.

5.16.1 Migration Type

The migration type defines if the migration data should be sent over an encrypted (`secure`) channel or an unencrypted (`insecure`) one. Setting the migration type to `insecure` means that the RAM content of a virtual guest is also transferred unencrypted, which can lead to information disclosure of critical data from inside the guest (for example, passwords or encryption keys).

Therefore, we strongly recommend using the secure channel if you do not have full control over the network and can not guarantee that no one is eavesdropping on it.

Note
Storage migration does not follow this setting. Currently, it always sends the storage content over a secure channel.

Encryption requires a lot of computing power, so this setting is often changed to `insecure` to achieve better performance. The impact on modern systems is lower because they implement AES encryption in hardware. The performance impact is particularly evident in fast networks, where you can transfer 10 Gbps or more.

5.16.2 Migration Network

By default, Proxmox VE uses the network in which cluster communication takes place to send the migration traffic. This is not optimal both because sensitive cluster traffic can be disrupted and this network may not have the best bandwidth available on the node.

Setting the migration network parameter allows the use of a dedicated network for all migration traffic. In addition to the memory, this also affects the storage traffic for offline migrations.

The migration network is set as a network using CIDR notation. This has the advantage that you don't have to set individual IP addresses for each node. Proxmox VE can determine the real address on the destination node from the network specified in the CIDR form. To enable this, the network must be specified so that each node has exactly one IP in the respective network.

Example

We assume that we have a three-node setup, with three separate networks. One for public communication with the Internet, one for cluster communication, and a very fast one, which we want to use as a dedicated network for migration.

A network configuration for such a setup might look as follows:

```
iface eno1 inet manual

# public network
auto vmbr0
iface vmbr0 inet static
    address 192.X.Y.57/24
    gateway 192.X.Y.1
    bridge-ports eno1
    bridge-stp off
    bridge-fd 0

# cluster network
auto eno2
iface eno2 inet static
    address  10.1.1.1/24

# fast network
auto eno3
iface eno3 inet static
    address  10.1.2.1/24
```

Here, we will use the network 10.1.2.0/24 as a migration network. For a single migration, you can do this using the `migration_network` parameter of the command-line tool:

```
# qm migrate 106 tre --online --migration_network 10.1.2.0/24
```

To configure this as the default network for all migrations in the cluster, set the `migration` property of the `/etc/pve/datacenter.cfg` file:

```
# use dedicated migration network
migration: secure,network=10.1.2.0/24
```

Note
The migration type must always be set when the migration network is set in `/etc/pve/datacenter.cfg`.

Chapter 6

Proxmox Cluster File System (pmxcfs)

The Proxmox Cluster file system ("pmxcfs") is a database-driven file system for storing configuration files, replicated in real time to all cluster nodes using `corosync`. We use this to store all Proxmox VE related configuration files.

Although the file system stores all data inside a persistent database on disk, a copy of the data resides in RAM. This imposes restrictions on the maximum size, which is currently 128 MiB. This is still enough to store the configuration of several thousand virtual machines.

This system provides the following advantages:

- Seamless replication of all configuration to all nodes in real time
- Provides strong consistency checks to avoid duplicate VM IDs
- Read-only when a node loses quorum
- Automatic updates of the corosync cluster configuration to all nodes
- Includes a distributed locking mechanism

6.1 POSIX Compatibility

The file system is based on FUSE, so the behavior is POSIX like. But some feature are simply not implemented, because we do not need them:

- You can just generate normal files and directories, but no symbolic links, ...
- You can't rename non-empty directories (because this makes it easier to guarantee that VMIDs are unique).
- You can't change file permissions (permissions are based on paths)
- `O_EXCL` creates were not atomic (like old NFS)
- `O_TRUNC` creates are not atomic (FUSE restriction)

6.2 File Access Rights

All files and directories are owned by user `root` and have group `www-data`. Only root has write permissions, but group `www-data` can read most files. Files below the following paths are only accessible by root:

```
/etc/pve/priv/
/etc/pve/nodes/${NAME}/priv/
```

6.3 Technology

We use the Corosync Cluster Engine for cluster communication, and SQlite for the database file. The file system is implemented in user space using FUSE.

6.4 File System Layout

The file system is mounted at:

```
/etc/pve
```

6.4.1 Files

`authkey.pub`	Public key used by the ticket system
`ceph.conf`	Ceph configuration file (note: /etc/ceph/ceph.conf is a symbolic link to this)
`cluster-id`	Random ID of the cluster, generated by pmxcfs and read-only (see Cluster ID)
`corosync.conf`	Corosync cluster configuration file (prior to Proxmox VE 4.x, this file was called cluster.conf)
`datacenter.cfg`	Proxmox VE datacenter-wide configuration (keyboard layout, proxy, . . .)
`domains.cfg`	Proxmox VE authentication domains
`firewall/cluster.fw`	Firewall configuration applied to all nodes
`firewall/<NAME>.fw`	Firewall configuration for individual nodes
`firewall/<VMID>.fw`	Firewall configuration for VMs and containers
`ha/crm_commands`	Displays HA operations that are currently being carried out by the CRM
`ha/manager_status`	JSON-formatted information regarding HA services on the cluster
`ha/resources.cfg`	Resources managed by high availability, and their current state
`ha/rules.cfg`	Rules putting constraints on the HA manager's scheduling of HA resources

multipath-overrides.conf	Hardware-specific multipath settings, in multipath.conf format, applied on all nodes
multipath.cfg	Proxmox VE cluster-wide multipath configuration (LUN entries)
nodes/<NAME>/config	Node-specific configuration
nodes/<NAME>/lxc/<VMID>.conf	VM configuration data for LXC containers
nodes/<NAME>/openvz/	Prior to Proxmox VE 4.0, used for container configuration data (deprecated, removed soon)
nodes/<NAME>/pve-ssl.key	Private SSL key for pve-ssl.pem
nodes/<NAME>/pve-ssl.pem	Public SSL certificate for web server (signed by cluster CA)
nodes/<NAME>/pveproxy-ssl.key	Private SSL key for pveproxy-ssl.pem (optional)
nodes/<NAME>/pveproxy-ssl.pem	Public SSL certificate (chain) for web server (optional override for pve-ssl.pem)
nodes/<NAME>/qemu-server/<VMID>.conf	VM configuration data for KVM VMs
priv/authkey.key	Private key used by ticket system
priv/authorized_keys	SSH keys of cluster members for authentication
priv/ceph*	Ceph authentication keys and associated capabilities
priv/known_hosts	SSH keys of the cluster members for verification
priv/lock/*	Lock files used by various services to ensure safe cluster-wide operations
priv/pve-root-ca.key	Private key of cluster CA
priv/shadow.cfg	Shadow password file for PVE Realm users
priv/storage/<STORAGE-ID>.pw	Contains the password of a storage in plain text
priv/tfa.cfg	Base64-encoded two-factor authentication configuration
priv/token.cfg	API token secrets of all tokens
pve-root-ca.pem	Public certificate of cluster CA
pve-www.key	Private key used for generating CSRF tokens
sdn/*	Shared configuration files for Software Defined Networking (SDN)
status.cfg	Proxmox VE external metrics server configuration
storage.cfg	Proxmox VE storage configuration
user.cfg	Proxmox VE access control configuration (users/groups/...)
virtual-guest/cpu-models.conf	For storing custom CPU models
virtual-guest/used-guest-ids	Guest IDs that have been in use, for optionally avoiding their reuse
vzdump.cron	Cluster-wide vzdump backup-job schedule

6.4.2 Symbolic links

Certain directories within the cluster file system use symbolic links, in order to point to a node's own configuration files. Thus, the files pointed to in the table below refer to different files on each node of the cluster.

local	nodes/<LOCAL_HOST_NAME>
lxc	nodes/<LOCAL_HOST_NAME>/lxc/

openvz	nodes/<LOCAL_HOST_NAME>/openvz/ (deprecated, removed soon)
qemu-server	nodes/<LOCAL_HOST_NAME>/qemu-server/

6.4.3 Special status files for debugging (JSON)

.version	File versions (to detect file modifications)
.members	Info about cluster members
.vmlist	List of all VMs
.clusterlog	Cluster log (last 50 entries)
.rrd	RRD data (most recent entries)

6.4.4 Enable/Disable debugging

You can enable verbose syslog messages with:

```
echo "1" >/etc/pve/.debug
```

And disable verbose syslog messages with:

```
echo "0" >/etc/pve/.debug
```

6.5 Recovery

If you have major problems with your Proxmox VE host, for example hardware issues, it could be helpful to copy the pmxcfs database file /var/lib/pve-cluster/config.db, and move it to a new Proxmox VE host. On the new host (with nothing running), you need to stop the pve-cluster service and replace the config.db file (required permissions 0600). Following this, adapt /etc/hostname and /etc/hosts according to the lost Proxmox VE host, then reboot and check (and don't forget your VM/CT data).

6.5.1 Remove Cluster Configuration

The recommended way is to reinstall the node after you remove it from your cluster. This ensures that all secret cluster/ssh keys and any shared configuration data is destroyed.

In some cases, you might prefer to put a node back to local mode without reinstalling, which is described in Separate A Node Without Reinstalling

6.5.2 Recovering/Moving Guests from Failed Nodes

For the guest configuration files in nodes/<NAME>/qemu-server/ (VMs) and nodes/<NAME>/lxc/ (containers), Proxmox VE sees the containing node <NAME> as the owner of the respective guest. This concept enables the usage of local locks instead of expensive cluster-wide locks for preventing concurrent guest configuration changes.

As a consequence, if the owning node of a guest fails (for example, due to a power outage, fencing event, etc.), a regular migration is not possible (even if all the disks are located on shared storage), because such a local lock on the (offline) owning node is unobtainable. This is not a problem for HA-managed guests, as Proxmox VE's High Availability stack includes the necessary (cluster-wide) locking and watchdog functionality to ensure correct and automatic recovery of guests from fenced nodes.

If a non-HA-managed guest has only shared disks (and no other local resources which are only available on the failed node), a manual recovery is possible by simply moving the guest configuration file from the failed node's directory in `/etc/pve/` to an online node's directory (which changes the logical owner or location of the guest).

For example, recovering the VM with ID `100` from an offline `node1` to another node `node2` works by running the following command as root on any member node of the cluster:

```
mv /etc/pve/nodes/node1/qemu-server/100.conf /etc/pve/nodes/node2/ ↩
   qemu-server/
```



Warning
Before manually recovering a guest like this, make absolutely sure that the failed source node is really powered off/fenced. Otherwise Proxmox VE's locking principles are violated by the `mv` command, which can have unexpected consequences.



Warning
Guests with local disks (or other local resources which are only available on the offline node) are not recoverable like this. Either wait for the failed node to rejoin the cluster or restore such guests from backups.

Chapter 7

Proxmox VE Storage

The Proxmox VE storage model is very flexible. Virtual machine images can either be stored on one or several local storages, or on shared storage like NFS or iSCSI (NAS, SAN). There are no limits, and you may configure as many storage pools as you like. You can use all storage technologies available for Debian Linux.

One major benefit of storing VMs on shared storage is the ability to live-migrate running machines without any downtime, as all nodes in the cluster have direct access to VM disk images. There is no need to copy VM image data, so live migration is very fast in that case.

The storage library (package `libpve-storage-perl`) uses a flexible plugin system to provide a common interface to all storage types. This can be easily adopted to include further storage types in the future.

7.1 Storage Types

There are basically two different classes of storage types:

File level storage
File level based storage technologies allow access to a fully featured (POSIX) file system. They are in general more flexible than any Block level storage (see below), and allow you to store content of any type. ZFS is probably the most advanced system, and it has full support for snapshots and clones.

Block level storage
Allows to store large *raw* images. It is usually not possible to store other files (ISO, backups, ..) on such storage types. Most modern block level storage implementations support snapshots and clones. Ceph RADOS is a distributed systems, replicating storage data to different nodes that can be accessed as RBD (RADOS Block Device).

Table 7.1: Available storage types

Description	Plugin type	Level	Shared	Snapshots	Stable
ZFS (local)	`zfspool`	both[1]	no	yes	yes
Directory	`dir`	file	no	yes[2]	yes
BTRFS	`btrfs`	file	no	yes	TP[5]

Table 7.1: (continued)

Description	Plugin type	Level	Shared	Snapshots	Stable
NFS	`nfs`	file	yes	yes[2]	yes
CIFS	`cifs`	file	yes	yes[2]	yes
Proxmox Backup	`pbs`	both	yes	n/a	yes
CephFS	`cephfs`	file	yes	n/a	yes
LVM	`lvm`	block	no[3]	yes[4]	yes
LVM-thin	`lvmthin`	block	no	yes	yes
iSCSI/kernel	`iscsi`	block	yes[3]	yes[4]	yes
iSCSI/libiscsi	`iscsidirect`	block	yes[3]	yes[4]	yes
NVMe-oF	`nvmeof`	block	yes[3]	yes[4]	yes
FC/SAS	`native`[6]	block	yes[3]	yes[4]	yes
Ceph/RBD	`rbd`	block	yes	yes	yes
ZFS over iSCSI	`zfs`	block	yes	yes	yes

[1]: Disk images for VMs are stored in ZFS volume (zvol) datasets, which provide block device functionality.

[2]: On file based storages, snapshots are possible with the *qcow2* format, either using the internal snapshot function, or snapshots as volume chains[4]. Creating and deleting internal *qcow2* snapshots will block a running VM and is not an efficient operation. The performance is particularly bad with network storages like NFS. On some setups and for large disks (multiple hundred GiB or TiB sized), these operations may take several minutes, or in extreme cases, even hours. If your setup is affected, create and remove snapshots while the VM is shut down, expecting a long task duration.

[3]: With iSCSI, NVMe over Fabrics (NVMe-oF), Fibre Channel (FC), or SAS block storage as shared storage in a cluster, LVM is used to split the LUN or namespace into virtual disks. A LUN is usually reachable over several paths; Multipath describes how Proxmox VE manages them in a cluster. FC and SAS LUNs need a multipath entry. NVMe-oF namespaces use the kernel's native multipath instead, see NVMe over Fabrics.

[4]: Since Proxmox VE 9, snapshots as a volume chain have been available for VMs. These snapshots use separate volumes for the snapshot data and layer them. For more details, see the description for `snapshot-as-volume-chain` in the LVM configuration section.

[5] Technology preview with best-effort support.

[6] Fibre Channel (FC) and SAS block storage is handled directly by the host without a dedicated storage plugin.

7.1.1 Thin Provisioning

A number of storages, and the QEMU image format `qcow2`, support *thin provisioning*. With thin provisioning activated, only the blocks that the guest system actually use will be written to the storage.

Say for instance you create a VM with a 32GB hard disk, and after installing the guest system OS, the root file system of the VM contains 3 GB of data. In that case only 3GB are written to the storage, even if the guest VM sees a 32GB hard drive. In this way thin provisioning allows you to create disk images which are larger than the currently available storage blocks. You can create large disk images for your VMs, and when the need arises, add more disks to your storage without resizing the VMs' file systems.

All storage types which have the "Snapshots" feature also support thin provisioning.



Caution
If a storage runs full, all guests using volumes on that storage receive IO errors. This can cause file system inconsistencies and may corrupt your data. So it is advisable to avoid over-provisioning of your storage resources, or carefully observe free space to avoid such conditions.

7.2 Storage Configuration

All Proxmox VE related storage configuration is stored within a single text file at `/etc/pve/storage.cfg`. As this file is within `/etc/pve/`, it gets automatically distributed to all cluster nodes. So all nodes share the same storage configuration.

Sharing storage configuration makes perfect sense for shared storage, because the same "shared" storage is accessible from all nodes. But it is also useful for local storage types. In this case such local storage is available on all nodes, but it is physically different and can have totally different content.

To add a storage in the web UI, use **Datacenter** → **Storage** → **Add**, which opens a wizard. Its first step lists the storage types and guided setups, grouped and with a search field. The next steps hold the settings of the chosen entry.

For shared LVM on a SAN LUN or an NVMe namespace, choose **Shared LVM on iSCSI**, **Shared LVM on Fibre Channel** or **Shared LVM on NVMe over Fabrics** in the wizard. These setups create the storages that are needed and enable multipath for a LUN.

7.2.1 Storage Pools

Each storage pool has a `<type>`, and is uniquely identified by its `<STORAGE_ID>`. A pool configuration looks like this:

```
<type>: <STORAGE_ID>
        <property> <value>
        <property> <value>
        <property>
        ...
```

The `<type>: <STORAGE_ID>` line starts the pool definition, which is then followed by a list of properties. Most properties require a value. Some have reasonable defaults, in which case you can omit the value.

To be more specific, take a look at the default storage configuration after installation. It contains one special local storage pool named `local`, which refers to the directory `/var/lib/vz` and is always available. The Proxmox VE installer creates additional storage entries depending on the storage type chosen at installation time.

Default storage configuration (/etc/pve/storage.cfg)

```
dir: local
        path /var/lib/vz
        content iso,vztmpl,backup
```

```
# default image store on LVM based installation
lvmthin: local-lvm
        thinpool data
        vgname pve
        content rootdir,images

# default image store on ZFS based installation
zfspool: local-zfs
        pool rpool/data
        sparse
        content images,rootdir
```



Caution

It is problematic to have multiple storage configurations pointing to the exact same underlying storage. Such an *aliased* storage configuration can lead to two different volume IDs (*volid*) pointing to the exact same disk image. Proxmox VE expects that the images' volume IDs point to, are unique. Choosing different content types for *aliased* storage configurations can be fine, but is not recommended.

7.2.2 Common Storage Properties

A few storage properties are common among different storage types.

nodes
List of cluster node names where this storage is usable/accessible. One can use this property to restrict storage access to a limited set of nodes.

content
A storage can support several content types, for example virtual disk images, cdrom iso images, container templates or container root directories. Not all storage types support all content types. One can set this property to select what this storage is used for.

images
QEMU/KVM VM images. This allows all volume types of VMs, that is `vm-vol` and `vm-state`.

rootdir
Allow to store container data. This allows all volume types of containers, which currently is only `ct-vol`.

vm-vol
The disks of VMs, including EFI disks, TPM states and cloud-init drives. Use this instead of `images` for a storage that should not hold the saved states of VMs.

vm-state
The saved states of VMs, as created by a snapshot that includes the RAM and by hibernation. Use this instead of `images` for a storage that should only hold these.

ct-vol
The volumes of containers.

vztmpl
Container templates.

backup
Backup files (`vzdump`).

iso
ISO images

snippets
Snippet files, for example guest hook scripts

import
OVAs and VM disk images that can be imported from this storage

See Volume Types of Guests for how `images` and `rootdir` relate to `vm-vol`, `vm-state` and `ct-vol`.

shared
Indicate that this is a single storage with the same contents on all nodes (or all listed in the *nodes* option). It will not make the contents of a local storage automatically accessible to other nodes, it just marks an already shared storage as such!

disable
You can use this flag to disable the storage completely.

prune-backups
Retention options for backups. For details, see Backup Retention.

format
Default image format (`raw|qcow2|vmdk`)

preallocation
Preallocation mode (`off|metadata|falloc|full`) for `raw` and `qcow2` images on file-based storages. The default is `metadata`, which is treated like `off` for `raw` images. When using network storages in combination with large `qcow2` images, using `off` can help to avoid timeouts.



Warning
It is not advisable to use the same storage pool on different Proxmox VE clusters. Some storage operation need exclusive access to the storage, so proper locking is required. While this is implemented within a cluster, it does not work between different clusters.

7.2.3 Volume Types of Guests

The content types `images` and `rootdir` allow all volumes of VMs or of containers on a storage. To allow only some of them, set the specific volume types as content types instead.

Table 7.2: Content types for the volumes of guests

Content type	Web interface	Allows
`images`	Disk image	All volumes of VMs: `vm-vol` and `vm-state`
`vm-vol`	VM Disk	Disks of VMs, including EFI disks, TPM states and cloud-init drives
`vm-state`	VM State	Saved states of VMs, from snapshots that include the RAM and from hibernation
`rootdir`	Container	All volumes of containers, which currently is only `ct-vol`
`ct-vol`	Container Volume	Root disks and mount points of containers

Existing storages do not need to be changed. Use the volume types if a storage should hold only some of the volumes of guests. For example, to keep the saved states of VMs off a storage that is used for VM disks and containers:

```
# pvesm set <STORAGE_ID> --content vm-vol,rootdir
```

Or to add a directory storage that only holds the saved states of VMs:

```
# pvesm add dir vmstate --path /mnt/vmstate --content vm-state
```

In the web interface, tick *Advanced* in the dialog for adding or editing a storage. The *Content* selector then also lists the volume types. Select *VM Disk* or *VM State* instead of *Disk image*, or *Container Volume* instead of *Container*. A volume type has no effect next to the content type that already allows it, for example `vm-vol` next to `images`, and is dropped from the configuration.

Where the state of a VM is saved if the storages of its disks do not allow `vm-state` is described for the vmstatestorage option.

Note
A volume type can only be added to a storage if all nodes of the cluster are online and run `pve-manager` in version 9.2.29 or newer. Older versions cannot read a content list with these types and use the default content types of the storage type instead.

Changing the content types of a storage does not move or remove the volumes that are already on it. A VM cannot be started while one of its disks is on a storage that does not allow VM disks, so move such disks to another storage first.

7.3 Volumes

We use a special notation to address storage data. When you allocate data from a storage pool, it returns such a volume identifier. A volume is identified by the `<STORAGE_ID>`, followed by a storage type dependent volume name, separated by colon. A valid `<VOLUME_ID>` looks like:

```
local:230/example-image.raw

local:iso/debian-501-amd64-netinst.iso

local:vztmpl/debian-5.0-joomla_1.5.9-1_i386.tar.gz

iscsi-storage:0.0.2.scsi-14 ↩
   f504e46494c4500494b5042546d2d646744372d31616d61
```

To get the file system path for a `<VOLUME_ID>` use:

```
pvesm path <VOLUME_ID>
```

7.3.1 Volume Ownership

There exists an ownership relation for `image` type volumes. Each such volume is owned by a VM or Container. For example volume `local:230/example-image.raw` is owned by VM 230. Most storage backends encodes this ownership information into the volume name.

When you remove a VM or Container, the system also removes all associated volumes which are owned by that VM or Container.

7.4 Using the Command-line Interface

It is recommended to familiarize yourself with the concept behind storage pools and volume identifiers, but in real life, you are not forced to do any of those low level operations on the command line. Normally, allocation and removal of volumes is done by the VM and Container management tools.

Nevertheless, there is a command-line tool called `pvesm` ("Proxmox VE Storage Manager"), which is able to perform common storage management tasks.

7.4.1 Examples

Add storage pools

```
pvesm add <TYPE> <STORAGE_ID> <OPTIONS>
pvesm add dir <STORAGE_ID> --path <PATH>
pvesm add nfs <STORAGE_ID> --path <PATH> --server <SERVER> --export  ↩
   <EXPORT>
pvesm add lvm <STORAGE_ID> --vgname <VGNAME>
pvesm add iscsi <STORAGE_ID> --portal <HOST[:PORT]> --target <TARGET ↩
   >
```

Disable storage pools

```
pvesm set <STORAGE_ID> --disable 1
```

Enable storage pools

```
pvesm set <STORAGE_ID> --disable 0
```

Change/set storage options

```
pvesm set <STORAGE_ID> <OPTIONS>
pvesm set <STORAGE_ID> --shared 1
pvesm set local --format qcow2
pvesm set <STORAGE_ID> --content iso
```

Remove storage pools. This does not delete any data, and does not disconnect or unmount anything. It just removes the storage configuration.

```
pvesm remove <STORAGE_ID>
```

Allocate volumes

```
pvesm alloc <STORAGE_ID> <VMID> <name> <size> [--format <raw|qcow2>]
```

Allocate a 4G volume in local storage. The name is auto-generated if you pass an empty string as `<name>`

```
pvesm alloc local <VMID> '' 4G
```

Free volumes

```
pvesm free <VOLUME_ID>
```



Warning
This really destroys all volume data.

List storage status

```
pvesm status
```

List storage contents

```
pvesm list <STORAGE_ID> [--vmid <VMID>]
```

List volumes allocated by VMID

```
pvesm list <STORAGE_ID> --vmid <VMID>
```

List iso images

```
pvesm list <STORAGE_ID> --content iso
```

List container templates

```
pvesm list <STORAGE_ID> --content vztmpl
```

Show file system path for a volume

```
pvesm path <VOLUME_ID>
```

Exporting the volume `local:103/vm-103-disk-0.qcow2` to the file `target`. This is mostly used internally with `pvesm import`. The stream format qcow2+size is different to the qcow2 format. Consequently, the exported file cannot simply be attached to a VM. This also holds for the other formats.

```
pvesm export local:103/vm-103-disk-0.qcow2 qcow2+size target --with- ↩
   snapshots 1
```

7.5 Directory Backend

Storage pool type: `dir`

Proxmox VE can use local directories or locally mounted shares for storage. A directory is a file level storage, so you can store any content type like virtual disk images, containers, templates, ISO images or backup files.

Note
You can mount additional storages via standard linux `/etc/fstab`, and then define a directory storage for that mount point. This way you can use any file system supported by Linux.

This backend assumes that the underlying directory is POSIX compatible, but nothing else. This implies that you cannot create snapshots at the storage level. But there exists a workaround for VM images using the `qcow2` file format, because that format supports snapshots internally.

Tip
Some storage types do not support `O_DIRECT`, so you can't use cache mode `none` with such storages. Simply use cache mode `writeback` instead.

We use a predefined directory layout to store different content types into different sub-directories. This layout is used by all file level storage backends.

Table 7.3: Directory layout

Content type	Subdir
VM images	`images/<VMID>/`
ISO images	`template/iso/`
Container templates	`template/cache/`
Backup files	`dump/`
Snippets	`snippets/`
Import	`import/`

7.5.1 Configuration

This backend supports all common storage properties, and adds two additional properties. The `path` property is used to specify the directory. This needs to be an absolute file system path.

The optional `content-dirs` property allows for the default layout to be changed. It consists of a comma-separated list of identifiers in the following format:

`vtype=path`

Where `vtype` is one of the allowed content types for the storage, and `path` is a path relative to the mountpoint of the storage.

Configuration Example (/etc/pve/storage.cfg)

```
dir: backup
        path /mnt/backup
        content backup
        prune-backups keep-last=7
        max-protected-backups 3
        content-dirs backup=custom/backup/dir
```

The above configuration defines a storage pool called `backup`. That pool can be used to store up to 7 regular backups (`keep-last=7`) and 3 protected backups per VM. The real path for the backup files is `/mnt/backup/custom/backup/dir/...`.

7.5.2 File naming conventions

This backend uses a well defined naming scheme for VM images:

`vm-<VMID>-<NAME>.<FORMAT>`

<VMID>
This specifies the owner VM.

<NAME>
This can be an arbitrary name (`ascii`) without white space. The backend uses `disk-[N]` as default, where `[N]` is replaced by an integer to make the name unique.

<FORMAT>
Specifies the image format (`raw|qcow2|vmdk`).

When you create a VM template, all VM images are renamed to indicate that they are now read-only, and can be used as a base image for clones:

`base-<VMID>-<NAME>.<FORMAT>`

Note
Such base images are used to generate cloned images. So it is important that those files are read-only, and never get modified. The backend changes the access mode to `0444`, and sets the immutable flag (`chattr +i`) if the storage supports that.

7.5.3 Storage Features

As mentioned above, most file systems do not support snapshots out of the box. To workaround that problem, this backend is able to use `qcow2` internal snapshot capabilities.

Same applies to clones. The backend uses the `qcow2` base image feature to create clones.

Table 7.4: Storage features for backend `dir`

Content types	Image formats	Shared	Snapshots	Clones
`images rootdir vztmpl iso backup snippets`	`raw qcow2 vmdk subvol`	no	qcow2	qcow2

7.5.4 Examples

Please use the following command to allocate a 4GB image on storage `local`:

```
# pvesm alloc local 100 vm-100-disk10.raw 4G
Formatting '/var/lib/vz/images/100/vm-100-disk10.raw', fmt=raw size ↩
   =4294967296
successfully created 'local:100/vm-100-disk10.raw'
```

Note
The image name must conform to above naming conventions.

The real file system path is shown with:

```
# pvesm path local:100/vm-100-disk10.raw
/var/lib/vz/images/100/vm-100-disk10.raw
```

And you can remove the image with:

```
# pvesm free local:100/vm-100-disk10.raw
```

7.6 NFS Backend

Storage pool type: `nfs`

The NFS backend is based on the directory backend, so it shares most properties. The directory layout and the file naming conventions are the same. The main advantage is that you can directly configure the NFS server properties, so the backend can mount the share automatically. There is no need to modify `/etc/fstab`. The backend can also test if the server is online, and provides a method to query the server for exported shares.

7.6.1 Configuration

The backend supports all common storage properties, except the shared flag, which is always set. Additionally, the following properties are used to configure the NFS server:

server
Server IP or DNS name. To avoid DNS lookup delays, it is usually preferable to use an IP address instead of a DNS name - unless you have a very reliable DNS server, or list the server in the local `/etc/hosts` file.

export
NFS export path (as listed by `pvesm nfsscan`).

You can also set NFS mount options:

path
The local mount point (defaults to `/mnt/pve/<STORAGE_ID>/`).

content-dirs
Overrides for the default directory layout. Optional.

options
NFS mount options (see `man nfs`).

Configuration Example (/etc/pve/storage.cfg)

```
nfs: iso-templates
        path /mnt/pve/iso-templates
        server 10.0.0.10
        export /space/iso-templates
        options vers=3,soft
        content iso,vztmpl
```

Tip
After an NFS request times out, NFS request are retried indefinitely by default. This can lead to unexpected hangs on the client side. For read-only content, it is worth to consider the NFS `soft` option, which limits the number of retries to three.

7.6.2 Storage Features

NFS does not support snapshots, but the backend uses `qcow2` features to implement snapshots and cloning.

Table 7.5: Storage features for backend `nfs`

Content types	Image formats	Shared	Snapshots	Clones

`images`
`rootdir`
`vztmpl iso`
`backup`
`snippets`
	`raw qcow2`
	`vmdk`
		yes	qcow2	qcow2

7.6.3 Examples

You can get a list of exported NFS shares with:

```
# pvesm scan nfs <server>
```

7.7 CIFS Backend

Storage pool type: `cifs`

The CIFS backend extends the directory backend, so that no manual setup of a CIFS mount is needed. Such a storage can be added directly through the Proxmox VE API or the web UI, with all our backend advantages, like server heartbeat check or comfortable selection of exported shares.

7.7.1 Configuration

The backend supports all common storage properties, except the shared flag, which is always set. Additionally, the following CIFS special properties are available:

server
Server IP or DNS name. Required.

Tip
To avoid DNS lookup delays, it is usually preferable to use an IP address instead of a DNS name - unless you have a very reliable DNS server, or list the server in the local `/etc/hosts` file.

share
CIFS share to use (get available ones with `pvesm scan cifs <address>` or the web UI). Required.

username
The username for the CIFS storage. Optional, defaults to ‘guest’.

password
The user password. Optional. It will be saved in a file only readable by root (`/etc/pve/priv/storage/`

domain
Sets the user domain (workgroup) for this storage. Optional.

smbversion
SMB protocol version. Optional, when set to `default` or when unset, negotiates the highest SMB2+ version supported by both the client and server. SMB1 is not supported due to security issues.

path
The local mount point. Optional, defaults to `/mnt/pve/<STORAGE_ID>/`.

content-dirs
Overrides for the default directory layout. Optional.

options
Additional CIFS mount options (see `man mount.cifs`). Some options are set automatically and shouldn't be set here. Proxmox VE will always set the option `soft`. Depending on the configuration, these options are set automatically: `username`, `credentials`, `guest`, `domain`, `vers`.

subdir
The subdirectory of the share to mount. Optional, defaults to the root directory of the share.

Configuration Example (/etc/pve/storage.cfg)

```
cifs: backup
        path /mnt/pve/backup
        server 10.0.0.11
        share VMData
        content backup
        options noserverino,echo_interval=30
        username anna
        smbversion 3
        subdir /data
```

7.7.2 Storage Features

CIFS does not support snapshots on a storage level. But you may use `qcow2` backing files if you still want to have snapshots and cloning features available.

Table 7.6: Storage features for backend `cifs`

Content types	Image formats	Shared	Snapshots	Clones

`images`
`rootdir`
`vztmpl iso`
`backup`
`snippets`
	`raw qcow2`
	`vmdk`
		yes	qcow2	qcow2

7.7.3 Examples

You can get a list of exported CIFS shares with:

```
# pvesm scan cifs <server> [--username <username>] [--password]
```

Then you can add one of these shares as a storage to the whole Proxmox VE cluster with:

```
# pvesm add cifs <storagename> --server <server> --share <share> [-- ↩
   username <username>] [--password]
```

7.8 Proxmox Backup Server

Storage pool type: `pbs`

This backend allows direct integration of a Proxmox Backup Server into Proxmox VE like any other storage.

A Proxmox Backup storage can be added directly through the Proxmox VE API, CLI or the web interface.

7.8.1 Configuration

The backend supports all common storage properties, except the shared flag, which is always set. Additionally, the following special properties to Proxmox Backup Server are available:

server
Server IP or DNS name. Required.

port
Use this port instead of the default one, i.e. `8007`. Optional.

username
The username for the Proxmox Backup Server storage. Required.

Tip
Do not forget to add the realm to the username. For example, `root@pam` or `archiver@pbs`.

---

password
The user password. The value will be saved in a file under `/etc/pve/priv/storage/<STORAGE-ID` with access restricted to the root user. Required.

datastore
The ID of the Proxmox Backup Server datastore to use. Required.

fingerprint
The fingerprint of the Proxmox Backup Server API TLS certificate. You can get it in the Servers Dashboard or using the `proxmox-backup-manager cert info` command. Required for self-signed certificates or any other one where the host does not trusts the servers CA.

encryption-key
A key to encrypt the backup data from the client side. Currently only non-password protected (no key derive function (kdf)) are supported. Will be saved in a file under `/etc/pve/priv/storage/<STORAG` with access restricted to the root user. Use the magic value `autogen` to automatically generate a new one using `proxmox-backup-client key create --kdf none <path>`. Optional.

master-pubkey
A public RSA key used to encrypt the backup encryption key as part of the backup task. Will be saved in a file under `/etc/pve/priv/storage/<STORAGE-ID>.master.pem` with access restricted to the root user. The encrypted copy of the backup encryption key will be appended to each backup and stored on the Proxmox Backup Server instance for recovery purposes. Optional, requires `encryption-key`.

Configuration Example (/etc/pve/storage.cfg)

```
pbs: backup
        datastore main
        server enya.proxmox.com
        content backup
        fingerprint 09:54:ef:..snip..:88:af:47:fe:4c:3b:cf:8b:26:88:0b:4e:3 ↩
           c:b2
        prune-backups keep-all=1
        username archiver@pbs
        encryption-key a9:ee:c8:02:13:..snip..:2d:53:2c:98
        master-pubkey 1
```

7.8.2 Storage Features

Proxmox Backup Server only supports backups, they can be block-level or file-level based. Proxmox VE uses block-level for virtual machines and file-level for container.

Table 7.7: Storage features for backend `pbs`

Content types	Image formats	Shared	Snapshots	Clones
`backup`	n/a	yes	n/a	n/a

7.8.3 Encryption



Optionally, you can configure client-side encryption with AES-256 in GCM mode. Encryption can be configured either via the web interface, or on the CLI with the `encryption-key` option (see above). The key will be saved in the file `/etc/pve/priv/storage/<STORAGE-ID>.enc`, which is only accessible by the root user.

Warning

Without their key, backups will be inaccessible. Thus, you should keep keys ordered and in a place that is separate from the contents being backed up. It can happen, for example, that you back up an entire system, using a key on that system. If the system then becomes inaccessible for any reason and needs to be restored, this will not be possible as the encryption key will be lost along with the broken system.

It is recommended that you keep your key safe, but easily accessible, in order for quick disaster recovery. For this reason, the best place to store it is in your password manager, where it is immediately recoverable. As a backup to this, you should also save the key to a USB flash drive and store that in a secure place. This way, it is detached from any system, but is still easy to recover from, in case of emergency. Finally, in preparation for the worst case scenario, you should also consider keeping a paper copy of your key locked away in a safe place. The `paperkey` subcommand can be used to create a QR encoded version of your key. The following command sends the output of the `paperkey` command to a text file, for easy printing.

```
# proxmox-backup-client key paperkey /etc/pve/priv/storage/<STORAGE-ID>.enc ↩
    --output-format text > qrkey.txt
```

Additionally, it is possible to use a single RSA master key pair for key recovery purposes: configure all clients doing encrypted backups to use a single public master key, and all subsequent encrypted backups will contain a RSA-encrypted copy of the used AES encryption key. The corresponding private master key allows recovering the AES key and decrypting the backup even if the client system is no longer available.



Warning
The same safe-keeping rules apply to the master key pair as to the regular encryption keys. Without a copy of the private key recovery is not possible! The `paperkey` command supports generating paper copies of private master keys for storage in a safe, physical location.

For disaster recovery at another site, for example from a copy of the backups that a sync job made to a second Proxmox Backup Server at that site, the restoring cluster needs the key as well. Add the datastore of the copy as storage there with the same key, for example with `pvesm add pbs <storage-id> ... --encryption-key <key-file>`, or add the key to an existing storage with `pvesm set <storage-id> --encryption-key <key-file>`. Keep the key outside the site it protects: removing a storage also deletes its key file.

Because the encryption is managed on the client side, you can use the same datastore on the server for unencrypted backups and encrypted backups, even if they are encrypted with different keys. However, deduplication between backups with different keys is not possible, so it is often better to create separate datastores.

Note
Do not use encryption if there is no benefit from it, for example, when you are running the server locally in a trusted network. It is always easier to recover from unencrypted backups.

7.8.4 Example: Add Storage over CLI

You can get a list of available Proxmox Backup Server datastores with:

```
# pvesm scan pbs <server> <username> [--password <string>] [--fingerprint < ↩
   string>]
```

Then you can add one of these datastores as a storage to the whole Proxmox VE cluster with:

```
# pvesm add pbs <id> --server <server> --datastore <datastore> --username < ↩
   username> --fingerprint 00:B4:... --password
```

7.9 Local ZFS Pool Backend

Storage pool type: `zfspool`

This backend allows you to access local ZFS pools (or ZFS file systems inside such pools).

7.9.1 Configuration

The backend supports the common storage properties `content`, `nodes`, `disable`, and the following ZFS specific properties:

pool
Select the ZFS pool/filesystem. All allocations are done within that pool.

blocksize
Set ZFS blocksize parameter.

sparse
Use ZFS thin-provisioning. A sparse volume is a volume whose reservation is not equal to the volume size.

mountpoint
The mount point of the ZFS pool/filesystem. Changing this does not affect the `mountpoint` property of the dataset seen by `zfs`. Defaults to `/<pool>`.

Configuration Example (/etc/pve/storage.cfg)

```
zfspool: vmdata
        pool tank/vmdata
        content rootdir,images
        sparse
```

7.9.2 File naming conventions

The backend uses the following naming scheme for VM images:

```
vm-<VMID>-<NAME>       // normal VM images
base-<VMID>-<NAME>     // template VM image (read-only)
subvol-<VMID>-<NAME>   // subvolumes (ZFS filesystem for containers)
```

<VMID>
This specifies the owner VM.

<NAME>
This can be an arbitrary name (`ascii`) without white space. The backend uses `disk[N]` as default, where `[N]` is replaced by an integer to make the name unique.

7.9.3 Storage Features

ZFS is probably the most advanced storage type regarding snapshot and cloning. The backend uses ZFS datasets for both VM images (format `raw`) and container data (format `subvol`). ZFS properties are inherited from the parent dataset, so you can simply set defaults on the parent dataset.

Table 7.8: Storage features for backend `zfs`

Content types	Image formats	Shared	Snapshots	Clones
`images rootdir`	`raw subvol`	no	yes	yes

7.9.4 Encryption

ZFS supports encryption of dataset hierarchies. Each encrypted dataset, is either an `encryption_root`, storing the properties for encryption itself or descendant of its `encryption_root` - see the `zfs-load-key(8` manpage for details.

Sending and receiving encrypted datasets is subject to constraints as some encryption parameters (initialization vectors for the symmetric ciphers) need to be either transferred with the data, breaking inheriting the encryption properties on the receiving side, or need to be recreated on target, requiring the data to be sent unencrypted - see the `zfs-recv(8)` manpage for details.

For migration and storage replication of encrypted datasets in Proxmox VE, the data is sent without the encryption properties, and the state of encryption is determined by the target.

If you want to send and receive encrypted ZFS datasets, you need to ensure that all involved storages on all nodes are encrypted.

7.9.5 Examples

It is recommended to create an extra ZFS file system to store your VM images:

```
# zfs create tank/vmdata
```

To enable compression on that newly allocated file system:

```
# zfs set compression=on tank/vmdata
```

You can get a list of available ZFS filesystems with:

```
# pvesm scan zfs
```

7.10 LVM Backend

Storage pool type: `lvm`

LVM is a lightweight software layer that sits on top of hard disks and partitions. It can be used to divide available disk space into smaller logical volumes.

Another use case is placing LVM on top of a large iSCSI LUN (Logical Unit Number) or a SAN (Storage Area Network) connected via Fibre Channel. This allows you to easily manage the space on the iSCSI LUN, which would otherwise be impossible because the iSCSI specification does not define a management interface for space allocation.

7.10.1 Configuration

The LVM backend supports the common storage properties `content`, `nodes`, `disable`, and the following LVM specific properties:

`vgname`
: LVM volume group name. This must point to an existing volume group.

base
Base volume. This volume is automatically activated before accessing the storage. This is mostly useful when the LVM volume group resides on a remote iSCSI server or on an NVMe over Fabrics namespace.

saferemove
Called "Wipe Removed Volumes" in the web UI. Zero-out data when removing LVs. When removing a volume, this makes sure that all data gets erased and cannot be accessed by other LVs created later (which happen to be assigned the same physical extents). This is a costly operation, but may be required as a security measure in certain environments.

Storage devices that support the "write zeroes" operation use it to zero blocks. Otherwise, zeroes are written manually. The volume is processed range by range, according to `saferemove-stepsize`.

on-volume-remove
Configure additional actions to run before an LV is removed. The LV is first renamed to `del-*`; if cleanup fails, it is kept and renamed to `failed-<N>-del-*`, so it can be inspected, cleaned up manually, or removed explicitly.

Set `discard=1` to issue discard (TRIM) requests for the LV's blocks before the LV is removed, so thin-provisioned backing storage, such as a SAN LUN, can reclaim space the LV occupied. This is called "Discard Removed Volumes" in the web UI. Configuring the discard option fails if any backing device in the LV's volume group is detected as not supporting it.

If `saferemove` and `discard` are both enabled, the LV is processed range by range. Ranges are zeroed until reaching a boundary aligned with both the zeroing step size and the discard granularity. The accumulated range is then discarded before processing continues. This prevents complete discard chunks from being skipped and avoids allocating the whole LV with zeroes on thin-provisioned backing storage before the space can be reclaimed again.

saferemove-stepsize
Wipe step size in MiB, capped to the maximum step size supported by the underlying storage. Up to 32 MiB (maximum) by default.

saferemove_throughput
Limits wipe throughput. If the backing storage supports the "write zeroes" operation, throughput is unlimited by default. Otherwise, manually written zeroes are limited to 10 MiB/s by default.

snapshot-as-volume-chain
Set this flag to enable snapshot support for virtual machines on LVM with a volume backing chain. With this setting, taking a snapshot persists the current state under the snapshot's name and starts a new volume backed by the snapshot.

A volume based on a snapshot references its parent snapshot volume as its backing volume and records only the differences to that backing volume. Snapshot volumes are currently thick-provisioned LVM logical volumes.

This design avoids issues with native LVM snapshots, such as significant input/output (I/O) penalties and unexpected, dangerous behavior when running out of pre-allocated space.

Snapshots as volume chains provide vendor-agnostic support for snapshots on any storage system that supports block storage. This includes iSCSI and Fibre Channel-attached SANs.

Note that, although this feature relies on qcow2, it only uses qcow2's ability to layer multiple volumes in a backing chain, not qcow2's snapshot functionality. The snapshot functionality is managed by the PVE storage system.

Enabling or disabling this flag only affects newly created virtual disk volumes. The flag cannot be disabled while the storage holds a volume in the qcow2 format, as such volumes need it.

For efficient support of `snapshot-as-volume-chain`, the backing storage must support thin-provisioning and discard. Each snapshot will appear to use the full volume size on the PVE side, but the actual space usage on the underlying storage will be smaller if those requirements are met.

Configuration Example (/etc/pve/storage.cfg)

```
lvm: myspace
        vgname myspace
        content rootdir,images
```

7.10.2 File naming conventions

The backend use basically the same naming conventions as the ZFS pool backend.

```
vm-<VMID>-<NAME>       // normal VM images
```

7.10.3 Storage Features

LVM is a typical block storage system. Unfortunately, regular LVM snapshots are inefficient because they interfere with all write operations within the entire volume group while the snapshot is active, which causes significant I/O degradation. This is why LVM does not support linked clones, and why Proxmox VE added support for snapshots as volume chains. This feature manages the snapshot volume through the storage plugin and uses qcow2 to layer separate volumes as a backing chain. This creates a single disk state that is exposed to the guest.

A benefit of LVM is that it can be used with shared storage. For example, an iSCSI LUN. The backend implements proper cluster-wide locking if the storage is marked as shared in the configuration.

Tip

Shared LVM on iSCSI, **Shared LVM on Fibre Channel** or **Shared LVM on NVMe over Fabrics** in **Datacenter** → **Storage** → **Add** in the web UI creates a shared LVM storage on a SAN LUN or an NVMe namespace.

Note

If you extend a shared volume group onto another device on one node, the other nodes may only see the added physical volume after LVM has scanned their devices again, for example with `pvscan --cache`. This command also resets the autoactivation records of LVM, which can let LVM activate logical volumes on its own later. Proxmox VE disables autoactivation for the logical volumes it creates. Before you run the command, make sure that autoactivation is also disabled for all other logical volumes of the volume group, for example with `lvchange --setautoactivation n <vg>/<lv>`. Proxmox VE runs the same rescan on its own when it does not find the volume group of a storage at all, so keep autoactivation disabled for all logical volumes of a shared volume group.

Tip
You can use the LVM-thin backend for non-shared local storage. It supports snapshots and linked clones.

Table 7.9: Storage features for backend `lvm`

Content types	Image formats	Shared	Snapshots	Full Clones	Linked Clones
`images rootdir`	`raw, qcow2`[1]	possible	yes[1]	yes	no

[1]: Since Proxmox VE 9, snapshots as a volume chain have been available for VMs, for details see the LVM configuration section.

7.10.4 Examples

You can get a list of available LVM volume groups with:

```
# pvesm scan lvm
```

7.11 LVM thin Backend

Storage pool type: `lvmthin`

LVM normally allocates blocks when you create a volume. LVM thin pools instead allocates blocks when they are written. This behaviour is called thin-provisioning, because volumes can be much larger than physically available space.

You can use the normal LVM command-line tools to manage and create LVM thin pools (see `man lvmthin` for details). Assuming you already have a LVM volume group called `pve`, the following commands create a new LVM thin pool (size 100G) called `data`:

```
lvcreate -L 100G -n data pve
lvconvert --type thin-pool pve/data
```

7.11.1 Configuration

The LVM thin backend supports the common storage properties `content`, `nodes`, `disable`, and the following LVM specific properties:

`vgname`
LVM volume group name. This must point to an existing volume group.

`thinpool`
The name of the LVM thin pool.

Configuration Example (/etc/pve/storage.cfg)

```
lvmthin: local-lvm
        thinpool data
        vgname pve
        content rootdir,images
```

7.11.2 File naming conventions

The backend use basically the same naming conventions as the ZFS pool backend.

```
vm-<VMID>-<NAME>       // normal VM images
```

7.11.3 Storage Features

LVM thin is a block storage, but fully supports snapshots and clones efficiently. New volumes are automatically initialized with zero.

It must be mentioned that LVM thin pools cannot be shared across multiple nodes, so you can only use them as local storage.

Table 7.10: Storage features for backend `lvmthin`

Content types	Image formats	Shared	Snapshots	Clones
`images` `rootdir`	`raw`	no	yes	yes

7.11.4 Examples

You can get a list of available LVM thin pools on the volume group `pve` with:

```
# pvesm scan lvmthin pve
```

7.12 Open-iSCSI initiator

Storage pool type: `iscsi`

iSCSI is a widely employed technology used to connect to storage servers. Almost all storage vendors support iSCSI. There are also open source iSCSI target solutions available, e.g. OpenMediaVault, which is based on Debian.

To use this backend, you need to install the Open-iSCSI (`open-iscsi`) package. This is a standard Debian package, but it is not installed by default to save resources.

```
# apt-get install open-iscsi
```

Low-level iscsi management task can be done using the `iscsiadm` tool.

Tip
To set up shared LVM on a LUN of an iSCSI target, use **Datacenter** → **Storage** → **Add** → **Shared LVM on iSCSI** in the web UI, see Multipath.

7.12.1 Configuration

The backend supports the common storage properties `content`, `nodes`, `disable`, and the following iSCSI specific properties:

portal
iSCSI portal (IP or DNS name with optional port).

target
iSCSI target.

managed-multipath
Combine the paths to each LUN of the target into one `dm-multipath` map on every node the storage is enabled on, and monitor the maps cluster-wide. A shared LVM storage on a target with several portals needs multipath, through this option or set up by hand. See Multipath.

Configuration Example (/etc/pve/storage.cfg)

```
iscsi: mynas
     portal 10.10.10.1
     target iqn.2006-01.openfiler.com:tsn.dcb5aaaddd
     content none
```

Note
To use LVM on top of iSCSI, set `content none`, in the web interface by clearing **Use LUNs directly**. That way it is not possible to create VMs using iSCSI LUNs directly. As a guest may use a LUN without data that could be detected, Proxmox VE refuses to create a volume group on a LUN of a target that a storage offers as disk images.

7.12.2 File naming conventions

The iSCSI protocol does not define an interface to allocate or delete data. Instead, that needs to be done on the target side and is vendor specific. The target simply exports them as numbered LUNs. So Proxmox VE iSCSI volume names just encodes some information about the LUN as seen by the linux kernel.

7.12.3 Storage Features

iSCSI is a block level type storage, and provides no management interface. So it is usually best to export one big LUN, and setup LVM on top of that LUN. You can then use the LVM plugin to manage the storage on that iSCSI LUN.

Table 7.11: Storage features for backend `iscsi`

Content types	Image formats	Shared	Snapshots	Clones
`images none`	`raw`	yes	no	no

7.12.4 Examples

You can scan a remote iSCSI portal and get a list of possible targets with:

```
pvesm scan iscsi <HOST[:PORT]>
```

7.13 User Mode iSCSI Backend

Storage pool type: `iscsidirect`

This backend provides basically the same functionality as the Open-iSCSI backend, but uses a user-level library to implement it. You need to install the `libiscsi-bin` package in order to use this backend.

It should be noted that there are no kernel drivers involved, so this can be viewed as performance optimization. But this comes with the drawback that you cannot use LVM on top of such iSCSI LUN. So you need to manage all space allocations at the storage server side.

7.13.1 Configuration

The user mode iSCSI backend uses the same configuration options as the Open-iSCSI backend, except for `managed-multipath`.

Configuration Example (/etc/pve/storage.cfg)

```
iscsidirect: faststore
     portal 10.10.10.1
     target iqn.2006-01.openfiler.com:tsn.dcb5aaaddd
```

7.13.2 Storage Features

Note
This backend works with VMs only. Containers cannot use this driver.

Table 7.12: Storage features for backend `iscsidirect`

Content types	Image formats	Shared	Snapshots	Clones
`images`	`raw`	yes	no	no

7.14 Multipath

Multipath lets a node reach a SAN LUN over several connections, called paths, so that I/O continues when one of them fails. Device-mapper multipath combines the paths of a LUN into one block device, a map, which every node identifies by the World Wide Identifier (WWID) of the LUN. Use it for shared LVM on iSCSI or Fibre Channel.

Proxmox VE sets up the maps on all nodes and shows their state under **Datacenter** → **SAN**. An iSCSI storage with **Multipath** enabled requests the maps of its LUNs, a Fibre Channel LUN needs a multipath entry. NVMe namespaces use the multipath support of the kernel instead, see NVMe over Fabrics, and are not covered here.

7.14.1 Prerequisites

- All nodes run pve-manager 9.2.34 or later. Older nodes do not apply the multipath configuration, and drop the **Multipath** option of iSCSI storages when they save the storage configuration.
- `multipath-tools` is installed on all nodes; it is only a recommended package.
- For iSCSI, the array allows the initiator name of each node, which **Datacenter** → **SAN** shows.
- For Fibre Channel, zoning and LUN masking allow the HBA ports of each node, whose WWPNs `cat /sys/class/fc_host/host*/port_name` lists.
- The same empty LUN is presented to the nodes that use it over redundant paths. For Fibre Channel, rescan the hosts on each node after mapping a LUN:

```
# for host in /sys/class/fc_host/host*; do echo '- - -' > /sys/class/ ↩
   scsi_host/${host##*/}/scan; done
```

  If the LUN does not show up, check that the target ports of the array are `Online`:

```
# for port in /sys/class/fc_remote_ports/rport-*; do echo $(cat $port/{ ↩
   port_name,port_state,roles}); done
```

7.14.2 Setting Up Shared LVM

1. On a node that can access the LUN, select **Shared LVM on iSCSI** or **Shared LVM on Fibre Channel** under **Datacenter** → **Storage** → **Add**. The **Add Shared LVM** menu of **Datacenter** → **SAN** has the same setups.

2. For iSCSI, enter the **ID** of the new storage, a portal and the target. If no iSCSI storage logs the nodes in to that target yet, the setup adds one named after the ID with a `-base` suffix, or as set under **Advanced**. Clear the nodes in the list of initiator names that should not use the storages.

3. Select the LUN after checking that no host uses it and that no data on it must be kept. For Fibre Channel, enter the **ID** of the new storage, and **Nodes** under **Advanced** limits it to some nodes. The volume group is named after the ID unless set under **Advanced**. If virtual machines need snapshots, enable **Allow Snapshots as Volume-Chain** before creating their disks, see LVM configuration.

4. Check the paths of every node in the result before placing guests on the storage, as the setup only checked the LUN on the node serving the web UI. Nodes show **Pending** while they set up the LUN, for up to a minute. A node that stays **Missing** cannot reach the LUN or has no map for it. A node with `1/1` has no redundancy.

For Fibre Channel, the setup uses an existing map as it is, so check that a map set up by hand exists on all nodes. Otherwise, it adds a multipath entry if there is none, with **Expected Paths** set to the paths of the node serving the web UI if it has at least two. Check that number, as a fabric may have been down during the setup.

If the setup fails, check the error and the task log before retrying. Closing the setup before it added its storage removes an iSCSI storage that it added, unless a storage uses it or it was changed meanwhile. If the web UI lost its connection, check whether that iSCSI storage is left over. Other changes stay, such as a multipath entry that the Fibre Channel setup added.

The setup refuses a LUN on which it finds data. To keep a volume group that a LUN already holds, add it under **Datacenter** → **Storage** → **Add** → **LVM** with **Shared** enabled. To reuse a LUN whose data is no longer needed, stop its users on all hosts, remove its storage references and use **Wipe** under **Node** → **SAN** as `root@pam`. The wipe removes partition tables and file system and LVM signatures, and zeroes the start of the LUN; it is not a secure erase. It refuses a LUN that a process on the node has open, but cannot detect every user, nor any on other hosts. Other nodes can still show the old usage afterwards.

Without the guided setup, add an iSCSI storage under **Datacenter** → **Storage** → **Add** → **iSCSI** with **Multipath** enabled and **Use LUNs directly** cleared, then an **LVM** storage with it as **Base storage**, the LUN as **Base volume** and **Shared** enabled. On the command line:

```
# pvesm add iscsi <iscsi-storage> --portal <portal> --target <iqn> \
    --content none --managed-multipath 1
# pvesm list <iscsi-storage> --content images
# pvesm add lvm <storage> --vgname <vg> --base <volume-id> --shared 1
```

Use the full volume ID from the listing, which ends in `dm-uuid-mpath-<wwid>`. Adding the LVM storage creates the volume group.

For Fibre Channel, look up the WWID of the LUN with `pvesm scan san-luns` and add an entry for it. Once the scan shows a by-id path with `dm-uuid-mpath-<wwid>`, create the volume group and storage on that node:

```
# pvesm scan san-luns --output-format json
# pvesh create /cluster/multipath/wwid --wwid <wwid> --paths-expected < ↩
   paths>
# pvesh create /nodes/localhost/disks/lvm --name <storage> \
    --device /dev/disk/by-id/dm-uuid-mpath-<wwid> --add_storage 1
```

To limit a storage to some nodes, set `--nodes <nodes>` on the entry or iSCSI storage and on the LVM storage. For Fibre Channel, leave out `--add_storage 1` and add the storage with `pvesm add lvm <storage> --vgname <storage> --shared 1 --nodes <nodes>`. Then check under **Datacenter** → **SAN** that every node has the LUN with all its paths.

7.14.3 Adding Another LUN

Present the new LUN to the same nodes. iSCSI storages detect it by themselves, for Fibre Channel rescan the hosts as shown in the prerequisites. Then run the guided setup again. For iSCSI, select the same target to use its iSCSI storage, after enabling **Multipath** on it if needed, see Existing Configurations.

7.14.4 Growing a LUN

1. Grow the LUN on the array. Never shrink a LUN in use.
2. On Fibre Channel nodes, rescan each path of the LUN with `echo 1 > /sys/block/<path>/device` for example for `sdc`. iSCSI storages rescan by themselves.
3. Wait until `multipath -ll <wwid>` or **Node** → **SAN** shows the new size on every node. A map grows once all its paths have grown; if it does not, run `multipathd resize map <map>`.
4. Run `pvresize /dev/disk/by-id/dm-uuid-mpath-<wwid>` on one node.

7.14.5 Removing a LUN

These steps retire a LUN together with its LVM storage. Proxmox VE never flushes a map or removes a WWID by itself. A map that queues I/O without paths can hang guests and LVM commands, so switch it to fail I/O before unmapping the LUN:

1. Stop all users of the LUN on all hosts. Remove the storage with `pvesm remove <storage>` and run `vgchange -an <vg>` on every node. Both keep the data.
2. Make the map fail I/O without paths with `pvesh set /cluster/multipath/wwid/<wwid> --no-path-retry fail`. Without an entry, create one with `pvesh create /cluster/multipa --wwid <wwid> --no-path-retry fail`, adding `--nodes <nodes>` if only some nodes see the LUN.
3. Wait until `multipath -ll <wwid>` no longer shows `queue_if_no_path` on any node. Note the paths of the map, such as `sdc`, with the WWID of each from `/sys/block/<path>/device/wwid`.
4. Unmap the LUN on the array.

5. On every node, flush the map with `multipath -f <map>`. If it stays busy, stop its remaining users instead of forcing it. Then remove each noted path whose WWID is unchanged with `echo 1 > /sys/block/<path>/device/delete`.

6. Remove the entry with `pvesh delete /cluster/multipath/wwid/<wwid>`. Removed earlier, the default retry policy of the array would apply to the map again.

7. On every node, wait until the WWID is gone from `/etc/multipath/conf.d/pve-aliases.conf`, about ten seconds, then run `multipath -w <wwid>`. Check that `grep -c '^/<wwid>/$' /etc/multipath/wwids` prints 0, also after the next status update.

If I/O already hangs because the LUN was unmapped first, run `multipathd disablequeueing map <map>` on the affected nodes and continue.

Removing the iSCSI storage of a target does not log out its sessions; use `iscsiadm` for that once no LUN of the target is in use.

7.14.6 Checking Path Failures

Datacenter → **SAN** shows configuration errors of the nodes, and the LUNs that Proxmox VE manages or that a storage uses with their state on each node. Other maps, for example those of a third-party storage plugin, are only counted under **Other Maps**. **Node** → **SAN** lists all LUNs of a node with their paths.

Used By under **Node** → **SAN** names the storage that uses a LUN or, without one, the process that has it open for writing, for example a guest with the LUN as disk from a third-party storage plugin. Such a LUN can neither be wiped nor selected in a guided setup.

The **State** of a LUN on a node is its count of usable paths out of the paths it has, or of its **Expected Paths** if more: green if all are usable, for example `2/2`, orange if not, for example `1/2`. A LUN without a multipath map shows its count without a green check, as nothing fails over between its paths. For several nodes, **State** lists each state of a node that is not fine, with the nodes in it if not all are, the worst first. If the only such state is **Unknown**, it lists the other nodes too. **Paths by Node**, or a double click on the LUN, shows the state of each node. **Multipath** shows how the map is managed: by an explicit entry, by a storage, or **Unmanaged** if Proxmox VE did not set it up.

Failed
: No path is usable, for example `Failed (0/2)`; I/O queues or fails depending on the retry policy.

Missing
: The node should have a map for the LUN but has none. Check the LUN under **Node** → **SAN** on that node, the **Message** of the node and its access on the array.

Unknown
: The node has no current report or cannot tell whether it has the map. Check the node under **Nodes**.

A node sends a multipath notification when not all paths of a LUN are usable in two consecutive checks, and again when none is left in two checks. A notification waits one more check while other LUNs of the node change the same way, so that it lists them too. A recovery notification follows once all paths of the LUN are usable in two consecutive checks. Without **Expected Paths**, a map with fewer paths than when the problem was notified does not count, as the kernel removes failed paths after a while. With it, such a map counts

once it has that many paths, but the notification then says that the alert is cleared rather than that paths are restored, as it does if **Expected Paths** was lowered meanwhile, or for a single path without **Expected Paths**, which does not tell whether others are missing. Such a notification also follows once two reports of the node no longer list the LUN.

A node whose **Multipath Setup** is not **OK**, for example because `multipathd` is not running, sends no such notifications; check its **Message** under **Datacenter** → **SAN**. A LUN that is **Missing** on a node is not notified either.

During a path failure, expand the LUN under **Node** → **SAN** on the affected node to see which paths failed. For iSCSI, **Node** → **SAN** → **iSCSI** shows the sessions. After restoring the connection, check that every node has all its paths again. Scripts can read the states with `pvesh get /cluster/san/status`.

An iSCSI storage expects one path per portal, so the array should report to each node only the portals it can reach. For Fibre Channel, set **Expected Paths** in the multipath entry, as the guided setup does. Otherwise, a path that the kernel removed after a failure no longer counts as missing.

A node reports up to about 700 LUNs. With more, it reports `too many LUNs to report`, and its LUNs are only shown under **Node** → **SAN**.

7.14.7 Multipath Entries

An entry in `/etc/pve/multipath.cfg` makes the nodes set up the map of a LUN and holds its settings. Fibre Channel and SAS LUNs need one. For a LUN of an iSCSI storage with **Multipath** enabled, an entry is only needed for its settings. Manage the entries under **Datacenter** → **SAN**, where **Add Multipath Entry** takes the WWID of a selected LUN, or with `pvesh` under `/cluster/multipath/wwid`.

alias
: The name of the map.

nodes
: The nodes that should have the map. All nodes if unset.

no-path-retry
: What happens to I/O while all paths are down: `queue` holds it until a path returns, `fail` fails it at once, and a number holds it for that many path checks. If unset, the settings for the array apply, which queue for some arrays. With `queue`, the guests and processes using the LUN hang for as long as no path returns, for example if the LUN was deleted on the array before it was removed from the nodes, see Removing a LUN.

paths-expected
: The number of paths each node should have. With fewer usable paths, the LUN shows in orange on that node, for example `1/2`.

Configuration Example (/etc/pve/multipath.cfg)

```
wwid: 36001405a1b2c3d4e5f60718293a4b5c6
     alias db-lun
     no-path-retry 12
     nodes node1,node2
     paths-expected 4
```

7.14.8 Array Settings and Existing Configurations

Use the built-in device profiles unless the array vendor requires changes. **Multipath Overrides** under **Datacenter** → **SAN** edits `/etc/pve/multipath-overrides.conf` for all nodes, for example to set a retry count for one array model:

```
devices {
    device {
        vendor "<vendor>"
        product "<product>"
        no_path_retry 12
    }
}
```

Proxmox VE sets `auto_resize grow_only`, so a map grows once all its paths have grown. This applies to all maps of a node, also to those of third-party storage plugins. To resize them by hand instead, add this to the overrides:

```
defaults {
    auto_resize never
}
```

To move from a hand-made `/etc/multipath.conf`:

1. Back up the configuration of every node. Move array settings to the overrides, and per-LUN settings and Fibre Channel WWIDs to multipath entries.
2. Enable **Multipath** on the existing iSCSI storages and keep their LVM base volumes. Check `multipathd show config` on every node before removing local settings. Do not edit the generated `/etc/multipat` files.
3. Once **Datacenter** → **SAN** shows the LUNs on every node, check with `lsblk` for active volumes that still use a single path, and stop and start or migrate their guests. See also the shared LVM autoactivation guidance.

7.15 NVMe over Fabrics Backend

Storage pool type: `nvmeof`

NVMe over Fabrics (NVMe-oF) gives a node access to the namespaces of an NVMe subsystem on a storage array over TCP. Namespaces are the NVMe counterpart of LUNs. Use one as the base volume of a shared LVM storage, or use the namespaces directly as disk images.

Each node connects one controller per portal of the storage. The kernel combines these paths into one device per namespace with its native NVMe multipath and reconnects lost paths on its own. `multipath-tools` is not involved.

7.15.1 Prerequisites

1. Upgrade all nodes to `pve-manager` 9.2.38 or newer before adding the first NVMe over Fabrics storage, also nodes that will not use it. A node without support for this storage type removes such

storages from the cluster-wide storage configuration when it writes that configuration, for example when a storage is added or edited on that node. Adding the first such storage is refused while a node is offline or runs an older version.

2. Install `nvme-cli` on every participating node. The `libpve-storage-perl` package recommends it, but installations without recommended packages need it added separately. Its installation creates the node's host NQN in `/etc/nvme/hostnqn` and host ID in `/etc/nvme/hostid`. Nodes cloned from one image share them. Give each a new identity before it connects, with `nvme gen-hostnqn > /etc/nvme/hostnqn` and `uuidgen > /etc/nvme/hostid`.

3. Allow each node's host NQN on the array. The names are shown under **Datacenter** → **SAN** and in the guided setup.

4. Present the same namespace to all intended nodes. Portals are IP addresses that every node of the storage can reach; host names are not accepted.

5. Use a storage network that only trusted hosts can reach. The connections use neither authentication nor TLS.

6. Keep native NVMe multipath enabled, which is the kernel default (`nvme_core.multipath=Y`). It joins the paths of a namespace only if the target declares that the subsystem may have several controllers, which most targets do, also with a single portal. A namespace that it does not join is refused as volume.

7.15.2 Setting Up Shared LVM

1. On a node that can reach the array, select **Shared LVM on NVMe over Fabrics** under **Datacenter** → **Storage** → **Add**. The **Add Shared LVM** menu of **Datacenter** → **SAN** has the same setup.

2. Enter the **ID** of the new LVM storage, a discovery portal and the subsystem, and check the portals. If no NVMe over Fabrics storage connects the nodes to that subsystem yet, the setup adds one named after the ID with a `-base` suffix, or as set under **Advanced**. This storage connects to the subsystem with `content none`, while the LVM storage manages guest disks. Clear the nodes in the list of host NQNs that should not use the storages. Continuing creates or reuses the NVMe over Fabrics storage before you select a namespace.

3. Select the namespace after checking that no host uses it and that no data on it must be kept. The volume group is named after the ID unless set under **Advanced**.

4. Check the state of the namespace on each node of the storage, which the setup shows once the storage is added, as described for LUNs in Multipath. For a node that stays **Missing**, check its access to the namespace on the array before placing guests on the storage.

The discovery fills in **Portals**. A discovery portal without a port is asked at port 8009, or at 4420 if that fails. Some targets, such as the Linux kernel target, report only the portal that was asked: add the others to the list. With a single portal, the state of the namespace shows `1/1`, which has no path redundancy. Portals can also be changed later in the edit dialog of the NVMe over Fabrics storage; each node then connects new ones on its own. The guided setup needs the discovery service of the target, also to reuse an existing connection; without one, add the storages as described next.

Datacenter → **Storage** → **Add** → **NVMe over Fabrics** adds only the NVMe over Fabrics storage. Without a discovery portal, enter the subsystem NQN and its portals as they are. Enable **Use namespaces directly**

there to use whole namespaces as guest disks, or add an **LVM** storage on a namespace later, with the NVMe over Fabrics storage as **Base storage**. Both at once are refused, as with direct use every namespace of the subsystem counts as in use by the storage. Before disabling direct use, check that no guest on any node has a namespace of the subsystem configured as disk: disabling it does not detach such disks.

To set it up by hand, run these commands on a node that can reach the array:

```
# pvesm scan nvmeof <portal>
# pvesm add nvmeof <nvmeof-storage> --subsysnqn <nqn> --portals <portals> \
    --content none
# pvesm list <nvmeof-storage>
# pvesm add lvm <storage> --vgname <vg> --base <volume-id> --shared 1
```

Use the complete volume ID from the listing, `<nvmeof-storage>:nvme-<wwid>`. Adding the LVM storage creates the volume group if it does not exist yet. Creating it is refused if the namespace holds data that Proxmox VE recognizes, such as partitions, a file system or a volume group, or if another storage references it. To keep an existing volume group, add the LVM storage with its name. To discard the data of a namespace instead, stop its users on all hosts and wipe it as described for LUNs in Multipath.

7.15.3 Configuration

The backend supports the common storage properties `content`, `nodes`, `disable`, and the following NVMe over Fabrics specific properties:

subsysnqn
: The NQN of the NVMe subsystem. It cannot be changed later, and only one storage can use a subsystem.

portals
: Comma-separated list of the subsystem's TCP portals, one per path. Each is an IPv4 address or an IPv6 address in brackets, with an optional port (default 4420).

fast-io-fail-tmo
: Seconds a path may be reconnecting before I/O sent to it fails. The default is 120 seconds. If no usable path of a namespace remains, its I/O can fail once its paths have been reconnecting that long. With `-1`, I/O waits until a path returns. A change applies to newly connected controllers only.

Configuration Example (/etc/pve/storage.cfg)

```
nvmeof: fabric
     subsysnqn nqn.2010-06.com.example:array1
     portals 192.0.2.10,192.0.2.11
     content none
```

Table 7.13: Storage features for backend `nvmeof`

Content types	Image formats	Shared	Snapshots	Clones
`images none`	`raw`	yes	no	no

Proxmox VE does not create or delete namespaces; manage them on the array. A volume is named `nvme-<wwid>` after its namespace, like its link in `/dev/disk/by-id/`.

7.15.4 Checking and Disconnecting Paths

Datacenter → **SAN** lists the namespaces of NVMe over Fabrics storages among the LUNs, with their state on each node of the storage and **Multipath** shown as **Native**, as does **Node** → **SAN** for the namespaces of a node. Expand a namespace under **Node** → **SAN** to inspect its paths. Its **State** counts the usable paths out of the portals of the storage, or out of the connected paths if more are connected, for example `1/2` while one of two paths is unusable, and shows **Failed** without a usable path. **Node** → **SAN** → **NVMe over Fabrics** lists the node's controllers, one per connected portal, with their **State**: **Connected**, or **Reconnecting** while the kernel retries a lost path. A node sends a multipath notification when the paths of a namespace stay degraded or failed in two consecutive checks, and when they recover, under the same rules as for a LUN. This does not need `multipathd`.

Each node of an enabled storage connects to the portals that it is not yet connected to. A portal that failed is retried after a minute. Removing a portal, or disabling or removing the storage, does not disconnect anything. To remove such a path, select its controller under **Node** → **SAN** → **NVMe over Fabrics** on each node and press **Disconnect**, or run `pvesh delete /nodes/<node>/san/nvmeof/controller/<controll`
This is refused if a namespace that is mounted, in use by another device or as swap, open in a process such as a running guest, or referenced by a storage would lose its last usable path. If the controller is no usable path itself, such as one that keeps reconnecting to a deleted subsystem, the local uses are still checked, but not the storage references, as that check reads the namespace. While a namespace has no usable path, its I/O waits until a path is usable again, or until `fast-io-fail-tmo` has passed for reconnecting controllers. An LVM command of the status checks can keep the namespace open meanwhile, and Disconnect refuses while it does. The process check does not find a process that opened the namespace through another device node, for example one in a container. A controller with namespaces that do not use native NVMe multipath is refused as well. A storage that still lists the portal connects to it again. Namespaces of a subsystem that no storage uses then show fewer paths, but none as missing, as nothing tells how many paths they should have.

7.15.5 Limits

- Only the TCP transport is supported, without authentication or TLS.
- The disk lists under **Node** → **Disks** and for Ceph OSDs leave out namespaces attached over TCP or RDMA, like iSCSI LUNs, as other nodes use them too. **Node** → **SAN** lists them.
- NVMe/FC namespaces need no storage of this type, and the guided setups and the cluster-wide status do not cover them. **Node** → **SAN** lists them. Create their volume group on the whole namespace under **Node** → **Disks** → **LVM**; with **Add Storage** enabled, this adds a shared LVM storage.

7.16 Ceph RADOS Block Devices (RBD)

Storage pool type: `rbd`

Ceph is a distributed object store and file system designed to provide excellent performance, reliability and scalability. RADOS block devices implement a feature rich block level storage, and you get the following advantages:

- thin provisioning
- resizable volumes
- distributed and redundant (striped over multiple OSDs)
- full snapshot and clone capabilities
- self healing
- no single point of failure
- scalable to the exabyte level
- kernel and user space implementation available

Note
For smaller deployments, it is also possible to run Ceph services directly on your Proxmox VE nodes. Recent hardware has plenty of CPU power and RAM, so running storage services and VMs on same node is possible.

7.16.1 Configuration

This backend supports the common storage properties `nodes`, `disable`, `content`, and the following `rbd` specific properties:

monhost
List of monitor daemon IPs. Optional, only needed if Ceph is not running on the Proxmox VE cluster. With `monhost` set, Proxmox VE treats the cluster as external and keeps a separate key copy for this storage, even if the monitors belong to the Ceph cluster of this Proxmox VE cluster.

pool
Ceph pool name.

username
Ceph client ID. Optional, defaults to `admin`. Use only the ID without the `client.` prefix.

krbd
Enforce access to rados block devices through the krbd kernel module. Optional.

Note
Containers will use `krbd` independent of the option value.

Configuration Example for an external Ceph cluster (/etc/pve/storage.cfg)

```
rbd: ceph-external
        monhost 10.1.1.20 10.1.1.21 10.1.1.22
        pool ceph-external
        content images
        username pve-rbd
```

Tip
You can use the `rbd` utility to do low-level management tasks.

7.16.2 Authentication

Note
If Ceph is installed locally on the Proxmox VE cluster, the following is done automatically when adding the storage.

If you use `cephx` authentication, which is enabled by default, provide a keyring from the external Ceph cluster. Obtain or create a dedicated identity with only the capabilities required for this storage, as described in Ceph User Management.[1] The example below uses `client.pve-rbd`; do not copy `client.admin` to a storage client.

Copy the keyring to one Proxmox VE node:

```
# scp <external-ceph-server>:/etc/ceph/ceph.client.pve-rbd.keyring /root/ ↩
   rbd.keyring
```

Then pass that file and the identity without its `client.` prefix to `pvesm`:

```
# pvesm add rbd <name> --monhost "10.1.1.20 10.1.1.21 10.1.1.22" \
    --pool ceph-external --content images --username pve-rbd \
    --keyring /root/rbd.keyring
```

After `pvesm` succeeds, remove `/root/rbd.keyring` because it contains the key in plain text.

When configuring an external RBD storage via the GUI, you can copy and paste the keyring into the appropriate field.

The keyring will be stored at

```
# /etc/pve/priv/ceph/<STORAGE_ID>.keyring
```

If the external cluster rotates this identity, replace the stored keyring before refreshing its consumers. The local cephx migration helper never rotates keys of external clusters.

[1] Ceph User Management

7.16.3 Ceph client configuration (optional)

Connecting to an external Ceph storage doesn't always allow setting client-specific options in the config DB on the external cluster. You can add a `ceph.conf` beside the Ceph keyring to change the Ceph client configuration for the storage.

The ceph.conf needs to have the same name as the storage.

```
# /etc/pve/priv/ceph/<STORAGE_ID>.conf
```

See the RBD configuration reference [2] for possible settings.

Note
Do not change these settings lightly. Proxmox VE is merging the <STORAGE_ID>.conf with the storage configuration.

7.16.4 Storage Features

The `rbd` backend is a block level storage, and implements full snapshot and clone functionality.

Table 7.14: Storage features for backend `rbd`

Content types	Image formats	Shared	Snapshots	Clones
`images` `rootdir`	`raw`	yes	yes	yes

7.17 Ceph Filesystem (CephFS)

Storage pool type: `cephfs`

CephFS implements a POSIX-compliant filesystem, using a Ceph storage cluster to store its data. As CephFS builds upon Ceph, it shares most of its properties. This includes redundancy, scalability, self-healing, and high availability.

Tip
Proxmox VE can manage Ceph setups, which makes configuring a CephFS storage easier. As modern hardware offers a lot of processing power and RAM, running storage services and VMs on same node is possible without a significant performance impact.

To use the CephFS storage plugin, you must replace the stock Debian Ceph client, by adding our Ceph repository. Once added, run `apt update`, followed by `apt dist-upgrade`, in order to get the newest packages.

[2] RBD configuration reference https://docs.ceph.com/en/tentacle/rbd/rbd-config-ref/



Warning
Please ensure that there are no other Ceph repositories configured. Otherwise the installation will fail or there will be mixed package versions on the node, leading to unexpected behavior.

7.17.1 Configuration

This backend supports the common storage properties `nodes`, `disable`, `content`, as well as the following `cephfs` specific properties:

fs-name
Name of the Ceph FS.

monhost
List of monitor daemon addresses. Optional, only needed if Ceph is not running on the Proxmox VE cluster. With `monhost` set, Proxmox VE treats the cluster as external and keeps a separate key copy for this storage, even if the monitors belong to the Ceph cluster of this Proxmox VE cluster.

path
The local mount point. Optional, defaults to `/mnt/pve/<STORAGE_ID>/`.

username
Ceph client ID. Optional, defaults to `admin`. Use only the ID without the `client.` prefix.

subdir
CephFS subdirectory to mount. Optional, defaults to `/`.

fuse
Access CephFS through FUSE, instead of the kernel client. Optional, defaults to `0`.

Configuration example for an external Ceph cluster (/etc/pve/storage.cfg)

```
cephfs: cephfs-external
        monhost 10.1.1.20 10.1.1.21 10.1.1.22
        path /mnt/pve/cephfs-external
        content backup
        username pve-cephfs
        fs-name cephfs
```

Note
Don't forget to set up the client's secret key file, if cephx was not disabled.

7.17.2 Authentication

Note
If Ceph is installed locally on the Proxmox VE cluster, the following is done automatically when adding the storage.

If you use `cephx` authentication, which is enabled by default, provide the secret of a dedicated identity with only the capabilities required for this storage. Obtain or create the identity as described in Ceph User Management.[1] The example below uses `client.pve-cephfs`; do not use `client.admin` for a storage client.

Export the bare key through SSH to one Proxmox VE node:

```
# ssh root@<external-ceph-server> \
    'ceph auth get-key client.pve-cephfs' > /root/cephfs.secret
```

Then pass that file and the identity without its `client.` prefix to `pvesm`:

```
# pvesm add cephfs <name> --monhost "10.1.1.20 10.1.1.21 10.1.1.22" \
    --fs-name cephfs --content backup --username pve-cephfs \
    --keyring /root/cephfs.secret
```

After `pvesm` succeeds, remove `/root/cephfs.secret` because it contains the key in plain text.

When configuring an external CephFS storage in the web interface, paste the secret into the appropriate field. CephFS uses the bare key, not the RBD keyring format with a `[client.<USER>]` section. Proxmox VE stores the secret at `/etc/pve/priv/ceph/<STORAGE_ID>.secret`.

If the external cluster rotates this identity, replace the stored secret before remounting the storage. The local cephx migration helper never rotates keys of external clusters.

7.17.3 Storage Features

The `cephfs` backend is a POSIX-compliant filesystem, on top of a Ceph cluster.

Table 7.15: Storage features for backend `cephfs`

Content types	Image formats	Shared	Snapshots	Clones
`vztmpl iso backup snippets`	`none`	yes	yes[1]	no

[1] While no known bugs exist, snapshots are not yet guaranteed to be stable, as they lack sufficient testing.

7.18 BTRFS Backend

Storage pool type: `btrfs`

On the surface, this storage type is very similar to the directory storage type, so see the directory backend section for a general overview.

The main difference is that with this storage type `raw` formatted disks will be placed in a subvolume, in order to allow taking snapshots and supporting offline storage migration with snapshots being preserved.

Note
BTRFS will honor the `O_DIRECT` flag when opening files, meaning VMs should not use cache mode `none`, otherwise there will be checksum errors.

7.18.1 Configuration

This backend is configured similarly to the directory storage. Note that when adding a directory as a BTRFS storage, which is not itself also the mount point, it is highly recommended to specify the actual mount point via the `is_mountpoint` option.

For example, if a BTRFS file system is mounted at `/mnt/data2` and its `pve-storage/` subdirectory (which may be a snapshot, which is recommended) should be added as a storage pool called `data2`, you can use the following entry:

```
btrfs: data2
        path /mnt/data2/pve-storage
        content rootdir,images
        is_mountpoint /mnt/data2
```

7.18.2 Snapshots

When taking a snapshot of a subvolume or `raw` file, the snapshot will be created as a read-only subvolume with the same path followed by an `@` and the snapshot's name.

7.19 ZFS over ISCSI Backend

Storage pool type: `zfs`

This backend accesses a remote machine having a ZFS pool as storage and an iSCSI target implementation via `ssh`. For each guest disk it creates a ZVOL and, exports it as iSCSI LUN. This LUN is used by Proxmox VE for the guest disk.

The following iSCSI target implementations are supported:

- LIO (Linux)
- IET (Linux)
- ISTGT (FreeBSD)

- Comstar (Solaris)

Note
This plugin needs a ZFS capable remote storage appliance, you cannot use it to create a ZFS Pool on a regular Storage Appliance/SAN

7.19.1 Configuration

In order to use the ZFS over iSCSI plugin you need to configure the remote machine (target) to accept `ssh` connections from the Proxmox VE node. Proxmox VE connects to the target for creating the ZVOLs and exporting them via iSCSI. Authentication is done through a ssh-key (without password protection) stored in `/etc/pve/priv/zfs/<target_ip>_id_rsa`

The following steps create a ssh-key and distribute it to the storage machine with IP 192.0.2.1:

```
mkdir /etc/pve/priv/zfs
ssh-keygen -f /etc/pve/priv/zfs/192.0.2.1_id_rsa
ssh-copy-id -i /etc/pve/priv/zfs/192.0.2.1_id_rsa.pub root@192.0.2.1
ssh -i /etc/pve/priv/zfs/192.0.2.1_id_rsa root@192.0.2.1
```

The backend supports the common storage properties `content`, `nodes`, `disable`, and the following ZFS over ISCSI specific properties:

pool
The ZFS pool/filesystem on the iSCSI target. All allocations are done within that pool.

portal
iSCSI portal (IP or DNS name with optional port).

target
iSCSI target.

iscsiprovider
The iSCSI target implementation used on the remote machine

comstar_tg
target group for comstar views.

comstar_hg
host group for comstar views.

lio_tpg
target portal group for Linux LIO targets

nowritecache
disable write caching on the target

blocksize
Set ZFS blocksize parameter.

sparse
Use ZFS thin-provisioning. A sparse volume is a volume whose reservation is not equal to the volume size.

Configuration Examples (/etc/pve/storage.cfg)

```
zfs: lio
   blocksize 4k
   iscsiprovider LIO
   pool tank
   portal 192.0.2.111
   target iqn.2003-01.org.linux-iscsi.lio.x8664:sn.xxxxxxxxxxxx
   content images
   lio_tpg tpg1
   sparse 1

zfs: solaris
   blocksize 4k
   target iqn.2010-08.org.illumos:02:xxxxxxxx-xxxx-xxxx-xxxx-xxxxxxxxxxxx: ↩
      tank1
   pool tank
   iscsiprovider comstar
   portal 192.0.2.112
   content images

zfs: freebsd
   blocksize 4k
   target iqn.2007-09.jp.ne.peach.istgt:tank1
   pool tank
   iscsiprovider istgt
   portal 192.0.2.113
   content images

zfs: iet
   blocksize 4k
   target iqn.2001-04.com.example:tank1
   pool tank
   iscsiprovider iet
   portal 192.0.2.114
   content images
```

7.19.2 Storage Features

The ZFS over iSCSI plugin provides a shared storage, which is capable of snapshots. You need to make sure that the ZFS appliance does not become a single point of failure in your deployment.

Table 7.16: Storage features for backend `iscsi`

Content types	Image formats	Shared	Snapshots	Clones
`images`	`raw`	yes	yes	no

Chapter 8

Deploy Hyper-Converged Ceph Cluster

8.1 Introduction



Proxmox VE unifies your compute and storage systems, that is, you can use the same physical nodes within a cluster for both computing (processing VMs and containers) and replicated storage. The traditional silos of compute and storage resources can be wrapped up into a single hyper-converged appliance. Separate storage networks (SANs) and connections via network attached storage (NAS) disappear. With the integration of Ceph, an open source software-defined storage platform, Proxmox VE has the ability to run and manage Ceph storage directly on the hypervisor nodes.

Ceph is a distributed object store and file system designed to provide excellent performance, reliability and scalability.

SOME ADVANTAGES OF CEPH ON PROXMOX VE ARE:

- Easy setup and management via CLI and GUI
- Thin provisioning
- Snapshot support

- Self healing
- Scalable to the exabyte level
- Provides block, file system, and object storage
- Setup pools with different performance and redundancy characteristics
- Data is replicated, making it fault tolerant
- Runs on commodity hardware
- No need for hardware RAID controllers
- Open source

For small to medium-sized deployments, it is possible to install a Ceph server for using RADOS Block Devices (RBD) or CephFS directly on your Proxmox VE cluster nodes (see Ceph RADOS Block Devices (RBD)). Recent hardware has a lot of CPU power and RAM, so running storage services and virtual guests on the same node is possible.

To simplify management, Proxmox VE provides you native integration to install and manage Ceph services on Proxmox VE nodes either via the built-in web interface, or using the *pveceph* command line tool.

8.2 Terminology

CEPH CONSISTS OF MULTIPLE DAEMONS, FOR USE AS AN RBD STORAGE:

- Ceph Monitor (ceph-mon, or MON)
- Ceph Manager (ceph-mgr, or MGR)
- Ceph Metadata Service (ceph-mds, or MDS)
- Ceph Object Storage Daemon (ceph-osd, or OSD)

Tip
We highly recommend to get familiar with Ceph [a], its architecture [b] and vocabulary [c].

[a] Ceph intro https://docs.ceph.com/en/tentacle/start/
[b] Ceph architecture https://docs.ceph.com/en/tentacle/architecture/
[c] Ceph glossary https://docs.ceph.com/en/tentacle/glossary

8.3 Recommendations for a Healthy Ceph Cluster

To build a hyper-converged Proxmox + Ceph Cluster, you must use at least three (preferably) identical servers for the setup.

Check also the recommendations from Ceph's website.

Note
The recommendations below should be seen as a rough guidance for choosing hardware. Therefore, it is still essential to adapt it to your specific needs. You should test your setup and monitor health and performance continuously.

CPU

Ceph services can be classified into two categories:

- Intensive CPU usage, benefiting from high CPU base frequencies and multiple cores. Members of that category are:
  - Object Storage Daemon (OSD) services
  - Meta Data Service (MDS) used for CephFS
- Moderate CPU usage, not needing multiple CPU cores. These are:
  - Monitor (MON) services
  - Manager (MGR) services

As a simple rule of thumb, you should assign at least one CPU core (or thread) to each Ceph service to provide the minimum resources required for stable and durable Ceph performance.

For example, if you plan to run a Ceph monitor, a Ceph manager and 6 Ceph OSDs services on a node you should reserve 8 CPU cores purely for Ceph when targeting basic and stable performance.

Note that an OSD's CPU usage depends mostly on the disk's performance. The higher the possible IOPS (**IO** **O**perations per **S**econd) of a disk, the more CPU can be utilized by an OSD service. For modern enterprise SSD disks, like NVMes that can permanently sustain a high IOPS load over 100'000 with sub millisecond latency, each OSD can use multiple CPU threads, e.g., four to six CPU threads utilized per NVMe backed OSD is likely for very high performance disks.

Memory

Especially in a hyper-converged setup, the memory consumption needs to be carefully planned out and monitored. In addition to the predicted memory usage of virtual machines and containers, you must also account for having enough memory available for Ceph to provide excellent and stable performance.

While usage may be less under normal conditions, it will consume more memory during critical operations, such as recovery, rebalancing, or backfilling. That means you should avoid maxing out your available memory already on regular operation, but rather leave some headroom to cope with outages.

The current recommendation is to configure OSDs with at least **8 GiB of memory** for good performance. The OSD daemon requires 4 GiB by default.

Note
Total memory consumption is primarily determined by the number of OSD daemons. However, for critical operations, all Ceph services may require additional memory.

Network

We recommend a network bandwidth of at least 10 Gbps, or more, to be used exclusively for Ceph traffic. A meshed network setup [1] is also an option for three to five node clusters, if there are no 10+ Gbps switches available.



Important
The volume of traffic, especially during recovery, will interfere with other services on the same network, especially the latency sensitive Proxmox VE corosync cluster stack can be affected, resulting in possible loss of cluster quorum. Moving the Ceph traffic to dedicated and physical separated networks will avoid such interference, not only for corosync, but also for the networking services provided by any virtual guests.

For estimating your bandwidth needs, you need to take the performance of your disks into account.. While a single HDD might not saturate a 1 Gb link, multiple HDD OSDs per node can already saturate 10 Gbps too. If modern NVMe-attached SSDs are used, a single one can already saturate 10 Gbps of bandwidth, or more. For such high-performance setups we recommend at least a 25 Gpbs, while even 40 Gbps or 100+ Gbps might be required to utilize the full performance potential of the underlying disks.

If unsure, we recommend using three (physical) separate networks for high-performance setups:

- one very high bandwidth (25+ Gbps) network for Ceph (internal) cluster traffic.
- one high bandwidth (10+ Gpbs) network for Ceph (public) traffic between the ceph server and ceph client storage traffic. Depending on your needs this can also be used to host the virtual guest traffic and the VM live-migration traffic.
- one medium bandwidth (1 Gbps) exclusive for the latency sensitive corosync cluster communication.

If a firewall is enabled you will have to open the ports used by Ceph, the easiest way to do this is to use a firewall `macro`.

Disks

When planning the size of your Ceph cluster, it is important to take the recovery time into consideration. Especially with small clusters, recovery might take long. It is recommended that you use SSDs instead of HDDs in small setups to reduce recovery time, minimizing the likelihood of a subsequent failure event during recovery.

In general, SSDs will provide more IOPS than spinning disks. With this in mind, in addition to the higher cost, it may make sense to implement a class based separation of pools. Another way to speed up OSDs is to use a faster disk as a journal or DB/**W**rite-**A**head-**L**og device, see creating Ceph OSDs. If a faster disk is used for multiple OSDs, a proper balance between OSD and WAL / DB (or journal) disk must be selected, otherwise the faster disk becomes the bottleneck for all linked OSDs.

Aside from the disk type, Ceph performs best with an evenly sized, and an evenly distributed amount of disks per node. For example, 4 x 500 GB disks within each node is better than a mixed setup with a single 1 TB and three 250 GB disk.

You also need to balance OSD count and single OSD capacity. More capacity allows you to increase storage density, but it also means that a single OSD failure forces Ceph to recover more data at once.

[1] Full Mesh Network for Ceph https://pve.proxmox.com/wiki/Full_Mesh_Network_for_Ceph_Server

Avoid RAID

As Ceph handles data object redundancy and multiple parallel writes to disks (OSDs) on its own, using a RAID controller normally doesn't improve performance or availability. On the contrary, Ceph is designed to handle whole disks on its own, without any abstraction in between. RAID controllers are not designed for the Ceph workload and may complicate things and sometimes even reduce performance, as their write and caching algorithms may interfere with the ones from Ceph.

Warning
Avoid RAID controllers. Use host bus adapter (HBA) instead.

8.4 Initial Ceph Installation & Configuration

8.4.1 Using the Web-based Wizard



With Proxmox VE you have the benefit of an easy to use installation wizard for Ceph. Click on one of your cluster nodes and navigate to the Ceph section in the menu tree. If Ceph is not already installed, you will see a prompt offering to do so.

The wizard is divided into multiple sections, where each needs to finish successfully, in order to use Ceph.

First you need to choose which Ceph version you want to install. Prefer the one from your other nodes, or the newest if this is the first node you install Ceph.

After starting the installation, the wizard will download and install all the required packages from Proxmox VE's Ceph repository.



After finishing the installation step, you will need to create a configuration. This step is only needed once per cluster, as this configuration is distributed automatically to all remaining cluster members through Proxmox VE's clustered configuration file system (pmxcfs).

The configuration step includes the following settings:

- **Public Network:** This network will be used for public storage communication (e.g., for virtual machines using a Ceph RBD backed disk, or a CephFS mount), and communication between the different Ceph services. This setting is required.
  Separating your Ceph traffic from the Proxmox VE cluster communication (corosync), and possibly the front-facing (public) networks of your virtual guests, is highly recommended. Otherwise, Ceph's high-bandwidth IO-traffic could cause interference with other low-latency dependent services.

- **Cluster Network:** Specify to separate the OSD replication and heartbeat traffic as well. This setting is optional.
  Using a physically separated network is recommended, as it will relieve the Ceph public and the virtual guests network, while also providing a significant Ceph performance improvements.
  The Ceph cluster network can be configured and moved to another physically separated network at a later time.



You have two more options which are considered advanced and therefore should only be changed if you know what you are doing.

- **Number of replicas**: Defines how often an object is replicated.
- **Minimum replicas**: Defines the minimum number of required replicas for I/O to be marked as complete.

Additionally, you need to choose your first monitor node. This step is required.

That's it. You should now see a success page as the last step, with further instructions on how to proceed. Your system is now ready to start using Ceph. To get started, you will need to create some additional monitors, OSDs and at least one pool.

The rest of this chapter will guide you through getting the most out of your Proxmox VE based Ceph setup. This includes the aforementioned tips and more, such as CephFS, which is a helpful addition to your new Ceph cluster.

8.4.2 CLI Installation of Ceph Packages

Alternatively to the recommended Proxmox VE Ceph installation wizard available in the web interface, you can use the following CLI command on each node:

```
pveceph install
```

This sets up an `apt` package repository in `/etc/apt/sources.list.d/ceph.sources` and installs the required software.

8.4.3 Initial Ceph configuration via CLI

Use the Proxmox VE Ceph installation wizard (recommended) or run the following command on one node:

```
pveceph init --network 10.10.10.0/24
```

This creates an initial configuration at `/etc/pve/ceph.conf` with a dedicated network for Ceph. This file is automatically distributed to all Proxmox VE nodes, using pmxcfs. The command also creates a symbolic link at `/etc/ceph/ceph.conf`, which points to that file. Thus, you can simply run Ceph commands without the need to specify a configuration file.

8.5 Ceph Monitor



The Ceph Monitor (MON) [2] maintains a master copy of the cluster map. For high availability, you need at least 3 monitors. One monitor will already be installed if you used the installation wizard. You won't need more than 3 monitors, as long as your cluster is small to medium-sized. Only really large clusters will require more than this.

8.5.1 Create Monitors

On each node where you want to place a monitor (three monitors are recommended), create one by using the *Ceph* → *Monitor* tab in the GUI or run:

```
pveceph mon create
```

[2] Ceph Monitor https://docs.ceph.com/en/tentacle/rados/configuration/mon-config-ref/

8.5.2 Destroy Monitors

To remove a Ceph Monitor via the GUI, first select a node in the tree view and go to the **Ceph** → **Monitor** panel. Select the MON and click the **Destroy** button.

To remove a Ceph Monitor via the CLI, first connect to the node on which the MON is running. Then execute the following command:

```
pveceph mon destroy
```

Note
At least three Monitors are needed for quorum.

8.6 Ceph Manager

The Manager daemon runs alongside the monitors. It provides an interface to monitor the cluster. Since the release of Ceph luminous, at least one ceph-mgr [3] daemon is required.

8.6.1 Create Manager

Multiple Managers can be installed, but only one Manager is active at any given time.

```
pveceph mgr create
```

Note
It is recommended to install the Ceph Manager on the monitor nodes. For high availability install more then one manager.

8.6.2 Destroy Manager

To remove a Ceph Manager via the GUI, first select a node in the tree view and go to the **Ceph** → **Monitor** panel. Select the Manager and click the **Destroy** button.

To remove a Ceph Monitor via the CLI, first connect to the node on which the Manager is running. Then execute the following command:

```
pveceph mgr destroy
```

Note
While a manager is not a hard-dependency, it is crucial for a Ceph cluster, as it handles important features like PG-autoscaling, device health monitoring, telemetry and more.

[3] Ceph Manager https://docs.ceph.com/en/tentacle/mgr/

8.7 Ceph OSDs



Ceph **O**bject **S**torage **D**aemons store objects for Ceph over the network. It is recommended to use one OSD per physical disk.

8.7.1 Create OSDs

You can create an OSD either via the Proxmox VE web interface or via the CLI using `pveceph`. For example:

```
pveceph osd create /dev/sd[X]
```

Tip
We recommend a Ceph cluster with at least three nodes and at least 12 OSDs, evenly distributed among the nodes.

If the disk was in use before (for example, for ZFS or as an OSD) you first need to zap all traces of that usage. To remove the partition table, boot sector and any other OSD leftover, you can use the following command:

```
ceph-volume lvm zap /dev/sd[X] --destroy
```



Warning
The above command will destroy all data on the disk!

Ceph Bluestore

Starting with the Ceph Kraken release, a new Ceph OSD storage type was introduced called Bluestore [4]. This is the default when creating OSDs since Ceph Luminous.

```
pveceph osd create /dev/sd[X]
```

Block.db and block.wal

If you want to use a separate DB/WAL device for your OSDs, you can specify it through the *-db_dev* and *-wal_dev* options. The WAL is placed with the DB, if not specified separately.

```
pveceph osd create /dev/sd[X] -db_dev /dev/sd[Y] -wal_dev /dev/sd[Z]
```

You can directly choose the size of those with the *-db_size* and *-wal_size* parameters respectively. If they are not given, the following values (in order) will be used:

- bluestore_block_{db,wal}_size from Ceph configuration...
  - ... database, section *osd*
  - ... database, section *global*
  - ... file, section *osd*
  - ... file, section *global*
- 10% (DB)/1% (WAL) of OSD size

Note
The DB stores BlueStore's internal metadata, and the WAL is BlueStore's internal journal or write-ahead log. It is recommended to use a fast SSD or NVRAM for better performance.

Ceph Filestore

Before Ceph Luminous, Filestore was used as the default storage type for Ceph OSDs. Starting with Ceph Nautilus, Proxmox VE does not support creating such OSDs with *pveceph* anymore. If you still want to create filestore OSDs, use *ceph-volume* directly.

```
ceph-volume lvm create --filestore --data /dev/sd[X] --journal /dev/sd[Y]
```

[4] Ceph Bluestore https://ceph.com/community/new-luminous-bluestore/

8.7.2 Destroy OSDs

If you experience problems with an OSD or its disk, try to troubleshoot them first to decide if a replacement is needed.

To destroy an OSD, navigate to the *<Node>* → *Ceph* → *OSD* panel or use the mentioned CLI commands on the node where the OSD is located.

1. Make sure the cluster has enough space to handle the removal of the OSD. In the *Ceph* → *OSD* panel,if the to-be destroyed OSD is still `up` and `in` (non-zero value at `AVAIL`), make sure that all OSDs have their `Used (%)` value well below the `nearfull_ratio` of default `85%`.

   This way you can reduce the risk from the upcoming rebalancing, which may cause OSDs to run full and thereby blocking I/O on Ceph pools.

   Use the following command to get the same information on the CLI:

   ```
   ceph osd df tree
   ```

2. If the to-be destroyed OSD is not `out` yet, select the OSD and click on **Out**. This will exclude it from data distribution and start a rebalance.

   The following command does the same:

   ```
   ceph osd out <id>
   ```

3. If you can, wait until Ceph has finished the rebalance to always have enough replicas. The OSD will be empty; once it is, it will show *0 PGs*.

4. Click on **Stop**. If stopping is not safe yet, a warning will appear, and you should click on **Cancel**. Try it again in a few moments.

   The following commands can be used to check if it is safe to stop and stop the OSD:

   ```
   ceph osd ok-to-stop <id>
   pveceph stop --service osd.<id>
   ```

5. Finally:

   To remove the OSD from Ceph and delete all disk data, first click on **More** → **Destroy**. Enable the cleanup option to clean up the partition table and other structures. This makes it possible to immediately reuse the disk in Proxmox VE. Then, click on **Remove**.

   The CLI command to destroy the OSD is:

   ```
   pveceph osd destroy <id> [--cleanup]
   ```

8.8 Ceph Configuration

Ceph daemon and clients pull their configuration from one or more sources [5]. In Proxmox VE, a minimal ceph.conf file is used to hold bootstrap settings. Most of the configuration is held in the central configuration database maintained by the MON services.

[5] Ceph config sources https://docs.ceph.com/en/latest/rados/configuration/ceph-conf/#config-sources

To persistently change configuration values use the following commands [6]:

`ceph config dump`	Show all configuration option(s)
`ceph config get <who> <name>`	Show configuration option(s) for an entity
`ceph config set <who> <name> <value>`	Set a configuration option for one or more entities
`ceph config rm <who> <name>`	Clear a configuration option for one or more entities

Example for increasing the osd_memory_target for all OSD daemons

```
ceph config set osd osd_memory_target 8G
```

Note
If an option exists in a local configuration file, the configuration in the MON DB will be ignored because it has a lower precedence.

8.9 Ceph Pools



A pool is a logical group for storing objects. It holds a collection of objects, known as **P**lacement **G**roups (`PG`, `pg_num`).

[6] Ceph MON DB commands https://docs.ceph.com/en/latest/rados/configuration/ceph-conf/#commands

8.9.1 Create and Edit Pools

You can create and edit pools from the command line or the web interface of any Proxmox VE host under **Ceph → Pools**.

When no options are given, we set a default of **128 PGs**, a **size of 3 replicas** and a **min_size of 2 replicas**, to ensure no data loss occurs if any OSD fails.



Warning
Do not set a min_size of 1. A replicated pool with min_size of 1 allows I/O on an object when it has only 1 replica, which could lead to data loss, incomplete PGs or unfound objects.

It is advised that you either enable the PG-Autoscaler or calculate the PG number based on your setup. You can find the formula and the PG calculator [7] online. From Ceph Nautilus onward, you can change the number of PGs [8] after the setup.

The PG autoscaler [9] can automatically scale the PG count for a pool in the background. Setting the `Target Size` or `Target Ratio` advanced parameters helps the PG-Autoscaler to make better decisions.

Example for creating a pool over the CLI

```
pveceph pool create <pool-name> --add_storages
```

Tip
If you would also like to automatically define a storage for your pool, keep the 'Add as Storage' checkbox checked in the web interface, or use the command-line option *--add_storages* at pool creation.

Pool Options



The following options are available on pool creation, and partially also when editing a pool.

Name
The name of the pool. This must be unique and can't be changed afterwards.

[7] PG calculator https://web.archive.org/web/20210301111112/http://ceph.com/pgcalc/
[8] Placement Groups https://docs.ceph.com/en/tentacle/rados/operations/placement-groups/
[9] Automated Scaling https://docs.ceph.com/en/tentacle/rados/operations/placement-groups/#automated-scaling

Size
The number of replicas per object. Ceph always tries to have this many copies of an object. Default: `3`.

PG Autoscale Mode
The automatic PG scaling mode [9] of the pool. If set to `warn`, it produces a warning message when a pool has a non-optimal PG count. Default: `warn`.

Add as Storage
Configure a VM or container storage using the new pool. Default: `true` (only visible on creation).

ADVANCED OPTIONS

Min. Size
The minimum number of replicas per object. Ceph will reject I/O on the pool if a PG has less than this many replicas. Default: `2`.

Crush Rule
The rule to use for mapping object placement in the cluster. These rules define how data is placed within the cluster. See Ceph CRUSH & device classes for information on device-based rules.

# of PGs
The number of placement groups [8] that the pool should have at the beginning. Default: `128`.

Target Ratio
The ratio of data that is expected in the pool. The PG autoscaler uses the ratio relative to other ratio sets. It takes precedence over the `target size` if both are set.

Target Size
The estimated amount of data expected in the pool. The PG autoscaler uses this size to estimate the optimal PG count.

Min. # of PGs
The minimum number of placement groups. This setting is used to fine-tune the lower bound of the PG count for that pool. The PG autoscaler will not merge PGs below this threshold.

Further information on Ceph pool handling can be found in the Ceph pool operation [10] manual.

8.9.2 Erasure Coded Pools

Erasure coding (EC) is a form of 'forward error correction' codes that allows to recover from a certain amount of data loss. Erasure coded pools can offer more usable space compared to replicated pools, but they do that for the price of performance.

[10] Ceph pool operation https://docs.ceph.com/en/tentacle/rados/operations/pools/

For comparison: in classic, replicated pools, multiple replicas of the data are stored (`size`) while in erasure coded pool, data is split into `k` data chunks with additional `m` coding (checking) chunks. Those coding chunks can be used to recreate data should data chunks be missing.

The number of coding chunks, `m`, defines how many OSDs can be lost without losing any data. The total amount of objects stored is `k + m`.

Creating EC Pools

Erasure coded (EC) pools can be created with the `pveceph` CLI tooling. Planning an EC pool needs to account for the fact, that they work differently than replicated pools.

The default `min_size` of an EC pool depends on the `m` parameter. If `m = 1`, the `min_size` of the EC pool will be `k`. The `min_size` will be `k + 1` if `m > 1`. The Ceph documentation recommends a conservative `min_size` of `k + 2` [11].

If there are less than `min_size` OSDs available, any IO to the pool will be blocked until there are enough OSDs available again.

Note
When planning an erasure coded pool, keep an eye on the `min_size` as it defines how many OSDs need to be available. Otherwise, IO will be blocked.

For example, an EC pool with `k = 2` and `m = 1` will have `size = 3`, `min_size = 2` and will stay operational if one OSD fails. If the pool is configured with `k = 2`, `m = 2`, it will have a `size = 4` and `min_size = 3` and stay operational if one OSD is lost.

To create a new EC pool, run the following command:

```
pveceph pool create <pool-name> --erasure-coding k=2,m=1
```

Optional parameters are `failure-domain` and `device-class`. If you need to change any EC profile settings used by the pool, you will have to create a new pool with a new profile.

This will create a new EC pool plus the needed replicated pool to store the RBD omap and other metadata. In the end, there will be a `<pool name>-data` and `<pool name>-metadata` pool. The default behavior is to create a matching storage configuration as well. If that behavior is not wanted, you can disable it by providing the `--add_storages 0` parameter. When configuring the storage configuration manually, keep in mind that the `data-pool` parameter needs to be set. Only then will the EC pool be used to store the data objects. For example:

Note
The optional parameters `--size`, `--min_size` and `--crush_rule` will be used for the replicated metadata pool, but not for the erasure coded data pool. If you need to change the `min_size` on the data pool, you can do it later. The `size` and `crush_rule` parameters cannot be changed on erasure coded pools.

[11] Ceph Erasure Coded Pool Recovery https://docs.ceph.com/en/tentacle/rados/operations/erasure-code/#erasure-coded-pool-recovery

If there is a need to further customize the EC profile, you can do so by creating it with the Ceph tools directly [12], and specify the profile to use with the `profile` parameter.

For example:

```
pveceph pool create <pool-name> --erasure-coding profile=<profile-name>
```

FastEC (`allow_ec_optimizations`)

Ceph Tentacle introduces a new erasure coding I/O path called FastEC, enabled per pool via the `allow_ec_opti` flag. FastEC adds partial reads and partial writes on EC pools, substantially improving small random I/O performance — the dominant access pattern of virtual machine disk I/O [13].



Warning
FastEC is a young feature and is still receiving fixes for data integrity and availability problems. Do not enable it on production pools, particularly not on pools that already hold data. If you want to try it, do so on a test cluster running the same Ceph version as production, with your typical workloads. Besides regular I/O, test at least upgrading an existing pool that holds data, discard and trim, resizing, scrubbing and repair, and recovery after an OSD failure. Pools without FastEC are not affected directly. However, they usually share OSDs with the FastEC pool and can become degraded or unavailable if a FastEC bug crashes these OSDs. A separate pool on a production cluster is therefore not a suitable test environment.

Proxmox VE never enables FastEC on its own, it is only active if you set the flag yourself.

FastEC has four requirements that the Ceph monitor enforces:

- the pool must be erasure coded;
- the cluster must be at `require_osd_release` tentacle or later;
- the erasure code profile must use a plugin and technique combination that supports the optimized EC path:

Plugin	Technique	FastEC
`isa`	`reed_sol_van`	yes
`isa`	`cauchy`	no
`jerasure`	`reed_sol_van`	yes
`jerasure`	all others	no
`lrc`	(any)	no
`shec`	(any)	no
`clay`	(any)	no

- the pool's stripe unit must be a multiple of 4096 bytes. The default stripe unit satisfies this, so this is only relevant for pools created with a custom `stripe_unit` in their erasure code profile.

[12] Ceph Erasure Code Profile https://docs.ceph.com/en/tentacle/rados/operations/erasure-code/#erasure-code-profiles
[13] Ceph Erasure Code https://docs.ceph.com/en/tentacle/rados/operations/erasure-code/

If any precondition is not met, `ceph osd pool set <pool>-data allow_ec_optimizations 1` fails with a descriptive error — no silent degradation.

`pveceph` does not set the plugin or technique explicitly when creating an EC profile — both are seeded from the monitor's `osd_pool_default_erasure_code_profile` option (`reed_sol_van` by default on both Squid and Tentacle). The technique requirement is therefore satisfied out of the box unless the operator has overridden this setting. Verify with:

```
ceph config get mon osd_pool_default_erasure_code_profile
```

If the output shows a technique other than `reed_sol_van`, either update the cluster-wide default or create a compatible profile explicitly and pass it via the `profile` property when creating the pool (see above).

Check the cluster release with:

```
ceph osd dump | grep require_osd_release
```

If this reports a release older than `tentacle`, run `ceph osd require-osd-release tentacle` after all OSDs have been upgraded.



Important
`allow_ec_optimizations` is a one-way switch. Once enabled on a pool, the Ceph monitor refuses to clear the flag again, so rolling back requires draining and recreating the pool. Enable it only after validating that FastEC works for your workload on a test cluster.

Enabling FastEC on a pool

FastEC is enabled per pool via the `ceph` CLI. It can be set on both new and existing (populated) pools, but enabling it on a populated pool is discouraged. No data migration or re-encoding takes place; only pool metadata changes. Existing objects keep their old on-disk layout.

To enable FastEC on a pool, run the following command against the data pool (typically named `<pool-name>-da`

```
ceph osd pool set <pool-name>-data allow_ec_optimizations 1
```

Verify the result with:

```
ceph osd pool get <pool-name>-data allow_ec_optimizations
```

The same command reports the current state for any EC pool, which is useful when auditing a cluster.

When the flag is set on a populated pool, be aware of the following:

- **Primary re-election.** FastEC marks data shards 1 through k-1 as non-primary, so PGs whose primary was on one of those shards will re-peer. This is a normal peering event and causes a brief I/O pause per affected PG.
- **Scrub interaction.** Re-peering cancels any in-flight scrub on affected PGs. Those PGs will need to be re-scrubbed after peering completes.

Adding EC Pools as Storage

You can add an already existing EC pool as storage to Proxmox VE. It works the same way as adding an `RBD` pool but requires the extra `data-pool` option.

```
pvesm add rbd <storage-name> --pool <replicated-pool> --data-pool <ec-pool>
```

Tip
Do not forget to add the `keyring` and `monhost` option for any external Ceph clusters, not managed by the local Proxmox VE cluster.

8.9.3 Destroy Pools

To destroy a pool via the GUI, select a node in the tree view and go to the **Ceph** → **Pools** panel. Select the pool to destroy and click the **Destroy** button. To confirm the destruction of the pool, you need to enter the pool name.

Run the following command to destroy a pool. Specify the *-remove_storages* to also remove the associated storage.

```
pveceph pool destroy <name>
```

Note
Pool deletion runs in the background and can take some time. You will notice the data usage in the cluster decreasing throughout this process.

8.9.4 PG Autoscaler

The PG autoscaler allows the cluster to consider the amount of (expected) data stored in each pool and to choose the appropriate pg_num values automatically. It is available since Ceph Nautilus.

You may need to activate the PG autoscaler module before adjustments can take effect.

```
ceph mgr module enable pg_autoscaler
```

The autoscaler is configured on a per pool basis and has the following modes:

warn	A health warning is issued if the suggested `pg_num` value differs too much from the current value.
on	The `pg_num` is adjusted automatically with no need for any manual interaction.
off	No automatic `pg_num` adjustments are made, and no warning will be issued if the PG count is not optimal.

The scaling factor can be adjusted to facilitate future data storage with the `target_size`, `target_size_rati` and the `pg_num_min` options.

Warning
By default, the autoscaler considers tuning the PG count of a pool if it is off by a factor of 3. This will lead to a considerable shift in data placement and might introduce a high load on the cluster.

You can find a more in-depth introduction to the PG autoscaler on Ceph's Blog - New in Nautilus: PG merging and autotuning.

8.10 Ceph CRUSH & Device Classes



The [14] (**C**ontrolled **R**eplication **U**nder **S**calable **H**ashing) algorithm is at the foundation of Ceph.

CRUSH calculates where to store and retrieve data from. This has the advantage that no central indexing service is needed. CRUSH works using a map of OSDs, buckets (device locations) and rulesets (data replication) for pools.

Note
Further information can be found in the Ceph documentation, under the section CRUSH map [a].

[a] CRUSH map https://docs.ceph.com/en/tentacle/rados/operations/crush-map/

[14] https://ceph.com/assets/pdfs/weil-crush-sc06.pdf

This map can be altered to reflect different replication hierarchies. The object replicas can be separated (e.g., failure domains), while maintaining the desired distribution.

A common configuration is to use different classes of disks for different Ceph pools. For this reason, Ceph introduced device classes with luminous, to accommodate the need for easy ruleset generation.

The device classes can be seen in the *ceph osd tree* output. These classes represent their own root bucket, which can be seen with the below command.

```
ceph osd crush tree --show-shadow
```

Example output form the above command:

```
ID  CLASS WEIGHT  TYPE NAME
-16  nvme 2.18307 root default~nvme
-13  nvme 0.72769     host sumi1~nvme
 12  nvme 0.72769         osd.12
-14  nvme 0.72769     host sumi2~nvme
 13  nvme 0.72769         osd.13
-15  nvme 0.72769     host sumi3~nvme
 14  nvme 0.72769         osd.14
 -1       7.70544 root default
 -3       2.56848     host sumi1
 12  nvme 0.72769         osd.12
 -5       2.56848     host sumi2
 13  nvme 0.72769         osd.13
 -7       2.56848     host sumi3
 14  nvme 0.72769         osd.14
```

To instruct a pool to only distribute objects on a specific device class, you first need to create a ruleset for the device class:

```
ceph osd crush rule create-replicated <rule-name> <root> <failure-domain> < ↩
   class>
```

<rule-name>	name of the rule, to connect with a pool (seen in GUI & CLI)
<root>	which crush root it should belong to (default Ceph root "default")
<failure-domain>	at which failure-domain the objects should be distributed (usually host)
<class>	what type of OSD backing store to use (e.g., nvme, ssd, hdd)

Once the rule is in the CRUSH map, you can tell a pool to use the ruleset.

```
ceph osd pool set <pool-name> crush_rule <rule-name>
```

Tip

If the pool already contains objects, these must be moved accordingly. Depending on your setup, this may introduce a big performance impact on your cluster. As an alternative, you can create a new pool and move disks separately.



Warning

The PG autoscaler skips pools whose CRUSH rules use different roots that share OSDs, and does not adjust their `pg_num`. A rule with a device class uses the root of that class, such as `default~nvme` in the example above, which shares its OSDs with the `default` root. This typically affects setups where some pools use a rule with a device class while others, often including the `.mgr` pool, use a rule without one. To avoid this, use rules with a device class either for all pools or for none.

8.11 Cephx Authentication

Cephx [15] protects access to a Ceph cluster.

Every Ceph service and client, including storage consumers and tools, authenticates to a monitor as a Ceph user, such as `client.admin` or `osd.3`, with that user's long-term secret key. The monitor then issues temporary credentials called tickets:

Term	Purpose
User key	Long-term secret used by a client or Ceph service to authenticate to a monitor.
Monitor ticket	Lets an authenticated Ceph user request tickets for Ceph services.
Service ticket	Grants temporary access to an OSD, manager, or metadata server.
Rotating service key	Lets Ceph services validate service tickets. Monitors replace these keys automatically.

A running client usually reads its user key only when it starts. Updating a saved key or keyring file does not update that process. Existing tickets and connections can also remain usable for some time. A key rotation must therefore account for running and temporarily disconnected clients.

8.11.1 Keyring Locations

The authoritative `client.admin` keyring in a Proxmox VE Ceph cluster is `/etc/pve/priv/ceph.client` not the copy in `/etc/ceph`. The Proxmox cluster file system (pmxcfs) synchronizes it to every node. Credentials for managed Ceph storages are below `/etc/pve/priv/ceph/`.

Keyrings below `/var/lib/ceph` belong to one Ceph service and are local to its node. `/etc/pve/priv/cep` contains both the shared `mon.` key and `client.admin`. Always merge updates into this file instead of overwriting it. `pveceph mon create` uses its `mon.` entry when it initializes a monitor.

8.11.2 Encrypted OSD Lockbox Keys

Each encrypted OSD uses a dedicated Ceph user named `client.osd-lockbox.<UUID>`. Its authentication key is called the lockbox key. It is not the disk-encryption key itself: it lets the OSD retrieve that key from Ceph and unlock its storage when it starts. Ceph and the OSD's block device must contain matching copies of the lockbox key.

[15] Cephx authorization and authentication protocol https://docs.ceph.com/en/tentacle/dev/cephx_protocol/

Warning
Never rotate a lockbox key with `ceph auth` alone. Use the migration helper, which verifies the OSD identity and updates both copies together.

8.12 Ceph Client



Add an RBD storage in the web interface to use a Ceph pool for virtual machine and container disks. For an external cluster, follow the authentication instructions to configure a dedicated Ceph user and its keyring.

8.13 CephFS

Ceph also provides a filesystem, which runs on top of the same object storage as RADOS block devices do. A **M**eta**d**ata **S**erver (`MDS`) is used to map the RADOS backed objects to files and directories, allowing Ceph to provide a POSIX-compliant, replicated filesystem. This allows you to easily configure a clustered, highly available, shared filesystem. Ceph's Metadata Servers guarantee that files are evenly distributed over the entire Ceph cluster. As a result, even cases of high load will not overwhelm a single host, which can be an issue with traditional shared filesystem approaches, for example `NFS`.



Proxmox VE supports both creating a hyper-converged CephFS and using an existing CephFS as storage to save backups, ISO files, and container templates.

8.13.1 Metadata Server (MDS)

CephFS needs at least one Metadata Server to be configured and running, in order to function. You can create an MDS through the Proxmox VE web GUI's `Node -> CephFS` panel or from the command line with:

```
pveceph mds create
```

Multiple metadata servers can be created in a cluster, but with the default settings, only one can be active at a time. If an MDS or its node becomes unresponsive (or crashes), another `standby` MDS will get promoted to `active`. You can speed up the handover between the active and standby MDS by using the *hotstandby* parameter option on creation, or if you have already created it you may set/add:

```
mds standby replay = true
```

in the respective MDS section of `/etc/pve/ceph.conf`. With this enabled, the specified MDS will remain in a `warm` state, polling the active one, so that it can take over faster in case of any issues.

Note
This active polling will have an additional performance impact on your system and the active `MDS`.

Multiple Active MDS

Since Luminous (12.2.x) you can have multiple active metadata servers running at once, but this is normally only useful if you have a high amount of clients running in parallel. Otherwise the `MDS` is rarely the bottleneck in a system. If you want to set this up, please refer to the Ceph documentation. [16]

8.13.2 Create CephFS

With Proxmox VE's integration of CephFS, you can easily create a CephFS using the web interface, CLI or an external API interface. Some prerequisites are required for this to work:

PREREQUISITES FOR A SUCCESSFUL CEPHFS SETUP:

- Install Ceph packages - if this was already done some time ago, you may want to rerun it on an up-to-date system to ensure that all CephFS related packages get installed.
- Setup Monitors
- Setup your OSDs
- Setup at least one MDS

After this is complete, you can simply create a CephFS through either the Web GUI's `Node -> CephFS` panel or the command-line tool `pveceph`, for example:

```
pveceph fs create --pg_num 128 --add-storage
```

This creates a CephFS named *cephfs*, using a pool for its data named *cephfs_data* with *128* placement groups and a pool for its metadata named *cephfs_metadata* with one quarter of the data pool's placement groups (`32`). Check the Proxmox VE managed Ceph pool chapter or visit the Ceph documentation for more information regarding an appropriate placement group number (`pg_num`) for your setup [8]. Additionally, the *--add-storage* parameter will add the CephFS to the Proxmox VE storage configuration after it has been created successfully.

8.13.3 Destroy CephFS



Warning
Destroying a CephFS will render all of its data unusable. This cannot be undone!

To completely and gracefully remove a CephFS, the following steps are necessary:

- Disconnect every non-Proxmox VE client (e.g. unmount the CephFS in guests).
- Disable all related CephFS Proxmox VE storage entries (to prevent it from being automatically mounted).
- Remove all used resources from guests (e.g. ISOs) that are on the CephFS you want to destroy.

[16] Configuring multiple active MDS daemons https://docs.ceph.com/en/tentacle/cephfs/multimds/

- Unmount the CephFS storages on all cluster nodes manually with

```
umount /mnt/pve/<STORAGE-NAME>
```

  Where <STORAGE-NAME> is the name of the CephFS storage in your Proxmox VE.

- Now make sure that no metadata server (MDS) is running for that CephFS, either by stopping or destroying them. This can be done through the web interface or via the command-line interface, for the latter you would issue the following command:

```
pveceph stop --service mds.NAME
```

  to stop them, or

```
pveceph mds destroy NAME
```

  to destroy them.

  Note that standby servers will automatically be promoted to active when an active MDS is stopped or removed, so it is best to first stop all standby servers.

- Now you can destroy the CephFS with

```
pveceph fs destroy NAME --remove-storages --remove-pools
```

  This will automatically destroy the underlying Ceph pools as well as remove the storages from pve config.

After these steps, the CephFS should be completely removed and if you have other CephFS instances, the stopped metadata servers can be started again to act as standbys.

8.14 Ceph Maintenance

8.14.1 Replace OSDs

With the following steps you can replace the disk of an OSD, which is one of the most common maintenance tasks in Ceph. If there is a problem with an OSD while its disk still seems to be healthy, read the troubleshooting section first.

1. If the disk failed, get a recommended replacement disk of the same type and size.
2. Destroy the OSD in question.
3. Detach the old disk from the server and attach the new one.
4. Create the OSD again.
5. After automatic rebalancing, the cluster status should switch back to HEALTH_OK. Any still listed crashes can be acknowledged by running the following command:

```
ceph crash archive-all
```

8.14.2 Trim/Discard

It is good practice to run *fstrim* (discard) regularly on VMs and containers. This releases data blocks that the filesystem isn't using anymore. It reduces data usage and resource load. Most modern operating systems issue such discard commands to their disks regularly. You only need to ensure that the Virtual Machines enable the disk discard option.

8.14.3 Scrub & Deep Scrub

Ceph ensures data integrity by *scrubbing* placement groups. Ceph checks every object in a PG for its health. There are two forms of Scrubbing, daily cheap metadata checks and weekly deep data checks. The weekly deep scrub reads the objects and uses checksums to ensure data integrity. If a running scrub interferes with business (performance) needs, you can adjust the time when scrubs [17] are executed.

8.14.4 Mute a Health Check

Muting a health check keeps it visible but excludes it from the overall health status, making new problems easier to notice. Ceph continues evaluating the check. Use a duration so that a deferred warning returns automatically, for example after two weeks:

```
ceph health mute <CHECK> 2w
```

In the web interface, expand the check under **Datacenter** → **Ceph**, click *Mute*, and set a duration. The check stays in the list, marked as muted; use *Unmute* in the same place to restore it earlier.

By default, a mute clears when more items become affected. Enable *Keep Mute*, or add `--sticky` to the command, only if the check should stay muted in that case. This does not change the duration: a timed sticky mute still expires.

Note
Muting does not resolve the condition. You accept its risk for as long as the mute lasts.

8.14.5 Migrate Cephx Keys from `aes` to `aes256k`

This section explains how to migrate the cluster-owned keys and the keys of compatible Ceph users from `aes` to `aes256k`. For an explanation of Ceph users, tickets, and key storage, see Cephx Authentication.

Why the Health Checks Appear

Ceph Squid 19.2.6 and Ceph Tentacle 20.2.4 add health checks for keys and temporary access credentials that use the older `aes` encryption method. The checks can therefore appear directly after an upgrade even if the cluster worked without warnings before. The older method is affected by *CVE-2025-30156*. See the upstream release announcement for background [18].

Two checks set the cluster status to *HEALTH_ERR*. This does not mean that storage access or a Ceph service has failed. Follow the steps below to migrate to `aes256k` and, when all clients support it, disable the vulnerable method.

[17] Ceph scrubbing https://docs.ceph.com/en/tentacle/rados/configuration/osd-config-ref/#scrubbing
[18] Ceph: Squid v19.2.6 and Tentacle v20.2.4 released https://ceph.io/en/news/blog/2026/v20-2-4-v19-2-6-combo-released/

Migration Steps

The migration helper checks the cluster, rotates keys, and resumes interrupted work. Review each dry run before applying its plan; add `--verbose` for full node, keyring, and device inventories and inspection diagnostics.

Reruns do not rotate completed keys again. After each run, invoke the helper without options to check the current state and follow the next steps it prints.

BEFORE YOU BEGIN

- Upgrade `pve-manager` to 9.2.19 or newer and install the latest Ceph packages on every node. Staged client-key rotation requires Ceph 19.2.6-pve3, 20.2.4-pve3, or newer on every monitor.
- Then complete the rolling restart of all Ceph services.
- Resolve health warnings and errors not listed in Health Check Reference. Ensure every node is reachable over SSH.
- Run the helper as `root` on one node only. Do not start another migration, a rolling restart, or change Ceph keys with other tools while it runs. The helper's lock does not block direct Ceph authentication commands.
- If Cephx is disabled on this cluster, follow Clusters with Cephx Disabled instead.

1. Migrate the Cluster-Owned Keys

Review the cluster-owned migration in the default dry-run mode:

```
/usr/share/pve-manager/migrations/pve-cephx-rotate-service-keys --rotate- ↩
   cluster-keys
```

If the plan reports no blocker, apply the same selection:

```
/usr/share/pve-manager/migrations/pve-cephx-rotate-service-keys --rotate- ↩
   cluster-keys --apply
```

The helper rotates the manager, metadata server, OSD, monitor, bootstrap, crash, and encrypted OSD lockbox keys. It restarts services one at a time when needed, including monitors. Storage-user keys and `client.admin` stay unchanged, existing tickets remain valid, and the old cipher stays enabled.

After Ceph updates its health status, the two error-severity checks clear. The warning about rotating service keys can remain for a few hours while old rotating keys expire. You do not need to wait for this warning to clear before continuing with the migration.

2. Migrate the Keys of Compatible Ceph Users

Check compatibility

Several workloads can share one Ceph user. Migrate its key only when every client supports `aes256k`, including disconnected and external clients. Ceph programs from the updated Proxmox VE packages support it; kernel clients require a **running** kernel version 7.0 or newer.

Virtual machine with RBD disks	Userspace, unless `krbd` is enabled.
Container on RBD	Always the kernel client.
CephFS mount	Kernel, unless `fuse` is enabled.

Check external systems too. If any affected client is incompatible or unknown, leave its user's key unchanged and postpone this step.

Stage the keys

Use `--rotate-all-storage-keys` for the dedicated users of managed local RBD and CephFS storages, together with `--rotate-admin-key` for `client.admin`, which the command line and storages without their own user share. Every client of these users is affected; storages of external clusters are excluded.

The helper stages each new key and writes it to the managed keyring and secret files. Both keys remain valid until confirmation, allowing clients to refresh before the old key is retired. If a monitor cannot keep both keys valid, the helper refuses staging and names the monitor to update or restart.

Review the combined plan:

```
/usr/share/pve-manager/migrations/pve-cephx-rotate-service-keys \
    --rotate-all-storage-keys --rotate-admin-key
```

If the plan reports no blocker, apply it:

```
/usr/share/pve-manager/migrations/pve-cephx-rotate-service-keys \
    --rotate-all-storage-keys --rotate-admin-key --apply
```

While a key is staged, do not add or downgrade monitors or change that user's keys with other tools. Its `AUTH_INSECURE_CLIENT_KEY_TYPE` warning remains until confirmation makes the new key current and invalidates the old one.

Refresh Clients

Refresh the clients after applying the plan, as they can only load a new key once it is staged:

- Live-migrate affected virtual machines in the web interface, or stop and start them. A guest reboot is not enough.
- Stop and start affected containers and other RBD clients.
- Let backups, restores, disk imports, and clones on Ceph storage finish before confirmation; these operations can retain the key they started with.
- The helper refreshes idle CephFS mounts and leaves busy or unresponsive mounts alone. Once nothing uses them, rerun the helper with `--apply` to retry the outstanding mounts. If your virtual machines have ISOs from a CephFS mount attached, you may have to detach the ISOs or migrate affected virtual machines to a different node to be able to refresh the CephFS mount on that node.
- For clients outside Proxmox VE, distribute the staged credential from the managed key files, then restart or remount those clients.

Then run the helper without options. It lists the sessions that may still hold an old key. Where it finds the kernel client of a session, it names the RBD mapping, with the container or virtual machine configured to use it, if any, or the CephFS client, with the CephFS mounts of the cluster found on that node. Other client hints, such as the virtual machines connected from a node, are host-wide, not session attribution or a complete workload inventory. Refresh the affected clients and run the helper again until it prints a confirmation command. Check disconnected clients and external key copies yourself.

3. Finish or Pause the Migration

Run a final dry run to check for remaining old-key sessions. It offers a confirmation command when its observed checks pass, but cannot verify disconnected clients or external key copies for you.

```
/usr/share/pve-manager/migrations/pve-cephx-rotate-service-keys
```



Warning
Clients that still need an old key or cipher cannot authenticate after this step. Existing IO can appear to work until a reconnect and then fail. Do not use `--force` to bypass a blocker.

After checking disconnected clients and external copies, run the exact command the dry run prints. When every rotation is ready and no key needs the old cipher, it will print the options `--apply --confirm-all-clie --restrict-ciphers`.

If any client remains incompatible, keep its key unchanged and the old cipher enabled rather than restricting it. You can mute the remaining warnings while waiting for those clients to upgrade.

Use `pveceph auth status` for current and pending key ciphers, as `ceph auth ls` does not list pending keys.

Note
`/etc/pve/priv/cephx-key-migration.json` records progress and contains secret old keys. Protect it and keep it until the migration is complete and every client has been refreshed. Deleting it earlier loses the records needed to resume.

Additional Migration Details

Health Check Reference

Health check	Meaning	Action
`AUTH_INSECURE_SERVICE_KEY_TYPE`	A Ceph service key uses the old cipher.	Run the cluster-owned migration. This check has error severity.
`AUTH_INSECURE_SERVICE_TICKETS`	Monitors issue service tickets with the old cipher.	Run the cluster-owned migration. This check has error severity.
`AUTH_INSECURE_CLIENT_KEY_TYPE`	The active key of a Ceph user uses the old cipher. A staged user stays listed until its rotation is confirmed.	Rotate the keys of compatible users and confirm them, or mute the warning.

Health check	Meaning	Action
AUTH_INSECURE_ROTATING_SERVICE_KEY	A rotating service key uses the old cipher.	Continue the migration; old rotating keys expire automatically and do not prevent final cipher restriction.
AUTH_INSECURE_KEYS_ALLOWED	Monitors accept the old cipher.	Finish the migration, or mute the warning while old clients remain.
AUTH_INSECURE_KEYS_CREATABLE	Monitors can create old-cipher keys.	Finish the migration, or mute the warning while old clients remain.

Clusters with Cephx Disabled

Ceph evaluates these health checks from the stored keys and cipher settings, also when Cephx is disabled, that is, when `auth_cluster_required`, `auth_service_required`, and `auth_client_required` are set to `none`. Disabling Cephx therefore does not clear them, and changing the authentication method interrupts existing clients, which need a restart or remount afterwards.

Only run a cluster without Cephx if its public network, not only its cluster network, is reachable solely by hosts you trust with full administrative access to Ceph. In particular, keep untrusted guests off that network. Without Cephx, Ceph grants every connection full access, whatever Ceph user it claims, and does not sign or encrypt messages. The Ceph project recommends against disabling Cephx [19]. Disabling it does not repair a failed key migration.

On a cluster with Cephx disabled:

1. Run the helper without options and apply its plan. It migrates the manager, metadata server, and OSD keys, restarting services one at a time when needed, and switches the service tickets to the new cipher. This clears both error-severity checks. If an old `mon.` key is stored in the authentication database, the helper instead refuses and asks you to migrate that key first.
2. Optionally, migrate the bootstrap and crash keys with `--rotate-client-keys`.
3. Mute the remaining warnings without a duration. While Cephx is disabled, the helper does not migrate the keys of other Ceph users, as their clients do not authenticate with Cephx:

```
ceph health mute AUTH_INSECURE_CLIENT_KEY_TYPE --sticky
ceph health mute AUTH_INSECURE_KEYS_ALLOWED --sticky
ceph health mute AUTH_INSECURE_KEYS_CREATABLE --sticky
```

Do not restrict the allowed ciphers or forbid creating old-cipher keys by hand while the preferred cipher is still `aes`, as creating keys then fails.

Before you enable Cephx again, unmute these checks and make sure that every monitor, Ceph service, and client still has a key file matching the authentication database. Restart the monitors first, then all other Ceph services, and restart or remount the clients. Then run the migration as described in Migration Steps.

Staged Keys and Confirmation

The helper disables automatic promotion of pending client keys so that the monitors keep both credentials valid. An older monitor would promote a staged key on its first use and end the grace period for the whole

[19] Ceph: Disabling Cephx https://docs.ceph.com/en/tentacle/rados/configuration/auth-config-ref/#disabling-cephx

cluster. The helper therefore stages only when every monitor supports the feature and checks this again on every run.

With `--apply`, `--confirm-all-clients-refreshed` makes every staged key current and invalidates its previous key. The initial check refuses the entire batch if any open rotation is not ready. The helper then rechecks each key before retiring its old credential. If a client returns during the batch, completed rotations stay committed and the blocked key stays staged. To confirm ready users separately, use `--confirm-clients-refreshed <USER>` with `--apply`.

Ceph 19.2.6-pve4 and 20.2.4-pve4 or newer monitors can identify each session's key, allowing refreshed clients to stay connected during forward or rollback confirmation. Upgrade and restart older monitors to use this feature. Without key identification, every visible client of that user must disconnect before confirmation; upgrading is preferable for a shared user such as `client.admin`.

Key Copies for External Clients

For an external client of the local cluster, copy the staged credential from the managed file for its Ceph user:

- RBD keyring: `/etc/pve/priv/ceph/<STORAGE_ID>.keyring`
- CephFS bare secret: `/etc/pve/priv/ceph/<STORAGE_ID>.secret`
- Administrative keyring: `/etc/pve/priv/ceph.client.admin.keyring`

Use the credential for that user, not `client.admin` as a substitute. Transfer it securely and update every saved copy before refreshing the client. Storage backed by an external cluster is different: the helper never rotates that cluster's keys. Follow its administrator's key-rotation procedure.

A storage with `monhost` set counts as external even if its monitors belong to the local cluster, so the helper does not update its key copy. If that copy holds the key of a Ceph user you migrate, update it with the staged key of the same user before confirming, or with the restored key before confirming a rollback. The helper refuses to retire a key it finds in a storage key copy; verify copies it cannot check yourself.

Ceph Users Not Managed by Proxmox VE

The helper lists local users not managed by Proxmox VE separately, as keys that need manual migration. Follow their client's supported rotation procedure, or leave their keys unchanged and keep the old cipher enabled.

If every client of such a user supports `aes256k`, move the clients to a new user with an `aes256k` key. Both users work side by side, so each client can switch when convenient, for example one node of a Kubernetes cluster using Ceph CSI at a time. For a user `client.app` with RBD access to the pool `vm-pool`:

1. Show the capabilities of the current user:

```
ceph auth get client.app
```

2. Create the new user with the same capabilities and an `aes256k` key:

```
ceph auth get-or-create client.app2 mon 'profile rbd' \
    osd 'profile rbd pool=vm-pool' --key-type=aes256k
```

3. Transfer the printed keyring securely and configure every client to use the new user.
4. Once a dry run of the helper with `--restrict-ciphers` lists no client connected as `client.app` any more, delete that user:

```
ceph auth del client.app
```

Alternatively, you can rotate the key in place with `ceph auth rotate --key-type=aes256k <USER>` [20]. This replaces the key at once, without the grace period of a staged key. Transfer the printed keyring securely, update every saved copy and refresh the clients.

If an earlier helper run with `--apply` recorded the previous key, the helper then asks you to confirm the refresh with `--confirm-clients-refreshed <USER> --apply`. The first confirmation may only record which clients are connected. In that case, repeat the command.

Roll Back a Staged Client Key

To return a staged user to its current key:

1. Run the helper with `--abort-staged-key <USER> --apply`. It restores the current key to every managed copy while both credentials remain valid.
2. Refresh all clients back to that key, including disconnected clients and external key copies. The helper retries managed CephFS mounts as during forward migration.
3. Run the helper with `--confirm-abort-clients-refreshed <USER> --apply` to retire the staged key. The helper refuses if monitor session collection is incomplete, a visible session uses the staged key, its key is unknown, or a storage key copy still holds the staged key.

Emergency Cipher Override

Monitors normally use the `auth_allowed_ciphers` list stored in the MonMap to decide which key ciphers may authenticate. The local startup option `mon_auth_emergency_allowed_ciphers` replaces that list for a monitor. It can temporarily allow the cipher of an existing administrative key after an incorrect restriction locked administrators out [21].

Ceph raises `AUTH_EMERGENCY_CIPHERS_SET` while this override is configured. The helper refuses the final restriction because changing the MonMap would not take effect. Use the override only to recover access, then repair the normal configuration, remove it from `/etc/pve/ceph.conf`, and restart every monitor before the final dry run.

Interrupted Runs and Manual Fallback

After an interruption, run the helper without options once the affected nodes are reachable. Unfinished key updates can resume while their daemons are stopped. Keep the journal unchanged and follow the printed next steps rather than starting a manual rotation. Check the affected nodes and service logs rather than assuming a down daemon's key needs repair.

[20] Ceph key rotation https://docs.ceph.com/en/latest/rados/configuration/auth-config-ref/#upgrading-and-rotating-cephx-keys

[21] Ceph: Emergency Allowed Ciphers https://docs.ceph.com/en/tentacle/rados/configuration/auth-config-ref/#emergency-allowed-ciphers

If the helper still cannot proceed, install the latest `pve-manager` and retry. Contact Proxmox support before editing the journal or keyrings, or before using the upstream Cephx key migration procedure [22]. That procedure changes the Ceph authentication database, but does not account for these Proxmox VE details:

- Ensure every managed key copy below `/etc/pve/priv` and `/var/lib/ceph` contains the key that Ceph accepts. Merge changes into `/etc/pve/priv/ceph.mon.keyring`; never overwrite it.
- Update an encrypted OSD's lockbox key in both the authentication database and its block-device LVM tag. Its temporary keyring is not the persistent copy.
- Refresh every client before invalidating its previous Ceph user key.
- Rotate `client.admin` last and prepare an independently tested recovery user before changing it.

Use manual key-rotation or cipher-restriction commands only with a complete, tested recovery plan that covers every item above.

8.14.6 Shutdown Proxmox VE + Ceph HCI Cluster

To shut down the whole Proxmox VE + Ceph cluster, first stop all Ceph clients. These will mainly be VMs and containers. If you have additional clients that might access a Ceph FS or an installed RADOS GW, stop these as well. Highly available guests will switch their state to *stopped* when powered down via the Proxmox VE tooling.

Once all clients, VMs and containers are off or not accessing the Ceph cluster anymore, verify that the Ceph cluster is in a healthy state. Either via the Web UI or the CLI:

```
ceph -s
```

In order to not cause any recovery during the shut down and later power on phases, enable the *noout* OSD flag. Either in the **Ceph** → **OSD** panel behind the **Manage Global Flags** button or the CLI:

```
ceph osd set noout
```

Start powering down your nodes without a monitor (MON). After these nodes are down, continue by shutting down nodes with monitors on them.

When powering on the cluster, start the nodes with monitors (MONs) first. Once all nodes are up and running, confirm that all Ceph services are up and running. In the end, the only warning you should see for Ceph is that the *noout* flag is still set. You can disable it via the web UI or via the CLI:

```
ceph osd unset noout
```

You can now start up the guests. Highly available guests will change their state to *started* when they power on.

[22] Ceph documentation: https://docs.ceph.com/en/tentacle/rados/configuration/auth-config-ref/#cephx-upgrade

8.14.7 Network Changes

It is possible to change the networks used by Ceph in a HCI setup without any downtime if **both the old and new networks can be configured at the same time**.

The procedure differs depending on which network you want to change.

Note
A word of caution! It is critical that the change of the used networks by Ceph is being done carefully. Otherwise it could lead to a broken Ceph cluster with downtime to get it back into a working state! We recommend doing a trial run of the procedure in a (virtual) test cluster before changing the production infrastructure.

After the new network has been configured on all hosts, make sure you test it before proceeding with the changes. One way is to ping all hosts on the new network. If you use a large MTU, make sure to also test that it works. For example by sending ping packets that will result in a final packet at the max MTU size.

To test an MTU of 9000, you will need the following packet sizes:

Note
We assume a simple network configuration. In more complicated setups, you might need to configure a lower MTU to account for any headers that might be added once a packet leaves the host.

IPv4	The overhead of IP and ICMP is *28* bytes; the resulting packet size for the ping then is *8972* bytes.
IPv6	The overhead is *48* bytes and the resulting packet size is *8952* bytes.

The resulting ping command will look like this for an IPv4:

```
ping -M do -s 8972 {target IP}
```

When you are switching between IPv4 and IPv6 networks, you need to make sure that the following options in the `ceph.conf` file are correctly set to `true` or `false`. These config options configure if Ceph services should bind to IPv4 or IPv6 addresses.

```
ms_bind_ipv4 = true
ms_bind_ipv6 = false
```

Change the Ceph Public Network

The Ceph Public network is the main communication channel in a Ceph cluster between the different services and clients (for example, a VM). Changing it to a different network is not as simple as changing the Ceph Cluster network. The main reason is that besides the configuration in the `ceph.conf` file, the Ceph MONs (monitors) have an internal configuration where they keep track of all the other MONs that are part of the cluster, the *monmap*.

Therefore, the procedure to change the Ceph Public network is a bit more involved:

1. Change `public_network` in the `/etc/pve/ceph.conf` file (do not change any other value)

---

2. Restart non MON services: OSDs, MGRs and MDS on one host
3. Wait until Ceph is back to *HEALTH_OK*
4. Verify services are using the new network
5. Continue restarting services on the next host
6. Destroy one MON
7. Recreate MON
8. Wait until Ceph is back to *HEALTH_OK*
9. Continue destroying and recreating MONs

You first need to edit the `/etc/pve/ceph.conf` file. Change the `public_network` line to match the new subnet.

```
public_network = 10.9.9.30/24
```



Warning
Do not change the `mon_host` line or any `[mon.HOSTNAME]` sections. These will be updated automatically when the MONs are destroyed and recreated.

Note
Don't worry if the host bits (for example, the last octet) are set by default, the netmask in CIDR notation defines the network part.

After you have changed the network, you need to restart the non MON services in the cluster for the changes to take effect. Do so one node at a time! To restart all non MON services on one node, you can use the following commands on that node. Ceph has `systemd` targets for each type of service.

```
systemctl restart ceph-osd.target
systemctl restart ceph-mgr.target
systemctl restart ceph-mds.target
```

Note
You will only have MDS daemons (Metadata Servers) if you use CephFS.

Note
After the first OSD service got restarted, the GUI will complain that the OSD is not reachable anymore. This is not an issue; VMs can still reach them. The reason for the message is that the MGR service cannot reach the OSD anymore. The error will vanish after the MGR services get restarted.



Warning
Do not restart OSDs on multiple hosts at the same time. Chances are that for some PGs (placement groups), 2 out of the (default) 3 replicas will be down. This will result in I/O being halted until the minimum required number (`min_size`) of replicas is available again.

To verify that the services are listening on the new network, you can run the following command on each node:

```
ss -tulpn | grep ceph
```

Note
Since OSDs will also listen on the Ceph Cluster network, expect to see that network too in the output of `ss -tulpn`.

Once the Ceph cluster is back in a fully healthy state (*HEALTH_OK*), and the services are listening on the new network, continue to restart the services on the host.

The last services that need to be moved to the new network are the Ceph MONs themselves. The easiest way is to destroy and recreate each monitor one by one. This way, any mention of it in the `ceph.conf` and the monitor internal `monmap` is handled automatically.

Destroy the first MON and create it again. Wait a few moments before you continue on to the next MON in the cluster, and make sure the cluster reports *HEALTH_OK* before proceeding.

Once all MONs are recreated, you can verify that any mention of MONs in the `ceph.conf` file references the new network. That means mainly the `mon_host` line and the `[mon.HOSTNAME]` sections.

One final `ss -tulpn | grep ceph` should show that the old network is not used by any Ceph service anymore.

Change the Ceph Cluster Network

The Ceph Cluster network is used for the replication traffic between the OSDs. Therefore, it can be beneficial to place it on its own fast physical network.

The overall procedure is:

1. Change `cluster_network` in the `/etc/pve/ceph.conf` file
2. Restart OSDs on one host
3. Wait until Ceph is back to *HEALTH_OK*
4. Verify OSDs are using the new network
5. Continue restarting OSDs on the next host

You first need to edit the `/etc/pve/ceph.conf` file. Change the `cluster_network` line to match the new subnet.

```
cluster_network = 10.9.9.30/24
```

Note
Don't worry if the host bits (for example, the last octet) are set by default; the netmask in CIDR notation defines the network part.

After you have changed the network, you need to restart the OSDs in the cluster for the changes to take effect. Do so one node at a time! To restart all OSDs on one node, you can use the following command on the CLI on that node:

```
systemctl restart ceph-osd.target
```



Warning
Do not restart OSDs on multiple hosts at the same time. Chances are that for some PGs (placement groups), 2 out of the (default) 3 replicas will be down. This will result in I/O being halted until the minimum required number (`min_size`) of replicas is available again.

To verify that the OSD services are listening on the new network, you can either check the **OSD Details** → **Network** tab in the **Ceph** → **OSD** panel or by running the following command on the host:

```
ss -tulpn | grep ceph-osd
```

Note
Since OSDs will also listen on the Ceph Public network, expect to see that network too in the output of `ss -tulpn`.

Once the Ceph cluster is back in a fully healthy state (*HEALTH_OK*), and the OSDs are listening on the new network, continue to restart the OSDs on the next host.

8.15 Ceph Monitoring and Troubleshooting

It is important to continuously monitor the health of a Ceph deployment from the beginning, either by using the Ceph tools or by accessing the status through the Proxmox VE API.

The following Ceph commands can be used to see if the cluster is healthy (*HEALTH_OK*), if there are warnings (*HEALTH_WARN*), or even errors (*HEALTH_ERR*). If the cluster is in an unhealthy state, the status commands below will also give you an overview of the current events and actions to take. To stop their execution, press CTRL-C.

Continuously watch the cluster status:

```
watch ceph --status
```

Print the cluster status once (not being updated) and continuously append lines of status events:

```
ceph --watch
```

8.15.1 Troubleshooting

This section includes frequently used troubleshooting information. More information can be found on the official Ceph website under Troubleshooting [23].

Relevant Logs on Affected Node

- Disk Health Monitoring
- *System* → *System Log* or via the CLI, for example of the last 2 days:

```
journalctl --since "2 days ago"
```

- IPMI and RAID controller logs

Ceph service crashes can be listed and viewed in detail by running the following commands:

```
ceph crash ls
ceph crash info <crash_id>
```

Crashes marked as new can be acknowledged by running:

```
ceph crash archive-all
```

To get a more detailed view, every Ceph service has a log file under `/var/log/ceph/`. If more detail is required, the log level can be adjusted [24].

Common Causes of Ceph Problems

- Network problems like congestion, a faulty switch, a shut down interface or a blocking firewall. Check whether all Proxmox VE nodes are reliably reachable on the corosync cluster network and on the Ceph public and cluster network.
- Disk or connection parts which are:
  - defective
  - not firmly mounted
  - lacking I/O performance under higher load (e.g. when using HDDs, consumer hardware or inadvisable RAID controllers)
- Not fulfilling the recommendations for a healthy Ceph cluster.

Common Ceph Problems

OSDs `down`/crashed

A faulty OSD will be reported as `down` and mostly (auto) `out` 10 minutes later. Depending on the cause, it can also automatically become `up` and `in` again. To try a manual activation via web interface, go to *Any node* → *Ceph* → *OSD*, select the OSD and click on **Start**, **In** and **Reload**. When using the shell, run following command on the affected node:

[23] Ceph troubleshooting https://docs.ceph.com/en/tentacle/rados/troubleshooting/
[24] Ceph log and debugging https://docs.ceph.com/en/tentacle/rados/troubleshooting/log-and-debug/

```
ceph-volume lvm activate --all
```

To activate a failed OSD, it may be necessary to safely reboot the respective node or, as a last resort, to recreate or replace the OSD.

Chapter 9

Storage Replication

The `pvesr` command-line tool manages the Proxmox VE storage replication framework. Storage replication brings redundancy for guests using local storage and reduces migration time.

It replicates guest volumes to another node so that all data is available without using shared storage. Replication uses snapshots to minimize traffic sent over the network. Therefore, new data is sent only incrementally after the initial full sync. In the case of a node failure, your guest data is still available on the replicated node.

The replication is done automatically in configurable intervals. The minimum replication interval is one minute, and the maximal interval once a week. The format used to specify those intervals is a subset of `systemd` calendar events, see Schedule Format section:

It is possible to replicate a guest to multiple target nodes, but not twice to the same target node.

Each replications bandwidth can be limited, to avoid overloading a storage or server.

Only changes since the last replication (so-called `deltas`) need to be transferred if the guest is migrated to a node to which it already is replicated. This reduces the time needed significantly. The replication direction automatically switches if you migrate a guest to the replication target node.

For example: VM100 is currently on `nodeA` and gets replicated to `nodeB`. You migrate it to `nodeB`, so now it gets automatically replicated back from `nodeB` to `nodeA`.

If you migrate to a node where the guest is not replicated, the whole disk data must send over. After the migration, the replication job continues to replicate this guest to the configured nodes.



Important
High-Availability is allowed in combination with storage replication, but there may be some data loss between the last synced time and the time a node failed.

9.1 Supported Storage Types

Table 9.1: Storage Types

Description	Plugin type	Snapshots	Stable
ZFS (local)	zfspool	yes	yes

9.2 Schedule Format

Replication uses calendar events for configuring the schedule.

9.3 Error Handling

If a replication job encounters problems, it is placed in an error state. In this state, the configured replication intervals get suspended temporarily. The failed replication is repeatedly tried again in a 30 minute interval. Once this succeeds, the original schedule gets activated again.

9.3.1 Possible issues

Some of the most common issues are in the following list. Depending on your setup there may be another cause.

- Network is not working.
- No free space left on the replication target storage.
- Storage with the same storage ID is not available on the target node.

Note
You can always use the replication log to find out what is causing the problem.

9.3.2 Migrating a guest in case of Error

In the case of a grave error, a virtual guest may get stuck on a failed node. You then need to move it manually to a working node again.

9.3.3 Example

Let's assume that you have two guests (VM 100 and CT 200) running on node A and replicate to node B. Node A failed and can not get back online. Now you have to migrate the guest to Node B manually.

- connect to node B over ssh or open its shell via the web UI
- check if that the cluster is quorate

```
# pvecm status
```

- If you have no quorum, we strongly advise to fix this first and make the node operable again. Only if this is not possible at the moment, you may use the following command to enforce quorum on the current node:

```
# pvecm expected 1
```

Warning
Avoid changes which affect the cluster if `expected votes` are set (for example adding/removing nodes, storages, virtual guests) at all costs. Only use it to get vital guests up and running again or to resolve the quorum issue itself.

- move both guest configuration files form the origin node A to node B:

```
# mv /etc/pve/nodes/A/qemu-server/100.conf /etc/pve/nodes/B/qemu-server ↩
   /100.conf
# mv /etc/pve/nodes/A/lxc/200.conf /etc/pve/nodes/B/lxc/200.conf
```

- Now you can start the guests again:

```
# qm start 100
# pct start 200
```

Remember to replace the VMIDs and node names with your respective values.

9.4 Managing Jobs



You can use the web GUI to create, modify, and remove replication jobs easily. Additionally, the command-line interface (CLI) tool `pvesr` can be used to do this.

You can find the replication panel on all levels (datacenter, node, virtual guest) in the web GUI. They differ in which jobs get shown: all, node- or guest-specific jobs.

When adding a new job, you need to specify the guest if not already selected as well as the target node. The replication schedule can be set if the default of `all 15 minutes` is not desired. You may impose a rate-limit on a replication job. The rate limit can help to keep the load on the storage acceptable.

A replication job is identified by a cluster-wide unique ID. This ID is composed of the VMID in addition to a job number. This ID must only be specified manually if the CLI tool is used.

9.5 Network

By default, replication traffic will go through the same network as the guest migration traffic. If the migration network is not set, this will in turn default to the management network.

To use a different network for the replication traffic, configure the `Replication Network` in the web interface under `Datacenter -> Options -> Replication Settings` or set the `replication` property in the `datacenter.cfg` file:

```
# use dedicated replication network
replication: secure,network=10.1.2.0/24
```

9.6 Command-line Interface Examples

Create a replication job which runs every 5 minutes with a limited bandwidth of 10 Mbps (megabytes per second) for the guest with ID 100.

```
# pvesr create-local-job 100-0 pve1 --schedule "*/5" --rate 10
```

Disable an active job with ID `100-0`.

```
# pvesr disable 100-0
```

Enable a deactivated job with ID `100-0`.

```
# pvesr enable 100-0
```

Change the schedule interval of the job with ID `100-0` to once per hour.

```
# pvesr update 100-0 --schedule '*/00'
```

Chapter 10

QEMU/KVM Virtual Machines

QEMU (short form for Quick Emulator) is an open source hypervisor that emulates a physical computer. From the perspective of the host system where QEMU is running, QEMU is a user program which has access to a number of local resources like partitions, files, network cards which are then passed to an emulated computer which sees them as if they were real devices.

A guest operating system running in the emulated computer accesses these devices, and runs as if it were running on real hardware. For instance, you can pass an ISO image as a parameter to QEMU, and the OS running in the emulated computer will see a real CD-ROM inserted into a CD drive.

QEMU can emulate a great variety of hardware, from ARM to Sparc. On x86 hosts, Proxmox VE is concerned with 32-bit and 64-bit PC clone emulation, since it represents the overwhelming majority of server hardware. On arm64 hosts, Proxmox VE emulates 64-bit ARM (aarch64) machines instead. Emulating the same architecture as the host is also one of the fastest options, due to the availability of processor extensions which greatly speed up QEMU when the emulated architecture matches the host architecture.

Note
You may sometimes encounter the term *KVM* (Kernel-based Virtual Machine). It means that QEMU is running with the support of the virtualization processor extensions, via the Linux KVM module. In the context of Proxmox VE *QEMU* and *KVM* can be used interchangeably, as QEMU in Proxmox VE will always try to load the KVM module.

QEMU inside Proxmox VE runs as a root process, since this is required to access block and PCI devices.

10.1 Emulated devices and paravirtualized devices

The PC hardware emulated by QEMU includes a motherboard, network controllers, SCSI, IDE and SATA controllers, serial ports (the complete list can be seen in the `kvm(1)` man page) all of them emulated in software. All these devices are the exact software equivalent of existing hardware devices, and if the OS running in the guest has the proper drivers it will use the devices as if it were running on real hardware. This allows QEMU to run *unmodified* operating systems.

This however has a performance cost, as running in software what was meant to run in hardware involves a lot of extra work for the host CPU. To mitigate this, QEMU can present to the guest operating system *paravirtualized devices*, where the guest OS recognizes it is running inside QEMU and cooperates with the hypervisor.

QEMU relies on the virtio virtualization standard, and is thus able to present paravirtualized virtio devices, which includes a paravirtualized generic disk controller, a paravirtualized network card, a paravirtualized serial port, a paravirtualized SCSI controller, etc ...

Tip

It is **highly recommended** to use the virtio devices whenever you can, as they provide a big performance improvement and are generally better maintained. Using the virtio generic disk controller versus an emulated IDE controller will double the sequential write throughput, as measured with `bonnie++(8)`. Using the virtio network interface can deliver up to three times the throughput of an emulated Intel E1000 network card, as measured with `iperf(1)`. [a]

[a] See this benchmark on the KVM wiki https://www.linux-kvm.org/page/Using_VirtIO_NIC

10.2 Virtual Machines Settings

Generally speaking Proxmox VE tries to choose sane defaults for virtual machines (VM). Make sure you understand the meaning of the settings you change, as it could incur a performance slowdown, or putting your data at risk.

10.2.1 General Settings



General settings of a VM include

- the **Node** : the physical server on which the VM will run
- the **VM ID**: a unique number in this Proxmox VE installation used to identify your VM
- **Name**: a free form text string you can use to describe the VM
- **Resource Pool**: a logical group of VMs

10.2.2 OS Settings



When creating a virtual machine (VM), setting the proper Operating System(OS) allows Proxmox VE to optimize some low level parameters. For instance Windows OS expect the BIOS clock to use the local time, while Unix based OS expect the BIOS clock to have the UTC time.

10.2.3 System Settings

On VM creation you can change some basic system components of the new VM. You can specify which display type you want to use.



Additionally, the SCSI controller can be changed. If you plan to install the QEMU Guest Agent, or if your selected ISO image already ships and installs it automatically, you may want to tick the *QEMU Agent* box,

which lets Proxmox VE know that it can use its features to show some more information, and complete some actions (for example, shutdown or snapshots) more intelligently.

Proxmox VE allows to boot VMs with different firmware and machine types, namely SeaBIOS and OVMF. In most cases you want to switch from the default SeaBIOS to OVMF only if you plan to use PCIe passthrough. On arm64 hosts OVMF is the default and only option, as SeaBIOS is x86-only.

Machine Type

A VM's *Machine Type* defines the hardware layout of the VM's virtual motherboard. You can choose between the default Intel 440FX or the Q35 chipset, which also provides a virtual PCIe bus, and thus may be desired if you want to pass through PCIe hardware. Additionally, you can select a vIOMMU implementation.

Note
The Intel 440FX and Q35 chipsets are specific to x86 guests. On arm64 hosts, virtual machines use the `virt` machine type, which models a generic, UEFI-based ARM machine.

Machine Version

Each machine type is versioned in QEMU and a given QEMU binary supports many machine versions. New versions might bring support for new features, fixes or general improvements. However, they also change properties of the virtual hardware. To avoid sudden changes from the guest's perspective and ensure compatibility of the VM state, live-migration and snapshots with RAM will keep using the same machine version in the new QEMU instance.

For Windows guests, the machine version is pinned during creation, because Windows is sensitive to changes in the virtual hardware - even between cold boots. For example, the enumeration of network devices might be different with different machine versions. Other OSes like Linux can usually deal with such changes just fine. For those, the *Latest* machine version is used by default. This means that after a fresh start, the newest machine version supported by the QEMU binary is used (e.g. the newest machine version QEMU 8.1 supports is version 8.1 for each machine type).

The machine version is also used as a safeguard when implementing new features or fixes that would change the hardware layout to ensure backward compatibility. For operations on a running VM, such as live migrations, the running machine version is saved to ensure that the VM can be recovered exactly as it was, not only from a QEMU virtualization perspective, but also in terms of how Proxmox VE will create the QEMU virtual machine instance.

PVE Machine Revision

Sometimes Proxmox VE needs to make changes to the hardware layout or modify options without waiting for a new QEMU release. For this, Proxmox VE has added an extra downstream revision in the form of `+pveX`. In these revisions, `X` is 0 for each new QEMU machine version and is omitted in this case, e.g. machine version `pc-q35-9.2` would be the same as machine version `pc-q35-9.2+pve0`.

If Proxmox VE wants to change the hardware layout or a default option, the revision is incremented and used for newly created guests or on reboot for VMs that always use the latest machine version.

QEMU Machine Version Deprecation

Starting with QEMU 10.1, machine versions are removed from upstream QEMU after 6 years. In Proxmox VE, major releases happen approximately every 2 years, so a major Proxmox VE release will support machine versions from approximately two previous major Proxmox VE releases.

Before upgrading to a new major Proxmox VE release, you should update VM configurations to avoid all machine versions that will be dropped during the next major Proxmox VE release. This ensures that the guests can still be used throughout that release. See the section Update to a Newer Machine Version.

The removal policy is not yet in effect for Proxmox VE 8, so the baseline for supported machine versions is 2.4. The last QEMU binary version released for Proxmox VE 9 is expected to be QEMU 11.2. This QEMU binary will remove support for machine versions older than 6.0, so 6.0 is the baseline for the Proxmox VE 9 release life cycle. The baseline is expected to increase by 2 major versions for each major Proxmox VE release, for example 8.0 for Proxmox VE 10.

Update to a Newer Machine Version

If you see a deprecation warning, you should change the machine version to a newer one. Be sure to have a working backup first and be prepared for changes to how the guest sees hardware. In some scenarios, re-installing certain drivers might be required. You should also check for snapshots with RAM that were taken with these machine versions (i.e. the `runningmachine` configuration entry). Unfortunately, there is no way to change the machine version of a snapshot, so you'd need to load the snapshot to salvage any data from it.

10.2.4 Hard Disk

Bus/Controller

QEMU can emulate a number of storage controllers:

Tip
It is highly recommended to use the **VirtIO SCSI** or **VirtIO Block** controller for performance reasons and because they are better maintained.

- the **IDE** controller, has a design which goes back to the 1984 PC/AT disk controller. Even if this controller has been superseded by recent designs, each and every OS you can think of has support for it, making it a great choice if you want to run an OS released before 2003. You can connect up to 4 devices on this controller.
- the **SATA** (Serial ATA) controller, dating from 2003, has a more modern design, allowing higher throughput and a greater number of devices to be connected. You can connect up to 6 devices on this controller.
- the **SCSI** controller, designed in 1985, is commonly found on server grade hardware, and can connect up to 14 storage devices. Proxmox VE emulates by default a LSI 53C895A controller.

  A SCSI controller of type *VirtIO SCSI single* and enabling the IO Thread setting for the attached disks is recommended if you aim for performance. This is the default for newly created Linux VMs since Proxmox VE 7.3. Each disk will have its own *VirtIO SCSI* controller, and QEMU will handle the disks IO in a dedicated thread. Linux distributions have support for this controller since 2012, and FreeBSD since 2014. For Windows OSes, you need to provide an extra ISO containing the drivers during the installation.

- The **VirtIO Block** controller, often just called VirtIO or virtio-blk, is an older type of paravirtualized controller. It has been superseded by the VirtIO SCSI Controller, in terms of features.

Image Format

On each controller you attach a number of emulated hard disks, which are backed by a file or a block device residing in the configured storage. The choice of a storage type will determine the format of the hard disk image. Storages which present block devices (LVM, ZFS, Ceph) will require the **raw disk image format**, whereas files based storages (like Ext4, XFS, NFS, or CIFS) will let you to choose either the **raw disk image format** or the **QEMU image format**.

- the **QEMU image format** is a copy on write format which allows snapshots, and thin provisioning of the disk image.
- the **raw disk image** is a bit-to-bit image of a hard disk, similar to what you would get when executing the `dd` command on a block device in Linux. This format does not support thin provisioning or snapshots by itself, requiring cooperation from the storage layer for these tasks. It may, however, be up to 10% faster than the **QEMU image format**. [1]
- the **VMware image format** only makes sense if you intend to import/export the disk image to other hypervisors.

Cache Mode

Setting the **Cache** mode of the hard drive will impact how the host system will notify the guest systems of block write completions. The **No cache** default means that the guest system will be notified that a write is complete when each block reaches the physical storage write queue, ignoring the host page cache. This provides a good balance between safety and speed.

If you want the Proxmox VE backup manager to skip a disk when doing a backup of a VM, you can set the **No backup** option on that disk.

If you want the Proxmox VE storage replication mechanism to skip a disk when starting a replication job, you can set the **Skip replication** option on that disk. As of Proxmox VE 5.0, replication requires the disk images to be on a storage of type `zfspool`, so adding a disk image to other storages when the VM has replication configured requires to skip replication for this disk image.

Trim/Discard

If your storage supports *thin provisioning* (see the storage chapter in the Proxmox VE guide), you can activate the **Discard** option on a drive. With **Discard** set and a *TRIM*-enabled guest OS [2], when the VM's filesystem marks blocks as unused after deleting files, the controller will relay this information to the storage, which will then shrink the disk image accordingly. For the guest to be able to issue *TRIM* commands, you must enable the **Discard** option on the drive. Some guest operating systems may also require the **SSD Emulation** flag to be set. Note that **Discard** on **VirtIO Block** drives is only supported on guests using Linux Kernel 5.0 or higher.

[1] See this benchmark for details https://events.static.linuxfound.org/sites/events/files/slides/-CloudOpen2013_Khoa_Huynh_v3.pdf

[2] TRIM, UNMAP, and discard https://en.wikipedia.org/wiki/Trim_%28computing%29

If you would like a drive to be presented to the guest as a solid-state drive rather than a rotational hard disk, you can set the **SSD emulation** option on that drive. There is no requirement that the underlying storage actually be backed by SSDs; this feature can be used with physical media of any type. Note that **SSD emulation** is not supported on **VirtIO Block** drives.

IO Thread

The **IO thread** option can only be used when using a disk with one of the following bus/device controllers:

- **SCSI**, if the emulated SCSI controller type is **VirtIO SCSI single**, or
- **VirtIO Block**

With **IO thread** enabled, QEMU creates one I/O thread per storage controller rather than handling all I/O in the main event loop or vCPU threads. One benefit is better work distribution and utilization of the underlying storage. Another benefit is reduced latency (hangs) in the guest for very I/O-intensive host workloads, since neither the main thread nor a vCPU thread can be blocked by disk I/O.

10.2.5 CPU



A **CPU socket** is a physical slot on a PC motherboard where you can plug a CPU. This CPU can then contain one or many **cores**, which are independent processing units. Whether you have a single CPU socket with 4 cores, or two CPU sockets with two cores is mostly irrelevant from a performance point of view. However some software licenses depend on the number of sockets a machine has, in that case it makes sense to set the number of sockets to what the license allows you.

Increasing the number of virtual CPUs (cores and sockets) will usually provide a performance improvement though that is heavily dependent on the use of the VM. Multi-threaded applications will of course benefit from a large number of virtual CPUs, as for each virtual cpu you add, QEMU will create a new thread of execution on the host system. If you're not sure about the workload of your VM, it is usually a safe bet to set the number of **Total cores** to 2.

Note
It is perfectly safe if the *overall* number of cores of all your VMs is greater than the number of cores on the server (for example, 4 VMs each with 4 cores (= total 16) on a machine with only 8 cores). In that case the host system will balance the QEMU execution threads between your server cores, just like if you were running a standard multi-threaded application. However, Proxmox VE will prevent you from starting VMs with more virtual CPU cores than physically available, as this will only bring the performance down due to the cost of context switches.

Resource Limits

cpulimit

In addition to the number of virtual cores, the total available "Host CPU Time" for the VM can be set with the **cpulimit** option. It is a floating point value representing CPU time in percent, so `1.0` is equal to `100%`, `2.5` to `250%` and so on. If a single process would fully use one single core it would have `100%` CPU Time usage. If a VM with four cores utilizes all its cores fully it would theoretically use `400%`. In reality the usage may be even a bit higher as QEMU can have additional threads for VM peripherals besides the vCPU core ones.

This setting can be useful when a VM should have multiple vCPUs because it is running some processes in parallel, but the VM as a whole should not be able to run all vCPUs at 100% at the same time.

For example, suppose you have a virtual machine that would benefit from having 8 virtual CPUs, but you don't want the VM to be able to max out all 8 cores running at full load - because that would overload the server and leave other virtual machines and containers with too little CPU time. To solve this, you could set **cpulimit** to `4.0` (=400%). This means that if the VM fully utilizes all 8 virtual CPUs by running 8 processes simultaneously, each vCPU will receive a maximum of 50% CPU time from the physical cores. However, if the VM workload only fully utilizes 4 virtual CPUs, it could still receive up to 100% CPU time from a physical core, for a total of 400%.

Note
VMs can, depending on their configuration, use additional threads, such as for networking or IO operations but also live migration. Thus a VM can show up to use more CPU time than just its virtual CPUs could use. To ensure that a VM never uses more CPU time than vCPUs assigned, set the **cpulimit** to the same value as the total core count.

cpuunits

With the **cpuunits** option, nowadays often called CPU shares or CPU weight, you can control how much CPU time a VM gets compared to other running VMs. It is a relative weight which defaults to `100` (or `1024` if the host uses legacy cgroup v1). If you increase this for a VM it will be prioritized by the scheduler in comparison to other VMs with lower weight.

For example, if VM 100 has set the default `100` and VM 200 was changed to `200`, the latter VM 200 would receive twice the CPU bandwidth than the first VM 100.

For more information see `man systemd.resource-control`, here `CPUQuota` corresponds to `cpulimit` and `CPUWeight` to our `cpuunits` setting. Visit its Notes section for references and implementation details.

affinity

With the **affinity** option, you can specify the physical CPU cores that are used to run the VM's vCPUs. Peripheral VM processes, such as those for I/O, are not affected by this setting. Note that the **CPU affinity is not a security feature**.

Forcing a CPU **affinity** can make sense in certain cases but is accompanied by an increase in complexity and maintenance effort. For example, if you want to add more VMs later or migrate VMs to nodes with fewer CPU cores. It can also easily lead to asynchronous and therefore limited system performance if some CPUs are fully utilized while others are almost idle.

The **affinity** is set through the `taskset` CLI tool. It accepts the host CPU numbers (see `lscpu`) in the `List Format` from `man cpuset`. This ASCII decimal list can contain numbers but also number ranges. For example, the **affinity** `0-1,8-11` (expanded `0, 1, 8, 9, 10, 11`) would allow the VM to run on only these six specific host cores.

CPU Type

QEMU can emulate a number different of **CPU types** from 486 to the latest Xeon processors. Each new processor generation adds new features, like hardware assisted 3d rendering, random number generation, memory protection, etc. Also, a current generation can be upgraded through microcode update with bug or security fixes.

Usually you should select for your VM a processor type which closely matches the CPU of the host system, as it means that the host CPU features (also called *CPU flags*) will be available in your VMs. If you want an exact match, you can set the CPU type to **host** in which case the VM will have exactly the same CPU flags as your host system.

This has a downside though. If you want to do a live migration of VMs between different hosts, your VM might end up on a new system with a different CPU type or a different microcode version. If the CPU flags passed to the guest are missing, the QEMU process will stop. To remedy this QEMU has also its own virtual CPU types, that Proxmox VE uses by default.

The backend default is *kvm64* which works on essentially all x86_64 host CPUs and the UI default when creating a new VM is *x86-64-v2-AES*, which requires a host CPU starting from Westmere for Intel or at least a fourth generation Opteron for AMD.

Note
The *kvm64* and *x86-64-v** CPU models described here are x86-only. On arm64 hosts, guests use ARM CPU models: *host* to expose the physical CPU (recommended on the supported hardware), or a generic model such as *max*, together with the `virt` machine type.

In short:

If you don't care about live migration or have a homogeneous cluster where all nodes have the same CPU and same microcode version, set the CPU type to host, as in theory this will give your guests maximum performance.

If you care about live migration and security, and you have only Intel CPUs or only AMD CPUs, choose the lowest generation CPU model of your cluster.

If you care about live migration without security, or have mixed Intel/AMD cluster, choose the lowest compatible virtual QEMU CPU type.

Note
Live migrations between Intel and AMD host CPUs have no guarantee to work.



Warning
The *host* CPU type can potentially enable new CPU features for the guest when the guest is restarted after a system upgrade. This can result in unexpected consequences.

See also List of AMD and Intel CPU Types as Defined in QEMU.

QEMU CPU Types

QEMU also provide virtual CPU types, compatible with both Intel and AMD host CPUs.

Note
To mitigate the Spectre vulnerability for virtual CPU types, you need to add the relevant CPU flags, see Meltdown / Spectre related CPU flags.

Historically, Proxmox VE had the *kvm64* CPU model, with CPU flags at the level of Pentium 4 enabled, so performance was not great for certain workloads.

In the summer of 2020, AMD, Intel, Red Hat, and SUSE collaborated to define three x86-64 microarchitecture levels on top of the x86-64 baseline, with modern flags enabled. For details, see the x86-64-ABI specification.

Note
Some newer distributions like CentOS 9 are now built with *x86-64-v2* flags as a minimum requirement.

- *kvm64 (x86-64-v1)*: Compatible with Intel CPU >= Pentium 4, AMD CPU >= Phenom.
- *x86-64-v2*: Compatible with Intel CPU >= Nehalem, AMD CPU >= Opteron_G3. Added CPU flags compared to *x86-64-v1*: *+cx16*, *+lahf-lm*, *+popcnt*, *+pni*, *+sse4.1*, *+sse4.2*, *+ssse3*.
- *x86-64-v2-AES*: Compatible with Intel CPU >= Westmere, AMD CPU >= Opteron_G4. Added CPU flags compared to *x86-64-v2*: *+aes*.
- *x86-64-v3*: Compatible with Intel CPU >= Haswell, AMD CPU >= EPYC. Added CPU flags compared to *x86-64-v2-AES*: *+avx*, *+avx2*, *+bmi1*, *+bmi2*, *+f16c*, *+fma*, *+movbe*, *+xsave*.
- *x86-64-v4*: Compatible with Intel CPU >= Skylake, AMD CPU >= EPYC v4 Genoa. Added CPU flags compared to *x86-64-v3*: *+avx512f*, *+avx512bw*, *+avx512cd*, *+avx512dq*, *+avx512vl*.

Custom CPU Types

You can define custom CPU types with a configurable set of base model, vendor, physical address bits, and per-flag toggles, then assign them to VMs like a built-in type. Custom types are referenced from a VM configuration as `custom-<name>`.

Manage them under `Datacenter -> Custom CPU Models` in the web UI. The model dialog embeds a flag editor grid with free-text search over flag name and description, an accelerator (kvm/tcg) selector, and a per-node multi-select that highlights the flags each selected cluster node currently reports as supported - useful to spot which flags would actually be available on the target hosts before committing to a model. The same grid is reused in the per-VM `Processor` edit dialog, restricted there to the flags settable per VM; configured flags unknown to the API or unsupported on the selected accelerator surface at the top with a warning.

Custom CPU types are still backed by the configuration file `/etc/pve/virtual-guest/cpu-models.con` and can be maintained from the CLI as well, see `man cpu-models.conf` for the format.

Access to a custom model is controlled per model via the ACL path `/mapping/cpu/<name>`. `Mapping.Audi` lets a user see the model in listings, `Mapping.Modify` gates create/update/delete in the panel, and `Mapping.Use` is required to assign the model to a VM. The latter is enforced on VM create, VM update, and VM clone, so a user who can clone a VM that uses a custom model still needs `Mapping.Use` on that model's ACL path.

Meltdown / Spectre related CPU flags

There are several CPU flags related to the Meltdown and Spectre vulnerabilities [3] which need to be set manually unless the selected CPU type of your VM already enables them by default.

There are two requirements that need to be fulfilled in order to use these CPU flags:

- The host CPU(s) must support the feature and propagate it to the guest's virtual CPU(s)
- The guest operating system must be updated to a version which mitigates the attacks and is able to utilize the CPU feature

Otherwise you need to set the desired CPU flag of the virtual CPU, either by editing the CPU options in the web UI, or by setting the *flags* property of the *cpu* option in the VM configuration file.

For Spectre v1,v2,v4 fixes, your CPU or system vendor also needs to provide a so-called "microcode update" for your CPU, see chapter Firmware Updates. Note that not all affected CPUs can be updated to support spec-ctrl.

To check if the Proxmox VE host is vulnerable, execute the following command as root:

```
for f in /sys/devices/system/cpu/vulnerabilities/*; do echo "${f##*/} -" $( ↩
   cat "$f"); done
```

A community script is also available to detect if the host is still vulnerable. [4]

[3] Meltdown Attack https://meltdownattack.com/
[4] spectre-meltdown-checker https://meltdown.ovh/

Intel processors

- *pcid*

  This reduces the performance impact of the Meltdown (CVE-2017-5754) mitigation called *Kernel Page-Table Isolation (KPTI)*, which effectively hides the Kernel memory from the user space. Without PCID, KPTI is quite an expensive mechanism [5].

  To check if the Proxmox VE host supports PCID, execute the following command as root:

  ```
  # grep ' pcid ' /proc/cpuinfo
  ```

  If this does not return empty your host's CPU has support for *pcid*.

- *spec-ctrl*

  Required to enable the Spectre v1 (CVE-2017-5753) and Spectre v2 (CVE-2017-5715) fix, in cases where retpolines are not sufficient. Included by default in Intel CPU models with -IBRS suffix. Must be explicitly turned on for Intel CPU models without -IBRS suffix. Requires an updated host CPU microcode (intel-microcode >= 20180425).

- *ssbd*

  Required to enable the Spectre V4 (CVE-2018-3639) fix. Not included by default in any Intel CPU model. Must be explicitly turned on for all Intel CPU models. Requires an updated host CPU microcode(intel-microcode >= 20180703).

AMD processors

- *ibpb*

  Required to enable the Spectre v1 (CVE-2017-5753) and Spectre v2 (CVE-2017-5715) fix, in cases where retpolines are not sufficient. Included by default in AMD CPU models with -IBPB suffix. Must be explicitly turned on for AMD CPU models without -IBPB suffix. Requires the host CPU microcode to support this feature before it can be used for guest CPUs.

- *virt-ssbd*

  Required to enable the Spectre v4 (CVE-2018-3639) fix. Not included by default in any AMD CPU model. Must be explicitly turned on for all AMD CPU models. This should be provided to guests, even if amd-ssbd is also provided, for maximum guest compatibility. Note that this must be explicitly enabled when when using the "host" cpu model, because this is a virtual feature which does not exist in the physical CPUs.

- *amd-ssbd*

  Required to enable the Spectre v4 (CVE-2018-3639) fix. Not included by default in any AMD CPU model. Must be explicitly turned on for all AMD CPU models. This provides higher performance than virt-ssbd, therefore a host supporting this should always expose this to guests if possible. virt-ssbd should none the less also be exposed for maximum guest compatibility as some kernels only know about virt-ssbd.

- *amd-no-ssb*

  Recommended to indicate the host is not vulnerable to Spectre V4 (CVE-2018-3639). Not included by default in any AMD CPU model. Future hardware generations of CPU will not be vulnerable to CVE-2018-3639, and thus the guest should be told not to enable its mitigations, by exposing amd-no-ssb. This is mutually exclusive with virt-ssbd and amd-ssbd.

[5] PCID is now a critical performance/security feature on x86 https://groups.google.com/forum/m/#!topic/mechanical-sympathy/L9mHTbeQLNU

Windows-related CPU settings

A couple of CPU defaults and properties are tuned specifically for Windows guests on recent Intel hardware:

- `cet-ibt` and `cet-ss` (Control-flow Enforcement Technology: indirect branch tracking and shadow stack) are disabled by default for Windows 11 machine types, as they currently break boot for Windows guests with virtualization-based security enabled. Workloads that explicitly rely on the flags can re-enable them per VM via the `Processor` flag editor.
- The QEMU `level` CPU property is exposed so it can be set per VM (or in a custom CPU model) without resorting to custom `args`. Setting `level=30` is a known workaround for Hyper-V boot failures of Windows guests on recent Intel hosts when the CPU type is `host` or `max`. The property only applies for x86_64 vCPUs; it is silently ignored on other architectures.

NUMA

You can also optionally emulate a **NUMA** [6] architecture in your VMs. The basics of the NUMA architecture mean that instead of having a global memory pool available to all your cores, the memory is spread into local banks close to each socket. This can bring speed improvements as the memory bus is not a bottleneck anymore. If your system has a NUMA architecture [7] we recommend to activate the option, as this will allow proper distribution of the VM resources on the host system. This option is also required to hot-plug cores or RAM in a VM.

If the NUMA option is used, it is recommended to set the number of sockets to the number of nodes of the host system.

vCPU hot-plug

Modern operating systems introduced the capability to hot-plug and, to a certain extent, hot-unplug CPUs in a running system. Virtualization allows us to avoid a lot of the (physical) problems real hardware can cause in such scenarios. Still, this is a rather new and complicated feature, so its use should be restricted to cases where its absolutely needed. Most of the functionality can be replicated with other, well tested and less complicated, features, see Resource Limits.

In Proxmox VE the maximal number of plugged CPUs is always `cores * sockets`. To start a VM with less than this total core count of CPUs you may use the **vcpus** setting, it denotes how many vCPUs should be plugged in at VM start.

Currently this feature is only supported on Linux, a kernel newer than 3.10 is needed, a kernel newer than 4.7 is recommended.

You can use a udev rule as follow to automatically set new CPUs as online in the guest:

```
SUBSYSTEM=="cpu", ACTION=="add", TEST=="online", ATTR{online}=="0", ATTR{ ↩
   online}="1"
```

Save this under /etc/udev/rules.d/ as a file ending in `.rules`.

Note: CPU hot-remove is machine dependent and requires guest cooperation. The deletion command does not guarantee CPU removal to actually happen, typically it's a request forwarded to guest OS using target dependent mechanism, such as ACPI on x86/amd64.

[6] https://en.wikipedia.org/wiki/Non-uniform_memory_access

[7] if the command `numactl --hardware | grep available` returns more than one node, then your host system has a NUMA architecture

10.2.6 Memory

For each VM you have the option to set a fixed size memory or asking Proxmox VE to dynamically allocate memory based on the current RAM usage of the host.

Fixed Memory Allocation



When setting memory and minimum memory to the same amount Proxmox VE will simply allocate what you specify to your VM.

Even when using a fixed memory size, the ballooning device gets added to the VM, because it delivers useful information such as how much memory the guest really uses. In general, you should leave **ballooning** enabled, but if you want to disable it (like for debugging purposes), simply uncheck **Ballooning Device** or set

```
balloon: 0
```

in the configuration.

Automatic Memory Allocation

When setting the minimum memory lower than memory, Proxmox VE will make sure that the minimum amount you specified is always available to the VM, and if RAM usage on the host is below a certain target percentage, will dynamically add memory to the guest up to the maximum memory specified. The target percentage defaults to 80% and can be configured in the node options.

When the host is running low on RAM, the VM will then release some memory back to the host, swapping running processes if needed and starting the oom killer in last resort. The passing around of memory between host and guest is done via a special `balloon` kernel driver running inside the guest, which will grab or release memory pages from the host. [8]

[8] A good explanation of the inner workings of the balloon driver can be found here https://rwmj.wordpress.com/2010/07/17/-virtio-balloon/

When multiple VMs use the autoallocate facility, it is possible to set a **Shares** coefficient which indicates the relative amount of the free host memory that each VM should take. Suppose for instance you have four VMs, three of them running an HTTP server and the last one is a database server. The host is configured to target 80% RAM usage. To cache more database blocks in the database server RAM, you would like to prioritize the database VM when spare RAM is available. For this you assign a Shares property of 3000 to the database VM, leaving the other VMs to the Shares default setting of 1000. The host server has 32GB of RAM, and is currently using 16GB, leaving 32 * 80/100 - 16 = 9GB RAM to be allocated to the VMs on top of their configured minimum memory amount. The database VM will benefit from 9 * 3000 / (3000 + 1000 + 1000 + 1000) = 4.5 GB extra RAM and each HTTP server from 1.5 GB.

All Linux distributions released after 2010 have the balloon kernel driver included. For Windows OSes, the balloon driver needs to be added manually and can incur a slowdown of the guest, so we don't recommend using it on critical systems.

When allocating RAM to your VMs, a good rule of thumb is always to leave 1GB of RAM available to the host.

10.2.7 Memory Encryption

AMD SEV

SEV (Secure Encrypted Virtualization) enables memory encryption per VM using AES-128 encryption and the AMD Secure Processor.

SEV-ES (Secure Encrypted Virtualization - Encrypted State) in addition encrypts all CPU register contents, to prevent leakage of information to the hypervisor.

SEV-SNP (Secure Encrypted Virtualization - Secure Nested Paging) also attempts to prevent software-based integrity attacks. See the AMD SEV SNP white paper for more information.

Host Requirements:

- AMD EPYC CPU
- SEV-ES is only supported on AMD EPYC 7002 series and newer EPYC CPUs
- SEV-SNP is only supported on AMD EPYC 7003 series and newer EPYC CPUs
- SEV-SNP requires host kernel version 6.11 or higher.
- configure AMD memory encryption in the BIOS settings of the host machine
- add "kvm_amd.sev=1" to kernel parameters if not enabled by default
- add "mem_encrypt=on" to kernel parameters if you want to encrypt memory on the host (SME) see https://www.kernel.org/doc/Documentation/x86/amd-memory-encryption.txt
- maybe increase SWIOTLB see https://github.com/AMDESE/AMDSEV#faq-4

To check if SEV is enabled on the host search for `sev` in dmesg and print out the SEV kernel parameter of kvm_amd:

```
# dmesg | grep -i sev
[...] ccp 0000:45:00.1: sev enabled
[...] ccp 0000:45:00.1: SEV API: <buildversion>
[...] SEV supported: <number> ASIDs
[...] SEV-ES supported: <number> ASIDs
# cat /sys/module/kvm_amd/parameters/sev
Y
```

Guest Requirements:

- edk2-OVMF
- advisable to use Q35
- The guest operating system must contain SEV-support.

Limitations:

- Because the memory is encrypted the memory usage on host is always wrong.
- Operations that involve saving or restoring memory like snapshots & live migration do not work yet or are attackable.
- PCI passthrough is not supported.
- SEV-ES & SEV-SNP are very experimental.
- EFI disks are not supported with SEV-SNP.
- With SEV-SNP, the `reboot` command inside a VM simply shuts down the VM.

Example Configuration (SEV):

```
# qm set <vmid> -amd-sev type=std,no-debug=1,no-key-sharing=1,kernel-hashes ↩
   =1
```

The **type** defines the encryption technology ("type=" is not necessary). Available options are std, es & snp.

The QEMU **policy** parameter gets calculated with the **no-debug** and **no-key-sharing** parameters. These parameters correspond to policy-bit 0 and 1. If **type** is **es** the policy-bit 2 is set to 1 so that SEV-ES is enabled. Policy-bit 3 (nosend) is always set to 1 to prevent migration-attacks. For more information on how to calculate the policy see: AMD SEV API Specification Chapter 3

The **kernel-hashes** option is off per default for backward compatibility with older OVMF images and guests that do not measure the kernel/initrd. See https://lists.gnu.org/archive/html/qemu-devel/2021-11/msg02598.html

Check if SEV is working in the VM

Method 1 - dmesg:

Output should look like this.

```
# dmesg | grep -i sev
AMD Memory Encryption Features active: SEV
```

Method 2 - MSR 0xc0010131 (MSR_AMD64_SEV):

Output should be 1.

```
# apt install msr-tools
# modprobe msr
# rdmsr -a 0xc0010131
1
```

Example Configuration (SEV-SNP):

```
# qm set <vmid> -amd-sev type=snp,allow-smt=1,no-debug=1,kernel-hashes=1
```

The `allow-smt` policy-bit is set by default. If you disable it by setting `allow-smt` to `0`, SMT must be disabled on the host in order for the VM to run.

Check if SEV-SNP is working in the VM

```
# dmesg | grep -i snp
Memory Encryption Features active: AMD SEV SEV-ES SEV-SNP
SEV: Using SNP CPUID table, 29 entries present.
SEV: SNP guest platform device initialized.
```

Links:

- https://developer.amd.com/sev/
- https://github.com/AMDESE/AMDSEV
- https://www.qemu.org/docs/master/system/i386/amd-memory-encryption.html
- https://www.amd.com/system/files/TechDocs/55766_SEV-KM_API_Specification.pdf
- https://documentation.suse.com/sles/15-SP1/html/SLES-amd-sev/index.html
- SEV Secure Nested Paging Firmware ABI Specification

10.2.8 Network Device



Each VM can have many *Network interface controllers* (NIC), of four different types:

- **Intel E1000** is the default, and emulates an Intel Gigabit network card.
- the **VirtIO** paravirtualized NIC should be used if you aim for maximum performance. Like all VirtIO devices, the guest OS should have the proper driver installed.
- the **Realtek 8139** emulates an older 100 MB/s network card, and should only be used when emulating older operating systems (released before 2002)
- the **vmxnet3** is another paravirtualized device, which should only be used when importing a VM from another hypervisor.

Proxmox VE will generate for each NIC a random **MAC address**, so that your VM is addressable on Ethernet networks.

The NIC you added to the VM can follow one of two different models:

- in the default **Bridged mode** each virtual NIC is backed on the host by a *tap device*, (a software loopback device simulating an Ethernet NIC). This tap device is added to a bridge, by default vmbr0 in Proxmox VE. In this mode, VMs have direct access to the Ethernet LAN on which the host is located.
- in the alternative **NAT mode**, each virtual NIC will only communicate with the QEMU user networking stack, where a built-in router and DHCP server can provide network access. This built-in DHCP will serve addresses in the private 10.0.2.0/24 range. The NAT mode is much slower than the bridged mode, and should only be used for testing. This mode is only available via CLI or the API, but not via the web UI.

You can also skip adding a network device when creating a VM by selecting **No network device**.

You can overwrite the **MTU** setting for each VM network device manually. Leaving the field empty or setting `mtu=1` will inherit the MTU from the underlying bridge. This option is only available for **VirtIO** network devices.

Multiqueue

If you are using the VirtIO driver, you can optionally activate the **Multiqueue** option. This option allows the guest OS to process networking packets using multiple virtual CPUs, providing an increase in the total number of packets transferred.

When using the VirtIO driver with Proxmox VE, each NIC network queue is passed to the host kernel, where the queue will be processed by a kernel thread spawned by the vhost driver. With this option activated, it is possible to pass *multiple* network queues to the host kernel for each NIC.

When using Multiqueue, it is recommended to set it to a value equal to the number of vCPUs of your guest. Remember that the number of vCPUs is the number of sockets times the number of cores configured for the VM. You also need to set the number of multi-purpose channels on each VirtIO NIC in the VM with this ethtool command:

```
ethtool -L ens1 combined X
```

where X is the number of the number of vCPUs of the VM.

To configure a Windows guest for Multiqueue install the Redhat VirtIO Ethernet Adapter drivers, then adapt the NIC's configuration as follows. Open the device manager, right click the NIC under "Network adapters",

and select "Properties". Then open the "Advanced" tab and select "Receive Side Scaling" from the list on the left. Make sure it is set to "Enabled". Next, navigate to "Maximum number of RSS Queues" in the list and set it to the number of vCPUs of your VM. Once you verified that the settings are correct, click "OK" to confirm them.

You should note that setting the Multiqueue parameter to a value greater than one will increase the CPU load on the host and guest systems as the traffic increases. We recommend to set this option only when the VM has to process a great number of incoming connections, such as when the VM is running as a router, reverse proxy or a busy HTTP server doing long polling.

10.2.9 Display

QEMU can virtualize a few types of VGA hardware. Some examples are:

- **std**, the default, emulates a card with Bochs VBE extensions.
- **cirrus**, this was once the default, it emulates a very old hardware module with all its problems. This display type should only be used if really necessary [9], for example, if using Windows XP or earlier
- **vmware**, is a VMWare SVGA-II compatible adapter.
- **qxl**, is the QXL paravirtualized graphics card. Selecting this also enables SPICE (a remote viewer protocol) for the VM.
- **virtio-gl**, often named VirGL is a virtual 3D GPU for use inside VMs that can offload workloads to the host GPU without requiring special (expensive) models and drivers and neither binding the host GPU completely, allowing reuse between multiple guests and or the host.

> **Note**
> VirGL support needs some extra libraries that aren't installed by default due to being relatively big and also not available as open source for all GPU models/vendors. For most setups you'll just need to do: `apt install libgl1 libegl1`

You can edit the amount of memory given to the virtual GPU, by setting the *memory* option. This can enable higher resolutions inside the VM, especially with SPICE/QXL.

As the memory is reserved by display device, selecting Multi-Monitor mode for SPICE (such as `qxl2` for dual monitors) has some implications:

- Windows needs a device for each monitor, so if your *ostype* is some version of Windows, Proxmox VE gives the VM an extra device per monitor. Each device gets the specified amount of memory.
- Linux VMs, can always enable more virtual monitors, but selecting a Multi-Monitor mode multiplies the memory given to the device with the number of monitors.

Selecting `serialX` as display *type* disables the VGA output, and redirects the Web Console to the selected serial port. A configured display *memory* setting will be ignored in that case.

[9] https://www.kraxel.org/blog/2014/10/qemu-using-cirrus-considered-harmful/ qemu: using cirrus considered harmful

VNC clipboard

You can enable the VNC clipboard by setting `clipboard` to `vnc`.

```
# qm set <vmid> -vga <displaytype>,clipboard=vnc
```

In order to use the clipboard feature, you must first install the SPICE guest tools. On Debian-based distributions, this can be achieved by installing `spice-vdagent`. For other Operating Systems search for it in the official repositories or see: https://www.spice-space.org/download.html

Once you have installed the spice guest tools, you can use the VNC clipboard function (e.g. in the noVNC console panel). However, if you're using SPICE, virtio or virgl, you'll need to choose which clipboard to use. This is because the default **SPICE** clipboard will be replaced by the **VNC** clipboard, if `clipboard` is set to `vnc`.

Note
In order to enable the VNC clipboard, QEMU is configured to use the qemu-vdagent device. Live migration support for this device was added with QEMU version 10.1. VMs running on a QEMU or machine version below 10.1 with an enabled VNC clipboard cannot be live-migrated.

10.2.10 USB Passthrough

There are two different types of USB passthrough devices:

- Host USB passthrough
- SPICE USB passthrough

Host USB passthrough works by giving a VM a USB device of the host. This can either be done via the vendor- and product-id, or via the host bus and port.

The vendor/product-id looks like this: **0123:abcd**, where **0123** is the id of the vendor, and **abcd** is the id of the product, meaning two pieces of the same usb device have the same id.

The bus/port looks like this: **1-2.3.4**, where **1** is the bus and **2.3.4** is the port path. This represents the physical ports of your host (depending of the internal order of the usb controllers).

If a device is present in a VM configuration when the VM starts up, but the device is not present in the host, the VM can boot without problems. As soon as the device/port is available in the host, it gets passed through.



Warning
Using this kind of USB passthrough means that you cannot move a VM online to another host, since the hardware is only available on the host the VM is currently residing.

The second type of passthrough is SPICE USB passthrough. If you add one or more SPICE USB ports to your VM, you can dynamically pass a local USB device from your SPICE client through to the VM. This can be useful to redirect an input device or hardware dongle temporarily.

It is also possible to map devices on a cluster level, so that they can be properly used with HA and hardware changes are detected and non root users can configure them. See Resource Mapping for details on that.

10.2.11 BIOS and UEFI

In order to properly emulate a computer, QEMU needs to use a firmware. Which, on common PCs often known as BIOS or (U)EFI, is executed as one of the first steps when booting a VM. It is responsible for doing basic hardware initialization and for providing an interface to the firmware and hardware for the operating system. By default QEMU uses **SeaBIOS** for this, which is an open-source, x86 BIOS implementation. SeaBIOS is a good choice for most standard setups.

Note
SeaBIOS, and thus `bios=seabios`, is available for x86 guests only. On arm64 hosts, virtual machines always boot through UEFI, using the ARM build of OVMF (AAVMF), so `bios=ovmf` is the only supported setting there.

Some operating systems (such as Windows 11) may require use of an UEFI compatible implementation. In such cases, you must use **OVMF** instead, which is an open-source UEFI implementation. [10]

There are other scenarios in which the SeaBIOS may not be the ideal firmware to boot from, for example if you want to do VGA passthrough. [11]

If you want to use OVMF, there are several things to consider:

In order to save things like the **boot order**, there needs to be an EFI Disk. This disk will be included in backups and snapshots, and there can only be one.

You can create such a disk with the following command:

```
# qm set <vmid> -efidisk0 <storage>:1,format=<format>,efitype=4m,pre- ↩
   enrolled-keys=1
```

Where **<storage>** is the storage where you want to have the disk, and **<format>** is a format which the storage supports. Alternatively, you can create such a disk through the web interface with *Add* → *EFI Disk* in the hardware section of a VM.

The **efitype** option specifies which version of the OVMF firmware should be used. For new VMs, this should always be *4m*, as it supports Secure Boot and has more space allocated to support future development (this is the default in the GUI).

pre-enroll-keys specifies if the efidisk should come pre-loaded with distribution-specific and Microsoft Standard Secure Boot keys. It also enables Secure Boot by default (though it can still be disabled in the OVMF menu within the VM). See also Secure Boot Certificate Expiration.

Note
If you want to start using Secure Boot in an existing VM (that still uses a *2m* efidisk), you need to recreate the efidisk. To do so, delete the old one (`qm set <vmid> -delete efidisk0`) and add a new one as described above. This will reset any custom configurations you have made in the OVMF menu!

When using OVMF with a virtual display (without VGA passthrough), you need to set the client resolution in the OVMF menu (which you can reach with a press of the ESC button during boot), or you have to choose SPICE as the display type.

When using OVMF with PXE boot, you have to add an RNG device to the VM. For security reasons, the OVMF firmware disables PXE boot for guests without a random number generator.

[10] See the OVMF Project https://github.com/tianocore/tianocore.github.io/wiki/OVMF

[11] Alex Williamson has a good blog entry about this https://vfio.blogspot.co.at/2014/08/primary-graphics-assignment-without-vga.html

Secure Boot Certificate Expiration

The original set of Microsoft certificates from 2011, which Windows and common Linux distributions use for secure boot, expires in June 2026. Microsoft created replacement certificates in 2023 [12].

The firmware only allows bootloaders signed with certificates present on the EFI disk. In particular, an EFI disk with only the 2011 certificates will reject bootloaders signed with the 2023 certificates. The `ms-cert=2023k` marker in the VM configuration for an EFI disk indicates that the new certificates are enrolled.

If the `pve-edk2-firmware` package version is at least `4.2025.05-1`, newly created EFI disks contain both the 2011 and 2023 certificates and will have the `ms-cert=2023k` marker. For EFI disks created before that, you need to enroll the certificates:

For Windows with BitLocker, run the following command inside PowerShell:

```
manage-bde -protectors -disable <drive>
```

For example, `<drive>` could be `C:`. This is required for each drive with BitLocker before proceeding. Otherwise, you will be prompted for the BitLocker recovery key on the next boot!

Select the EFI disk in the *Hardware* view in the UI and use *Disk Action > Enroll Updated Certificates*. Alternatively, enroll the certificates via the `/nodes/{node}/qemu/{vmid}/config` API endpoint. The enrollment takes effect when the VM is next started. The

```
qm enroll-efi-keys <vmid>
```

CLI command achieves the same, but requires the VM to be shut down.

For further steps on updating secure boot within Windows and signing the bootloader with the new 2023 certificates, refer to the Microsoft support articles about enterprise deployment guidance for CVE-2023-24932 and the related security update which needs to be installed first.

Note
The markers `ms-cert=2023` and `ms-cert=2023w` may indicate partial enrollment. The VM start task log will warn about this. You should apply the enrollment procedure for such EFI disks too.

10.2.12 Trusted Platform Module (TPM)

A **Trusted Platform Module** is a device which stores secret data - such as encryption keys - securely and provides tamper-resistance functions for validating system boot.

Certain operating systems (such as Windows 11) require such a device to be attached to a machine (be it physical or virtual).

A TPM is added by specifying a **tpmstate** volume. This works similar to an efidisk, in that it cannot be changed (only removed) once created. You can add one via the following command:

```
# qm set <vmid> -tpmstate0 <storage>:1,version=<version>
```

Where **<storage>** is the storage you want to put the state on, and **<version>** is either *v1.2* or *v2.0*. You can also add one via the web interface, by choosing *Add* → *TPM State* in the hardware section of a VM.

The *v2.0* TPM spec is newer and better supported, so unless you have a specific implementation that requires a *v1.2* TPM, it should be preferred.

[12] Microsoft support article about the issue https://support.microsoft.com/en-us/topic/windows-secure-boot-certificate-expiration-and-ca-updates-7ff40d33-95dc-4c3c-8725-a9b95457578e

Note
Compared to a physical TPM, an emulated one does **not** provide any real security benefits. The point of a TPM is that the data on it cannot be modified easily, except via commands specified as part of the TPM spec. Since with an emulated device the data storage happens on a regular volume, it can potentially be edited by anyone with access to it.

10.2.13 Inter-VM shared memory

You can add an Inter-VM shared memory device (`ivshmem`), which allows one to share memory between the host and a guest, or also between multiple guests.

To add such a device, you can use `qm`:

```
# qm set <vmid> -ivshmem size=32,name=foo
```

Where the size is in MiB. The file will be located under `/dev/shm/pve-shm-$name` (the default name is the vmid).

Note
Currently the device will get deleted as soon as any VM using it got shutdown or stopped. Open connections will still persist, but new connections to the exact same device cannot be made anymore.

A use case for such a device is the Looking Glass [13] project, which enables high performance, low-latency display mirroring between host and guest.

10.2.14 Audio Device

To add an audio device run the following command:

```
qm set <vmid> -audio0 device=<device>
```

Supported audio devices are:

- `ich9-intel-hda`: Intel HD Audio Controller, emulates ICH9
- `intel-hda`: Intel HD Audio Controller, emulates ICH6
- `AC97`: Audio Codec '97, useful for older operating systems like Windows XP

There are two backends available:

- *spice*
- *none*

The *spice* backend can be used in combination with SPICE while the *none* backend can be useful if an audio device is needed in the VM for some software to work. To use the physical audio device of the host use device passthrough (see PCI Passthrough and USB Passthrough). Remote protocols like Microsoft's RDP have options to play sound.

[13] Looking Glass: https://looking-glass.io/

10.2.15 VirtIO RNG

A RNG (Random Number Generator) is a device providing entropy (*randomness*) to a system. A virtual hardware-RNG can be used to provide such entropy from the host system to a guest VM. This helps to avoid entropy starvation problems in the guest (a situation where not enough entropy is available and the system may slow down or run into problems), especially during the guests boot process.

To add a VirtIO-based emulated RNG, run the following command:

```
qm set <vmid> -rng0 source=<source>[,max_bytes=X,period=Y]
```

`source` specifies where entropy is read from on the host and has to be one of the following:

- `/dev/urandom`: Non-blocking kernel entropy pool (preferred)
- `/dev/random`: Blocking kernel pool (not recommended, can lead to entropy starvation on the host system)
- `/dev/hwrng`: To pass through a hardware RNG attached to the host (if multiple are available, the one selected in `/sys/devices/virtual/misc/hw_random/rng_current` will be used)

A limit can be specified via the `max_bytes` and `period` parameters, they are read as `max_bytes` per `period` in milliseconds. However, it does not represent a linear relationship: 1024B/1000ms would mean that up to 1 KiB of data becomes available on a 1 second timer, not that 1 KiB is streamed to the guest over the course of one second. Reducing the `period` can thus be used to inject entropy into the guest at a faster rate.

By default, the limit is set to 1024 bytes per 1000 ms (1 KiB/s). It is recommended to always use a limiter to avoid guests using too many host resources. If desired, a value of *0* for `max_bytes` can be used to disable all limits.

10.2.16 Virtiofs

Virtiofs is a shared filesystem designed for virtual environments. It allows to share a directory tree available on the host by mounting it within VMs. It does not use the network stack and aims to offer similar performance and semantics as the source filesystem.

To use virtiofs, the virtiofsd daemon needs to run in the background. This happens automatically in Proxmox VE when starting a VM using a virtiofs mount.

Linux VMs with kernel >=5.4 support virtiofs by default (virtiofs kernel module), but some features require a newer kernel.

To use virtiofs, ensure that virtiofsd is installed on the Proxmox VE host:

```
apt install virtiofsd
```

There is a guide available on how to utilize virtiofs in Windows VMs.

Known Limitations

- If virtiofsd crashes, its mount point will hang in the VM until the VM is completely stopped.
- virtiofsd not responding may result in a hanging mount in the VM, similar to an unreachable NFS.
- Memory hotplug does not work in combination with virtiofs (also results in hanging access).
- Memory related features such as live migration, snapshots, and hibernate are not available with virtiofs devices.
- Windows cannot understand ACLs in the context of virtiofs. Therefore, do not expose ACLs for Windows VMs, otherwise the virtiofs device will not be visible within the VM.

Add Mapping for Shared Directories

To add a mapping for a shared directory, you can use the API directly with `pvesh` as described in the Resource Mapping section:

```
pvesh create /cluster/mapping/dir --id dir1 \
    --map node=node1,path=/path/to/share1 \
    --map node=node2,path=/path/to/share2 \
```

Add virtiofs to a VM

To share a directory using virtiofs, add the parameter `virtiofs<N>` (N can be anything between 0 and 9) to the VM config and use a directory ID (dirid) that has been configured in the resource mapping. Additionally, you can set the `cache` option to either `always`, `never`, `metadata`, or `auto` (default: `auto`), depending on your requirements. How the different caching modes behave can be read here under the "Caching Modes" section.

The `virtiofsd` supports ACL and xattr passthrough (can be enabled with the `expose-acl` and `expose-xat` options), allowing the guest to access ACLs and xattrs if the underlying host filesystem supports them, but they must also be compatible with the guest filesystem (for example most Linux filesystems support ACLs, while Windows filesystems do not).

The `expose-acl` option automatically implies `expose-xattr`, that is, it makes no difference if you set `expose-xattr` to `0` if `expose-acl` is set to `1`.

If you want virtiofs to honor the `O_DIRECT` flag, you can set the `direct-io` parameter to `1` (default: `0`). This will degrade performance, but is useful if applications do their own caching.

```
qm set <vmid> -virtiofs0 dirid=<dirid>,cache=always,direct-io=1
qm set <vmid> -virtiofs1 <dirid>,cache=never,expose-xattr=1
qm set <vmid> -virtiofs2 <dirid>,expose-acl=1
```

To temporarily mount virtiofs in a guest VM with the Linux kernel virtiofs driver, run the following command inside the guest:

```
mount -t virtiofs <dirid> <mount point>
```

To have a persistent virtiofs mount, you can create an fstab entry:

```
<dirid> <mount point> virtiofs rw,relatime 0 0
```

The dirid associated with the path on the current node is also used as the mount tag (name used to mount the device on the guest).

For more information on available virtiofsd parameters, see the GitLab virtiofsd project page.

10.2.17 Device Boot Order

QEMU can tell the guest which devices it should boot from, and in which order. This can be specified in the config via the `boot` property, for example:

```
boot: order=scsi0;net0;hostpci0
```



This way, the guest would first attempt to boot from the disk `scsi0`, if that fails, it would go on to attempt network boot from `net0`, and in case that fails too, finally attempt to boot from a passed through PCIe device (seen as disk in case of NVMe, otherwise tries to launch into an option ROM).

On the GUI you can use a drag-and-drop editor to specify the boot order, and use the checkbox to enable or disable certain devices for booting altogether.

Note
If your guest uses multiple disks to boot the OS or load the bootloader, all of them must be marked as *bootable* (that is, they must have the checkbox enabled or appear in the list in the config) for the guest to be able to boot. This is because recent SeaBIOS and OVMF versions only initialize disks if they are marked *bootable*.

In any case, even devices not appearing in the list or having the checkmark disabled will still be available to the guest, once it's operating system has booted and initialized them. The *bootable* flag only affects the guest BIOS and bootloader.

10.2.18 Automatic Start and Shutdown of Virtual Machines

After creating your VMs, you probably want them to start automatically when the host system boots. For this you need to select the option *Start at boot* from the *Options* Tab of your VM in the web interface, or set it with the following command:

```
# qm set <vmid> -onboot 1
```

Start and Shutdown Order



In some case you want to be able to fine tune the boot order of your VMs, for instance if one of your VM is providing firewalling or DHCP to other guest systems. For this you can use the following parameters:

- **Start/Shutdown order**: Defines the start order priority. For example, set it to 1 if you want the VM to be the first to be started. (We use the reverse startup order for shutdown, so a machine with a start order of 1 would be the last to be shut down). If multiple VMs have the same order defined on a host, they will additionally be ordered by *VMID* in ascending order.
- **Startup delay**: Defines the interval between this VM start and subsequent VMs starts. For example, set it to 240 if you want to wait 240 seconds before starting other VMs.
- **Shutdown timeout**: Defines the duration in seconds Proxmox VE should wait for the VM to be offline after issuing a shutdown command. By default this value is set to 180, which means that Proxmox VE will issue a shutdown request and wait 180 seconds for the machine to be offline. If the machine is still online after the timeout it will be stopped forcefully.

Note
VMs managed by the HA stack do not follow the *start on boot* and *boot order* options currently. Those VMs will be skipped by the startup and shutdown algorithm as the HA manager itself ensures that VMs get started and stopped.

Please note that machines without a Start/Shutdown order parameter will always start after those where the parameter is set. Further, this parameter can only be enforced between virtual machines running on the same host, not cluster-wide.

If you require a delay between the host boot and the booting of the first VM, see the section on Proxmox VE Node Management.

10.2.19 QEMU Guest Agent

The QEMU Guest Agent is a service which runs inside the VM, providing a communication channel between the host and the guest. It is used to exchange information and allows the host to issue commands to the guest.

For example, the IP addresses in the VM summary panel are fetched via the guest agent.

Or when starting a backup, the guest is told via the guest agent to sync outstanding writes via the `guest-fsfree` and `guest-fsfreeze-thaw` commands.

For the guest agent to work properly the following steps must be taken:

- install the agent in the guest and make sure it is running
- enable the communication via the agent in Proxmox VE

Install Guest Agent

For most Linux distributions, the guest agent is available. The package is usually named `qemu-guest-agent`.

For Windows, see our Windows VirtIO Drivers article for more information on how to acquire and install the drivers.

Enable Guest Agent Communication

Communication from Proxmox VE with the guest agent can be enabled in the VM's **Options** panel. A fresh start of the VM is necessary for the changes to take effect.

Automatic TRIM Using QGA

It is possible to enable the *Run guest-trim* option. With this enabled, Proxmox VE will issue a trim command to the guest after the following operations that have the potential to write out zeros to the storage:

- moving a disk to another storage
- live migrating a VM to another node with local storage

On a thin provisioned storage, this can help to free up unused space.

Note
There is a caveat with ext4 on Linux, because it uses an in-memory optimization to avoid issuing duplicate TRIM requests. Since the guest doesn't know about the change in the underlying storage, only the first guest-trim will run as expected. Subsequent ones, until the next reboot, will only consider parts of the filesystem that changed since then.

Filesystem Freeze & Thaw

By default, if the QEMU Guest Agent is enabled in the guest's config and if the agent is available inside of the guest, then the virtual machine's filesystems are synced via the `guest-fsfreeze-freeze` QEMU Guest Agent command when certain operations are performed. This is done to provide data consistency.

See the QEMU Guest Agent Protocol Reference for more details.

A freeze will be issued for any of the following operations on a VM:

- Performing a backup in snapshot mode
- Creating a clone of a VM while it is running
- Replicating a VM while it is running
- Taking a snapshot without RAM of a running VM
- Importing a disk image from a running guest will issue a freeze for that running guest

On Windows guests, some applications might handle consistent backups themselves by hooking into the Windows VSS (Volume Shadow Copy Service) layer, a freeze then might interfere with that. For example, it has been observed that calling `guest-fsfreeze-freeze` with some SQL Servers triggers VSS to call the SQL Writer VSS module in a mode that breaks the SQL Server backup chain for differential backups.

There are two options on how to handle such a situation.

1. Configure the QEMU Guest Agent to use a different VSS variant that does not interfere with other VSS users. The Proxmox VE wiki has more details.
2. Alternatively, you can configure Proxmox VE to not issue a freeze-and-thaw cycle by disabling the `freeze-fs` guest agent option. This can also be done in the GUI: open the *Options* panel of the virtual machine, then the *QEMU Guest Agent* dialog, and disable the *Freeze/thaw guest filesystems during certain operations for consistency* option.



Important
Disabling this option can potentially lead to backups with inconsistent filesystems. Therefore, adapting the QEMU Guest Agent configuration in the guest is the preferred option.

Guest Clock Synchronization

While a VM is paused, the guest's clock does not advance. A similar problem occurs when restoring a VM from a previously saved state, for example after hibernation or after rolling back to a snapshot that includes RAM. Once the VM runs again, the guest's clock lags behind the host's time. A live migration can have the same effect if transferring the final part of the VM's state takes a long time, because the VM is paused during that phase. A time synchronization service in the guest, such as NTP, may correct a large offset only slowly or not at all, depending on its configuration. Until then, time-sensitive services can misbehave.

With the `sync-time-on-resume` QEMU Guest Agent option enabled, Proxmox VE sets the guest's clock to the host's current time via the `guest-set-time` guest agent command right after the following operations:

- resuming a paused VM
- resuming a hibernated VM
- rolling back to a snapshot that includes RAM
- taking a snapshot of a running VM
- live migrating a VM to another node
- performing a backup in suspend mode

The option is disabled by default. You can enable it in the *QEMU Guest Agent* dialog in the VM's *Options* panel, or with `qm set <vmid> --agent 1,sync-time-on-resume=1`.

Overriding the Option for a Single Operation

For a single operation, the configured value can be overridden with the `--sync-time-on-resume` parameter. This is supported when resuming a paused or hibernated VM (`qm resume`), starting a hibernated VM (`qm start`), and rolling back to a snapshot with RAM (`qm rollback`). For example, to resume a VM without synchronizing its clock:

```
# qm resume <vmid> --sync-time-on-resume 0
```

Snapshots, live migrations and backups always use the configured value.

Rolling Back to a Snapshot

When rolling back to a snapshot with RAM, Proxmox VE decides whether to synchronize the clock as follows:

- If the `--sync-time-on-resume` parameter is given, its value is used.
- Otherwise, if the guest agent is enabled in the configuration before the rollback, its `sync-time-on-resume` setting is used (disabled if not set). This way, the current setting also applies to snapshots taken before the option was enabled.
- Otherwise, the `sync-time-on-resume` setting stored in the snapshot is used.

In any case, the guest agent must be enabled in the snapshot's configuration, since the restored VM runs with the hardware configuration of the snapshot. The agent must also be running inside the guest.

Troubleshooting

VM does not shut down

Make sure the guest agent is installed and running.

Once the guest agent is enabled, Proxmox VE will send power commands like *shutdown* via the guest agent. If the guest agent is not running, commands cannot get executed properly and the shutdown command will run into a timeout.

10.2.20 SPICE Enhancements

SPICE Enhancements are optional features that can improve the remote viewer experience.

To enable them via the GUI go to the **Options** panel of the virtual machine. Run the following command to enable them via the CLI:

```
qm set <vmid> -spice_enhancements foldersharing=1,videostreaming=all
```

> **Note**
> To use these features the Display of the virtual machine must be set to SPICE (qxl).

Folder Sharing

Share a local folder with the guest. The `spice-webdavd` daemon needs to be installed in the guest. It makes the shared folder available through a local WebDAV server located at http://localhost:9843.

For Windows guests the installer for the *Spice WebDAV daemon* can be downloaded from the official SPICE website.

Most Linux distributions have a package called `spice-webdavd` that can be installed.

To share a folder in Virt-Viewer (Remote Viewer) go to *File* → *Preferences*. Select the folder to share and then enable the checkbox.

Note
Folder sharing currently only works in the Linux version of Virt-Viewer.

Caution
Experimental! Currently this feature does not work reliably.

Video Streaming

Fast refreshing areas are encoded into a video stream. Two options exist:

- **all**: Any fast refreshing area will be encoded into a video stream.
- **filter**: Additional filters are used to decide if video streaming should be used (currently only small window surfaces are skipped).

A general recommendation if video streaming should be enabled and which option to choose from cannot be given. Your mileage may vary depending on the specific circumstances.

Troubleshooting

Shared folder does not show up

Make sure the WebDAV service is enabled and running in the guest. On Windows it is called *Spice webdav proxy*. In Linux the name is *spice-webdavd* but can be different depending on the distribution.

If the service is running, check the WebDAV server by opening http://localhost:9843 in a browser in the guest.

It can help to restart the SPICE session.

10.3 Migration



If you have a cluster, you can migrate your VM to another host with

```
# qm migrate <vmid> <target>
```

There are generally two mechanisms for this

- Online Migration (aka Live Migration)
- Offline Migration

10.3.1 Online Migration

If your VM is running and no locally bound resources are configured (such as devices that are passed through), you can initiate a live migration with the `--online` flag in the `qm migration` command evocation. The web interface defaults to live migration when the VM is running.

Note
Live migration is only possible between hosts of the same CPU architecture. A running guest's CPU state cannot be transferred between an x86 and an arm64 host.

How it works

Online migration first starts a new QEMU process on the target host with the *incoming* flag, which performs only basic initialization with the guest vCPUs still paused and then waits for the guest memory and device state data streams of the source Virtual Machine. All other resources, such as disks, are either shared or got already sent before runtime state migration of the VMs begins; so only the memory content and device state remain to be transferred.

Once this connection is established, the source begins asynchronously sending the memory content to the target. If the guest memory on the source changes, those sections are marked dirty and another pass is made to send the guest memory data. This loop is repeated until the data difference between running source VM and incoming target VM is small enough to be sent in a few milliseconds, because then the source VM can be paused completely, without a user or program noticing the pause, so that the remaining data can be sent to the target, and then unpause the targets VM's CPU to make it the new running VM in well under a second.

Requirements

For Live Migration to work, there are some things required:

- The VM has no local resources that cannot be migrated. For example, PCI or USB devices that are passed through currently block live-migration. Local Disks, on the other hand, can be migrated by sending them to the target just fine.
- The hosts are located in the same Proxmox VE cluster.
- The hosts have a working (and reliable) network connection between them.
- The target host must have the same, or higher versions of the Proxmox VE packages. Although it can sometimes work the other way around, this cannot be guaranteed.

- The hosts have CPUs from the same vendor with similar capabilities. Different vendor **might** work depending on the actual models and VMs CPU type configured, but it cannot be guaranteed - so please test before deploying such a setup in production.

Conntrack State Migration

Note
Conntrack state migration is considered best-effort only and might not work, as it heavily depends on the network setup. For example, setups using source address masquerading (SNAT) on the host will most likely **not** work.

Conntrack is a Linux kernel mechanism to enable a stateful firewall by tracking individual connection. When live migrating running VMs, active in- and/or outbound connections **might** get interrupted as soon as the VM starts running on the target host, as the new host node does not have the same conntrack entries and thus the firewall can drop packets.

Conntrack state migration copies all conntrack entries on the host for the live-migrated VM to the target node and afterwards flushes the migrated entries from the conntrack table on the source node.

10.3.2 Offline Migration

If you have local resources, you can still migrate your VMs offline as long as all disk are on storage defined on both hosts. Migration then copies the disks to the target host over the network, as with online migration. Note that any hardware passthrough configuration may need to be adapted to the device location on the target host.

10.4 Copies and Clones



VM installation is usually done using an installation media (CD-ROM) from the operating system vendor. Depending on the OS, this can be a time consuming task one might want to avoid.

An easy way to deploy many VMs of the same type is to copy an existing VM. We use the term *clone* for such copies, and distinguish between *linked* and *full* clones.

Full Clone
The result of such copy is an independent VM. The new VM does not share any storage resources with the original.

It is possible to select a **Target Storage**, so one can use this to migrate a VM to a totally different storage. You can also change the disk image **Format** if the storage driver supports several formats.

Note
A full clone needs to read and copy all VM image data. This is usually much slower than creating a linked clone.

Some storage types allows to copy a specific **Snapshot**, which defaults to the *current* VM data. This also means that the final copy never includes any additional snapshots from the original VM.

Linked Clone
Modern storage drivers support a way to generate fast linked clones. Such a clone is a writable copy whose initial contents are the same as the original data. Creating a linked clone is nearly instantaneous, and initially consumes no additional space.

They are called *linked* because the new image still refers to the original. Unmodified data blocks are read from the original image, but modification are written (and afterwards read) from a new location. This technique is called *Copy-on-write*.

This requires that the original volume is read-only. With Proxmox VE one can convert any VM into a read-only Template). Such templates can later be used to create linked clones efficiently.

Note
You cannot delete an original template while linked clones exist.

It is not possible to change the **Target storage** for linked clones, because this is a storage internal feature.

The **Target node** option allows you to create the new VM on a different node. The only restriction is that the VM is on shared storage, and that storage is also available on the target node.

To avoid resource conflicts, all network interface MAC addresses get randomized, and we generate a new *UUID* for the VM BIOS (smbios1) setting.

10.5 Virtual Machine Templates

One can convert a VM into a Template. Such templates are read-only, and you can use them to create linked clones.

Note
It is not possible to start templates, because this would modify the disk images. If you want to change the template, create a linked clone and modify that.

10.6 VM Generation ID

Proxmox VE supports Virtual Machine Generation ID (*vmgenid*) [14] for virtual machines. This can be used by the guest operating system to detect any event resulting in a time shift event, for example, restoring a backup or a snapshot rollback.

When creating new VMs, a *vmgenid* will be automatically generated and saved in its configuration file.

To create and add a *vmgenid* to an already existing VM one can pass the special value '1' to let Proxmox VE autogenerate one or manually set the *UUID* [15] by using it as value, for example:

```
# qm set VMID -vmgenid 1
# qm set VMID -vmgenid 00000000-0000-0000-0000-000000000000
```

Note
The initial addition of a *vmgenid* device to an existing VM, may result in the same effects as a change on snapshot rollback, backup restore, etc., has as the VM can interpret this as generation change.

In the rare case the *vmgenid* mechanism is not wanted one can pass '0' for its value on VM creation, or retroactively delete the property in the configuration with:

```
# qm set VMID -delete vmgenid
```

The most prominent use case for *vmgenid* are newer Microsoft Windows operating systems, which use it to avoid problems in time sensitive or replicate services (such as databases or domain controller [16]) on snapshot rollback, backup restore or a whole VM clone operation.

10.7 Importing Virtual Machines

Importing existing virtual machines from foreign hypervisors or other Proxmox VE clusters can be achieved through various methods, the most common ones are:

- Using the native import wizard, which utilizes the *import* content type, such as provided by the ESXi special storage.
- Performing a backup on the source and then restoring on the target. This method works best when migrating from another Proxmox VE instance.
- using the OVF-specific import command of the `qm` command-line tool.

If you import VMs to Proxmox VE from other hypervisors, it's recommended to familiarize yourself with the concepts of Proxmox VE.

[14] Official *vmgenid* Specification https://docs.microsoft.com/en-us/windows/desktop/hyperv_v2/virtual-machine-generation-identifier

[15] Online GUID generator http://guid.one/

[16] https://docs.microsoft.com/en-us/windows-server/identity/ad-ds/get-started/virtual-dc/virtualized-domain-controller-architecture

10.7.1 Import Wizard



Proxmox VE provides an integrated VM importer using the storage plugin system for native integration into the API and web-based user interface. You can use this to import the VM as a whole, with most of its config mapped to Proxmox VE's config model and reduced downtime.

Note
The import wizard was added during the Proxmox VE 8.2 development cycle and is in tech preview state. While it's already promising and working stable, it's still under active development.

To use the import wizard you have to first set up a new storage for an import source, you can do so on the web-interface under *Datacenter* → *Storage* → *Add*.

Then you can select the new storage in the resource tree and use the *Virtual Guests* content tab to see all available guests that can be imported.



Select one and use the *Import* button (or double-click) to open the import wizard. You can modify a subset of the available options here and then start the import. Please note that you can do more advanced modifications after the import finished.

Tip

The ESXi import wizard has been tested with ESXi versions 6.5 through 8.0. Note that guests using vSAN storage cannot be directly imported directly; their disks must first be moved to another storage. While it is possible to use a vCenter as the import source, performance is dramatically degraded (5 to 10 times slower).

For a step-by-step guide and tips for how to adapt the virtual guest to the new hyper-visor see our migrate to Proxmox VE wiki article.

OVA/OVF Import

To import OVA/OVF files, you first need a File-based storage with the *import* content type. On this storage, there will be an *import* folder where you can put OVA files or OVF files with the corresponding images in a flat structure. Alternatively you can use the web UI to upload or download OVA files directly. You can then use the web UI to select those and use the import wizard to import the guests.

For OVA files, there is additional space needed to temporarily extract the image. This needs a file-based storage that has the *images* content type configured. By default the source storage is selected for this, but you can specify a *Import Working Storage* on which the images will be extracted before importing to the actual target storage.

Note
Since OVA/OVF file structure and content are not always well maintained or defined, it might be necessary to adapt some guest settings manually. For example the SCSI controller type is almost never defined in OVA/OVF files, but the default is unbootable with OVMF (UEFI), so you should select *Virtio SCSI* or *VMware PVSCSI* for these cases.

10.7.2 Import OVF/OVA Through CLI

A VM export from a foreign hypervisor takes usually the form of one or more disk images, with a configuration file describing the settings of the VM (RAM, number of cores).
The disk images can be in the vmdk format, if the disks come from VMware or VirtualBox, or qcow2 if the disks come from a KVM hypervisor. The most popular configuration format for VM exports is the OVF standard, but in practice interoperation is limited because many settings are not implemented in the standard itself, and hypervisors export the supplementary information in non-standard extensions.

Besides the problem of format, importing disk images from other hypervisors may fail if the emulated hardware changes too much from one hypervisor to another. Windows VMs are particularly concerned by this, as the OS is very picky about any changes of hardware. This problem may be solved by installing the MergeIDE.zip utility available from the Internet before exporting and choosing a hard disk type of **IDE** before booting the imported Windows VM.

Finally there is the question of paravirtualized drivers, which improve the speed of the emulated system and are specific to the hypervisor. GNU/Linux and other free Unix OSes have all the necessary drivers installed by default and you can switch to the paravirtualized drivers right after importing the VM. For Windows VMs, you need to install the Windows paravirtualized drivers by yourself.

GNU/Linux and other free Unix can usually be imported without hassle. Note that we cannot guarantee a successful import/export of Windows VMs in all cases due to the problems above.

Step-by-step example of a Windows OVF import

Microsoft provides Virtual Machines downloads to get started with Windows development.We are going to use one of these to demonstrate the OVF import feature.

Download the Virtual Machine zip

After getting informed about the user agreement, choose the *Windows 10 Enterprise (Evaluation - Build)* for the VMware platform, and download the zip.

Extract the disk image from the zip

Using the `unzip` utility or any archiver of your choice, unpack the zip, and copy via ssh/scp the ovf and vmdk files to your Proxmox VE host.

Import the Virtual Machine

This will create a new virtual machine, using cores, memory and VM name as read from the OVF manifest, and import the disks to the `local-lvm` storage. You have to configure the network manually.

```
# qm importovf 999 WinDev1709Eval.ovf local-lvm
```

The VM is ready to be started.

Adding an external disk image to a Virtual Machine

You can also add an existing disk image to a VM, either coming from a foreign hypervisor, or one that you created yourself.

Suppose you created a Debian/Ubuntu disk image with the *vmdebootstrap* tool:

```
vmdebootstrap --verbose \
 --size 10GiB --serial-console \
 --grub --no-extlinux \
 --package openssh-server \
 --package avahi-daemon \
 --package qemu-guest-agent \
 --hostname vm600 --enable-dhcp \
 --customize=./copy_pub_ssh.sh \
 --sparse --image vm600.raw
```

You can now create a new target VM, importing the image to the storage `pvedir` and attaching it to the VM's SCSI controller:

```
# qm create 600 --net0 virtio,bridge=vmbr0 --name vm600 --serial0 socket \
   --boot order=scsi0 --scsihw virtio-scsi-pci --ostype l26 \
   --scsi0 pvedir:0,import-from=/path/to/dir/vm600.raw
```

The VM is ready to be started.

10.8 Cloud-Init Support

Cloud-Init is the de facto multi-distribution package that handles early initialization of a virtual machine instance. Using Cloud-Init, configuration of network devices and ssh keys on the hypervisor side is possible. When the VM starts for the first time, the Cloud-Init software inside the VM will apply those settings.

Many Linux distributions provide ready-to-use Cloud-Init images, mostly designed for *OpenStack*. These images will also work with Proxmox VE. While it may seem convenient to get such ready-to-use images, we usually recommended to prepare the images by yourself. The advantage is that you will know exactly what you have installed, and this helps you later to easily customize the image for your needs.

Once you have created such a Cloud-Init image we recommend to convert it into a VM template. From a VM template you can quickly create linked clones, so this is a fast method to roll out new VM instances. You just need to configure the network (and maybe the ssh keys) before you start the new VM.

We recommend using SSH key-based authentication to login to the VMs provisioned by Cloud-Init. It is also possible to set a password, but this is not as safe as using SSH key-based authentication because Proxmox VE needs to store an encrypted version of that password inside the Cloud-Init data.

Proxmox VE generates an ISO image to pass the Cloud-Init data to the VM. For that purpose, all Cloud-Init VMs need to have an assigned CD-ROM drive. Usually, a serial console should be added and used as

a display. Many Cloud-Init images rely on this, it is a requirement for OpenStack. However, other images might have problems with this configuration. Switch back to the default display configuration if using a serial console doesn't work.

10.8.1 Preparing Cloud-Init Templates

The first step is to prepare your VM. Basically you can use any VM. Simply install the Cloud-Init packages **inside the VM** that you want to prepare. On Debian/Ubuntu based systems this is as simple as:

```
apt-get install cloud-init
```



Warning
This command is **not** intended to be executed on the Proxmox VE host, but only inside the VM.

Already many distributions provide ready-to-use Cloud-Init images (provided as `.qcow2` files), so alternatively you can simply download and import such images. For the following example, we will use the cloud image provided by Ubuntu at https://cloud-images.ubuntu.com.

```
# download the image
wget https://cloud-images.ubuntu.com/bionic/current/bionic-server-cloudimg- ↩
   amd64.img

# create a new VM with VirtIO SCSI controller
qm create 9000 --memory 2048 --net0 virtio,bridge=vmbr0 --scsihw virtio- ↩
   scsi-pci

# import the downloaded disk to the local-lvm storage, attaching it as a  ↩
   SCSI drive
qm set 9000 --scsi0 local-lvm:0,import-from=/path/to/bionic-server-cloudimg ↩
   -amd64.img
```

Note
Ubuntu Cloud-Init images require the `virtio-scsi-pci` controller type for SCSI drives.

Add Cloud-Init CD-ROM drive



The next step is to configure a CD-ROM drive, which will be used to pass the Cloud-Init data to the VM.

```
qm set 9000 --ide2 local-lvm:cloudinit
```

To be able to boot directly from the Cloud-Init image, set the `boot` parameter to `order=scsi0` to restrict BIOS to boot from this disk only. This will speed up booting, because VM BIOS skips the testing for a bootable CD-ROM.

```
qm set 9000 --boot order=scsi0
```

For many Cloud-Init images, it is required to configure a serial console and use it as a display. If the configuration doesn't work for a given image however, switch back to the default display instead.

```
qm set 9000 --serial0 socket --vga serial0
```

In a last step, it is helpful to convert the VM into a template. From this template you can then quickly create linked clones. The deployment from VM templates is much faster than creating a full clone (copy).

```
qm template 9000
```

10.8.2 Deploying Cloud-Init Templates



You can easily deploy such a template by cloning:

```
qm clone 9000 123 --name ubuntu2
```

Then configure the SSH public key used for authentication, and configure the IP setup:

```
qm set 123 --sshkey ~/.ssh/id_rsa.pub
qm set 123 --ipconfig0 ip=10.0.10.123/24,gw=10.0.10.1
```

You can also configure all the Cloud-Init options using a single command only. We have simply split the above example to separate the commands for reducing the line length. Also make sure to adopt the IP setup for your specific environment.

10.8.3 Custom Cloud-Init Configuration

The Cloud-Init integration also allows custom config files to be used instead of the automatically generated configs. This is done via the `cicustom` option on the command line:

```
qm set 9000 --cicustom "user=<volume>,network=<volume>,meta=<volume>"
```

The custom config files have to be on a storage that supports snippets and have to be available on all nodes the VM is going to be migrated to. Otherwise the VM won't be able to start. For example:

```
qm set 9000 --cicustom "user=local:snippets/userconfig.yaml"
```

There are three kinds of configs for Cloud-Init. The first one is the `user` config as seen in the example above. The second is the `network` config and the third the `meta` config. They can all be specified together or mixed and matched however needed. The automatically generated config will be used for any that don't have a custom config file specified.

The generated config can be dumped to serve as a base for custom configs:

```
qm cloudinit dump 9000 user
```

The same command exists for `network` and `meta`.

10.8.4 Cloud-Init on Windows

There is a reimplementation of Cloud-Init available for Windows called cloudbase-init. Not every feature of Cloud-Init is available with Cloudbase-Init, and some features differ compared to Cloud-Init.

Cloudbase-Init requires both `ostype` set to any Windows version and the `citype` set to `configdrive2`, which is the default with any Windows `ostype`.

There are no ready-made cloud images for Windows available for free. Using Cloudbase-Init requires manually installing and configuring a Windows guest.

10.8.5 Preparing Cloudbase-Init Templates

The first step is to install Windows in a VM. Download and install Cloudbase-Init in the guest. It may be necessary to install the Beta version. Don't run Sysprep at the end of the installation. Instead configure Cloudbase-Init first.

A few common options to set would be:

- *username*: This sets the username of the administrator
- *groups*: This allows one to add the user to the `Administrators` group
- *inject_user_password*: Set this to `true` to allow setting the password in the VM config
- *first_logon_behaviour*: Set this to `no` to not require a new password on login
- *rename_admin_user*: Set this to `true` to allow renaming the default `Administrator` user to the username specified with `username`
- *metadata_services*: Set this to `cloudbaseinit.metadata.services.configdrive.ConfigDriv` for Cloudbase-Init to first check this service. Otherwise it may take a few minutes for Cloudbase-Init to configure the system after boot.

Some plugins, for example the SetHostnamePlugin, require reboots and will do so automatically. To disable automatic reboots by Cloudbase-Init, you can set `allow_reboot` to `false`.

A full set of configuration options can be found in the official cloudbase-init documentation.

It can make sense to make a snapshot after configuring in case some parts of the config still need adjustments. After configuring Cloudbase-Init you can start creating the template. Shutdown the Windows guest, add a Cloud-Init disk and make it into a template.

```
qm set 9000 --ide2 local-lvm:cloudinit
qm template 9000
```

Clone the template into a new VM:

```
qm clone 9000 123 --name windows123
```

Then set the password, network config and SSH key:

```
qm set 123 --cipassword <password>
qm set 123 --ipconfig0 ip=10.0.10.123/24,gw=10.0.10.1
qm set 123 --sshkey ~/.ssh/id_rsa.pub
```

Make sure that the `ostype` is set to any Windows version before setting the password. Otherwise the password will be encrypted and Cloudbase-Init will use the encrypted password as plaintext password.

When everything is set, start the cloned guest. On the first boot the login won't work and it will reboot automatically for the changed hostname. After the reboot the new password should be set and login should work.

10.8.6 Cloudbase-Init and Sysprep

Sysprep is a feature to reset the configuration of Windows and provide a `new` system. This can be used in conjunction with Cloudbase-Init to create a clean template.

When using Sysprep there are 2 configuration files that need to be adapted. The first one is the normal configuration file, the second one is the one ending in `-unattend.conf`.

Cloudbase-Init runs in 2 steps, first the Sysprep step using the `-unattend.conf` and then the regular step using the primary config file.

For `Windows Server` running Sysprep with the provided `Unattend.xml` file should work out of the box. Normal Windows versions however require additional steps:

1. Open a PowerShell instance
2. Enable the Administrator user:

   ```
   net user Administrator /active:yes`
   ```

3. Install Cloudbase-Init using the Administrator user
4. Modify `Unattend.xml` to include the command to enable the Administrator user on the first boot after sysprepping:

   ```
   <RunSynchronousCommand wcm:action="add">
     <Path>net user administrator /active:yes</Path>
     <Order>1</Order>
     <Description>Enable Administrator User</Description>
   </RunSynchronousCommand>
   ```

   Make sure the `<Order>` does not conflict with other synchronous commands. Modify `<Order>` of the Cloudbase-Init command to run after this one by increasing the number to a higher value: `<Order>2</Order>`

5. (Windows 11 only) Remove the conflicting Microsoft.OneDriveSync package:

   ```
   Get-AppxPackage -AllUsers Microsoft.OneDriveSync | Remove-AppxPackage ↩
      -AllUsers
   ```

6. `cd` into the Cloudbase-Init config directory:

   ```
   cd 'C:\Program Files\Cloudbase Solutions\Cloudbase-Init\conf'
   ```

7. (optional) Create a snapshot of the VM before Sysprep in case of a misconfiguration
8. Run Sysprep:

```
C:\Windows\System32\Sysprep\sysprep.exe /generalize /oobe /unattend: ↩
   Unattend.xml
```

After following the above steps the VM should be in shut down state due to the Sysprep. Now you can make it into a template, clone it and configure it as needed.

10.8.7 Cloud-Init specific Options

cicustom: [meta=<volume>] [,network=<volume>] [,user=<volume>] [,vendor=<volume>]
Specify custom files to replace the automatically generated ones at start.

meta=<volume>
Specify a custom file containing all meta data passed to the VM via cloud-init. This is provider specific meaning configdrive2 and nocloud differ.

network=<volume>
To pass a custom file containing all network data to the VM via cloud-init.

user=<volume>
To pass a custom file containing all user data to the VM via cloud-init.

vendor=<volume>
To pass a custom file containing all vendor data to the VM via cloud-init.

cipassword: <string>
Password to assign the user. Using this is generally not recommended. Use ssh keys instead. Also note that older cloud-init versions do not support hashed passwords.

citype: <configdrive2 | nocloud | opennebula>
Specifies the cloud-init configuration format. The default depends on the configured operating system type (`ostype`. We use the `nocloud` format for Linux, and `configdrive2` for windows.

ciupgrade: <boolean> (*default =* 1)
do an automatic package upgrade after the first boot.

ciuser: <string>
User name to change ssh keys and password for instead of the image's configured default user.

ipconfig[n]: [gw=<GatewayIPv4>] [,gw6=<GatewayIPv6>] [,ip=<IPv4Format/CIDR>] [,ip6=<IPv6Format/CIDR>]
Specify IP addresses and gateways for the corresponding interface.

IP addresses use CIDR notation, gateways are optional but need an IP of the same type specified.

The special string *dhcp* can be used for IP addresses to use DHCP, in which case no explicit gateway should be provided. For IPv6 the special string *auto* can be used to use stateless autoconfiguration. This requires cloud-init 19.4 or newer.

If cloud-init is enabled and neither an IPv4 nor an IPv6 address is specified, it defaults to using dhcp on IPv4.

gw=<GatewayIPv4>
Default gateway for IPv4 traffic.

Note
Requires option(s): `ip`

gw6=<GatewayIPv6>
Default gateway for IPv6 traffic.

Note
Requires option(s): `ip6`

ip=<IPv4Format/CIDR> (***default =*** **dhcp**)
IPv4 address in CIDR format.

ip6=<IPv6Format/CIDR> (***default =*** **dhcp**)
IPv6 address in CIDR format.

nameserver: <string>
Sets DNS server IP address for a container. Create will automatically use the setting from the host if neither searchdomain nor nameserver are set.

searchdomain: <string>
Sets DNS search domains for a container. Create will automatically use the setting from the host if neither searchdomain nor nameserver are set.

sshkeys: <string>
Setup public SSH keys (one key per line, OpenSSH format).

10.9 PCI(e) Passthrough

PCI(e) passthrough is a mechanism to give a virtual machine control over a PCI device from the host. This can have some advantages over using virtualized hardware, for example lower latency, higher performance, or more features (e.g., offloading).

But, if you pass through a device to a virtual machine, you cannot use that device anymore on the host or in any other VM.

Note that, while PCI passthrough is available for i440fx and q35 machines, PCIe passthrough is only available on q35 machines. This does not mean that PCIe-capable devices that are passed through as PCI devices

will only run at PCI speeds. Passing through devices as PCIe just sets a flag for the guest to tell it that the device is a PCIe device instead of a "really fast legacy PCI device". Some guest applications benefit from this.

10.9.1 General Requirements

Since passthrough is performed on real hardware, it needs to fulfill some requirements. A brief overview of these requirements is given below, for more information on specific devices, see PCI Passthrough Examples.

Hardware

Your hardware needs to support `IOMMU` (**I**/**O** **M**emory **M**anagement **U**nit) interrupt remapping, this includes the CPU and the motherboard.

Generally, Intel systems with VT-d and AMD systems with AMD-Vi support this. On arm64, the equivalent is the System Memory Management Unit (SMMU), provided by supported platforms. It is not guaranteed that everything will work out of the box, due to bad hardware implementation and missing or low quality drivers.

Further, server grade hardware has often better support than consumer grade hardware, but even then, many modern systems can support this.

Please refer to your hardware vendor to check if they support this feature under Linux for your specific setup.

Determining PCI Card Address

The easiest way is to use the GUI to add a device of type "Host PCI" in the VM's hardware tab. Alternatively, you can use the command line.

You can locate your card using

```
lspci
```

Configuration

Once you ensured that your hardware supports passthrough, you will need to do some configuration to enable PCI(e) passthrough.

IOMMU

You will have to enable IOMMU support in your BIOS/UEFI. Usually the corresponding setting is called `IOMMU` or `VT-d`, but you should find the exact option name in the manual of your motherboard.

With AMD CPUs IOMMU is enabled by default. With recent kernels (6.8 or newer), this is also true for Intel CPUs. On older kernels, it is necessary to enable it on Intel CPUs via the kernel command line by adding:

```
intel_iommu=on
```

Note
The `intel_iommu=on` parameter applies to x86 hosts. On arm64, the SMMU is enabled through firmware and ACPI, so no such kernel command line parameter is needed.

IOMMU Passthrough Mode

If your hardware supports IOMMU passthrough mode, enabling this mode might increase performance. This is because VMs then bypass the (default) DMA translation normally performed by the hypervisor and instead pass DMA requests directly to the hardware IOMMU. To enable these options, add:

```
iommu=pt
```

to the kernel commandline.

Kernel Modules

Make sure the following modules are loaded by adding them to a file under '/etc/modules-load.d/', for example '/etc/modules-load.d/vfio.conf':

Mediated devices passthrough
If passing through mediated devices (e.g. vGPUs), the following is not needed. In these cases, the device will be owned by the appropriate host driver directly.

```
vfio
vfio_iommu_type1
vfio_pci
```

After changing anything modules related, you need to refresh your initramfs. On Proxmox VE this can be done by executing:

```
# update-initramfs -u -k all
```

To check if the modules are being loaded, the output of

```
# lsmod | grep vfio
```

should include the three modules from above.

Finish Configuration

Finally, reboot to bring the changes into effect and check that IOMMU is indeed enabled.

```
# dmesg | grep -e DMAR -e IOMMU -e AMD-Vi
```

should display that IOMMU, Directed I/O or Interrupt Remapping is enabled, depending on hardware and kernel the exact message can vary.

For notes on how to troubleshoot or verify if IOMMU is working as intended, please see the Verifying IOMMU Parameters section in our wiki.

It is also important that the device(s) you want to pass through are in a **separate** IOMMU group. This can be checked with a call to the Proxmox VE API:

```
# pvesh get /nodes/{nodename}/hardware/pci --pci-class-blacklist ""
```

It is okay if the device is in an IOMMU group together with its functions (e.g. a GPU with the HDMI Audio device) or with its root port or PCI(e) bridge.

PCI(e) slots
Some platforms handle their physical PCI(e) slots differently. Sometimes it can help to put the card in another PCI(e) slot, if you do not get the desired `IOMMU` group separation.

Unsafe interrupts
For some platforms, it may be necessary to allow unsafe interrupts. To do so, add the following line to a file ending in `.conf` under **/etc/modprobe.d/**:

```
options vfio_iommu_type1 allow_unsafe_interrupts=1
```

Please be aware that this option can make your system unstable.

GPU Passthrough Notes

It is not possible to display the frame buffer of the GPU via NoVNC or SPICE on the Proxmox VE web interface.

When passing through a whole GPU or a vGPU and graphic output is wanted, one has to either physically connect a monitor to the card, or configure a remote desktop software (for example, VNC or RDP) inside the guest.

If you only want to use the GPU as a hardware accelerator — for example, with programs using OpenCL or CUDA — this isn't necessary.

10.9.2 Host Device Passthrough

The most used variant of PCI(e) passthrough is to pass through a whole PCI(e) card, for example a GPU or a network card.

Host Configuration

Proxmox VE tries to automatically make the PCI(e) device unavailable for the host. However, if this doesn't work, there are two things that can be done:

- pass the device IDs to the options of the *vfio-pci* modules by adding

  ```
  options vfio-pci ids=1234:5678,4321:8765
  ```

  to a `.conf` file in **/etc/modprobe.d/** where `1234:5678` and `4321:8765` are the vendor and device IDs obtained by:

  ```
  # lspci -nn
  ```

- blacklist the driver on the host completely, ensuring it is free to bind for passthrough instead, by adding

  ```
  blacklist DRIVERNAME
  ```

  to a `.conf` file in **/etc/modprobe.d/**.

  To find the driver name, execute

```
# lspci -k
```

for example:

```
# lspci -k | grep -A 3 "VGA"
```

will output something similar to

```
01:00.0 VGA compatible controller: NVIDIA Corporation GP108 [GeForce GT  ↩
   1030] (rev a1)
        Subsystem: Micro-Star International Co., Ltd. [MSI] GP108 [ ↩
           GeForce GT 1030]
        Kernel driver in use: <some-module>
        Kernel modules: <some-module>
```

Now we can blacklist the drivers by writing them into a `.conf` file:

```
echo "blacklist <some-module>" >> /etc/modprobe.d/blacklist.conf
```

For both methods you need to update the initramfs and reboot after that.

Should this not work, you might need to set a soft dependency to load *vfio-pci* before loading the GPU modules. This can be done with the *softdep* flag, see also the manpages on *modprobe.d* for more information.

For example, if you are using drivers named <some-module>:

```
# echo "softdep <some-module> pre: vfio-pci" >> /etc/modprobe.d/<some- ↩
   module>.conf
```

Verify Configuration

To check if your changes were successful, you can use

```
# lspci -nnk
```

and check your device entry. If it says

```
Kernel driver in use: vfio-pci
```

or the *in use* line is missing entirely, the device is ready to be used for passthrough.

Mediated devices
For mediated devices this line will differ as the device will be owned by the host driver directly, not *vfio-pci*.

VM Configuration

When passing through a GPU, the best compatibility is reached when using *q35* as machine type, *OVMF* (*UEFI* for VMs) instead of SeaBIOS and PCIe instead of PCI. Note that if you want to use *OVMF* for GPU passthrough, the GPU needs to have a UEFI-capable ROM, otherwise use SeaBIOS instead. To check if the ROM is UEFI capable, see the PCI Passthrough Examples wiki.

Furthermore, when using OVMF, VGA arbitration can potentially be disabled, which reduces the amount of legacy code that needs to run at boot. To disable VGA arbitration:

```
echo "options vfio-pci ids=<vendor-id>,<device-id> disable_vga=1" > /etc/ ↩
   modprobe.d/vfio.conf
```

replacing the <vendor-id> and <device-id> with the ones obtained from:

```
# lspci -nn
```

PCI devices can be added in the web interface in the hardware section of the VM. Alternatively, you can use the command line; set the **hostpciX** option in the VM configuration, for example by executing:

```
# qm set VMID -hostpci0 00:02.0
```

or by adding a line to the VM configuration file:

```
hostpci0: 00:02.0
```

If your device has multiple functions (e.g., '`00:02.0`' and '`00:02.1`'), you can pass them through all together with the shortened syntax ``00:02`. *This is equivalent to checking the ``All Functions`* checkbox in the web interface.

There are some options which may be necessary, depending on the device and guest OS:

- **x-vga=on|off** marks the PCI(e) device as the primary GPU of the VM. With this enabled the **vga** configuration option will be ignored.
- **pcie=on|off** tells Proxmox VE to use a PCIe or PCI port. Some guests/device combinations require PCIe rather than PCI. PCIe is only available for *q35* machine types.
- **rombar=on|off** makes the firmware ROM visible for the guest. Default is on. Some PCI(e) devices need this disabled.
- **romfile=<path>**, is an optional path to a ROM file for the device to use. This is a relative path under **/usr/share/kvm/**.

Example

An example of PCIe passthrough with a GPU set to primary:

```
# qm set VMID -hostpci0 02:00,pcie=on,x-vga=on
```

PCI ID overrides

You can override the PCI vendor ID, device ID, and subsystem IDs that will be seen by the guest. This is useful if your device is a variant with an ID that your guest's drivers don't recognize, but you want to force those drivers to be loaded anyway (e.g. if you know your device shares the same chipset as a supported variant).

The available options are `vendor-id`, `device-id`, `sub-vendor-id`, and `sub-device-id`. You can set any or all of these to override your device's default IDs.

For example:

```
# qm set VMID -hostpci0 02:00,device-id=0x10f6,sub-vendor-id=0x0000
```

10.9.3 SR-IOV

Another variant for passing through PCI(e) devices is to use the hardware virtualization features of your devices, if available.

Enabling SR-IOV
To use SR-IOV, platform support is especially important. It may be necessary to enable this feature in the BIOS/UEFI first, or to use a specific PCI(e) port for it to work. If in doubt, consult the manual of the platform or contact its vendor.

SR-IOV (**S**ingle-**R**oot **I**nput/**O**utput **V**irtualization) enables a single device to provide multiple *VFs* (**V**irtual **F**unctions) to the system. Each of those *VFs* can be used in a different VM, with full hardware features and also better performance and lower latency than software-virtualized devices.

Currently, the most common use case for this is with NICs (**N**etwork **I**nterface **C**ard) with SR-IOV support, which can provide multiple VFs per physical port. This allows features such as checksum offloading to be used inside a VM, reducing the (host) CPU overhead.

Host Configuration

Generally, there are two methods for enabling virtual functions on a device.

- sometimes there is an option for the driver module e.g. for some Intel drivers

  ```
  max_vfs=4
  ```

  which can be placed in a file with a *.conf* ending under /**etc**/**modprobe.d**/. (Do not forget to update your initramfs after that)

  Please refer to your driver module documentation for the exact parameters and options.

- The second, more generic, approach is using the `sysfs`. If a device and driver support this, you can change the number of VFs on the fly. For example, to set up 4 VFs on device 0000:01:00.0 execute:

  ```
  # echo 4 > /sys/bus/pci/devices/0000:01:00.0/sriov_numvfs
  ```

  To make this change persistent, you can use the ‘sysfsutils` Debian package. After installation, configure it via /**etc**/**sysfs.conf** or a `FILE.conf’ in /**etc**/**sysfs.d**/.

VM Configuration

After creating VFs, you should see them as separate PCI(e) devices when outputting them with `lspci`. Get their ID and pass them through like a normal PCI(e) device.

10.9.4 Mediated Devices (vGPU, GVT-g)

Mediated devices are another method to reuse features and performance from physical hardware for virtualized hardware. These are most commonly found in virtualized GPU setups such as Intel’s GVT-g and NVIDIA’s vGPUs used in their GRID technology.

With this, a physical card is able to create virtual cards, similar to SR-IOV. The difference is that mediated devices do not appear as PCI(e) devices on the host, and are thus only suited for use in virtual machines.

Host Configuration

In general, your card's driver must support that feature, otherwise it will not work. So please refer to your vendor for compatible drivers and how to configure them.

Intel's drivers for GVT-g are integrated in the kernel and should work with 5th, 6th and 7th generation Intel Core Processors, as well as E3 v4, E3 v5 and E3 v6 Xeon Processors.

To enable it for Intel Graphics, you have to make sure to load the module *kvmgt* (for example via `/etc/modules-` and to enable it on the kernel commandline and add the following parameter:

```
i915.enable_gvt=1
```

After that remember to update the initramfs, and reboot your host.

VM Configuration

To use a mediated device, simply specify the `mdev` property on a `hostpciX` VM configuration option.

You can get the supported devices via the *sysfs*. For example, to list the supported types for the device *0000:00:02.0* you would simply execute:

```
# ls /sys/bus/pci/devices/0000:00:02.0/mdev_supported_types
```

Each entry is a directory which contains the following important files:

- *available_instances* contains the amount of still available instances of this type; each *mdev* used in a VM reduces this.
- *description* contains a short description about the capabilities of the type
- *create* is the endpoint to create such a device — Proxmox VE does this automatically for you if a *hostpciX* option with `mdev` is configured.

Example configuration with an `Intel GVT-g vGPU` (`Intel Skylake 6700k`):

```
# qm set VMID -hostpci0 00:02.0,mdev=i915-GVTg_V5_4
```

With this set, Proxmox VE automatically creates such a device on VM start, and cleans it up again when the VM stops.

10.9.5 Usage in Clusters

It is also possible to map devices at a cluster level, so that they can be properly used with HA and hardware changes are detected and non-root users can configure them. See Resource Mapping for details on that.

10.9.6 vIOMMU (emulated IOMMU)

vIOMMU is the emulation of a hardware IOMMU within a virtual machine, providing improved memory access control and security for virtualized I/O devices. Using the vIOMMU option also allows you to pass through PCI(e) devices to level-2 VMs in level-1 VMs via Nested Virtualization. To pass through physical PCI(e) devices from the host to nested VMs, follow the PCI(e) passthrough instructions.

There are currently two vIOMMU implementations available: Intel and VirtIO.

Intel vIOMMU

Intel vIOMMU-specific VM requirements:

- Whether you are using an Intel or AMD CPU on your host, it is important to set `intel_iommu=on` in the VM's kernel parameters.
- To use Intel vIOMMU you need to set **q35** as the machine type.

If all requirements are met, you can add `viommu=intel` to the machine parameter in the configuration of the VM that should be able to pass through PCI devices.

```
# qm set VMID -machine q35,viommu=intel
```

QEMU documentation for VT-d

VirtIO vIOMMU

This vIOMMU implementation is more recent and does not have as many limitations as Intel vIOMMU but is currently less used in production and less documented.

With VirtIO vIOMMU there is **no** need to set any kernel parameters. It is also **not** necessary to use q35 as the machine type, but it is advisable if you want to use PCIe.

```
# qm set VMID -machine q35,viommu=virtio
```

Blog-Post by Michael Zhao explaining virtio-iommu

10.10 Hookscripts

You can add a hook script to VMs with the config property `hookscript`.

```
# qm set 100 --hookscript local:snippets/hookscript.pl
```

It will be called during various phases of the guests lifetime. For an example and documentation see the example script under `/usr/share/pve-docs/examples/guest-example-hookscript.pl`.

10.11 Hibernation

You can suspend a VM to disk with the GUI option `Hibernate` or with

```
# qm suspend ID --todisk
```

That means that the current content of the memory will be saved onto disk and the VM gets stopped. On the next start, the memory content will be loaded and the VM can continue where it was left off.

State storage selection

If no target storage for the memory is given, it will be automatically chosen, the first of:

1. The storage `vmstatestorage` from the VM config.
2. The first shared storage from any VM disk.
3. The first non-shared storage from any VM disk.
4. The storage `local` as a fallback.

A storage of a VM disk is skipped if it allows the disks of VMs, but not their saved states, see the `content` property in the storage chapter. Saving the state fails if such a storage is given as target or set as `vmstatestora`

10.12 Resource Mapping



When using or referencing local resources (e.g. address of a pci device), using the raw address or id is sometimes problematic, for example:

- when using HA, a different device with the same id or path may exist on the target node, and if one is not careful when assigning such guests to HA groups, the wrong device could be used, breaking configurations.

- changing hardware can change ids and paths, so one would have to check all assigned devices and see if the path or id is still correct.

To handle this better, one can define cluster wide resource mappings, such that a resource has a cluster unique, user selected identifier which can correspond to different devices on different hosts. With this, HA won't start a guest with a wrong device, and hardware changes can be detected.

Creating such a mapping can be done with the Proxmox VE web GUI under `Datacenter` in the relevant tab in the `Resource Mappings` category, or on the cli with

```
# pvesh create /cluster/mapping/<type> <options>
```



Where `<type>` is the hardware type (currently either `pci`, `usb` or dir) and `<options>` are the device mappings and other configuration parameters.

Note that the options must include a map property with all identifying properties of that hardware, so that it's possible to verify the hardware did not change and the correct device is passed through.

For example to add a PCI device as `device1` with the path `0000:01:00.0` that has the device id `0001` and the vendor id `0002` on the node `node1`, and `0000:02:00.0` on `node2` you can add it with:

```
# pvesh create /cluster/mapping/pci --id device1 \
 --map node=node1,path=0000:01:00.0,id=0002:0001 \
 --map node=node2,path=0000:02:00.0,id=0002:0001
```

You must repeat the `map` parameter for each node where that device should have a mapping (note that you can currently only map one USB device per node per mapping).

Using the GUI makes this much easier, as the correct properties are automatically picked up and sent to the API.



It's also possible for PCI devices to provide multiple devices per node with multiple map properties for the nodes. If such a device is assigned to a guest, the first free one will be used when the guest is started. The order of the paths given is also the order in which they are tried, so arbitrary allocation policies can be implemented.

This is useful for devices with SR-IOV, since some times it is not important which exact virtual function is passed through.

You can assign such a device to a guest either with the GUI or with

```
# qm set ID -hostpci0 <name>
```

for PCI devices, or

```
# qm set <vmid> -usb0 <name>
```

for USB devices.

Where `<vmid>` is the guests id and `<name>` is the chosen name for the created mapping. All usual options for passing through the devices are allowed, such as `mdev`.

To create mappings `Mapping.Modify` on `/mapping/<type>/<name>` is necessary (where `<type>` is the device type and `<name>` is the name of the mapping).

To use these mappings, `Mapping.Use` on `/mapping/<type>/<name>` is necessary (in addition to the normal guest privileges to edit the configuration).

Additional Options

There are additional options when defining a cluster wide resource mapping. Currently there are the following options:

- `mdev` (PCI): This marks the PCI device as being capable of providing `mediated devices`. When this is enabled, you can select a type when configuring it on the guest. If multiple PCI devices are selected for the mapping, the mediated device will be created on the first one where there are any available instances of the selected type.
- `live-migration-capable` (PCI): This marks the PCI device as being capable of being live migrated between nodes. This requires driver and hardware support. Only NVIDIA GPUs with recent kernel are known to support this. Note that live migrating passed through devices is an experimental feature and may not work or cause issues.

10.13 Managing Virtual Machines with qm

qm is the tool to manage QEMU/KVM virtual machines on Proxmox VE. You can create and destroy virtual machines, and control execution (start/stop/suspend/resume). Besides that, you can use qm to set parameters in the associated config file. It is also possible to create and delete virtual disks.

10.13.1 CLI Usage Examples

Using an iso file uploaded on the *local* storage, create a VM with a 4 GB IDE disk on the *local-lvm* storage

```
# qm create 300 -ide0 local-lvm:4 -net0 e1000 -cdrom local:iso/proxmox- ↩
   mailgateway_2.1.iso
```

Start the new VM

```
# qm start 300
```

Send a shutdown request, then wait until the VM is stopped.

```
# qm shutdown 300 && qm wait 300
```

Same as above, but only wait for 40 seconds.

```
# qm shutdown 300 && qm wait 300 -timeout 40
```

If the VM does not shut down, force-stop it and overrule any running shutdown tasks. As stopping VMs may incur data loss, use it with caution.

```
# qm stop 300 -overrule-shutdown 1
```

Destroying a VM always removes it from Access Control Lists and it always removes the firewall configuration of the VM. You have to activate *--purge*, if you want to additionally remove the VM from replication jobs, backup jobs and HA resource configurations.

Note
Activating purge will also remove the HA resource from any affinity rules referencing it and will remove rules that have only this one remaining resource.

```
# qm destroy 300 --purge
```

Move a disk image to a different storage.

```
# qm move-disk 300 scsi0 other-storage
```

Reassign a disk image to a different VM. This will remove the disk `scsi1` from the source VM and attaches it as `scsi3` to the target VM. In the background the disk image is being renamed so that the name matches the new owner.

```
# qm move-disk 300 scsi1 --target-vmid 400 --target-disk scsi3
```

10.14 Configuration

VM configuration files are stored inside the Proxmox cluster file system, and can be accessed at `/etc/pve/qemu`
Like other files stored inside `/etc/pve/`, they get automatically replicated to all other cluster nodes.

Note
VMIDs < 100 are reserved for internal purposes, and VMIDs need to be unique cluster wide.

Example VM Configuration

```
boot: order=virtio0;net0
cores: 1
sockets: 1
memory: 512
name: webmail
ostype: l26
net0: e1000=EE:D2:28:5F:B6:3E,bridge=vmbr0
virtio0: local:vm-100-disk-1,size=32G
```

Those configuration files are simple text files, and you can edit them using a normal text editor (`vi`, `nano`, ...). This is sometimes useful to do small corrections, but keep in mind that you need to restart the VM to apply such changes.

For that reason, it is usually better to use the `qm` command to generate and modify those files, or do the whole thing using the GUI. Our toolkit is smart enough to instantaneously apply most changes to running VM. This feature is called "hot plug", and there is no need to restart the VM in that case.

10.14.1 File Format

VM configuration files use a simple colon separated key/value format. Each line has the following format:

```
# this is a comment
OPTION: value
```

Blank lines in those files are ignored, and lines starting with a `#` character are treated as comments and are also ignored.

10.14.2 Snapshots

When you create a snapshot, `qm` stores the configuration at snapshot time into a separate snapshot section within the same configuration file. For example, after creating a snapshot called “testsnapshot”, your configuration file will look like this:

VM configuration with snapshot

```
memory: 512
swap: 512
parent: testsnaphot
...

[testsnaphot]
memory: 512
swap: 512
snaptime: 1457170803
...
```

There are a few snapshot related properties like `parent` and `snaptime`. The `parent` property is used to store the parent/child relationship between snapshots. `snaptime` is the snapshot creation time stamp (Unix epoch).

You can optionally save the memory of a running VM with the option `vmstate`. For details about how the target storage gets chosen for the VM state, see State storage selection in the chapter Hibernation.

10.14.3 Meta Information

The read-only `meta` property contains information that Proxmox VE records automatically about the VM:

`ctime`
: The time the VM was created, in seconds since the UNIX epoch.

`creation-qemu`
: The QEMU version that the VM was created with. For VMs without a fixed machine version, Proxmox VE uses it to keep parts of the virtual hardware as they were at creation, for example the machine version of Windows VMs, see Machine Type.

`uid` and `rtime`
: The guest identity of the VM, available since Proxmox VE 9.3, see Guest Identity.

Example meta property of a VM

```
meta: creation-qemu=10.1.2,ctime=1772444467,rtime=1794320571482,uid= ↩
   w5qczgiem26qnwzwsoil
```

A clone keeps its source VM's `ctime` and `creation-qemu` values. A restored VM uses the values from the backup. VMs created with older versions of Proxmox VE can lack these values.

Proxmox VE versions older than 9.3 ignore the whole `meta` property of a VM with a guest identity, including `creation-qemu`, and drop it when they write the configuration. A VM started on a node running such a version can therefore get different virtual hardware. Migrating or cloning a VM to such a node is refused, see Mixed Versions in a Cluster.

10.14.4 Options

acpi: <boolean> (*default =* 1)
Enable/disable ACPI.

affinity: <string>
List of host cores used to execute guest processes, for example: 0,5,8-11

agent: [enabled=]<1|0> [,freeze-fs=<1|0>] [,fstrim_cloned_disks=<1|0>] [,sync-time-on-resume=<1|0>] [,type=<virtio|isa>]
Enable/disable communication with the QEMU Guest Agent and its properties.

enabled=<boolean> (*default =* 0)
Enable/disable communication with a QEMU Guest Agent (QGA) running in the VM.

freeze-fs=<boolean> (*default =* 1)
Whether to issue the guest-fsfreeze-freeze and guest-fsfreeze-thaw QEMU guest agent commands. Backups in snapshot mode, clones, snapshots without RAM, importing disks from a running guest, and replications normally issue a guest-fsfreeze-freeze and a respective thaw command when the QEMU Guest agent option is enabled in the guest's configuration and the agent is running inside of the guest.

The deprecated *freeze-fs-on-backup* setting is treated as an alias for this setting.

fstrim_cloned_disks=<boolean> (*default =* 0)
Run fstrim after moving a disk or migrating the VM.

sync-time-on-resume=<boolean> (*default =* 0)
Whether to issue the *guest-set-time* QEMU guest agent command to synchronize the guest's clock to the host's current time after operations that can leave the guest's clock behind. This happens when resuming from hibernation, resuming from a paused state, taking a snapshot, after a live migration, after a backup in suspend mode, and after rolling back to a snapshot that includes RAM. In these cases the guest's clock may still reflect an earlier time. The time is only synchronized when the QEMU Guest Agent option is enabled in the guest's configuration and the agent is running inside of the guest. For resume, hibernation resume and snapshot rollback, the synchronization can be overridden per operation.

type=<isa | virtio> (*default =* virtio)
Select the agent type

allow-ksm: <boolean> (*default =* 1)
Allow memory pages of this guest to be merged via KSM (Kernel Samepage Merging).

amd-sev: [type=]<sev-type> [,allow-smt=<1|0>] [,kernel-hashes=<1|0>] [,no-debug=<1|0>] [,no-key-sharing=<1|0>]
Secure Encrypted Virtualization (SEV) features by AMD CPUs

allow-smt=<boolean> (*default =* 1)
Sets policy bit to allow Simultaneous Multi Threading (SMT) (Ignored unless for SEV-SNP)

kernel-hashes=<boolean> (*default =* 0)
Add kernel hashes to guest firmware for measured linux kernel launch

no-debug=<boolean> (*default =* 0)
Sets policy bit to disallow debugging of guest

no-key-sharing=<boolean> (*default =* 0)
Sets policy bit to disallow key sharing with other guests (Ignored for SEV-SNP)

type=<sev-type>
Enable standard SEV with type=*std* or enable experimental SEV-ES with the *es* option or enable experimental SEV-SNP with the *snp* option.

arch: <aarch64 | x86_64>
Virtual processor architecture. Defaults to the host architecture.

args: <string>
Arbitrary arguments passed to kvm, for example:

args: -no-reboot -smbios *type=0,vendor=FOO*

> **Note**
> this option is for experts only.

audio0: device=<ich9-intel-hda|intel-hda|AC97>
[,driver=<spice|none>]
Configure a audio device, useful in combination with QXL/Spice.

device=<AC97 | ich9-intel-hda | intel-hda>
Configure an audio device.

driver=<none | spice> (*default =* spice)
Driver backend for the audio device.

autostart: <boolean> (*default =* 0)
Automatic restart after crash (currently ignored).

balloon: <integer> (0 - N)
Amount of target RAM for the VM in MiB. The balloon driver is enabled by default, unless it is explicitly disabled by setting the value to zero.

bios: <ovmf | seabios> (*default =* seabios)
Select BIOS implementation.

boot: [[legacy=]<[acdn]{1,4}>] [,order=<device[;device...]>]
Specify guest boot order. Use the *order=* sub-property as usage with no key or *legacy=* is deprecated.

legacy=<[acdn]{1,4}> (*default =* cdn)
Boot on floppy (a), hard disk (c), CD-ROM (d), or network (n). Deprecated, use *order=* instead.

order=<device[;device...]>
The guest will attempt to boot from devices in the order they appear here.

Disks, optical drives and passed-through storage USB devices will be directly booted from, NICs will load PXE, and PCIe devices will either behave like disks (e.g. NVMe) or load an option ROM (e.g. RAID controller, hardware NIC).

Note that only devices in this list will be marked as bootable and thus loaded by the guest firmware (BIOS/UEFI). If you require multiple disks for booting (e.g. software-raid), you need to specify all of them here.

Overrides the deprecated *legacy=[acdn]** value when given.

bootdisk: (ide|sata|scsi|virtio)\d+
Enable booting from specified disk. Deprecated: Use *boot: order=foo;bar* instead.

cdrom: <volume>
This is an alias for option -ide2

cicustom: [meta=<volume>] [,network=<volume>] [,user=<volume>] [,vendor=<volume>]
cloud-init: Specify custom files to replace the automatically generated ones at start.

meta=<volume>
Specify a custom file containing all meta data passed to the VM via cloud-init. This is provider specific meaning configdrive2 and nocloud differ.

network=<volume>
To pass a custom file containing all network data to the VM via cloud-init.

user=<volume>
To pass a custom file containing all user data to the VM via cloud-init.

vendor=<volume>
To pass a custom file containing all vendor data to the VM via cloud-init.

cipassword: <string>
cloud-init: Password to assign the user. Using this is generally not recommended. Use ssh keys instead. Also note that older cloud-init versions do not support hashed passwords.

citype: <configdrive2 | nocloud | opennebula>
Specifies the cloud-init configuration format. The default depends on the configured operating system type (`ostype`. We use the `nocloud` format for Linux, and `configdrive2` for windows.

ciupgrade: <boolean> (*default =* 1)
cloud-init: do an automatic package upgrade after the first boot.

ciuser: <string>
cloud-init: User name to change ssh keys and password for instead of the image's configured default user.

cores: <integer> (1 - N) (*default =* 1)
The number of cores per socket.

cpu: [[cputype=]<string>] [,flags=<+FLAG[;-FLAG...]>]
[,guest-phys-bits=<integer>] [,hidden=<1|0>]
[,hv-vendor-id=<vendor-id>] [,level=<integer>]
[,phys-bits=<8-64|host>] [,reported-model=<enum>]
Emulated CPU type.

cputype=<string> (*default =* kvm64)
Emulated CPU type. Can be default or custom name (custom model names must be prefixed with *custom-*).

flags=<+FLAG[;-FLAG...]>
List of additional CPU flags separated by *;*. Use *+FLAG* to enable, *-FLAG* to disable a flag. There is a special *nested-virt* shorthand which controls nested virtualization for the current CPU (*svm* for AMD and *vmx* for Intel). Custom CPU models can specify any flag supported by QEMU/KVM, VM-specific flags must be from the following set for security reasons: aes, amd-no-ssb, amd-ssbd, hv-evmcs, hv-tlbflush, ibpb, md-clear, nested-virt, pcid, pdpe1gb, spec-ctrl, ssbd, virt-ssbd

guest-phys-bits=<integer> (32 - 64)
Number of physical address bits available to the guest.

hidden=<boolean> (*default =* 0)
Do not identify as a KVM virtual machine. Only affects vCPUs with x86-64 architecture.

hv-vendor-id=<vendor-id>
The Hyper-V vendor ID. Some drivers or programs inside Windows guests need a specific ID.

level=<integer> (0 - 4294967295)
Maximum input value for the basic CPUID leaves the guest can query - that is the vendor (leaf 0), family/model/stepping and feature bits (leaf 1), cache and topology info (leaves 4 and B), and so on. Higher-numbered leaves are hidden. Setting *30* is a common workaround for Hyper-V boot failures on Windows guests running on recent Intel hosts. Only applies when the vCPU architecture is x86_64.

phys-bits=<8-64|host>
The physical memory address bits that are reported to the guest OS. Should be smaller or equal to the host's. Set to *host* to use value from host CPU, but note that doing so will break live migration to CPUs with other values.

reported-model=<486 | Broadwell | Broadwell-IBRS | Broadwell-noTSX | Broadwell-noTSX-IBRS | Cascadelake-Server | Cascadelake-Server-noTSX | Cascadelake-Server-v2 | Cascadelake-Server-v4 | Cascadelake-Server-v5 | Cascadelake-Server-v6 | Cascadelake-Server-v7 | ClearwaterForest | ClearwaterForest-v2 | ClearwaterForest-v3 | ClearwaterForest-v4 | Conroe | Cooperlake | Cooperlake-v2 | DiamondRapids | DiamondRapids-v2 | EPYC | EPYC-Genoa | EPYC-Genoa-v2 | EPYC-Genoa-v3 | EPYC-IBPB | EPYC-Milan | EPYC-Milan-v2 | EPYC-Milan-v3 | EPYC-Milan-v4 | EPYC-Rome | EPYC-Rome-v2 | EPYC-Rome-v3 | EPYC-Rome-v4 | EPYC-Rome-v5 | EPYC-Turin | EPYC-Turin-v2 | EPYC-v3 | EPYC-v4 | EPYC-v5 | GraniteRapids | GraniteRapids-v2 | GraniteRapids-v3 | GraniteRapids-v4 | GraniteRapids-v5 | GraniteRapids-v6 | GraniteRapids-v7 | Haswell | Haswell-IBRS | Haswell-noTSX | Haswell-noTSX-IBRS | Icelake-Client | Icelake-Client-noTSX | Icelake-Server | Icelake-Server-noTSX | Icelake-Server-v3 | Icelake-Server-v4 | Icelake-Server-v5 | Icelake-Server-v6 | Icelake-Server-v7 | Icelake-Server-v8 | Icelake-Server-v9 | IvyBridge | IvyBridge-IBRS | KnightsMill | Nehalem | Nehalem-IBRS | Opteron_G1 | Opteron_G2 | Opteron_G3 | Opteron_G4 | Opteron_G5 | Penryn | SandyBridge | SandyBridge-IBRS | SapphireRapids | SapphireRapids-v2 | SapphireRapids-v3 | SapphireRapids-v4 | SapphireRapids-v5 | SapphireRapids-v6 | SapphireRapids-v7 | SapphireRapids-v8 | SierraForest | SierraForest-v2 | SierraForest-v3 | SierraForest-v4 | SierraForest-v5 | SierraForest-v6 | Skylake-Client | Skylake-Client-IBRS | Skylake-Client-noTSX-IBRS | Skylake-Client-v4 | Skylake-Server | Skylake-Server-IBRS | Skylake-Server-noTSX-IBRS | Skylake-Server-v4 | Skylake-Server-v5 | Skylake-Server-v6 | Westmere | Westmere-IBRS | a64fx | athlon | core2duo | coreduo | cortex-a35 | cortex-a53 | cortex-a55 | cortex-a57 | cortex-a710 | cortex-a72 | cortex-a76 | cortex-a78ae | host | kvm32 | kvm64 | max | neoverse-n1 | neoverse-n2 | neoverse-v1 | pentium | pentium2 | pentium3 | phenom | qemu32 | qemu64> (*default* = kvm64)

CPU model and vendor to report to the guest. Must be a QEMU/KVM supported model. Only valid for custom CPU model definitions, default models will always report themselves to the guest OS.

cpulimit: <number> (0 - 128) (*default* = 0)

Limit of CPU usage.

Note

If the computer has 2 CPUs, it has total of *2* CPU time. Value *0* indicates no CPU limit.

cpuunits: <integer> (1 - 262144) (*default* = cgroup v1: 1024, cgroup v2: 100)
CPU weight for a VM. Argument is used in the kernel fair scheduler. The larger the number is, the more CPU time this VM gets. Number is relative to weights of all the other running VMs.

description: <string>
Description for the VM. Shown in the web-interface VM's summary. This is saved as comment inside the configuration file.

efidisk0: [file=]<volume> [,efitype=<2m|4m>] [,format=<enum>] [,ms-cert=<enum>] [,pre-enrolled-keys=<1|0>] [,size=<DiskSize>]
Configure a disk for storing EFI vars.

efitype=<2m | 4m> (*default* = 2m)
Size and type of the OVMF EFI vars. *4m* is newer and recommended, and required for Secure Boot. For backwards compatibility, *2m* is used if not otherwise specified. Ignored for VMs with arch=aarch64 (ARM).

file=<volume>
The drive's backing volume.

format=<cloop | qcow | qcow2 | qed | raw | vmdk>
The drive's backing file's data format.

ms-cert=<2011 | 2023 | 2023k | 2023w> (*default* = 2011)
Informational marker indicating the version of the latest Microsoft UEFI certificates that have been enrolled by Proxmox VE. The value *2023k* means that the *Microsoft UEFI CA 2023*, the *Windows UEFI CA 2023* and the *Microsoft Corporation KEK 2K CA 2023* certificates are included. The values *2023* and *2023w* are deprecated and for compatibility only.

pre-enrolled-keys=<boolean> (*default* = 0)
Use am EFI vars template with distribution-specific and Microsoft Standard keys enrolled, if used with *efitype=4m*. Note that this will enable Secure Boot by default, though it can still be turned off from within the VM.

size=<DiskSize>
Disk size. This is purely informational and has no effect.

freeze: <boolean>
Freeze CPU at startup (use *c* monitor command to start execution).

hookscript: <string>
Script that will be executed during various steps in the vms lifetime.

hostpci[n]: [[host=]<HOSTPCIID[;HOSTPCIID2...]>] [,device-id=<hex id>] [,driver=<vfio|keep>] [,legacy-igd=<1|0>] [,mapping=<mapping-id>] [,mdev=<string>] [,pcie=<1|0>] [,rombar=<1|0>] [,romfile=<string>] [,sub-device-id=<hex id>] [,sub-vendor-id=<hex id>] [,vendor-id=<hex id>] [,x-vga=<1|0>]

Map host PCI devices into guest.

Note
This option allows direct access to host hardware. So it is no longer possible to migrate such machines - use with special care.



Caution
Experimental! User reported problems with this option.

device-id=<hex id>
Override PCI device ID visible to guest

driver=<keep | vfio> (*default =* vfio)
If set to *keep* the device will neither be reset nor bound to the *vfio-pci* driver. Useful for devices that already have the correct driver loaded.

host=<HOSTPCIID[;HOSTPCIID2...]>
Host PCI device pass through. The PCI ID of a host's PCI device or a list of PCI virtual functions of the host. HOSTPCIID syntax is:

bus:dev.func (hexadecimal numbers)

You can use the *lspci* command to list existing PCI devices.

Either this or the *mapping* key must be set.

legacy-igd=<boolean> (*default =* 0)
Pass this device in legacy IGD mode, making it the primary and exclusive graphics device in the VM. Requires *pc-i440fx* machine type and VGA set to *none*.

mapping=<mapping-id>
The ID of a cluster wide mapping. Either this or the default-key *host* must be set.

mdev=<string>
The type of mediated device to use. An instance of this type will be created on startup of the VM and will be cleaned up when the VM stops.

pcie=<boolean> (*default =* 0)
Choose the PCI-express bus (needs the *q35* machine model).

rombar=<boolean> (*default =* 1)
Specify whether or not the device's ROM will be visible in the guest's memory map.

romfile=<string>
Custom pci device rom filename (must be located in /usr/share/kvm/).

sub-device-id=<hex id>
Override PCI subsystem device ID visible to guest

sub-vendor-id=<hex id>
Override PCI subsystem vendor ID visible to guest

vendor-id=<hex id>
Override PCI vendor ID visible to guest

x-vga=<boolean> (*default =* 0)
Enable vfio-vga device support.

hotplug: <string> (*default =* network,disk,usb)
Selectively enable hotplug features. This is a comma separated list of hotplug features: *network*, *disk*, *cpu*, *memory*, *usb* and *cloudinit*. Use *0* to disable hotplug completely. Using *1* as value is an alias for the default `network,disk,usb`. USB hotplugging is possible for guests with machine version >= 7.1 and ostype l26 or windows > 7.

hugepages: <1024 | 2 | any>
Enables hugepages memory.

Sets the size of hugepages in MiB. If the value is set to *any* then 1 GiB hugepages will be used if possible, otherwise the size will fall back to 2 MiB.

ide[n]: [file=]<volume> [,aio=<native|threads|io_uring>]
[,backup=<1|0>] [,bps=<bps>] [,bps_max_length=<seconds>]
[,bps_rd=<bps>] [,bps_rd_max_length=<seconds>] [,bps_wr=<bps>]
[,bps_wr_max_length=<seconds>] [,cache=<enum>]
[,detect_zeroes=<1|0>] [,discard=<ignore|on>] [,format=<enum>]
[,iops=<iops>] [,iops_max=<iops>] [,iops_max_length=<seconds>]
[,iops_rd=<iops>] [,iops_rd_max=<iops>]
[,iops_rd_max_length=<seconds>] [,iops_wr=<iops>]
[,iops_wr_max=<iops>] [,iops_wr_max_length=<seconds>]
[,mbps=<mbps>] [,mbps_max=<mbps>] [,mbps_rd=<mbps>]
[,mbps_rd_max=<mbps>] [,mbps_wr=<mbps>] [,mbps_wr_max=<mbps>]
[,media=<cdrom|disk>] [,model=<model>] [,replicate=<1|0>]
[,rerror=<ignore|report|stop>] [,serial=<serial>] [,shared=<1|0>]
[,size=<DiskSize>] [,snapshot=<1|0>] [,ssd=<1|0>] [,werror=<enum>]
[,wwn=<wwn>]
Use volume as IDE hard disk or CD-ROM (n is 0 to 3).

aio=<io_uring | native | threads>
AIO type to use.

backup=<boolean>
Whether the drive should be included when making backups.

bps=<bps>
Maximum r/w speed in bytes per second. Deprecated: Use *mbps* instead.

bps_max_length=<seconds>
Maximum length of I/O bursts in seconds.

bps_rd=<bps>
Maximum read speed in bytes per second. Deprecated: Use *mbps_rd* instead.

bps_rd_max_length=<seconds>
Maximum length of read I/O bursts in seconds.

bps_wr=<bps>
Maximum write speed in bytes per second. Deprecated: Use *mbps_wr* instead.

bps_wr_max_length=<seconds>
Maximum length of write I/O bursts in seconds.

cache=<directsync | none | unsafe | writeback | writethrough>
The drive's cache mode

detect_zeroes=<boolean>
Controls whether to detect and try to optimize writes of zeroes.

discard=<ignore | on>
Controls whether to pass discard/trim requests to the underlying storage.

file=<volume>
The drive's backing volume.

format=<cloop | qcow | qcow2 | qed | raw | vmdk>
The drive's backing file's data format.

iops=<iops>
Maximum r/w I/O in operations per second.

iops_max=<iops>
Maximum unthrottled r/w I/O pool in operations per second.

iops_max_length=<seconds>
Maximum length of I/O bursts in seconds.

iops_rd=<iops>
Maximum read I/O in operations per second.

iops_rd_max=<iops>
Maximum unthrottled read I/O pool in operations per second.

iops_rd_max_length=<seconds>
Maximum length of read I/O bursts in seconds.

iops_wr=<iops>
Maximum write I/O in operations per second.

iops_wr_max=<iops>
Maximum unthrottled write I/O pool in operations per second.

iops_wr_max_length=<seconds>
Maximum length of write I/O bursts in seconds.

mbps=<mbps>
Maximum r/w speed in megabytes per second.

mbps_max=<mbps>
Maximum unthrottled r/w pool in megabytes per second.

mbps_rd=<mbps>
Maximum read speed in megabytes per second.

mbps_rd_max=<mbps>
Maximum unthrottled read pool in megabytes per second.

mbps_wr=<mbps>
Maximum write speed in megabytes per second.

mbps_wr_max=<mbps>
Maximum unthrottled write pool in megabytes per second.

media=<cdrom | disk> (***default =*** **disk**)
The drive's media type.

model=<model>
The drive's reported model name, url-encoded, up to 40 bytes long.

replicate=<boolean> (***default =*** **1**)
Whether the drive should considered for replication jobs.

rerror=<ignore | report | stop>
Read error action.

serial=<serial>
The drive's reported serial number, url-encoded, up to 20 bytes long.

shared=<boolean> (***default =*** **0**)
Mark this locally-managed volume as available on all nodes.



Warning
This option does not share the volume automatically, it assumes it is shared already!

size=<DiskSize>
Disk size. This is purely informational and has no effect.

snapshot=<boolean>
Controls qemu's snapshot mode feature. If activated, changes made to the disk are temporary and will be discarded when the VM is shutdown.

ssd=<boolean>
Whether to expose this drive as an SSD, rather than a rotational hard disk.

werror=<enospc | ignore | report | stop>
Write error action.

wwn=<wwn>
The drive's worldwide name, encoded as 16 bytes hex string, prefixed by *0x*.

intel-tdx: [type=]<tdx-type> [,attestation=<1|0>] [,vsock-cid=<integer>] [,vsock-port=<integer>]
Trusted Domain Extension (TDX) features by Intel CPUs

attestation=<boolean> (*default =* 1)
Enable TDX attestation by including quote-generation-socket

type=<tdx-type>
Enable TDX

vsock-cid=<integer> (2 - N) (*default =* 2)
CID for vsock of Quote Generation Service

vsock-port=<integer> (0 - N) (*default =* 4050)
Port for vsock of Quote Generation Service

ipconfig[n]: [gw=<GatewayIPv4>] [,gw6=<GatewayIPv6>] [,ip=<IPv4Format/CIDR>] [,ip6=<IPv6Format/CIDR>]
cloud-init: Specify IP addresses and gateways for the corresponding interface.

IP addresses use CIDR notation, gateways are optional but need an IP of the same type specified.

The special string *dhcp* can be used for IP addresses to use DHCP, in which case no explicit gateway should be provided. For IPv6 the special string *auto* can be used to use stateless autoconfiguration. This requires cloud-init 19.4 or newer.

If cloud-init is enabled and neither an IPv4 nor an IPv6 address is specified, it defaults to using dhcp on IPv4.

gw=<GatewayIPv4>
Default gateway for IPv4 traffic.

Note
Requires option(s): `ip`

gw6=<GatewayIPv6>
Default gateway for IPv6 traffic.

Note
Requires option(s): `ip6`

ip=<IPv4Format/CIDR> (*default =* dhcp)
IPv4 address in CIDR format.

ip6=<IPv6Format/CIDR> (*default =* dhcp)
IPv6 address in CIDR format.

ivshmem: size=<integer> [,name=<string>]
Inter-VM shared memory. Useful for direct communication between VMs, or to the host.

name=<string>
The name of the file. Will be prefixed with *pve-shm-*. Default is the VMID. Will be deleted when the VM is stopped.

size=<integer> (1 - N)
The size of the file in MB.

keephugepages: <boolean> (*default =* 0)
Use together with hugepages. If enabled, hugepages will not not be deleted after VM shutdown and can be used for subsequent starts.

keyboard: <da | de | de-ch | en-gb | en-us | es | fi | fr | fr-be | fr-ca | fr-ch | hu | is | it | ja | lt | mk | nl | no | pl | pt | pt-br | sl | sv | tr>
Keyboard layout for VNC server. This option is generally not required and is often better handled from within the guest OS.

kvm: <boolean> (*default =* 1)
Enable/disable KVM hardware virtualization.

localtime: <boolean>
Set the real time clock (RTC) to local time. This is enabled by default if the `ostype` indicates a Microsoft Windows OS.

lock: <backup | clone | create | import | migrate | rollback | snapshot | snapshot-delete | suspended | suspending>
Lock/unlock the VM.

machine: [[type=]<machine type>] [,aw-bits=<number>] [,enable-s3=<1|0>] [,enable-s4=<1|0>] [,viommu=<intel|virtio>]
Specify the QEMU machine.

aw-bits=<number> (32 - 64)
Specifies the vIOMMU address space bit width.

Intel vIOMMU supports a bit width of either 39 or 48 bits and VirtIO vIOMMU supports any bit width between 32 and 64 bits.

enable-s3=<boolean>
Enables S3 power state. Defaults to false beginning with machine types 9.2+pve1, true before.

enable-s4=<boolean>
Enables S4 power state. Defaults to false beginning with machine types 9.2+pve1, true before.

type=<machine type>
Specifies the QEMU machine type.

viommu=<intel | virtio>
Enable and set guest vIOMMU variant (Intel vIOMMU needs q35 to be set as machine type).

memory: [current=]<integer>
Memory properties.

current=<integer> (16 - N) (*default =* 512)
Current amount of online RAM for the VM in MiB. This is the maximum available memory when you use the balloon device.

migrate_downtime: <number> (0 - N) (*default =* 0.1)
Set maximum tolerated downtime (in seconds) for migrations. Should the migration not be able to converge in the very end, because too much newly dirtied RAM needs to be transferred, the limit will be increased automatically step-by-step until migration can converge. Will be capped to 2000 seconds (maximum in QEMU).

migrate_speed: <integer> (0 - N) (*default =* 0)
Set maximum speed (in MB/s) for migrations. Value 0 is no limit.

name: <string>
Set a name for the VM. Only used on the configuration web interface.

nameserver: <string>
cloud-init: Sets DNS server IP address for a container. Create will automatically use the setting from the host if neither searchdomain nor nameserver are set.

net[n]: [model=]<enum> [,bridge=<bridge>] [,firewall=<1|0>]
[,host-tunnel=<1|0>] [,link_down=<1|0>]
[,macaddr=<XX:XX:XX:XX:XX:XX>] [,mtu=<integer>] [,queues=<integer>]
[,rate=<number>] [,tag=<integer>] [,trunks=<vlanid[;vlanid...]>]
[,<model>=<macaddr>]
Specify network devices.

bridge=<bridge>
Bridge to attach the network device to. The Proxmox VE standard bridge is called *vmbr0*.

If you do not specify a bridge, we create a kvm user (NATed) network device, which provides DHCP and DNS services. The following addresses are used:

```
10.0.2.2   Gateway
10.0.2.3   DNS Server
10.0.2.4   SMB Server
```

The DHCP server assign addresses to the guest starting from 10.0.2.15.

firewall=<boolean>
Whether this interface should be protected by the firewall.

host-tunnel=<boolean>
Enable host GSO over UDP tunnel offload (VirtIO only). Requires QEMU > 10.2 and guest and host kernel support. Disabled by default starting with machine version 11.0+pve1 to work around an issue with the virtio-net driver in guest kernels. With machine versions 10.2 and 11.0, this is enabled by default.

link_down=<boolean>
Whether this interface should be disconnected (like pulling the plug).

macaddr=<XX:XX:XX:XX:XX:XX>
A common MAC address with the I/G (Individual/Group) bit not set.

model=<e1000 | e1000-82540em | e1000-82544gc | e1000-82545em | e1000e | i82551 | i82557b | i82559er | ne2k_isa | ne2k_pci | pcnet | rtl8139 | virtio | vmxnet3>
Network Card Model. The *virtio* model provides the best performance with very low CPU overhead. If your guest does not support this driver, it is usually best to use *e1000*.

mtu=<integer> (1 - 65520)
Force MTU of network device (VirtIO only). Setting to *1* or empty will use the bridge MTU

queues=<integer> (0 - 64)
Number of packet queues to be used on the device.

rate=<number> (0 - N)
Rate limit in mbps (megabytes per second) as floating point number.

tag=<integer> (1 - 4094)
VLAN tag to apply to packets on this interface.

trunks=<vlanid[;vlanid...]>
VLAN trunks to pass through this interface.

numa: <boolean> (*default =* 0)
Enable/disable NUMA.

numa[n]: cpus=<id[-id];...> [,hostnodes=<id[-id];...>] [,memory=<number>] [,policy=<preferred|bind|interleave>]
NUMA topology.

cpus=<id[-id];...>
CPUs accessing this NUMA node.

hostnodes=<id[-id];...>
Host NUMA nodes to use.

memory=<number>
Amount of memory this NUMA node provides.

policy=<bind | interleave | preferred>
NUMA allocation policy. Possible values are:

- preferred: prefer the given host node list for allocation
- bind: restrict memory allocation to the given host node list
- interleave: interleave memory allocations across the given host node list
  The models are explained in more details in the kernel's documentation https://docs.kernel.org/-admin-guide/mm/numa_memory_policy.html#components-of-memory-policies.

onboot: <boolean> (*default* = 0)
Specifies whether a VM will be started during system bootup.

ostype: <l24 | l26 | other | solaris | w2k | w2k3 | w2k8 | win10 | win11 | win7 | win8 | wvista | wxp> (*default* = other)
Specify guest operating system. This is used to enable special optimization/features for specific operating systems:

other	unspecified OS
wxp	Microsoft Windows XP
w2k	Microsoft Windows 2000
w2k3	Microsoft Windows 2003
w2k8	Microsoft Windows 2008
wvista	Microsoft Windows Vista
win7	Microsoft Windows 7
win8	Microsoft Windows 8/2012/2012r2
win10	Microsoft Windows 10/2016/2019
win11	Microsoft Windows 11/2022/2025
l24	Linux 2.4 Kernel
l26	Linux 2.6 - 7.X Kernel
solaris	Solaris/OpenSolaris/OpenIndiania kernel

parallel[n]: /dev/parport\d+|/dev/usb/lp\d+
Map host parallel devices (n is 0 to 2).

Note
This option allows direct access to host hardware. So it is no longer possible to migrate such machines - use with special care.



Caution
Experimental! User reported problems with this option.

protection: <boolean> (*default* = 0)
Sets the protection flag of the VM. This will disable the remove VM and remove disk operations.

reboot: <boolean> (*default* = 1)
Allow reboot. If set to *0* the VM exit on reboot.

rng0: [source=]</dev/urandom|/dev/random|/dev/hwrng>
[,max_bytes=<integer>] [,period=<integer>]
Configure a VirtIO-based Random Number Generator.

max_bytes=<integer> (*default* = 1024)
Maximum bytes of entropy allowed to get injected into the guest every *period* milliseconds. Use 0 to disable limiting (potentially dangerous!).

period=<integer> (*default* = 1000)
Every *period* milliseconds the entropy-injection quota is reset, allowing the guest to retrieve another *max_bytes* of entropy.

source=</dev/hwrng | /dev/random | /dev/urandom>
The file on the host to gather entropy from. Using urandom does **not** decrease security in any meaningful way, as it's still seeded from real entropy, and the bytes provided will most likely be mixed with real entropy on the guest as well. */dev/hwrng* can be used to pass through a hardware RNG from the host.

sata[n]: [file=]<volume> [,aio=<native|threads|io_uring>]
[,backup=<1|0>] [,bps=<bps>] [,bps_max_length=<seconds>]
[,bps_rd=<bps>] [,bps_rd_max_length=<seconds>] [,bps_wr=<bps>]
[,bps_wr_max_length=<seconds>] [,cache=<enum>]
[,detect_zeroes=<1|0>] [,discard=<ignore|on>] [,format=<enum>]
[,iops=<iops>] [,iops_max=<iops>] [,iops_max_length=<seconds>]
[,iops_rd=<iops>] [,iops_rd_max=<iops>]
[,iops_rd_max_length=<seconds>] [,iops_wr=<iops>]
[,iops_wr_max=<iops>] [,iops_wr_max_length=<seconds>]
[,mbps=<mbps>] [,mbps_max=<mbps>] [,mbps_rd=<mbps>]
[,mbps_rd_max=<mbps>] [,mbps_wr=<mbps>] [,mbps_wr_max=<mbps>]
[,media=<cdrom|disk>] [,replicate=<1|0>]
[,rerror=<ignore|report|stop>] [,serial=<serial>] [,shared=<1|0>]
[,size=<DiskSize>] [,snapshot=<1|0>] [,ssd=<1|0>] [,werror=<enum>]
[,wwn=<wwn>]
Use volume as SATA hard disk or CD-ROM (n is 0 to 5).

aio=<io_uring | native | threads>
AIO type to use.

backup=<boolean>
Whether the drive should be included when making backups.

bps=<bps>
Maximum r/w speed in bytes per second. Deprecated: Use *mbps* instead.

bps_max_length=<seconds>
Maximum length of I/O bursts in seconds.

bps_rd=<bps>
Maximum read speed in bytes per second. Deprecated: Use *mbps_rd* instead.

bps_rd_max_length=<seconds>
Maximum length of read I/O bursts in seconds.

bps_wr=<bps>
Maximum write speed in bytes per second. Deprecated: Use *mbps_wr* instead.

bps_wr_max_length=<seconds>
Maximum length of write I/O bursts in seconds.

cache=<directsync | none | unsafe | writeback | writethrough>
The drive's cache mode

detect_zeroes=<boolean>
Controls whether to detect and try to optimize writes of zeroes.

discard=<ignore | on>
Controls whether to pass discard/trim requests to the underlying storage.

file=<volume>
The drive's backing volume.

format=<cloop | qcow | qcow2 | qed | raw | vmdk>
The drive's backing file's data format.

iops=<iops>
Maximum r/w I/O in operations per second.

iops_max=<iops>
Maximum unthrottled r/w I/O pool in operations per second.

iops_max_length=<seconds>
Maximum length of I/O bursts in seconds.

iops_rd=<iops>
Maximum read I/O in operations per second.

iops_rd_max=<iops>
Maximum unthrottled read I/O pool in operations per second.

iops_rd_max_length=<seconds>
Maximum length of read I/O bursts in seconds.

iops_wr=<iops>
Maximum write I/O in operations per second.

iops_wr_max=<iops>
Maximum unthrottled write I/O pool in operations per second.

iops_wr_max_length=<seconds>
Maximum length of write I/O bursts in seconds.

mbps=<mbps>
Maximum r/w speed in megabytes per second.

mbps_max=<mbps>
Maximum unthrottled r/w pool in megabytes per second.

mbps_rd=<mbps>
Maximum read speed in megabytes per second.

mbps_rd_max=<mbps>
Maximum unthrottled read pool in megabytes per second.

mbps_wr=<mbps>
Maximum write speed in megabytes per second.

mbps_wr_max=<mbps>
Maximum unthrottled write pool in megabytes per second.

media=<cdrom | disk> (*default =* disk)
The drive's media type.

replicate=<boolean> (*default =* 1)
Whether the drive should considered for replication jobs.

rerror=<ignore | report | stop>
Read error action.

serial=<serial>
The drive's reported serial number, url-encoded, up to 20 bytes long.

shared=<boolean> (*default =* 0)
Mark this locally-managed volume as available on all nodes.



Warning
This option does not share the volume automatically, it assumes it is shared already!

size=<DiskSize>
Disk size. This is purely informational and has no effect.

snapshot=<boolean>
Controls qemu's snapshot mode feature. If activated, changes made to the disk are temporary and will be discarded when the VM is shutdown.

ssd=<boolean>
Whether to expose this drive as an SSD, rather than a rotational hard disk.

werror=<enospc | ignore | report | stop>
Write error action.

wwn=<wwn>
The drive's worldwide name, encoded as 16 bytes hex string, prefixed by *0x*.

scsi[n]: [file=]<volume> [,aio=<native|threads|io_uring>]
[,backup=<1|0>] [,bps=<bps>] [,bps_max_length=<seconds>]
[,bps_rd=<bps>] [,bps_rd_max_length=<seconds>] [,bps_wr=<bps>]
[,bps_wr_max_length=<seconds>] [,cache=<enum>]
[,detect_zeroes=<1|0>] [,discard=<ignore|on>] [,format=<enum>]
[,iops=<iops>] [,iops_max=<iops>] [,iops_max_length=<seconds>]
[,iops_rd=<iops>] [,iops_rd_max=<iops>]
[,iops_rd_max_length=<seconds>] [,iops_wr=<iops>]
[,iops_wr_max=<iops>] [,iops_wr_max_length=<seconds>]
[,iothread=<1|0>] [,mbps=<mbps>] [,mbps_max=<mbps>]
[,mbps_rd=<mbps>] [,mbps_rd_max=<mbps>] [,mbps_wr=<mbps>]
[,mbps_wr_max=<mbps>] [,media=<cdrom|disk>] [,product=<product>]
[,queues=<integer>] [,replicate=<1|0>]
[,rerror=<ignore|report|stop>] [,ro=<1|0>] [,scsiblock=<1|0>]
[,serial=<serial>] [,shared=<1|0>] [,size=<DiskSize>]
[,snapshot=<1|0>] [,ssd=<1|0>] [,vendor=<vendor>] [,werror=<enum>]
[,wwn=<wwn>]
Use volume as SCSI hard disk or CD-ROM (n is 0 to 30).

aio=<io_uring | native | threads>
AIO type to use.

backup=<boolean>
Whether the drive should be included when making backups.

bps=<bps>
Maximum r/w speed in bytes per second. Deprecated: Use *mbps* instead.

bps_max_length=<seconds>
Maximum length of I/O bursts in seconds.

bps_rd=<bps>
Maximum read speed in bytes per second. Deprecated: Use *mbps_rd* instead.

bps_rd_max_length=<seconds>
Maximum length of read I/O bursts in seconds.

bps_wr=<bps>
Maximum write speed in bytes per second. Deprecated: Use *mbps_wr* instead.

bps_wr_max_length=<seconds>
Maximum length of write I/O bursts in seconds.

cache=<directsync | none | unsafe | writeback | writethrough>
The drive's cache mode

detect_zeroes=<boolean>
Controls whether to detect and try to optimize writes of zeroes.

discard=<ignore | on>
Controls whether to pass discard/trim requests to the underlying storage.

file=<volume>
The drive's backing volume.

format=<cloop | qcow | qcow2 | qed | raw | vmdk>
The drive's backing file's data format.

iops=<iops>
Maximum r/w I/O in operations per second.

iops_max=<iops>
Maximum unthrottled r/w I/O pool in operations per second.

iops_max_length=<seconds>
Maximum length of I/O bursts in seconds.

iops_rd=<iops>
Maximum read I/O in operations per second.

iops_rd_max=<iops>
Maximum unthrottled read I/O pool in operations per second.

iops_rd_max_length=<seconds>
Maximum length of read I/O bursts in seconds.

iops_wr=<iops>
Maximum write I/O in operations per second.

iops_wr_max=<iops>
Maximum unthrottled write I/O pool in operations per second.

iops_wr_max_length=<seconds>
Maximum length of write I/O bursts in seconds.

iothread=<boolean>
Whether to use iothreads for this drive

mbps=<mbps>
Maximum r/w speed in megabytes per second.

mbps_max=<mbps>
Maximum unthrottled r/w pool in megabytes per second.

mbps_rd=<mbps>
Maximum read speed in megabytes per second.

mbps_rd_max=<mbps>
Maximum unthrottled read pool in megabytes per second.

mbps_wr=<mbps>
Maximum write speed in megabytes per second.

mbps_wr_max=<mbps>
Maximum unthrottled write pool in megabytes per second.

media=<cdrom | disk> (*default =* disk)
The drive's media type.

product=<product>
The drive's product name, up to 16 bytes long.

queues=<integer> (2 - N)
Number of queues.

replicate=<boolean> (*default =* 1)
Whether the drive should considered for replication jobs.

rerror=<ignore | report | stop>
Read error action.

ro=<boolean>
Whether the drive is read-only.

scsiblock=<boolean> (*default =* 0)
whether to use scsi-block for full passthrough of host block device



Warning
can lead to I/O errors in combination with low memory or high memory fragmentation on host

serial=<serial>
The drive's reported serial number, url-encoded, up to 20 bytes long.

shared=<boolean> (*default =* 0)
Mark this locally-managed volume as available on all nodes.



Warning
This option does not share the volume automatically, it assumes it is shared already!

size=<DiskSize>
Disk size. This is purely informational and has no effect.

snapshot=<boolean>
Controls qemu's snapshot mode feature. If activated, changes made to the disk are temporary and will be discarded when the VM is shutdown.

ssd=<boolean>
Whether to expose this drive as an SSD, rather than a rotational hard disk.

vendor=<vendor>
The drive's vendor name, up to 8 bytes long.

werror=<enospc | ignore | report | stop>
Write error action.

wwn=<wwn>
The drive's worldwide name, encoded as 16 bytes hex string, prefixed by *0x*.

scsihw: <lsi | lsi53c810 | megasas | pvscsi | virtio-scsi-pci | virtio-scsi-single> (*default =* lsi)
SCSI controller model

searchdomain: <string>
cloud-init: Sets DNS search domains for a container. Create will automatically use the setting from the host if neither searchdomain nor nameserver are set.

serial[n]: (/dev/[^,]+|socket)
Create a serial device inside the VM (n is 0 to 3), and pass through a host serial device (i.e. /dev/ttyS0), or create a unix socket on the host side (use *qm terminal* to open a terminal connection).

Note
If you pass through a host serial device, it is no longer possible to migrate such machines - use with special care.



Caution
Experimental! User reported problems with this option.

shares: <integer> (0 - 50000) (*default =* 1000)
Amount of memory shares for auto-ballooning. The larger the number is, the more memory this VM gets. Number is relative to weights of all other running VMs. Using zero disables auto-ballooning. Auto-ballooning is done by pvestatd.

smbios1: [base64=<1|0>] [,family=<Base64 encoded string>] [,manufacturer=<Base64 encoded string>] [,product=<Base64 encoded string>] [,serial=<Base64 encoded string>] [,sku=<Base64 encoded string>] [,uuid=<UUID>] [,version=<Base64 encoded string>]
Specify SMBIOS type 1 fields.

base64=<boolean>
Flag to indicate that the SMBIOS values are base64 encoded

family=<Base64 encoded string>
Set SMBIOS1 family string.

manufacturer=<Base64 encoded string>
Set SMBIOS1 manufacturer.

product=<Base64 encoded string>
Set SMBIOS1 product ID.

serial=<Base64 encoded string>
Set SMBIOS1 serial number.

sku=<Base64 encoded string>
Set SMBIOS1 SKU string.

uuid=<UUID>
Set SMBIOS1 UUID.

version=<Base64 encoded string>
Set SMBIOS1 version.

smp: **<integer> (1 - N)** (***default =*** **1**)
The number of CPUs. Please use option -sockets instead.

sockets: **<integer> (1 - N)** (***default =*** **1**)
The number of CPU sockets.

spice_enhancements: **[foldersharing=<1|0>]**
[,videostreaming=<off|all|filter>]
Configure additional enhancements for SPICE.

foldersharing=<boolean> (***default =*** **0**)
Enable folder sharing via SPICE. Needs Spice-WebDAV daemon installed in the VM.

videostreaming=<all | filter | off> (***default =*** **off**)
Enable video streaming. Uses compression for detected video streams.

sshkeys: **<string>**
cloud-init: Setup public SSH keys (one key per line, OpenSSH format).

startdate: **(now | YYYY-MM-DD | YYYY-MM-DDTHH:MM:SS)** (***default =*** **now**)
Set the initial date of the real time clock. Valid format for date are:'now' or *2006-06-17T16:01:21* or *2006-06-17*.

startup: **`[[order=]\d+] [,up=\d+] [,down=\d+] `**
Startup and shutdown behavior. Order is a non-negative number defining the general startup order. Shutdown in done with reverse ordering. Additionally you can set the *up* or *down* delay in seconds, which specifies a delay to wait before the next VM is started or stopped.

tablet: <boolean> (*default =* 1)
Enable/disable the USB tablet device. This device is usually needed to allow absolute mouse positioning with VNC. Else the mouse runs out of sync with normal VNC clients. If you're running lots of console-only guests on one host, you may consider disabling this to save some context switches. This is turned off by default if you use spice (`qm set <vmid> --vga qxl`).

tags: <string>
Tags of the VM. This is only meta information.

tdf: <boolean> (*default =* 0)
Enable/disable time drift fix.

template: <boolean> (*default =* 0)
Enable/disable Template.

tpmstate0: [file=]<volume> [,format=<raw|qcow2|vmdk>] [,size=<DiskSize>] [,version=<v1.2|v2.0>]
Configure a Disk for storing TPM state. The format is fixed to *raw*.

file=<volume>
The drive's backing volume.

format=<qcow2 | raw | vmdk>
Format of the image.

size=<DiskSize>
Disk size. This is purely informational and has no effect.

version=<v1.2 | v2.0> (*default =* v1.2)
The TPM interface version. v2.0 is newer and should be preferred. Note that this cannot be changed later on.

unused[n]: [file=]<volume>
Reference to unused volumes. This is used internally, and should not be modified manually.

file=<volume>
The drive's backing volume.

usb[n]: [[host=]<HOSTUSBDEVICE|spice>] [,mapping=<mapping-id>] [,usb3=<1|0>]
Configure an USB device (n is 0 to 4, for machine version >= 7.1 and ostype l26 or windows > 7, n can be up to 14).

host=<HOSTUSBDEVICE|spice>
The Host USB device or port or the value *spice*. HOSTUSBDEVICE syntax is:

```
'bus-port(.port)*' (decimal numbers) or
'vendor_id:product_id' (hexadecimal numbers) or
'spice'
```

You can use the *lsusb -t* command to list existing usb devices.

Note
This option allows direct access to host hardware. So it is no longer possible to migrate such machines - use with special care.

The value *spice* can be used to add a usb redirection devices for spice.

Either this or the *mapping* key must be set.

mapping=<mapping-id>
The ID of a cluster wide mapping. Either this or the default-key *host* must be set.

usb3=<boolean> (*default =* 0)
Specifies whether if given host option is a USB3 device or port. For modern guests (machine version >= 7.1 and ostype l26 and windows > 7), this flag is irrelevant (all devices are plugged into a xhci controller).

vcpus: <integer> (1 - N) (*default =* 0)
Number of hotplugged vcpus.

vga: [[type=]<enum>] [,clipboard=<vnc>] [,memory=<integer>]
Configure the VGA Hardware. If you want to use high resolution modes (>= 1280x1024x16) you may need to increase the vga memory option. Since QEMU 2.9 the default VGA display type is *std* for all OS types besides some Windows versions (XP and older) which use *cirrus*. The *qxl* option enables the SPICE display server. For win* OS you can select how many independent displays you want, Linux guests can add displays them self. You can also run without any graphic card, using a serial device as terminal.

clipboard=<vnc>
Enable a specific clipboard. If not set, depending on the display type the SPICE one will be added. Live migration with a VNC clipboard is not possible with QEMU machine version < 10.1.

memory=<integer> (4 - 512)
Sets the VGA memory (in MiB). Has no effect with serial display.

type=<cirrus | none | qxl | qxl2 | qxl3 | qxl4 | serial0 | serial1 | serial2 | serial3 | std | virtio | virtio-gl | vmware> (*default =* std)
Select the VGA type. Using type *cirrus* is not recommended.

virtio[n]: [file=]<volume> [,aio=<native|threads|io_uring>]
[,backup=<1|0>] [,bps=<bps>] [,bps_max_length=<seconds>]
[,bps_rd=<bps>] [,bps_rd_max_length=<seconds>] [,bps_wr=<bps>]
[,bps_wr_max_length=<seconds>] [,cache=<enum>]
[,detect_zeroes=<1|0>] [,discard=<ignore|on>] [,format=<enum>]
[,iops=<iops>] [,iops_max=<iops>] [,iops_max_length=<seconds>]
[,iops_rd=<iops>] [,iops_rd_max=<iops>]
[,iops_rd_max_length=<seconds>] [,iops_wr=<iops>]
[,iops_wr_max=<iops>] [,iops_wr_max_length=<seconds>]
[,iothread=<1|0>] [,mbps=<mbps>] [,mbps_max=<mbps>]
[,mbps_rd=<mbps>] [,mbps_rd_max=<mbps>] [,mbps_wr=<mbps>]
[,mbps_wr_max=<mbps>] [,media=<cdrom|disk>] [,replicate=<1|0>]
[,rerror=<ignore|report|stop>] [,ro=<1|0>] [,serial=<serial>]
[,shared=<1|0>] [,size=<DiskSize>] [,snapshot=<1|0>]
[,werror=<enum>]

Use volume as VIRTIO hard disk (n is 0 to 15).

aio=<io_uring | native | threads>
AIO type to use.

backup=<boolean>
Whether the drive should be included when making backups.

bps=<bps>
Maximum r/w speed in bytes per second. Deprecated: Use *mbps* instead.

bps_max_length=<seconds>
Maximum length of I/O bursts in seconds.

bps_rd=<bps>
Maximum read speed in bytes per second. Deprecated: Use *mbps_rd* instead.

bps_rd_max_length=<seconds>
Maximum length of read I/O bursts in seconds.

bps_wr=<bps>
Maximum write speed in bytes per second. Deprecated: Use *mbps_wr* instead.

bps_wr_max_length=<seconds>
Maximum length of write I/O bursts in seconds.

cache=<directsync | none | unsafe | writeback | writethrough>
The drive's cache mode

detect_zeroes=<boolean>
Controls whether to detect and try to optimize writes of zeroes.

discard=<ignore | on>
Controls whether to pass discard/trim requests to the underlying storage.

file=<volume>
The drive's backing volume.

format=<cloop | qcow | qcow2 | qed | raw | vmdk>
The drive's backing file's data format.

iops=<iops>
Maximum r/w I/O in operations per second.

iops_max=<iops>
Maximum unthrottled r/w I/O pool in operations per second.

iops_max_length=<seconds>
Maximum length of I/O bursts in seconds.

iops_rd=<iops>
Maximum read I/O in operations per second.

iops_rd_max=<iops>
Maximum unthrottled read I/O pool in operations per second.

iops_rd_max_length=<seconds>
Maximum length of read I/O bursts in seconds.

iops_wr=<iops>
Maximum write I/O in operations per second.

iops_wr_max=<iops>
Maximum unthrottled write I/O pool in operations per second.

iops_wr_max_length=<seconds>
Maximum length of write I/O bursts in seconds.

iothread=<boolean>
Whether to use iothreads for this drive

mbps=<mbps>
Maximum r/w speed in megabytes per second.

mbps_max=<mbps>
Maximum unthrottled r/w pool in megabytes per second.

mbps_rd=<mbps>
Maximum read speed in megabytes per second.

mbps_rd_max=<mbps>
Maximum unthrottled read pool in megabytes per second.

mbps_wr=<mbps>
Maximum write speed in megabytes per second.

mbps_wr_max=<mbps>
Maximum unthrottled write pool in megabytes per second.

media=<cdrom | disk> (*default =* **disk**)
The drive's media type.

replicate=<boolean> (*default =* **1**)
Whether the drive should considered for replication jobs.

rerror=<ignore | report | stop>
Read error action.

ro=<boolean>
Whether the drive is read-only.

serial=<serial>
The drive's reported serial number, url-encoded, up to 20 bytes long.

shared=<boolean> (*default =* **0**)
Mark this locally-managed volume as available on all nodes.



Warning
This option does not share the volume automatically, it assumes it is shared already!

size=<DiskSize>
Disk size. This is purely informational and has no effect.

snapshot=<boolean>
Controls qemu's snapshot mode feature. If activated, changes made to the disk are temporary and will be discarded when the VM is shutdown.

werror=<enospc | ignore | report | stop>
Write error action.

virtiofs[n]: [dirid=]<mapping-id> [,cache=<enum>] [,direct-io=<1|0>] [,expose-acl=<1|0>] [,expose-xattr=<1|0>]
Configuration for sharing a directory between host and guest using Virtio-fs.

cache=<always | auto | metadata | never> (*default =* **auto**)
The caching policy the file system should use (auto, always, metadata, never).

direct-io=<boolean> (*default =* **0**)
Honor the O_DIRECT flag passed down by guest applications.

dirid=<mapping-id>
Mapping identifier of the directory mapping to be shared with the guest. Also used as a mount tag inside the VM.

expose-acl=<boolean> (*default =* **0**)
Enable support for POSIX ACLs (enabled ACL implies xattr) for this mount.

expose-xattr=<boolean> (*default =* 0)
Enable support for extended attributes for this mount.

vmgenid: <UUID> (*default =* 1 (autogenerated))
The VM generation ID (vmgenid) device exposes a 128-bit integer value identifier to the guest OS. This allows to notify the guest operating system when the virtual machine is executed with a different configuration (e.g. snapshot execution or creation from a template). The guest operating system notices the change, and is then able to react as appropriate by marking its copies of distributed databases as dirty, re-initializing its random number generator, etc. Note that auto-creation only works when done through API/CLI create or update methods, but not when manually editing the config file.

vmstatestorage: <storage ID>
Default storage for VM state volumes/files.

watchdog: [[model=]<i6300esb>] [,action=<enum>]
Create a virtual hardware watchdog device. Once enabled (by a guest action), the watchdog must be periodically polled by an agent inside the guest or else the watchdog will reset the guest (or execute the respective action specified)

action=<debug | none | pause | poweroff | reset | shutdown>
The action to perform if after activation the guest fails to poll the watchdog in time.

model=<i6300esb> (*default =* i6300esb)
Watchdog type to emulate.

10.15 Locks

Online migrations, snapshots and backups (vzdump) set a lock to prevent incompatible concurrent actions on the affected VMs. Sometimes you need to remove such a lock manually (for example after a power failure).

```
# qm unlock <vmid>
```



Caution
Only do that if you are sure the action which set the lock is no longer running.

Chapter 11

Proxmox Container Toolkit

Containers are a lightweight alternative to fully virtualized machines (VMs). They use the kernel of the host system that they run on, instead of emulating a full operating system (OS). This means that containers can access resources on the host system directly.

The runtime costs for containers is low, usually negligible. However, there are some drawbacks that need be considered:

- Only Linux distributions can be run in Proxmox Containers. It is not possible to run other operating systems like, for example, FreeBSD or Microsoft Windows inside a container.
- For security reasons, access to host resources needs to be restricted. Therefore, containers run in their own separate namespaces. Additionally some syscalls (user space requests to the Linux kernel) are not allowed within containers.

Proxmox VE uses Linux Containers (LXC) as its underlying container technology. The “Proxmox Container Toolkit” (`pct`) simplifies the usage and management of LXC, by providing an interface that abstracts complex tasks.

Containers are tightly integrated with Proxmox VE. This means that they are aware of the cluster setup, and they can use the same network and storage resources as virtual machines. You can also use the Proxmox VE firewall, or manage containers using the HA framework.

Our primary goal has traditionally been to offer an environment that provides the benefits of using a VM, but without the additional overhead. This means that Proxmox Containers have been primarily categorized as “System Containers”.

With the introduction of OCI (**O**pen **C**ontainer **I**nitiative) image support, Proxmox VE now also integrates “Application Containers” as a technology preview. When creating a container from an OCI image, the image is automatically converted to the LXC stack that Proxmox VE uses.

This approach allows users to benefit from a wide ecosystem of pre-packaged applications while retaining the robust management features of Proxmox VE.

While running lightweight “Application Containers” directly offers significant advantages over a full VM, for use cases demanding maximum isolation and the ability to live-migrate, nesting containers inside a Proxmox QEMU VM remains a recommended practice.

11.1 Technology Overview

- LXC (https://linuxcontainers.org/)
- Integrated into Proxmox VE graphical web user interface (GUI)
- Easy to use command-line tool `pct`
- Access via Proxmox VE REST API
- *lxcfs* to provide containerized /proc file system
- Control groups (*cgroups*) for resource isolation and limitation
- *AppArmor* and *seccomp* to improve security
- Modern Linux kernels
- Image based deployment (templates)
- Uses Proxmox VE storage library
- Container setup from host (network, DNS, storage, etc.)

11.2 Supported Distributions

List of officially supported distributions can be found below.

Templates for the following distributions are available through our repositories. You can use pveam tool or the Graphical User Interface to download them.

11.2.1 Alpine Linux

> Alpine Linux is a security-oriented, lightweight Linux distribution based on musl libc and busybox.
>
> — https://alpinelinux.org

For currently supported releases see:

https://alpinelinux.org/releases/

11.2.2 Arch Linux

> Arch Linux, a lightweight and flexible Linux® distribution that tries to Keep It Simple.
>
> — https://archlinux.org/

Arch Linux is using a rolling-release model, see its wiki for more details:

https://wiki.archlinux.org/title/Arch_Linux

11.2.3 CentOS, Almalinux, Rocky Linux

CentOS / CentOS Stream

> The CentOS Linux distribution is a stable, predictable, manageable and reproducible platform derived from the sources of Red Hat Enterprise Linux (RHEL)
>
> — https://centos.org

For currently supported releases see:

https://en.wikipedia.org/wiki/CentOS#End-of-support_schedule

Almalinux

> An Open Source, community owned and governed, forever-free enterprise Linux distribution, focused on long-term stability, providing a robust production-grade platform. AlmaLinux OS is 1:1 binary compatible with RHEL® and pre-Stream CentOS.
>
> — https://almalinux.org

For currently supported releases see:

https://en.wikipedia.org/wiki/AlmaLinux#Releases

Rocky Linux

> Rocky Linux is a community enterprise operating system designed to be 100% bug-for-bug compatible with America's top enterprise Linux distribution now that its downstream partner has shifted direction.
>
> — https://rockylinux.org

For currently supported releases see:

https://en.wikipedia.org/wiki/Rocky_Linux#Releases

11.2.4 Debian

> Debian is a free operating system, developed and maintained by the Debian project. A free Linux distribution with thousands of applications to meet our users' needs.
>
> — https://www.debian.org/intro/index#software

For currently supported releases see:

https://www.debian.org/releases/stable/releasenotes

11.2.5 Devuan

> Devuan GNU+Linux is a fork of Debian without systemd that allows users to reclaim control over their system by avoiding unnecessary entanglements and ensuring Init Freedom.
>
> — https://www.devuan.org

For currently supported releases see:

https://www.devuan.org/os/releases

11.2.6 Fedora

> Fedora creates an innovative, free, and open source platform for hardware, clouds, and containers that enables software developers and community members to build tailored solutions for their users.
>
> — https://getfedora.org

For currently supported releases see:

https://fedoraproject.org/wiki/Releases

11.2.7 Gentoo

> a highly flexible, source-based Linux distribution.
>
> — https://www.gentoo.org

Gentoo is using a rolling-release model.

11.2.8 OpenSUSE

> The makers' choice for sysadmins, developers and desktop users.
>
> — https://www.opensuse.org

For currently supported releases see:

https://get.opensuse.org/leap/

11.2.9 Ubuntu

> Ubuntu is the modern, open source operating system on Linux for the enterprise server, desktop, cloud, and IoT.
>
> — https://ubuntu.com/

For currently supported releases see:

https://wiki.ubuntu.com/Releases

11.3 Container Images

Container images, sometimes also referred to as “templates” or “appliances”, are `tar` archives which contain everything to run a container. Proxmox VE can utilize two main types of images: **System Container Templates** for creating full virtual environments, and **Application Container Images** based on the OCI standard for running specific applications.

11.3.1 System Container Templates

Proxmox VE itself provides a variety of basic templates for the most common Linux distributions. They can be downloaded using the GUI or the `pveam` (short for Proxmox VE Appliance Manager) command-line utility. Additionally, TurnKey Linux container templates are also available to download.

The list of available templates is updated daily through the *pve-daily-update* timer. You can also trigger an update manually by executing:

```
# pveam update
```

To view the list of available images run:

```
# pveam available
```

You can restrict this large list by specifying the `section` you are interested in, for example basic `system` images:

List available system images

```
# pveam available --section system
system          alpine-3.12-default_20200823_amd64.tar.xz
system          alpine-3.13-default_20210419_amd64.tar.xz
system          alpine-3.14-default_20210623_amd64.tar.xz
system          archlinux-base_20210420-1_amd64.tar.gz
system          centos-7-default_20190926_amd64.tar.xz
system          centos-8-default_20201210_amd64.tar.xz
system          debian-9.0-standard_9.7-1_amd64.tar.gz
system          debian-10-standard_10.7-1_amd64.tar.gz
system          devuan-3.0-standard_3.0_amd64.tar.gz
system          fedora-33-default_20201115_amd64.tar.xz
system          fedora-34-default_20210427_amd64.tar.xz
system          gentoo-current-default_20200310_amd64.tar.xz
system          opensuse-15.2-default_20200824_amd64.tar.xz
system          ubuntu-16.04-standard_16.04.5-1_amd64.tar.gz
system          ubuntu-18.04-standard_18.04.1-1_amd64.tar.gz
system          ubuntu-20.04-standard_20.04-1_amd64.tar.gz
system          ubuntu-20.10-standard_20.10-1_amd64.tar.gz
system          ubuntu-21.04-standard_21.04-1_amd64.tar.gz
```

Before you can use such a template, you need to download them into one of your storages. If you’re unsure to which one, you can simply use the `local` named storage for that purpose. For clustered installations, it is preferred to use a shared storage so that all nodes can access those images.

```
# pveam download local debian-10.0-standard_10.0-1_amd64.tar.gz
```

You are now ready to create containers using that image, and you can list all downloaded images on storage `local` with:

```
# pveam list local
local:vztmpl/debian-10.0-standard_10.0-1_amd64.tar.gz  219.95MB
```

Tip
You can also use the Proxmox VE web interface GUI to download, list and delete container templates.

`pct` uses them to create a new container, for example:

```
# pct create 999 local:vztmpl/debian-10.0-standard_10.0-1_amd64.tar.gz
```

The above command shows you the full Proxmox VE volume identifiers. They include the storage name, and most other Proxmox VE commands can use them. For example you can delete that image later with:

```
# pveam remove local:vztmpl/debian-10.0-standard_10.0-1_amd64.tar.gz
```

11.3.2 Open Container Initiative (OCI) Images

Proxmox VE can also use OCI images to create containers, both system containers but also application containers. Note that running application containers in Proxmox VE is currently considered a technology preview.

A container created from an OCI image still uses the existing LXC framework.

11.3.3 Obtaining OCI Images

In the web interface an OCI image can be uploaded manually or pulled from a registry using the **Pull from OCI registry** button on the container template view of a storage.

Once the template is on a storage, you can create the container with `pct create` or use the wizard in the web interface.

11.4 Container Settings

11.4.1 General Settings



General settings of a container include

- the **Node** : the physical server on which the container will run
- the **CT ID**: a unique number in this Proxmox VE installation used to identify your container
- **Hostname**: the hostname of the container
- **Resource Pool**: a logical group of containers and VMs
- **Password**: the root password of the container
- **SSH Public Key**: a public key for connecting to the root account over SSH
- **Unprivileged container**: this option allows to choose at creation time if you want to create a privileged or unprivileged container.
- **Nesting**: expose procfs and sysfs to allow nested containers. Note that systemd also uses this to isolate services.

Unprivileged Containers

Unprivileged containers use a new kernel feature called user namespaces. The root UID 0 inside the container is mapped to an unprivileged user outside the container. This means that most security issues (container escape, resource abuse, etc.) in these containers will affect a random unprivileged user, and would be a generic kernel security bug rather than an LXC issue. The LXC team thinks unprivileged containers are safe by design.

This is the default option when creating a new container.

Note
If the container uses systemd as an init system, please be aware the systemd version running inside the container should be equal to or greater than 220.

Privileged Containers

Security in containers is achieved by using mandatory access control *AppArmor* restrictions, *seccomp* filters and Linux kernel namespaces. The LXC team considers this kind of container as unsafe, and they will not consider new container escape exploits to be security issues worthy of a CVE and quick fix. That's why privileged containers should only be used in trusted environments.

11.4.2 CPU



You can restrict the number of visible CPUs inside the container using the `cores` option. This is implemented using the Linux *cpuset* cgroup (**c**ontrol **group**). A special task inside `pvestatd` tries to distribute running containers among available CPUs periodically. To view the assigned CPUs run the following command:

```
# pct cpusets
 --------------------
 102:               6 7
 105:       2 3 4 5
 108:  0 1
 --------------------
```

Containers use the host kernel directly. All tasks inside a container are handled by the host CPU scheduler. Proxmox VE uses the Linux *CFS* (**C**ompletely **F**air **S**cheduler) scheduler by default, which has additional bandwidth control options.

`cpulimit`: You can use this option to further limit assigned CPU time. Please note that this is a floating point number, so it is perfectly valid to assign two cores to a container, but restrict overall CPU consumption to half a core.

```
cores: 2
cpulimit: 0.5
```

`cpuunits`: This is a relative weight passed to the kernel scheduler. The larger the number is, the more CPU time this container gets. Number is relative to the weights of all the other running containers. The default is `100` (or `1024` if the host uses legacy cgroup v1). You can use this setting to prioritize some containers.

11.4.3 Memory



Container memory is controlled using the cgroup memory controller.

`memory`: Limit overall memory usage. This corresponds to the `memory.limit_in_bytes` cgroup setting.

`swap`: Allows the container to use additional swap memory from the host swap space. This corresponds to the `memory.memsw.limit_in_bytes` cgroup setting, which is set to the sum of both value (`memory + swap`).

11.4.4 Mount Points



The root mount point is configured with the `rootfs` property. You can configure up to 256 additional mount points. The corresponding options are called `mp0` to `mp255`. They can contain the following settings:

rootfs: [volume=]<volume> [,acl=<1|0>]
[,idmap=<type:container:disk:range-size[;type:container:disk:range-size;...
[,mountoptions=<opt[;opt...]>] [,quota=<1|0>] [,replicate=<1|0>]
[,ro=<1|0>] [,shared=<1|0>] [,size=<DiskSize>]

Use volume as container root. See below for a detailed description of all options.

mp[n]: [volume=]<volume> ,mp=<Path> [,acl=<1|0>] [,backup=<1|0>]
[,idmap=<type:container:disk:range-size[;type:container:disk:range-size;...
[,keepattrs=<1|0>] [,mountoptions=<opt[;opt...]>] [,quota=<1|0>]
[,replicate=<1|0>] [,ro=<1|0>] [,shared=<1|0>] [,size=<DiskSize>]

Use volume as container mount point. Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume.

acl=<boolean>
Explicitly enable or disable ACL support.

backup=<boolean>
Whether to include the mount point in backups (only used for volume mount points).

idmap=<type:container:disk:range-size[;type:container:disk:range-size;.

Customize UID/GID mappings that override the container's `lxc.idmap` for this mount point. Accepts a semicolon-separated list of `type:container:disk:range-size` entries.

`type` is `u` for UID or `g` for GID.

`container` is the first ID as seen inside the container.

`disk` is the first corresponding ID on the underlying filesystem.

`range-size` is the number of consecutive IDs to map.

Unmapped IDs fall back to the container's `lxc.idmap`.

Example 1: `u:123:456:1` maps UID 123 in the container to UID 456 on the disk. Files owned by UID 456 on the disk will appear as UID 123 inside the container.

Example 2: `g:100:50:5` maps 5 consecutive GIDs, such that GIDs 100-104 in the container are mapped to GIDs 50-54 on the disk.

Example 3: `passthrough` identity-maps all UIDs and GIDs, meaning IDs inside the container will match the IDs on the disk.

keepattrs=<boolean> (*default =* 0)
Inherit UID, GID and access mode from the mount point directory, if it exists already.

mountoptions=<opt[;opt...]>
Extra mount options for rootfs/mps.

mp=<Path>
Path to the mount point as seen from inside the container.

> **Note**
> Must not contain any symlinks for security reasons.

quota=<boolean>
Enable user quotas inside the container (not supported with zfs subvolumes)

replicate=<boolean> (*default =* 1)
Will include this volume to a storage replica job.

ro=<boolean>
Read-only mount point

shared=<boolean> (*default =* 0)
Mark this non-volume mount point as available on all nodes.

> 
> **Warning**
> This option does not share the mount point automatically, it assumes it is shared already!

size=<DiskSize>
Volume size (read only value).

volume=<volume>
Volume, device or directory to mount into the container.

Currently there are three types of mount points: storage backed mount points, bind mounts, and device mounts.

Typical container rootfs configuration

```
rootfs: thin1:base-100-disk-1,size=8G
```

Storage Backed Mount Points

Storage backed mount points are managed by the Proxmox VE storage subsystem and come in three different flavors:

- Image based: these are raw images containing a single ext4 formatted file system.
- ZFS subvolumes: these are technically bind mounts, but with managed storage, and thus allow resizing and snapshotting.
- Directories: passing `size=0` triggers a special case where instead of a raw image a directory is created.

Note
The special option syntax `STORAGE_ID:SIZE_IN_GB` for storage backed mount point volumes will automatically allocate a volume of the specified size on the specified storage. For example, calling

```
pct set 100 -mp0 thin1:10,mp=/path/in/container
```

will allocate a 10GB volume on the storage `thin1` and replace the volume ID place holder `10` with the allocated volume ID, and setup the moutpoint in the container at `/path/in/container`

Bind Mount Points

Bind mounts allow you to access arbitrary directories from your Proxmox VE host inside a container. Some potential use cases are:

- Accessing your home directory in the guest
- Accessing an USB device directory in the guest
- Accessing an NFS mount from the host in the guest

Bind mounts are considered to not be managed by the storage subsystem, so you cannot make snapshots or deal with quotas from inside the container. With unprivileged containers you might run into permission problems caused by the user mapping and cannot use ACLs.

Note
The contents of bind mount points are not backed up when using `vzdump`.



Warning
For security reasons, bind mounts should only be established using source directories especially reserved for this purpose, e.g., a directory hierarchy under `/mnt/bindmounts`. Never bind mount system directories like `/`, `/var` or `/etc` into a container - this poses a great security risk.

Note
The bind mount source path must not contain any symlinks.

For example, to make the directory `/mnt/bindmounts/shared` accessible in the container with ID `100` under the path `/shared`, add a configuration line such as:

```
mp0: /mnt/bindmounts/shared,mp=/shared
```

into `/etc/pve/lxc/100.conf`.

Or alternatively use the `pct` tool:

```
pct set 100 -mp0 /mnt/bindmounts/shared,mp=/shared
```

to achieve the same result.

Device Mount Points

Device mount points allow to mount block devices of the host directly into the container. Similar to bind mounts, device mounts are not managed by Proxmox VE's storage subsystem, but the `quota` and `acl` options will be honored.

Note
Device mount points should only be used under special circumstances. In most cases a storage backed mount point offers the same performance and a lot more features.

Note
The contents of device mount points are not backed up when using `vzdump`.

11.4.5 Network



You can configure up to 32 network interfaces for a single container. The corresponding options are called `net0` to `net31`, and they can contain the following settings:

net[n]: name=<string> [,bridge=<bridge>] [,firewall=<1|0>]
[,gw=<GatewayIPv4>] [,gw6=<GatewayIPv6>] [,host-managed=<1|0>]
[,hwaddr=<XX:XX:XX:XX:XX:XX>] [,ip=<(IPv4/CIDR|dhcp|manual)>]
[,ip6=<(IPv6/CIDR|auto|dhcp|manual)>] [,link_down=<1|0>]
[,mtu=<integer>] [,rate=<mbps>] [,tag=<integer>]
[,trunks=<vlanid[;vlanid...]>] [,type=<veth>]

Specifies network interfaces for the container.

bridge=<bridge>
Bridge to attach the network device to.

firewall=<boolean>
Controls whether this interface's firewall rules should be used.

gw=<GatewayIPv4>
Default gateway for IPv4 traffic.

gw6=<GatewayIPv6>
Default gateway for IPv6 traffic.

host-managed=<boolean>
Whether this interface's IP configuration should be managed by the host. When enabled, the host (rather than the container) is responsible for the interface's IP configuration. The container should not run its own DHCP client or network manager on this interface. This is useful for containers that lack an internal network management stack, like many application containers.

hwaddr=<XX:XX:XX:XX:XX:XX>
A common MAC address with the I/G (Individual/Group) bit not set.

ip=<(IPv4/CIDR|dhcp|manual)>
IPv4 address in CIDR format.

ip6=<(IPv6/CIDR|auto|dhcp|manual)>
IPv6 address in CIDR format.

link_down=<boolean>
Whether this interface should be disconnected (like pulling the plug).

mtu=<integer> (64 - 65535)
Maximum transfer unit of the interface. (lxc.network.mtu)

name=<string>
Name of the network device as seen from inside the container. (lxc.network.name)

rate=<mbps>
Apply rate limiting to the interface

tag=<integer> (1 - 4094)
VLAN tag for this interface.

trunks=<vlanid[;vlanid...]>
VLAN ids to pass through the interface

type=<veth>
Network interface type.

11.4.6 Automatic Start and Shutdown of Containers

To automatically start a container when the host system boots, select the option *Start at boot* in the *Options* panel of the container in the web interface or run the following command:

```
# pct set CTID -onboot 1
```

Start and Shutdown Order



If you want to fine tune the boot order of your containers, you can use the following parameters:

- **Start/Shutdown order**: Defines the start order priority. For example, set it to 1 if you want the CT to be the first to be started. (We use the reverse startup order for shutdown, so a container with a start order of 1 would be the last to be shut down)
- **Startup delay**: Defines the interval between this container start and subsequent containers starts. For example, set it to 240 if you want to wait 240 seconds before starting other containers.
- **Shutdown timeout**: Defines the duration in seconds Proxmox VE should wait for the container to be offline after issuing a shutdown command. By default this value is set to 60, which means that Proxmox VE will issue a shutdown request, wait 60s for the machine to be offline, and if after 60s the machine is still online will notify that the shutdown action failed.

Please note that containers without a Start/Shutdown order parameter will always start after those where the parameter is set, and this parameter only makes sense between the machines running locally on a host, and not cluster-wide.

If you require a delay between the host boot and the booting of the first container, see the section on Proxmox VE Node Management.

11.4.7 Hookscripts

You can add a hook script to CTs with the config property `hookscript`.

```
# pct set 100 -hookscript local:snippets/hookscript.pl
```

It will be called during various phases of the guests lifetime. For an example and documentation see the example script under `/usr/share/pve-docs/examples/guest-example-hookscript.pl`.

11.5 Security Considerations

Containers use the kernel of the host system. This exposes an attack surface for malicious users. In general, full virtual machines provide better isolation. This should be considered if containers are provided to unknown or untrusted people.

To reduce the attack surface, LXC uses many security features like AppArmor, CGroups and kernel namespaces.

11.5.1 AppArmor

AppArmor profiles are used to restrict access to possibly dangerous actions. Some system calls, i.e. `mount`, are prohibited from execution.

To trace AppArmor activity, use:

```
# dmesg | grep apparmor
```

Although it is not recommended, AppArmor can be disabled for a container. This brings security risks with it. Some syscalls can lead to privilege escalation when executed within a container if the system is misconfigured or if a LXC or Linux Kernel vulnerability exists.

To disable AppArmor for a container, add the following line to the container configuration file located at `/etc/pve/lxc/CTID.conf`:

```
lxc.apparmor.profile = unconfined
```



Warning
Please note that this is not recommended for production use.

11.5.2 Control Groups (*cgroup*)

cgroup is a kernel mechanism used to hierarchically organize processes and distribute system resources.

The main resources controlled via *cgroups* are CPU time, memory and swap limits, and access to device nodes. *cgroups* are also used to "freeze" a container before taking snapshots.

The current version of *cgroups* is *cgroupv2*. The v1 version of the cgroup subsystem was deprecated with the release of Proxmox VE 7.0 and removed entirely with Proxmox VE 9.0. Before Proxmox VE 7.0, a "hybrid" mode was the default.

CGroup Version Compatibility

The main difference between pure *cgroupv2* and the old hybrid environments regarding Proxmox VE is that with *cgroupv2* memory and swap are now controlled independently. The memory and swap settings for containers can map directly to these values, whereas previously only the memory limit and the limit of the **sum** of memory and swap could be limited.

Another important difference is that the *devices* controller is configured in a completely different way. Because of this, file system quotas are currently not supported in a pure *cgroupv2* environment.

cgroupv2 support by the container's OS is needed to run in a pure *cgroupv2* environment. Containers running *systemd* version 231 or newer support *cgroupv2* [1], as do containers not using *systemd* as init system [2].

Note
CentOS 7 and Ubuntu 16.10 are two prominent Linux distributions releases, which have a *systemd* version that is too old to run in a *cgroupv2* environment, you can either

- Upgrade the whole distribution to a newer release. For the examples above, that could be Ubuntu 18.04 or 20.04, and CentOS 8 (or RHEL/CentOS derivatives like AlmaLinux or Rocky Linux). This has the benefit to get the newest bug and security fixes, often also new features, and moving the EOL date in the future.
- Upgrade the Containers systemd version. If the distribution provides a backports repository this can be an easy and quick stop-gap measurement.
- Move the container, or its services, to a Virtual Machine. Virtual Machines have a much less interaction with the host, that's why one can install decades old OS versions just fine there.

Changing CGroup Version

Before Proxmox VE 9.0, you could switch back to the previous version with the following kernel command-line parameter:

```
systemd.unified_cgroup_hierarchy=0
```

See this section on editing the kernel boot command line on where to add the parameter.

11.6 Guest Operating System Configuration

Proxmox VE tries to detect the Linux distribution in the container, and modifies some files. Here is a short list of things done at container startup:

set /etc/hostname
: to set the container name

[1] this includes all newest major versions of container templates shipped by Proxmox VE
[2] for example Alpine Linux

modify /etc/hosts
to allow lookup of the local hostname

network setup
pass the complete network setup to the container

configure DNS
pass information about DNS servers

adapt the init system
for example, fix the number of spawned getty processes

set the root password
when creating a new container

rewrite ssh_host_keys
so that each container has unique keys

randomize crontab
so that cron does not start at the same time on all containers

Changes made by Proxmox VE are enclosed by comment markers:

```
# --- BEGIN PVE ---
<data>
# --- END PVE ---
```

Those markers will be inserted at a reasonable location in the file. If such a section already exists, it will be updated in place and will not be moved.

Modification of a file can be prevented by adding a `.pve-ignore.` file for it. For instance, if the file `/etc/.pve-ignore.hosts` exists then the `/etc/hosts` file will not be touched. This can be a simple empty file created via:

```
# touch /etc/.pve-ignore.hosts
```

Most modifications are OS dependent, so they differ between different distributions and versions. You can completely disable modifications by manually setting the `ostype` to `unmanaged`.

OS type detection is done by testing for certain files inside the container. Proxmox VE first checks the `/etc/os-release` file [3]. If that file is not present, or it does not contain a clearly recognizable distribution identifier the following distribution specific release files are checked.

Ubuntu
inspect /etc/lsb-release (`DISTRIB_ID=Ubuntu`)

Debian
test /etc/debian_version

[3] /etc/os-release replaces the multitude of per-distribution release files https://manpages.debian.org/stable/systemd/os-release.5.en.html

Fedora
test /etc/fedora-release

RedHat or CentOS
test /etc/redhat-release

ArchLinux
test /etc/arch-release

Alpine
test /etc/alpine-release

Gentoo
test /etc/gentoo-release

Note
Container start fails if the configured `ostype` differs from the auto detected type.

11.7 Container Storage

The Proxmox VE LXC container storage model is more flexible than traditional container storage models. A container can have multiple mount points. This makes it possible to use the best suited storage for each application.

For example the root file system of the container can be on slow and cheap storage while the database can be on fast and distributed storage via a second mount point. See section Mount Points for further details.

Any storage type supported by the Proxmox VE storage library can be used. This means that containers can be stored on local (for example `lvm`, `zfs` or directory), shared external (like `iSCSI`, `NFS`) or even distributed storage systems like Ceph. Advanced storage features like snapshots or clones can be used if the underlying storage supports them. The `vzdump` backup tool can use snapshots to provide consistent container backups.

Furthermore, local devices or local directories can be mounted directly using *bind mounts*. This gives access to local resources inside a container with practically zero overhead. Bind mounts can be used as an easy way to share data between containers.

11.7.1 FUSE Mounts



Warning
Because of existing issues in the Linux kernel's freezer subsystem the usage of FUSE mounts inside a container is strongly advised against, as containers need to be frozen for suspend or snapshot mode backups.

If FUSE mounts cannot be replaced by other mounting mechanisms or storage technologies, it is possible to establish the FUSE mount on the Proxmox host and use a bind mount point to make it accessible inside the container.

11.7.2 Using Quotas Inside Containers

Quotas allow to set limits inside a container for the amount of disk space that each user can use.

Note
This currently requires the use of legacy *cgroups*.

Note
This only works on ext4 image based storage types and currently only works with privileged containers.

Activating the `quota` option causes the following mount options to be used for a mount point: `usrjquota=aquo`

This allows quotas to be used like on any other system. You can initialize the `/aquota.user` and `/aquota.group` files by running:

```
# quotacheck -cmug /
# quotaon /
```

Then edit the quotas using the `edquota` command. Refer to the documentation of the distribution running inside the container for details.

Note
You need to run the above commands for every mount point by passing the mount point's path instead of just `/`.

11.7.3 Using ACLs Inside Containers

The standard Posix **A**ccess **C**ontrol **L**ists are also available inside containers. ACLs allow you to set more detailed file ownership than the traditional user/group/others model.

11.7.4 Backup of Container mount points

To include a mount point in backups, enable the `backup` option for it in the container configuration. For an existing mount point `mp0`

```
mp0: guests:subvol-100-disk-1,mp=/root/files,size=8G
```

add `backup=1` to enable it.

```
mp0: guests:subvol-100-disk-1,mp=/root/files,size=8G,backup=1
```

Note
When creating a new mount point in the GUI, this option is enabled by default.

To disable backups for a mount point, add `backup=0` in the way described above, or uncheck the **Backup** checkbox on the GUI.

11.7.5 Replication of Containers mount points

By default, additional mount points are replicated when the Root Disk is replicated. If you want the Proxmox VE storage replication mechanism to skip a mount point, you can set the **Skip replication** option for that mount point. As of Proxmox VE 5.0, replication requires a storage of type `zfspool`. Adding a mount point to a different type of storage when the container has replication configured requires to have **Skip replication** enabled for that mount point.

11.8 Backup and Restore

11.8.1 Container Backup

It is possible to use the `vzdump` tool for container backup. Please refer to the `vzdump` manual page for details.

11.8.2 Restoring Container Backups

Restoring container backups made with `vzdump` is possible using the `pct restore` command. By default, `pct restore` will attempt to restore as much of the backed up container configuration as possible. It is possible to override the backed up configuration by manually setting container options on the command line (see the `pct` manual page for details).

Note
`pvesm extractconfig` can be used to view the backed up configuration contained in a vzdump archive.

A restore from standard input over an existing container with a guest identity always needs the `allow-identity` option, see Restore Over an Existing Guest.

There are two basic restore modes, only differing by their handling of mount points:

“Simple” Restore Mode

If neither the `rootfs` parameter nor any of the optional `mpX` parameters are explicitly set, the mount point configuration from the backed up configuration file is restored using the following steps:

1. Extract mount points and their options from backup
2. Create volumes for storage backed mount points on the storage provided with the `storage` parameter (default: `local`).
3. Extract files from backup archive
4. Add bind and device mount points to restored configuration (limited to root user)

Note
Since bind and device mount points are never backed up, no files are restored in the last step, but only the configuration options. The assumption is that such mount points are either backed up with another mechanism (e.g., NFS space that is bind mounted into many containers), or not intended to be backed up at all.

This simple mode is also used by the container restore operations in the web interface.

"Advanced" Restore Mode

By setting the `rootfs` parameter (and optionally, any combination of `mpX` parameters), the `pct restore` command is automatically switched into an advanced mode. This advanced mode completely ignores the `rootfs` and `mpX` configuration options contained in the backup archive, and instead only uses the options explicitly provided as parameters.

This mode allows flexible configuration of mount point settings at restore time, for example:

- Set target storages, volume sizes and other options for each mount point individually
- Redistribute backed up files according to new mount point scheme
- Restore to device and/or bind mount points (limited to root user)

11.9 Managing Containers with `pct`

The "Proxmox Container Toolkit" (`pct`) is the command-line tool to manage Proxmox VE containers. It enables you to create or destroy containers, as well as control the container execution (start, stop, reboot, migrate, etc.). It can be used to set parameters in the config file of a container, for example the network configuration or memory limits.

11.9.1 CLI Usage Examples

Create a container based on a Debian template (provided you have already downloaded the template via the web interface)

```
# pct create 100 /var/lib/vz/template/cache/debian-10.0-standard_10.0-1 ↩
  _amd64.tar.gz
```

Start container 100

```
# pct start 100
```

Start a login session via getty

```
# pct console 100
```

Enter the LXC namespace and run a shell as root user

```
# pct enter 100
```

Display the configuration

```
# pct config 100
```

Add a network interface called `eth0`, bridged to the host bridge `vmbr0`, set the address and gateway, while it's running

```
# pct set 100 -net0 name=eth0,bridge=vmbr0,ip=192.168.15.147/24,gw ↩
   =192.168.15.1
```

Reduce the memory of the container to 512MB

```
# pct set 100 -memory 512
```

Destroying a container always removes it from Access Control Lists and it always removes the firewall configuration of the container. You have to activate *--purge*, if you want to additionally remove the container from replication jobs, backup jobs and HA resource configurations.

Note
Activating purge will also remove the HA resource from any affinity rules referencing it and will remove rules that have only this one remaining resource.

```
# pct destroy 100 --purge
```

Move a mount point volume to a different storage.

```
# pct move-volume 100 mp0 other-storage
```

Reassign a volume to a different CT. This will remove the volume `mp0` from the source CT and attaches it as `mp1` to the target CT. In the background the volume is being renamed so that the name matches the new owner.

```
#  pct move-volume 100 mp0 --target-vmid 200 --target-volume mp1
```

11.9.2 Obtaining Debugging Logs

In case `pct start` is unable to start a specific container, it might be helpful to collect debugging output by passing the `--debug` flag (replace `CTID` with the container's CTID):

```
# pct start CTID --debug
```

Alternatively, you can use the following `lxc-start` command, which will save the debug log to the file specified by the `-o` output option:

```
# lxc-start -n CTID -F -l DEBUG -o /tmp/lxc-CTID.log
```

This command will attempt to start the container in foreground mode, to stop the container run `pct shutdown CTID` or `pct stop CTID` in a second terminal.

The collected debug log is written to `/tmp/lxc-CTID.log`.

Note
If you have changed the container's configuration since the last start attempt with `pct start`, you need to run `pct start` at least once to also update the configuration used by `lxc-start`.

11.10 Migration

If you have a cluster, you can migrate your Containers with

```
# pct migrate <ctid> <target>
```

This works as long as your Container is offline. If it has local volumes or mount points defined, the migration will copy the content over the network to the target host if the same storage is defined there.

Running containers cannot live-migrated due to technical limitations. You can do a restart migration, which shuts down, moves and then starts a container again on the target node. As containers are very lightweight, this results normally only in a downtime of some hundreds of milliseconds.

A restart migration can be done through the web interface or by using the `--restart` flag with the `pct migrate` command.

A restart migration will shut down the Container and kill it after the specified timeout (the default is 180 seconds). Then it will migrate the Container like an offline migration and when finished, it starts the Container on the target node.

11.11 Configuration

The `/etc/pve/lxc/<CTID>.conf` file stores container configuration, where `<CTID>` is the numeric ID of the given container. Like all other files stored inside `/etc/pve/`, they get automatically replicated to all other cluster nodes.

Note
CTIDs < 100 are reserved for internal purposes, and CTIDs need to be unique cluster wide.

Example Container Configuration

```
ostype: debian
arch: amd64
hostname: www
memory: 512
swap: 512
net0: bridge=vmbr0,hwaddr=66:64:66:64:64:36,ip=dhcp,name=eth0,type=veth
rootfs: local:107/vm-107-disk-1.raw,size=7G
```

The configuration files are simple text files. You can edit them using a normal text editor, for example, `vi` or `nano`. This is sometimes useful to do small corrections, but keep in mind that you need to restart the container to apply such changes.

For that reason, it is usually better to use the `pct` command to generate and modify those files, or do the whole thing using the GUI. Our toolkit is smart enough to instantaneously apply most changes to running containers. This feature is called “hot plug”, and there is no need to restart the container in that case.

In cases where a change cannot be hot-plugged, it will be registered as a pending change (shown in red color in the GUI). They will only be applied after rebooting the container.

11.11.1 File Format

The container configuration file uses a simple colon separated key/value format. Each line has the following format:

```
# this is a comment
OPTION: value
```

Blank lines in those files are ignored, and lines starting with a # character are treated as comments and are also ignored.

It is possible to add low-level, LXC style configuration directly, for example:

```
lxc.init_cmd: /sbin/my_own_init
```

or

```
lxc.init_cmd = /sbin/my_own_init
```

The settings are passed directly to the LXC low-level tools.

11.11.2 Snapshots

When you create a snapshot, `pct` stores the configuration at snapshot time into a separate snapshot section within the same configuration file. For example, after creating a snapshot called “testsnapshot”, your configuration file will look like this:

Container configuration with snapshot

```
memory: 512
swap: 512
parent: testsnaphot
...

[testsnaphot]
memory: 512
swap: 512
snaptime: 1457170803
...
```

There are a few snapshot related properties like `parent` and `snaptime`. The `parent` property is used to store the parent/child relationship between snapshots. `snaptime` is the snapshot creation time stamp (Unix epoch).

11.11.3 Meta Information

The read-only `meta` property contains information that Proxmox VE records automatically about the container:

`ctime`
: The time the container was created, in seconds since the UNIX epoch.

`uid` and `rtime`
The guest identity of the container, available since Proxmox VE 9.3, see Guest Identity.

Example meta property of a container

```
meta: ctime=1772444467,rtime=1794320571482,uid=w5qczgiem26qnwzwsoil
```

A clone keeps its source container's `ctime`. A restored container uses the `ctime` from the backup. Containers created with Proxmox VE versions older than 9.3 have no `ctime`.

Proxmox VE versions older than 9.3 do not know the `meta` property of containers and drop it when they write the configuration. Therefore, migrating or cloning a container to a node running such a version is refused, see Mixed Versions in a Cluster.

11.11.4 Options

`arch`: `<amd64 | arm64 | armhf | i386 | riscv32 | riscv64>` (*default* = `amd64`)
OS architecture type.

`cmode`: `<console | shell | tty>` (*default* = `tty`)
Console mode. By default, the console command tries to open a connection to one of the available tty devices. By setting cmode to *console* it tries to attach to /dev/console instead. If you set cmode to *shell*, it simply invokes a shell inside the container (no login).

`console`: `<boolean>` (*default* = `1`)
Attach a console device (/dev/console) to the container.

`cores`: `<integer> (1 - 8192)`
The number of cores assigned to the container. A container can use all available cores by default.

`cpulimit`: `<number> (0 - 8192)` (*default* = `0`)
Limit of CPU usage.

> **Note**
> If the computer has 2 CPUs, it has a total of *2* CPU time. Value *0* indicates no CPU limit.

`cpuunits`: `<integer> (0 - 500000)` (*default* = `cgroup v1: 1024, cgroup v2: 100`)
CPU weight for a container. Argument is used in the kernel fair scheduler. The larger the number is, the more CPU time this container gets. Number is relative to the weights of all the other running guests.

`debug`: `<boolean>` (*default* = `0`)
Try to be more verbose. For now this only enables debug log-level on start.

description: <string>
Description for the Container. Shown in the web-interface CT's summary. This is saved as comment inside the configuration file.

dev[n]: [[path=]<Path>] [,deny-write=<1|0>] [,gid=<integer>] [,mode=<Octal access mode>] [,uid=<integer>]
Device to pass through to the container

deny-write=<boolean> (*default =* 0)
Deny the container to write to the device

gid=<integer> (0 - N)
Group ID to be assigned to the device node

mode=<Octal access mode>
Access mode to be set on the device node

path=<Path>
Path to the device to pass through to the container

uid=<integer> (0 - N)
User ID to be assigned to the device node

entrypoint: (?^:[^\x00-\x08\x0a-\x1F\x7F]+\z) (*default =* **/sbin/init**)
Command to run as init, optionally with arguments; may start with an absolute path, relative path, or a binary in $PATH.

env:
(?^:(?:\w+=[^\x00-\x08\x0a-\x1F\x7F]*)(?:\0\w+=[^\x00-\x08\x0a-\x1F\x7F]*)*

The container runtime environment as NUL-separated list. Replaces any lxc.environment.runtime entries in the config.

features: [force_rw_sys=<1|0>] [,fuse=<1|0>] [,keyctl=<1|0>] [,mknod=<1|0>] [,mount=<fstype;fstype;...>] [,nesting=<1|0>]
Allow containers access to advanced features.

force_rw_sys=<boolean> (*default =* 0)
Mount /sys in unprivileged containers as `rw` instead of `mixed`. This can break networking under newer (>= v245) systemd-network use.

fuse=<boolean> (*default =* 0)
Allow using *fuse* file systems in a container. Note that interactions between fuse and the freezer cgroup can potentially cause I/O deadlocks.

keyctl=<boolean> (*default =* 0)
For unprivileged containers only: Allow the use of the keyctl() system call. This is required to use docker inside a container. By default unprivileged containers will see this system call as

non-existent. This is mostly a workaround for systemd-networkd, as it will treat it as a fatal error when some keyctl() operations are denied by the kernel due to lacking permissions. Essentially, you can choose between running systemd-networkd or docker.

mknod=<boolean> (*default =* 0)
Allow unprivileged containers to use mknod() to add certain device nodes. This requires a kernel with seccomp trap to user space support (5.3 or newer).

mount=<fstype;fstype;...>
Allow mounting file systems of specific types. This should be a list of file system types as used with the mount command. Note that this can have negative effects on the container's security. With access to a loop device, mounting a file can circumvent the mknod permission of the devices cgroup, mounting an NFS file system can block the host's I/O completely and prevent it from rebooting, etc.

nesting=<boolean> (*default =* 0)
Allow nesting. Best used with unprivileged containers with additional id mapping. Note that this will expose procfs and sysfs contents of the host to the guest. This is also required by systemd to isolate services.

hookscript: <string>
Script that will be executed during various steps in the containers lifetime.

hostname: <string>
Set a host name for the container.

lock: <backup | create | destroyed | disk | fstrim | migrate | mounted | rollback | snapshot | snapshot-delete>
Lock/unlock the container.

memory: <integer> (16 - N) (*default =* 512)
Amount of RAM for the container in MB.

mp[n]: [volume=]<volume> ,mp=<Path> [,acl=<1|0>] [,backup=<1|0>] [,idmap=<type:container:disk:range-size[;type:container:disk:range-size;...] [,keepattrs=<1|0>] [,mountoptions=<opt[;opt...]>] [,quota=<1|0>] [,replicate=<1|0>] [,ro=<1|0>] [,shared=<1|0>] [,size=<DiskSize>]
Use volume as container mount point. Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume.

acl=<boolean>
Explicitly enable or disable ACL support.

backup=<boolean>
Whether to include the mount point in backups (only used for volume mount points).

idmap=<type:container:disk:range-size[;type:container:disk:range-size;...

Customize UID/GID mappings that override the container's `lxc.idmap` for this mount point. Accepts a semicolon-separated list of `type:container:disk:range-size` entries.

`type` is `u` for UID or `g` for GID.

`container` is the first ID as seen inside the container.

`disk` is the first corresponding ID on the underlying filesystem.

`range-size` is the number of consecutive IDs to map.

Unmapped IDs fall back to the container's `lxc.idmap`.

Example 1: `u:123:456:1` maps UID 123 in the container to UID 456 on the disk. Files owned by UID 456 on the disk will appear as UID 123 inside the container.

Example 2: `g:100:50:5` maps 5 consecutive GIDs, such that GIDs 100-104 in the container are mapped to GIDs 50-54 on the disk.

Example 3: `passthrough` identity-maps all UIDs and GIDs, meaning IDs inside the container will match the IDs on the disk.

keepattrs=<boolean> (*default =* 0)
Inherit UID, GID and access mode from the mount point directory, if it exists already.

mountoptions=<opt[;opt...]>
Extra mount options for rootfs/mps.

mp=<Path>
Path to the mount point as seen from inside the container.

> **Note**
> Must not contain any symlinks for security reasons.

quota=<boolean>
Enable user quotas inside the container (not supported with zfs subvolumes)

replicate=<boolean> (*default =* 1)
Will include this volume to a storage replica job.

ro=<boolean>
Read-only mount point

shared=<boolean> (*default =* 0)
Mark this non-volume mount point as available on all nodes.

> 
> **Warning**
> This option does not share the mount point automatically, it assumes it is shared already!

size=<DiskSize>
Volume size (read only value).

volume=<volume>
Volume, device or directory to mount into the container.

nameserver: <string>
Comma-separated list of IP addresses. Sets the addresses of the DNS servers of the container. Create will automatically use the setting from the host if you neither set searchdomain nor nameserver.

net[n]: name=<string> [,bridge=<bridge>] [,firewall=<1|0>]
[,gw=<GatewayIPv4>] [,gw6=<GatewayIPv6>] [,host-managed=<1|0>]
[,hwaddr=<XX:XX:XX:XX:XX:XX>] [,ip=<(IPv4/CIDR|dhcp|manual)>]
[,ip6=<(IPv6/CIDR|auto|dhcp|manual)>] [,link_down=<1|0>]
[,mtu=<integer>] [,rate=<mbps>] [,tag=<integer>]
[,trunks=<vlanid[;vlanid...]>] [,type=<veth>]

Specifies network interfaces for the container.

bridge=<bridge>
Bridge to attach the network device to.

firewall=<boolean>
Controls whether this interface's firewall rules should be used.

gw=<GatewayIPv4>
Default gateway for IPv4 traffic.

gw6=<GatewayIPv6>
Default gateway for IPv6 traffic.

host-managed=<boolean>
Whether this interface's IP configuration should be managed by the host. When enabled, the host (rather than the container) is responsible for the interface's IP configuration. The container should not run its own DHCP client or network manager on this interface. This is useful for containers that lack an internal network management stack, like many application containers.

hwaddr=<XX:XX:XX:XX:XX:XX>
A common MAC address with the I/G (Individual/Group) bit not set.

ip=<(IPv4/CIDR|dhcp|manual)>
IPv4 address in CIDR format.

ip6=<(IPv6/CIDR|auto|dhcp|manual)>
IPv6 address in CIDR format.

link_down=<boolean>
Whether this interface should be disconnected (like pulling the plug).

mtu=<integer> (64 - 65535)
Maximum transfer unit of the interface. (lxc.network.mtu)

name=<string>
Name of the network device as seen from inside the container. (lxc.network.name)

rate=<mbps>
Apply rate limiting to the interface

tag=<integer> (1 - 4094)
VLAN tag for this interface.

trunks=<vlanid[;vlanid...]>
VLAN ids to pass through the interface

type=<veth>
Network interface type.

onboot: <boolean> (*default =* 0)
Specifies whether a container will be started during system bootup.

ostype: <alpine | archlinux | centos | debian | devuan | fedora | gentoo | nixos | opensuse | ubuntu | unmanaged>
OS type. This is used to setup configuration inside the container, and corresponds to lxc setup scripts in /usr/share/lxc/config/<ostype>.common.conf. Value *unmanaged* can be used to skip and OS specific setup.

protection: <boolean> (*default =* 0)
Sets the protection flag of the container. This will prevent the CT or CT's disk remove/update operation.

rootfs: [volume=]<volume> [,acl=<1|0>] [,idmap=<type:container:disk:range-size[;type:container:disk:range-size;... [,mountoptions=<opt[;opt...]>] [,quota=<1|0>] [,replicate=<1|0>] [,ro=<1|0>] [,shared=<1|0>] [,size=<DiskSize>]
Use volume as container root.

acl=<boolean>
Explicitly enable or disable ACL support.

idmap=<type:container:disk:range-size[;type:container:disk:range-size;.

Customize UID/GID mappings that override the container's `lxc.idmap` for this mount point. Accepts a semicolon-separated list of `type:container:disk:range-size` entries.

`type` is `u` for UID or `g` for GID.

`container` is the first ID as seen inside the container.

`disk` is the first corresponding ID on the underlying filesystem.

`range-size` is the number of consecutive IDs to map.

Unmapped IDs fall back to the container's `lxc.idmap`.

Example 1: `u:123:456:1` maps UID 123 in the container to UID 456 on the disk. Files owned by UID 456 on the disk will appear as UID 123 inside the container.

Example 2: `g:100:50:5` maps 5 consecutive GIDs, such that GIDs 100-104 in the container are mapped to GIDs 50-54 on the disk.

Example 3: `passthrough` identity-maps all UIDs and GIDs, meaning IDs inside the container will match the IDs on the disk.

mountoptions=<opt[;opt...]>
Extra mount options for rootfs/mps.

quota=<boolean>
Enable user quotas inside the container (not supported with zfs subvolumes)

replicate=<boolean> (*default =* 1)
Will include this volume to a storage replica job.

ro=<boolean>
Read-only mount point

shared=<boolean> (*default =* 0)
Mark this non-volume mount point as available on all nodes.



Warning
This option does not share the mount point automatically, it assumes it is shared already!

size=<DiskSize>
Volume size (read only value).

volume=<volume>
Volume, device or directory to mount into the container.

searchdomain: <string>
Sets DNS search domains for a container. Create will automatically use the setting from the host if you neither set searchdomain nor nameserver.

startup: `[[order=]\d+] [,up=\d+] [,down=\d+] `
Startup and shutdown behavior. Order is a non-negative number defining the general startup order. Shutdown in done with reverse ordering. Additionally you can set the *up* or *down* delay in seconds, which specifies a delay to wait before the next VM is started or stopped.

swap: <integer> (0 - N) (*default =* 512)
Amount of SWAP for the container in MB.

tags: <string>
Tags of the Container. This is only meta information.

template: <boolean> (*default =* 0)
Enable/disable Template.

timezone: <string>
Time zone to use in the container. If option isn't set, then nothing will be done. Can be set to *host* to match the host time zone, or an arbitrary time zone option from /usr/share/zoneinfo/zone.tab

tty: <integer> (0 - 6) (*default =* 2)
Specify the number of tty available to the container

unprivileged: <boolean> (*default =* 0)
Makes the container run as unprivileged user. For creation, the default is 1. For restore, the default is the value from the backup. (Should not be modified manually.)

unused[n]: [volume=]<volume>
Reference to unused volumes. This is used internally, and should not be modified manually.

volume=<volume>
The volume that is not used currently.

11.12 Locks

Container migrations, snapshots and backups (`vzdump`) set a lock to prevent incompatible concurrent actions on the affected container. Sometimes you need to remove such a lock manually (e.g., after a power failure).

```
# pct unlock <CTID>
```



Caution
Only do this if you are sure the action which set the lock is no longer running.

Chapter 12

Software-Defined Network

The **S**oftware-**D**efined **N**etwork (SDN) feature in Proxmox VE enables the creation of virtual zones and networks (VNets). This functionality simplifies advanced networking configurations and multitenancy setup.

12.1 Introduction

The Proxmox VE SDN allows for separation and fine-grained control of virtual guest networks, using flexible, software-controlled configurations.

Separation is managed through **zones**, virtual networks (**VNets**), and **subnets**. A zone is its own virtually separated network area. A VNet is a virtual network that belongs to a zone. A subnet is an IP range inside a VNet.

Depending on the type of the zone, the network behaves differently and offers specific features, advantages, and limitations.

Use cases for SDN range from an isolated private network on each individual node to complex overlay networks across multiple PVE clusters on different locations.

After configuring an VNet in the cluster-wide datacenter SDN administration interface, it is available as a common Linux bridge, locally on each node, to be assigned to VMs and Containers.

12.2 Support Status

12.2.1 History

The Proxmox VE SDN stack has been available as an experimental feature since 2019 and has been continuously improved and tested by many developers and users. With its integration into the web interface in Proxmox VE 6.2, a significant milestone towards broader integration was achieved. During the Proxmox VE 7 release cycle, numerous improvements and features were added. Based on user feedback, it became apparent that the fundamental design choices and their implementation were quite sound and stable. Consequently, labeling it as ‘experimental’ did not do justice to the state of the SDN stack. For Proxmox VE 8, a decision was made to lay the groundwork for full integration of the SDN feature by elevating the management of networks and interfaces to a core component in the Proxmox VE access control stack. In Proxmox VE 8.1, two major milestones were achieved: firstly, DHCP integration was added to the IP address management (IPAM) feature, and secondly, the SDN integration is now installed by default.

12.2.2 Current Status

The current support status for the various layers of our SDN installation is as follows:

- Core SDN, which includes VNet management and its integration with the Proxmox VE stack, is fully supported.
- IPAM, including DHCP management for virtual guests, is in tech preview.
- Complex routing via FRRouting and controller integration are in tech preview.

12.3 Installation

12.3.1 SDN Core

Since Proxmox VE 8.1 the core Software-Defined Network (SDN) packages are installed by default.

If you upgrade from an older version, you need to install the `libpve-network-perl` package on every node:

```
apt update
apt install libpve-network-perl
```

Note
Proxmox VE version 7.0 and above have the `ifupdown2` package installed by default. If you originally installed your system with an older version, you need to explicitly install the `ifupdown2` package.

After installation, you need to ensure that the following line is present at the end of the `/etc/network/interfa` configuration file on all nodes, so that the SDN configuration gets included and activated.

```
source /etc/network/interfaces.d/*
```

12.3.2 DHCP IPAM

The DHCP integration into the built-in *PVE* IP Address Management stack currently uses `dnsmasq` for giving out DHCP leases. This is currently opt-in.

To use that feature you need to install the `dnsmasq` package on every node:

```
apt update
apt install dnsmasq
# disable default instance
systemctl disable --now dnsmasq
```

12.3.3 FRRouting

The Proxmox VE SDN stack uses the FRRouting project for advanced setups. This is currently opt-in.

To use the SDN routing integration you need to install the `frr-pythontools` package on all nodes:

```
apt update
apt install frr-pythontools
```

Then enable the frr service on all nodes:

```
systemctl enable frr.service
```

12.4 Configuration Overview

Configuration is done at the web UI at datacenter level, separated into the following sections:

- SDN: Here you get an overview of the current active SDN state, and you can apply all pending changes to the whole cluster.
- Zones: Create and manage the virtually separated network zones
- VNets: Create virtual network bridges and manage subnets

The Options category allows adding and managing additional services to be used in your SDN setup.

- Controllers: For controlling layer 3 routing in complex setups
- DHCP: Define a DHCP server for a zone that automatically allocates IPs for guests in the IPAM and leases them to the guests via DHCP.
- IPAM: Enables external for IP address management for guests
- DNS: Define a DNS server integration for registering virtual guests' hostname and IP addresses

12.5 Technology & Configuration

The Proxmox VE Software-Defined Network implementation uses standard Linux networking as much as possible. The reason for this is that modern Linux networking provides almost all needs for a feature full SDN implementation and avoids adding external dependencies and reduces the overall amount of components that can break.

The Proxmox VE SDN configurations are located in `/etc/pve/sdn`, which is shared with all other cluster nodes through the Proxmox VE configuration file system. Those configurations get translated to the respective configuration formats of the tools that manage the underlying network stack (for example `ifupdown2` or `frr`).

New changes are not immediately applied but recorded as pending first. You can then apply a set of different changes all at once in the main *SDN* overview panel on the web interface. This system allows to roll-out various changes as single atomic one.

The SDN tracks the rolled-out state through the *.running-config* and *.version* files located in */etc/pve/sdn*.

12.6 Zones

A zone defines a virtually separated network. Zones are restricted to specific nodes and assigned permissions, in order to restrict users to a certain zone and its contained VNets.

Different technologies can be used for separation:

- Simple: Isolated Bridge. A simple layer 3 routing bridge (NAT)
- VLAN: Virtual LANs are the classic method of subdividing a LAN
- QinQ: Stacked VLAN (formally known as `IEEE 802.1ad`)
- VXLAN: Layer 2 VXLAN network via a UDP tunnel
- EVPN (BGP EVPN): VXLAN with BGP to establish Layer 3 routing

12.6.1 Common Options

The following options are available for all zone types:

Nodes
The nodes which the zone and associated VNets should be deployed on.

IPAM
Use an IP Address Management (IPAM) tool to manage IPs in the zone. Optional, defaults to `pve`.

DNS
DNS API server. Optional.

ReverseDNS
Reverse DNS API server. Optional.

DNSZone
DNS domain name. Used to register hostnames, such as `<hostname>.<domain>`. The DNS zone must already exist on the DNS server. Optional.

12.6.2 Simple Zones

This is the simplest plugin. It will create an isolated VNet bridge. This bridge is not linked to a physical interface, and VM traffic is only local on each the node. It can be used in NAT or routed setups.

Simple zone configuration options:

Dedicated VRF
Give the zone a routing table of its own, see Dedicated VRF. The option is in the advanced settings of the zone and disabled by default.

Dedicated VRF

A virtual routing and forwarding (VRF) device gives the VNets of a simple zone a routing table of their own on each node, separate from the routing table of the host and from other zones. For example, the VRF of the zone `myzone` is `vrf_myzone`. Zones with a dedicated VRF can use the same subnets.

Guests can reach networks outside the zone through:

- A host interface in the VRF, called uplink below, for example a VLAN interface to an upstream router.
- An OSPF or BGP fabric that uses the zone, see Fabrics in a Zone VRF, which also describes the `rp_filter` setting such a fabric needs.

Without either, the zone has no connection to other networks. By default, services of the host such as SSH or the web interface cannot be reached from the zone. Enabling the `net.ipv4.tcp_l3mdev_accept` or `net.ipv4.udp_l3mdev_accept` sysctl changes this for TCP or UDP.

To add an uplink:

1. Apply the SDN configuration, so that the VRF of the zone exists on the nodes.
2. On each node that needs an uplink, edit the interface under `Node -> System -> Network`, select the VRF of the zone in *VRF*, and set *IPv4 Forwarding* to *Enabled*. Then apply the network configuration. The *VRF* and *IPv4 Forwarding* columns of the interface list, hidden by default, show these settings for all interfaces.

An uplink needs IPv4 forwarding to route traffic into the zone, including the replies to connections of guests. `ifupdown2` enables it on bridges in the VRF, but not on physical, bond or VLAN interfaces. In `/etc/network/` an uplink looks like this:

```
auto eno2.100
iface eno2.100 inet static
        address 198.51.100.2/30
        ip-forward on
        vrf vrf_myzone
```

For IPv6, enable forwarding globally with the `net.ipv6.conf.all.forwarding` sysctl, or set the `net/ipv6/conf/<interface>/force_forwarding` sysctl to `1` on the uplinks and the VNets of the zone.

Before you remove a node from the zone, remove the VRF from the uplinks of that node, and the node from the fabrics that use the zone. Before you disable the dedicated VRF or delete the zone, remove the VRF from the uplinks of all its nodes, the fabrics that use the zone, and its static routes. Applying the SDN configuration warns about host interfaces that still use a VRF that no longer exists on the node.

Static routes

To reach networks behind an uplink, for example with a default route via the upstream router, add static routes in the *Static Routes* tab of the zone, which is available with a dedicated VRF. FRR installs them in the VRF, so set it up on the nodes of the zone first, see FRRouting. Each route has a *Destination Prefix* and a *Gateway*, an *Outgoing Interface*, or both. An IPv6 link-local gateway needs an outgoing interface. *Distance* is optional. In the zone configuration, a default route via the router of the uplink example above is `route prefix=0.0.0.0/0,via=198.51.100.1`.

Changing static routes, changing the nodes of a zone with static routes, or deleting such a zone requires *Sys.Modify* on all affected nodes, as routes can affect the host.

DHCP
The DHCP server of the zone runs in its VRF. Guests use it as DNS server by default, which needs a route from the VRF to the upstream DNS servers. Otherwise, set *DHCP DNS Resolver* on the subnet to a DNS server the guests can reach.

SNAT
With *SNAT* enabled on a subnet, traffic of the subnet that leaves through an uplink gets the address of the uplink. All interfaces in the VRF that are configured in `/etc/network/interfaces` itself are used as uplinks, but not interfaces from included files or of fabrics. Networks behind an uplink only see the address of the node, so only put interfaces into the VRF that should be uplinks.

SNAT does not protect guests from incoming connections, use the firewall for that. A packet that arrives on an uplink with a forged source address of the subnet is translated as well if it leaves through an uplink. Drop such packets with the firewall, or with strict reverse path filtering for IPv4 if replies always come back through the uplink they left through.

Connection tracking
Each zone with a dedicated VRF gets a connection tracking zone, so that connections with the same addresses in different zones are tracked separately. This needs the `proxmox-firewall` package on the nodes, even if the nftables-based firewall is not used. The zone is assigned automatically and shown as `ct-zone` in the zone configuration. Proxmox VE reserves the connection tracking zones 16384 to 32767, do not use them in your own rules.

The tracking rules are set up when the network configuration is applied and at boot. If you change the interfaces of a VRF in another way, for example with `ifreload -a`, or flush the nftables ruleset, apply the network configuration again.

Firewall
Use the nftables-based firewall to keep the connections of guests in different zones apart. With `pve-firewall`, guests with the firewall enabled on a network device share their connection tracking state across all zones, and applying the configuration warns about this.

An address or an IPSet of a VNet in a firewall rule does not tell zones apart, so with overlapping subnets, it matches traffic of all zones with that subnet. For traffic from a zone to the host, the host firewall sees `vrf_<zone>` as input interface.

With the nftables-based firewall, traffic on a bridge in the VRF, including a VNet, is tracked in the zone of the VRF, also traffic between guests on that bridge. For a VLAN uplink on top of a bridge, such as `vmbr0.100`, this works for tagged traffic. It does not work for untagged traffic that only gets its VLAN on the bridge port, for VLAN interfaces with a MAC address of their own, or for 802.1ad. Replies to connections with SNAT can then get lost. A physical interface, a bond or a VLAN interface on one of them as uplink avoids this.

Guests can reach the infrastructure addresses in the VRF, such as the addresses of fabric interfaces, of nodes, or of the upstream router. To block them with the nftables-based firewall, add the addresses to a datacenter IPSet, for example `vrf-infra`, and drop traffic from the subnets of the zone to it, both to the node itself and beyond:

```
# /etc/pve/firewall/cluster.fw

[RULES]
```

```
FORWARD DROP -source +sdn/vnet0-all -dest +dc/vrf-infra
IN DROP -source +sdn/vnet0-all -dest +dc/vrf-infra
```

With SNAT, the upstream router only sees the address of the node, so only the firewall of the node can filter by the address of a guest.

12.6.3 VLAN Zones

The VLAN plugin uses an existing local Linux or OVS bridge to connect to the node's physical interface. It uses VLAN tagging defined in the VNet to isolate the network segments. This allows connectivity of VMs between different nodes.

VLAN zone configuration options:

Bridge
: The local bridge or OVS switch, already configured on **each** node that allows node-to-node connection. It is recommended to make a Linux bridge VLAN-aware.

12.6.4 QinQ Zones

QinQ also known as VLAN stacking, that uses multiple layers of VLAN tags for isolation. The QinQ zone defines the outer VLAN tag (the *Service VLAN*) whereas the inner VLAN tag is defined by the VNet.

Note
Your physical network switches must support stacked VLANs for this configuration.

QinQ zone configuration options:

Bridge
: A local, VLAN-aware bridge that is already configured on each local node

Service VLAN
: The main VLAN tag of this zone

Service VLAN Protocol
: Allows you to choose between an 802.1q (default) or 802.1ad service VLAN type.

MTU
: Due to the double stacking of tags, you need 4 more bytes for QinQ VLANs. For example, you must reduce the MTU to `1496` if you physical interface MTU is `1500`.

12.6.5 VXLAN Zones

The VXLAN plugin establishes a tunnel (overlay) on top of an existing network (underlay). This encapsulates layer 2 Ethernet frames within layer 4 UDP datagrams using the default destination port `4789`.

You have to configure the underlay network yourself to enable UDP connectivity between all peers.

You can, for example, create a VXLAN overlay network on top of public internet, appearing to the VMs as if they share the same local Layer 2 network.



Warning
VXLAN on its own does does not provide any encryption. When joining multiple sites via VXLAN, make sure to establish a secure connection between the site, for example by using a site-to-site VPN.

VXLAN zone configuration options:

Peers Address List
A list of IP addresses of each node in the VXLAN zone. This can be external nodes reachable at this IP address. All nodes in the cluster need to be mentioned here.

SDN Fabric
Instead of manually defining all the peers, use a Fabric for automatically generating the peer list.

MTU
Because VXLAN encapsulation uses 50 bytes, the MTU needs to be 50 bytes lower than the outgoing physical interface.

12.6.6 EVPN Zones

The EVPN zone creates a routable Layer 3 network, capable of spanning across multiple clusters. This is achieved by establishing a VPN and utilizing BGP as the routing protocol.

The VNet of EVPN can have an anycast IP address and/or MAC address. The bridge IP is the same on each node, meaning a virtual guest can use this address as gateway.

Routing can work across VNets from different zones through a VRF (Virtual Routing and Forwarding) interface.

EVPN zone configuration options:

VRF VXLAN ID
A VXLAN-ID used for dedicated routing interconnect between VNets. It must be different than the VXLAN-ID of the VNets.

Primay Controller
The primary EVPN-controller to use for this zone. The primary controller is used for auto-deriving the VTEP IPs, based on the peer definition. For more information see the controller section.

Addtional Controllers
Additional EVPN controllers to use for this zone. Controllers listed here will announce the L2VPN EVPN routes for this zone.

VNet MAC Address
Anycast MAC address that gets assigned to all VNets in this zone. Will be auto-generated if not defined.

Exit Nodes
Nodes that shall be configured as exit gateways from the EVPN network, through the real network. The configured nodes will announce a default route in the EVPN network. Optional.

Primary Exit Node
If you use multiple exit nodes, force traffic through this primary exit node, instead of load-balancing on all nodes. Optional but necessary if you want to use SNAT or if your upstream router doesn't support ECMP.

Exit Nodes Local Routing
This is a special option if you need to reach a VM/CT service from an exit node. (By default, the exit nodes only allow forwarding traffic between real network and EVPN network). Optional.

Advertise Subnets
Announce the full subnet in the EVPN network. If you have silent VMs/CTs (for example, if you have multiple IPs and the anycast gateway doesn't see traffic from these IPs, the IP addresses won't be able to be reached inside the EVPN network). Optional.

Disable ARP ND Suppression
Don't suppress ARP or ND (Neighbor Discovery) packets. This is required if you use floating IPs in your VMs (IP and MAC addresses are being moved between systems). Optional.

Route-target Import
Allows you to import a list of external EVPN route targets. Used for cross-DC or different EVPN network interconnects. Optional.

MTU
Because VXLAN encapsulation uses 50 bytes, the MTU needs to be 50 bytes less than the maximal MTU of the outgoing physical interface. Optional, defaults to 1450.

12.7 VNets

After creating a virtual network (VNet) through the SDN GUI, a local network interface with the same name is available on each node. To connect a guest to the VNet, assign the interface to the guest and set the IP address accordingly.

Depending on the zone, these options have different meanings and are explained in the respective zone section in this document.



Warning
In the current state, some options may have no effect or won't work in certain zones.

VNet configuration options:

ID
An up to 8 character ID to identify a VNet

Alias
More descriptive identifier. Assigned as an alias on the interface. Optional

Zone
The associated zone for this VNet

Tag
The unique VLAN or VXLAN ID

VLAN Aware
Enables vlan-aware option on the interface, enabling configuration in the guest.

Isolate Ports
Sets the isolated flag for all guest ports of this interface, but not for the interface itself. This means guests can only send traffic to non-isolated bridge-ports, which is the bridge itself. In order for this setting to take effect, you need to restart the affected guest.

Note
Port isolation is local to each host. Use the VNET Firewall to further isolate traffic in the VNET across nodes. For example, DROP by default and only allow traffic from the IP subnet to the gateway and vice versa.

12.8 Subnets

A subnet define a specific IP range, described by the CIDR network address. Each VNet, can have one or more subnets.

A subnet can be used to:

- Restrict the IP addresses you can define on a specific VNet
- Assign routes/gateways on a VNet in layer 3 zones
- Enable SNAT on a VNet in layer 3 zones
- Auto assign IPs on virtual guests (VM or CT) through IPAM plugins

- DNS registration through DNS plugins

If an IPAM server is associated with the subnet zone, the subnet prefix will be automatically registered in the IPAM.

Subnet configuration options:

ID
A CIDR network address, for example 10.0.0.0/8

Gateway
The IP address of the network's default gateway. On layer 3 zones (Simple/EVPN plugins), it will be deployed on the VNet.

SNAT
Enable Source NAT which allows VMs from inside a VNet to connect to the outside network by forwarding the packets to the nodes outgoing interface. On EVPN zones, forwarding is done on EVPN gateway-nodes. Optional.

DNS Zone Prefix
Add a prefix to the domain registration, like <hostname>.prefix.<domain> Optional.

DHCP DNS Resolver
The DNS server that DHCP announces to guests. Without it, guests use the DHCP server of the zone, which forwards queries to the DNS servers of the host. Optional.

12.9 Controllers

Some zones implement a separated control and data plane that require an external controller to manage the VNet's control plane.

Currently, only the `EVPN` zone requires an external controller.

12.9.1 EVPN Controller

The `EVPN`, zone requires an external controller to manage the control plane. The EVPN controller plugin configures the Free Range Routing (frr) router.

To enable the EVPN controller, you need to enable FRR on every node, see install FRRouting.

EVPN controller configuration options:

ASN
A unique BGP ASN. It's highly recommended to use a private ASN (64512 – 65534, 4200000000 – 4294967294), as otherwise you could end up breaking global routing by mistake. Every EVPN controller configured on a node must have the same ASN configured.

SDN Fabric
A Fabric that contains all the nodes part of the EVPN zone. Will be used as the underlay network.

Peers
An IP list of all nodes that are part of the EVPN zone. (could also be external nodes or route reflector servers)

Nodes
A list of nodes where this controller should be active. This can be used to configure EVPN peering sessions on specific nodes only.

Peer Group Name
EVPN controllers use the peer group name *VTEP* by default. When defining multiple EVPN controllers, each additional controller needs to specify a custom peer group name to be used in the FRR configuration.

BGP Mode
Allows configuring the type of BGP session manually. The *auto* mode preserves the old behavior of the SDN stack: EVPN controllers were iBGP, unless there was a BGP controller configured. In that case the EVPN controller re-used the BGP session from the BGP controller. With this option, the type of BGP session can be overridden manually - allowing for explicitly configuring the type of BGP session that should be established with the EVPN controller.

ebgp-multihop
Increase the number of hops to reach peers, in case they are not directly connected or they use loopback. (only for BGP Mode *external*).

ASN

Every router can be member of exactly one Autonomous System, so any iBGP sessions on a given node (irregardless of address family) need to have the same ASN configured. Any configuration that has two iBGP sessions with different ASNs is rejected and an error thrown, since it is by definition not possible to have two iBGP sessions with different ASNs on the same BGP instance, as one instance can only have one local ASN.

The local ASN of the FRR instance is auto-derived based on the settings in the SDN controllers:

If only a BGP or EVPN controller exists (but not both), then the respective ASN from the controller is used.

For backwards-compatibility reasons, the SDN stack checks if there are any EVPN controllers in auto mode. If a BGP controller exists, then the ASN from the BGP controller will be used in any case.

Otherwise, if an EVPN controller is configured, then the ASN from the EVPN controller is used - otherwise the ASN from the BGP controller.

The SDN stack utilizes the local-as directive together with the `no-prepend replace-as` option in the FRR configuration for handling multiple ASNs in the configuration. This is the case when the BGP and EVPN controller have different ASNs configured and auto mode is disabled.

VTEP IP auto-generation

The VTEP IPs for the VXLAN devices of a zone will be auto-derived based on the (primary) controller defined in the EVPN zone:

If a BGP or IS-IS controller with a loopback interface is used, then the IP from the loopback interface will be used as VTEP IP.

If the peer list of the controller contains an IP that is locally configured on the node, then this IP will be used as VTEP IP.

Otherwise, the EVPN controller will check the route in the default routing table for the first peer IP and use the source IP address specified in the routing table as VTEP IP. This can cause issues if the route gets announced dynamically e.g. via a fabric. In that case it is necessary for the kernel routing table to contain the required entry when applying the configuration for the EVPN controller.

12.9.2 BGP Controller

The BGP controller is not used directly by a zone. You can use it to configure FRR to manage BGP peers.

For BGP-EVPN, it can be used to define a different ASN by node, so doing EBGP. It can also be used to export EVPN routes to an external BGP peer.

Note
By default, for a simple full mesh EVPN, you don't need to define a BGP controller.

BGP controller configuration options:

Node
The node of this BGP controller

ASN
A unique BGP ASN. It's highly recommended to use a private ASN in the range (64512 - 65534) or (4200000000 - 4294967294), as otherwise you could break global routing by mistake.

Peer
A list of peer IP addresses you want to communicate with using the underlying BGP network.

EBGP
If your peer's remote-AS is different, this enables EBGP.

Loopback Interface
Use a loopback or dummy interface as the source of the EVPN network (for multipath).

ebgp-multihop
Increase the number of hops to reach peers, in case they are not directly connected or they use loopback.

bgp-multipath-as-path-relax
Allow ECMP if your peers have different ASN.

12.9.3 ISIS Controller

The ISIS controller is not used directly by a zone. You can use it to configure FRR to export EVPN routes to an ISIS domain.

ISIS controller configuration options:

Node
The node of this ISIS controller.

Domain
A unique ISIS domain.

Network Entity Title
A Unique ISIS network address that identifies this node.

Interfaces
A list of physical interface(s) used by ISIS.

Loopback
Use a loopback or dummy interface as the source of the EVPN network (for multipath).

12.10 Fabrics



Fabrics in Proxmox VE SDN provide automated routing between nodes in a cluster. They simplify the configuration of underlay networks between nodes to form the foundation for SDN deployments.

They automatically configure routing protocols on your physical network interfaces to establish connectivity between nodes in the cluster. This creates a resilient, auto-configuring network fabric that adapts to changes in network topology. These fabrics can be used as a full-mesh network for Ceph or in the EVPN controller and VXLAN zone.

12.10.1 Installation

The FRR implementations of OpenFabric and OSPF are used, so first ensure that the `frr` and `frr-pythontool` packages are installed:

```
apt update
apt install frr frr-pythontools
```

12.10.2 Permissions

To view the configuration of an SDN fabric users need SDN.Audit or SDN.Allocate permissions. To create or modify a fabric configuration, users need SDN.Allocate permissions. To view the configuration of a node,

users need the Sys.Audit or Sys.Modify permissions. When adding or updating nodes within a fabric, additional Sys.Modify permission for the specific node is required, since this operation involves writing to the node's /etc/network/interfaces file.

12.10.3 Configuration

To create a Fabric, head over to Datacenter→SDN→Fabrics and click "Add Fabric". After selecting the preferred protocol, the fabric is created. With the "+" button you can select the nodes which you want to add to the fabric, you also have to select the interfaces used to communicate with the other nodes.

Loopback Prefix

You can specify a CIDR network range (e.g., 192.0.2.0/24) as a loopback prefix for the fabric. When configured, the system will automatically verify that all router-IDs are contained within this prefix. This ensures consistency in your addressing scheme and helps prevent addressing conflicts or errors.

Router-ID Selection

Each node in a fabric needs a unique router-ID, which is an IPv4 address in dotted decimal notation (e.g., 192.0.2.1). In OpenFabric this can also be an IPv6 address in the typical hexadecimal representation separated by colons (e.g., 2001:db8::1428:57ab). A dummy interface with the router-ID as address will automatically be created and will act as a loopback interface for the fabric (it's also passive by default).

RouteMaps

For every fabric, an access-list and a route-map are automatically created. These configure the router to rewrite the source address of outgoing packets. When you communicate with another node (for example, by pinging it), this ensures that traffic originates from the local dummy interface's IP address rather than from the physical interface. This provides consistent routing behavior and proper source address selection throughout the fabric.

Notes on IPv6

IPv6 is currently only usable on OpenFabric fabrics. These IPv6 Fabrics need global IPv6 forwarding enabled on all nodes contained in the fabric. Without IPv6 forwarding, non-full-mesh fabrics won't work because the transit nodes don't forward packets to the outer nodes. Currently there isn't an easy way to enable IPv6 forwarding per-interface like with IPv4, so it has to be enabled globally. This can be accomplished by appending this line:

```
post-up sysctl -w net.ipv6.conf.all.forwarding=1
```

to a fabric interface in the `/etc/network/interfaces` file. This will enable IPv6 forwarding globally once that interface comes up. Note that this affects how your interfaces handle automatic IPv6 setup (SLAAC), Neighbour Advertisements, Router Solicitations, and Router Advertisements. More details here: https://www.kernel.org/doc/Documentation/networking/ip-sysctl.txt under `net.ipv6.conf.all.forwardin`

12.10.4 Fabrics in a Zone VRF

OSPF and BGP fabrics can route in the VRF of a simple zone instead of the default routing table of the host, for example to connect the zone across nodes or to an upstream network. Select the zone in *VRF Zone* when you create the fabric, it cannot be changed later. Only simple zones with a dedicated VRF can be selected, and all nodes of the fabric need to be part of the zone. The fabric puts its interfaces into the VRF, so do not set a VRF for them in the network configuration of the nodes. Applying the SDN configuration warns about such a setting, which can override the VRF of the fabric.

Interfaces of WireGuard fabrics cannot be used, as the WireGuard fabric keeps their addresses and routes in the default routing table.

Fabrics used as underlay for EVPN controllers or VXLAN zones need to stay in the default routing table.

Reverse path filtering drops traffic of fabrics in a VRF, also in the loose mode that `/usr/lib/sysctl.d/pve-f` sets for `all`. The kernel uses the higher value of `all` and of the interface, so on each node of the fabric, set `rp_filter` to `0` for `all` and for every interface of the fabric. Use a file that sorts after `pve-firewall.conf`, so that it overrides the value set there, for example `/etc/sysctl.d/zz-rp-filte` Replace `<interface>` with the name of a fabric interface, and add one such line for each of them:

```
net.ipv4.conf.all.rp_filter = 0
net/ipv4/conf/<interface>/rp_filter = 0
```

Apply the file with `sysctl --system` or by rebooting the node. Other interfaces keep their own value, which is `2` by default.

12.10.5 OpenFabric

OpenFabric is a routing protocol specifically designed for data center fabrics. It's based on IS-IS and optimized for the spine-leaf topology common in data centers.



Configuration options:

On the Fabric

Name
: This is the name of the OpenFabric fabric and can be at most 8 characters long.

IPv4 Prefix
: IPv4 CIDR network range (e.g., 192.0.2.0/24) used to verify that all router-IDs in the fabric are contained within this prefix.

IPv6 Prefix
IPv6 CIDR network range (e.g., 2001:db8::/64) used to verify that all router-IDs in the fabric are contained within this prefix.



Warning
For IPv6 fabrics to work, global forwarding needs to be enabled on all nodes. Check Notes on IPv6 for how to do it and additional info.

Hello Interval
Controls how frequently (in seconds) hello packets are sent to discover and maintain connections with neighboring nodes. Lower values detect failures faster but increase network traffic. This option is global on the fabric, meaning every interface on every node in this fabric will inherit this hello-interval property. The default value is 3 seconds.

CSNP Interval
Sets how frequently (in seconds) the node synchronizes its routing database with neighbors. Lower values keep the network topology information more quickly in sync but increase network traffic. This option is global on the fabric, meaning every interface on every node in this fabric will inherit this property. The default value is 10 seconds.

On the Node



Options that are available on every node that is part of a fabric:

Node
Select the node which will be added to the fabric. Only nodes that currently are in the cluster will be shown.

IPv4
A unique IPv4 address used to generate the OpenFabric Network Entity Title (NET). Each node in the same fabric must have a different Router-ID, while a single node must use the same NET address across all fabrics (If this is not given Proxmox VE will automatically choose one and ensure that the configuration is valid).

IPv6
A unique IPv6 address used to generate the OpenFabric Network Entity Title (NET). Each node in the same fabric must have a different Router-ID, while a single node must use the same NET address across all fabrics. If a IPv4 and IPv6 address is configured, the IPv4 one will be used to derive the NET.



Warning
When using IPv6 addresses, the last 3 segments are used to generate the NET. Ensure these segments differ between nodes.

Interfaces
Specify the interfaces used to establish peering connections with other OpenFabric nodes. Preferably select interfaces without pre-assigned IP addresses, then configure addresses in the IPv4/IPv6 column if needed. A dummy "loopback" interface with the router-id is automatically created.

On The Interface

The following optional parameters can be configured per interface when enabling the additional columns:

IP
A IPv4 that should get automatically configured on this interface. Must include the netmask (e.g. /31)

IPv6
A IPv6 that should get automatically configured on this interface. Must include the netmask (e.g. /127).

Hello Multiplier
Defines how many missed hello packets constitute a failed connection. Higher values make the connection more resilient to packet loss but slow down failure detection. The default value is 10.



Warning
When you remove an interface with an entry in `/etc/network/interfaces` that has `manual` set, then the IP will not get removed on applying the SDN configuration.

12.10.6 OSPF

OSPF (Open Shortest Path First) is a widely-used link-state routing protocol that efficiently calculates the shortest path for routing traffic through IP networks.



Configuration options:

On the Fabric

IPv4 Prefix
: IPv4 CIDR network range (e.g., 192.0.2.0/24) used to verify that all router-IDs in the fabric are contained within this prefix.

Area
: This specifies the OSPF area identifier, which can be either a 32-bit signed integer or an IP address. Areas are a way to organize and structure OSPF networks hierarchically, with Area 0 (or 0.0.0.0) serving as the backbone area.

VRF Zone
: A simple zone with a dedicated VRF in which the fabric routes, see Fabrics in a Zone VRF. Without one, the fabric uses the default routing table.

Redistribute
: Optional list of source protocols whose routes are imported into OSPF. Each entry picks a source (`bgp`, `connected`, `kernel` or `static`) and may additionally reference a route map to filter or transform routes before they are advertised. Useful for example to leak BGP fabric routes into OSPF, or to advertise locally connected networks without configuring them per interface.

  On a node, all OSPF fabrics in the same VRF, including the default VRF, share their redistributions. Configure each source in just one of them. If several fabrics redistribute the same source, the first fabric in ID order sets its metric and route map.

On the Node



Options that are available on every node that is part of a fabric:

Node
: Select the node which will be added to the fabric. Only nodes that are currently in the cluster will be shown.

IPv4
: A unique Router-ID used to identify this router within the OSPF network. Each node in the same fabric must have a different Router-ID.

Interfaces
: Specify the interfaces used to establish peering connections with other OSPF nodes. Preferably select interfaces without pre-assigned IP addresses, then configure addresses in the IPv4 column if needed. A dummy "loopback" interface with the router-id is automatically created.

On The Interface

The following optional parameter can be configured per interface:

IP
: A IPv4 that should get automatically configured on this interface. Must include the netmask (e.g. /31)



Warning
When you remove an interface with an entry in `/etc/network/interfaces` that has `manual` set, then the IP will not get removed on applying the SDN configuration.

Note
The dummy interface will automatically be configured as `passive`. Every interface which doesn't have an ip-address configured will be treated as a `point-to-point` link.

12.10.7 WireGuard

WireGuard can be used for establishing a VPN between Proxmox VE nodes and / or external nodes. It does not provide dynamic routing by itself, but can be used in conjunction with dynamic routing protocols operating on layer 3 and above (OSPF, BGP) to provide a dynamically routed, encrypted transport, for example to carry EVPN or VXLAN traffic.

Note
In order to use WireGuard, the package `wireguard-tools` needs to be installed.

Configuration options:

On the Fabric

Name
This is the name of the WireGuard fabric and can be at most 8 characters long.

Persistent Keepalive
If this is set, then WireGuard will send an empty authenticated packet every N seconds to each configured peer. This can help keeping connections alive when using stateful firewalls or NAT.

On the Node

There are two types of nodes: internal and external. Internal nodes are Proxmox VE nodes, external nodes everything else. They are essentially reusable peer definitions that can be used across the whole cluster.

INTERNAL

Endpoint
This is the IP or hostname that other Proxmox VE nodes should use for connecting to this Proxmox VE node (e.g. `192.0.2.1` / `2001:db8::1`). This is used together with the *Listen Port* configured on the separate interfaces for constructing the actual endpoint. For instance, if a node has the IP `192.0.2.1` as an *Endpoint* and an interface `wg0` with *Listen Port* `51820` configured, then other nodes will use `192.0.2.1:51820` as endpoint for connecting to this node.

Allowed IPs
A comma-separated list of CIDRs (for example `198.51.100.0/24`, or `0.0.0.0/0` to tunnel all IPv4 traffic). When selecting this node as a peer on other nodes, the list is used as the `AllowedIPs` setting in the WireGuard peer configuration, that is, both the source filter for incoming traffic and the routing destination for outgoing traffic to this node.

EXTERNAL

Name
The name of the external node.

Public Key
The public key used by the external node.

Endpoint
The IP or hostname together with the port that other nodes use to connect to this external peer (e.g. `192.0.2.1:51820`). If an endpoint uses an IPv6 address, then the address needs to be enclosed in square brackets (e.g. `[2001:db8::1]:51820`).

Allowed IPs
A comma-separated list of CIDRs (for example `198.51.100.0/24`, or `0.0.0.0/0` to tunnel all IPv4 traffic). When selecting this node as a peer on other nodes, the list is used as the `AllowedIPs` setting in the WireGuard peer configuration, that is, both the source filter for incoming traffic and the routing destination for outgoing traffic to this node.

On The Interface

Name
The name of the network interface on the Linux host. One to eight characters that must start with an alphanumeric character; the remaining characters may be alphanumeric or hyphens.

IP
The IPv4 address in CIDR notation that should be configured on this interface (for example `198.51.100.1`

IPv6
The IPv6 address in CIDR notation that should be configured on this interface (for example `2001:db8::1/`

Listen Port
The listening port for this interface.

Peers
A list of peers that should be configured for that interface. All nodes that are part of the fabric can be selected as peers - the peer definition will be auto-generated from the configuration in the node.

MTU
The MTU of the interface. WireGuard adds up to 80 bytes, so set it 80 bytes below the MTU of the underlying network, for example 1420 for 1500. The web interface fills in 1420 for new interfaces. Without an MTU, `ifupdown2` uses its default, normally 1500. The minimum is 1280, as the kernel disables IPv6 on interfaces with a smaller MTU.

When defining an interface, Proxmox VE automatically generates a private key for it in `/etc/pve/priv/wg-ke` upon saving the interface, and stores the matching public key alongside the interface in the fabric configuration so it can be shown in the Web UI when editing the node. Removing an interface from a node removes the corresponding private key from `wg-keys.cfg` as part of the same API call.

The fabric automatically generates routes through the WireGuard interface for every peer's allowed IPs. For example, if interface wg0 has two peers with `198.51.100.0/24` and `203.0.113.0/24` as allowed IPs, then routes for both subnets are created. If the peer references the interface of a Proxmox VE node, that interface's configured IP address is additionally added as a host route to the allowed IPs (for example, a peer node configured with `192.0.2.10/24` gets `192.0.2.10/32` added).

On The Peer

Skip Route Generation
The fabric will autogenerate routes in the kernel routing table for all allowed IPs of a peer. By setting this option, no routes will be inserted into the kernel routing table.

12.10.8 Status Reporting

To see the status of a fabric on a node, select the fabric under the node in the resource tree. The information shown depends on the protocol of the fabric.

WireGuard

The tooltip of a WireGuard fabric in the resource tree shows it as *ok* if all of its interfaces on the node are up, use their configured public key and listen port, and have exactly the configured peers. A listen port of 0 is not checked. The check uses the applied configuration, not pending changes. It does not show whether the peers are reachable, see the *Status* of the neighbors for recent contact with them. On a node that is not part of the fabric, the interfaces and neighbors are empty.

Interfaces

Lists the WireGuard interfaces configured for the node, including missing ones, with the following properties:

Name
The name of the network interface on the host.

Type
wireguard if the interface on the node is a WireGuard interface, shown as - otherwise.

State
The state of the interface on the node:

- *up*: The interface exists and has the `UP` flag set.
- *down*: The interface exists, but does not have the `UP` flag set.
- *missing*: The interface does not exist on the node, for example because applying the configuration failed on the node.
- *unknown*: The interface exists, but its WireGuard state could not be read.
- *error*: The interface exists, but is not a WireGuard interface.

Public Key
The public key that can be used for communicating with the WireGuard instance on this interface. Shown as - if WireGuard does not report one, for example because the interface has no private key.

Listen Port
The port that can be used to reach this WireGuard instance. Shown as - if WireGuard does not report the interface.

Neighbors

Lists the peers that WireGuard reports for the interfaces of the node, with the following properties:

Name
The name of the peer in the fabric configuration. For a node of the cluster, its interface follows in parentheses. A peer without a name, shown as -, has a public key that is not configured for this interface.

Neighbor
The endpoint that is currently used to reach this peer (e.g. 192.0.2.1:51820). WireGuard updates the endpoint to the address it last received traffic from, so this can differ from the configured endpoint, for example if the peer is behind NAT. Shown as - if the endpoint is not known yet.

Interface
The interface that has this neighbor configured.

Status
How recently the neighbor completed a handshake:

- *active*: The latest handshake was less than 180 seconds ago, or within the longer interval allowed with persistent keepalive.
- *down*: Persistent keepalive is enabled, but there was no handshake within that interval. Check the connection to the neighbor.
- *idle*: Persistent keepalive is disabled and there was no recent handshake. This is normal for an unused tunnel. To monitor neighbors also without traffic, enable *Persistent Keepalive (s)* on the fabric.

Public Key
The public key of the neighbor.

Allowed IPs
A comma-separated list of CIDRs. On this interface, traffic to a destination is sent to the neighbor with the most specific matching prefix, and traffic from a source address is only accepted from that neighbor. Shown as - if WireGuard reports no allowed IPs for the neighbor.

Latest Handshake
The time of the latest handshake with this neighbor. A dash means that there was no handshake yet.

Persistent Keepalive (s)
The persistent keepalive interval that WireGuard currently uses for this neighbor, or *off* if it is disabled. This can differ from the configured interval, for example if applying the configuration failed.

Bytes transmitted
The amount of traffic that has been sent to this neighbor.

Bytes received
The amount of traffic that has been received from this neighbor.

12.11 Prefix Lists and Route Maps

Prefix lists and route maps let you control which routes are exchanged between the Proxmox VE nodes and their BGP, EVPN, OSPF, or OpenFabric peers, and modify attributes of those routes on the way in or out. The two work together: a prefix list classifies routes by their destination CIDR, while a route map chains match conditions and actions into an ordered policy.

If you have used `ip prefix-list` and `route-map` on FRR, Cisco IOS, or Juniper before, the Proxmox VE entities behave the same way. The Proxmox VE layer manages the configuration as cluster-wide entities under `/etc/pve/sdn/` and translates them to FRR `prefix-list` and `route-map` stanzas when applying the SDN configuration. The merged FRR configuration ends up in `/etc/frr/frr.conf` on each node; any node-local additions in `/etc/frr/frr.conf.local` are appended on top.

Like the rest of the SDN configuration, edits go to a pending state first and become active only after you apply changes in the main `SDN` panel.

12.11.1 Prefix Lists

A prefix list is an ordered, named list of entries that each match a single destination CIDR (or a range of prefix lengths within that CIDR) and either `permit` or `deny` it. FRR evaluates entries in order of their sequence number and stops at the first match; if no entry matches, the prefix list denies implicitly, same as plain FRR.

Prefix lists are managed under `Datacenter -> SDN -> Prefix Lists`. Each list has a name and contains one or more entries with the following properties:

Sequence Nr.
: Order in which the entry is evaluated within the list. Must be unique per list and at least `1`. If left empty on creation, Proxmox VE auto-assigns the next free sequence number using the convention `max + 5`, leaving room for later insertions.

Action
: Either `permit` or `deny`. There is an implicit `deny` at the end of each list.

Prefix
: Destination network in CIDR notation, for example `192.0.2.0/24` or `2001:db8::/32`. The prefix `0.0.0.0/0` (and `::/0`) is allowed and matches the default route.

Prefix >= (ge)
: Optional minimum prefix length. If set, the entry matches any subnet of `prefix` whose length is at least `ge`.

Prefix ⇐ (le)
: Optional maximum prefix length. If set, the entry matches any subnet of `prefix` whose length is at most `le`.

Without `le` or `ge` an entry matches the prefix exactly. With both set, it matches any subnet within the given length range. For example `10.0.0.0/8 ge 16 le 24` matches every /16 to /24 subnet inside

10.0.0.0/8. This is the standard FRR/Cisco semantics. Additional validation enforced by Proxmox VE: ge must not exceed le, neither may be smaller than the prefix's own length, and both must stay within the address family bound (/32 for IPv4, /128 for IPv6).

Note
The names only_default, only_default_v6, and loopbacks_ips are reserved. The BGP and EVPN controllers generate these automatically and they cannot be used as user-defined prefix list names.

12.11.2 Route Maps

A route map is an ordered list of entries that match incoming or outgoing routes against criteria, optionally modify attributes such as the metric or local preference, and either permit (forward the route, possibly modified) or deny (drop the route). FRR evaluates entries in order; the first match controls the action. Every route map implicitly has an otherwise empty deny as its last entry, denying all routes that did not match an entry explicitly.

Route maps are managed under Datacenter -> SDN -> Route Maps. Each entry has the following properties:

Order
Order in which the entry is evaluated, between 0 and 65535. Mandatory and must be unique within a route map. Leaving gaps between orders, for example assigning entries 10, 20, 30, leaves room for later insertions without renumbering.

Action
Either permit or deny. permit lets the route pass (after any set actions); deny drops it.

Match
One or more match conditions. Available keys are: route-type, vni, ip-address-prefix-list, ip6-address-prefix-list, ip-next-hop-prefix-list, ip6-next-hop-prefix-list ip-next-hop-address, ip6-next-hop-address, metric, local-preference, peer, and tag. The four *-prefix-list keys reference a prefix list by name. tag matches a 32-bit route tag attribute, the same value that the tag set action assigns; this lets one entry mark routes with a tag and a later entry (in the same or another map) act on them. All match conditions of an entry must be true for it to apply.

Set
One or more attributes to set when the entry matches. Available keys are ip-next-hop, ip-next-hop- ip-next-hop-unchanged, ip6-next-hop, ip6-next-hop-peer-address, ip6-next-ho local-preference, tag, weight, metric, and src. The metric value supports N, +N, -N (adjust), rtt, +rtt, -rtt, igp, and aigp. The tag value accepts an integer or the literal untagged.

Exit Action
Controls how evaluation continues after a match. Leave empty for the default behavior (terminate on match). on-match-next proceeds with the immediately following entry. on-match-goto

`<order>` jumps to the first entry whose order is greater than or equal to the given value. `continue <order>` jumps to the entry with exactly that order. All three correspond to the FRR `on-match` / `continue` directives.

Call
Optionally call another route map at the end of this entry's processing. This corresponds to the FRR `call` directive.

Note
A route map referenced by a controller cannot be deleted while it is still in use. Delete the reference from the controller first. The names `MAP_VTEP_IN`, `MAP_VTEP_OUT`, `correct_src`, and any name starting with `pve_` are reserved for internally generated route maps.

12.11.3 Where Prefix Lists and Route Maps Are Used

The BGP and EVPN controllers each take an `incoming` and an `outgoing` route map. Incoming maps run against routes received from a peer before installing them; outgoing maps run against routes before announcing them. Both fields are optional and selected from the route maps configured in the SDN.

The OSPF and OpenFabric fabrics take a `Route Filter` option that references a prefix list. When set, only routes whose destinations pass the prefix list are installed in the kernel routing table. Without an explicit filter, the fabric generates a default filter from the fabric's own `IPv4 Prefix` and `IPv6 Prefix` CIDRs (an FRR `access-list` permitting those networks); configure a route filter when you need a different policy, for example to allow a default route learned from a border node.

12.11.4 Examples

Allow only the IPv4 default route, for example as a route filter on a node that should learn just an upstream default:

```
# /etc/pve/sdn/prefix-lists.cfg

prefix-list: default-only
 entries action=permit,prefix=0.0.0.0/0,seq=10
```

Allow every subnet between /16 and /24 inside `10.0.0.0/8`, and deny anything else within the `10.0.0.0/8` block:

```
prefix-list: internal-subnets
 entries action=permit,prefix=10.0.0.0/8,ge=16,le=24,seq=10
 entries action=deny,prefix=10.0.0.0/8,le=32,seq=20
```

Outgoing BGP policy that lowers `local-preference` to 50 on routes matched by the `internal-subnets` prefix list, and otherwise leaves routes untouched. Each route map entry is its own section, with the order encoded as a suffix on the section ID:

```
# /etc/pve/sdn/route-maps.cfg

route-map-entry: bgp-out_10
 action permit
```

```
 match key=ip-address-prefix-list,value=internal-subnets
 set key=local-preference,value=50

route-map-entry: bgp-out_20
 action permit
```

The trailing `permit` entry with no match is the FRR pattern for "allow everything else"; without it the implicit deny at the end of the route map would drop all unmatched routes.

12.11.5 BGP

BGP (Border Gateway Protocol) can be used as an eBGP unnumbered fabric. Each node has its own Autonomous System Number (ASN) and peers with its neighbors over physical interfaces without requiring IP addresses on the fabric links.

Configuration options:

On the Fabric

IPv4 Prefix
IPv4 CIDR network range (e.g., 192.0.2.0/24) used to verify that all node IPv4 addresses (BGP router-IDs) are contained within this prefix.

IPv6 Prefix
IPv6 CIDR network range (e.g., 2001:db8::/64) used to verify that all node IPv6 addresses in the fabric are contained within this prefix.

BFD
Enable Bidirectional Forwarding Detection on all peering sessions in this fabric. BFD provides fast failure detection for links between nodes.

VRF Zone
A simple zone with a dedicated VRF in which the fabric routes, see Fabrics in a Zone VRF. Without one, the fabric uses the default routing table.

Route Filter
A prefix list applied to the fabric peer-group's inbound direction. When set, this prefix list replaces the implicit "must be within the fabric prefix" filter. Useful to widen the accepted range (e.g. accept additional non-fabric prefixes redistributed via the fabric) or to use a more expressive match. References a prefix list defined under SDN.

Incoming Route Map
A route map chained from the fabric peer-group's implicit inbound filter via FRR's `call` action. Only prefixes that have already passed the implicit prefix check (or the Route Filter override) reach this route map. Useful to transform or further narrow accepted routes (e.g. adjust community or local-preference), but cannot widen the accepted set. Use Route Filter to override the implicit filter. References a route map defined under SDN.

Outgoing Route Map
A route map applied to the fabric peer-group's outbound direction. Used to transform or filter what is announced to fabric neighbors. References a route map defined under SDN.

Redistribute
Which other-protocol routes the BGP router on each node should redistribute into the fabric. Supported sources are `connected`, `kernel`, `static`, and `ospf`. An optional per-source route map can be attached to shape the redistributed routes before they are announced.

Note
At least one of IPv4 Prefix or IPv6 Prefix must be configured.

On the Node

Options that are available on every node that is part of a fabric:

Node
Select the node which will be added to the fabric. Only nodes that are currently in the cluster will be shown.

ASN
BGP Autonomous System Number for this node. It is recommended to use a private ASN (64512-65534 for 16-bit, 4200000000-4294967294 for 32-bit).

IPv4
A unique IPv4 address for this node, also used as the BGP router-id. Required when the fabric has an IPv4 prefix configured; each node in the same fabric must have a different address.

IPv6
IPv6 address for this node. If only an IPv6 address is configured (without an IPv4 address), the BGP router-id is derived from it via a FNV-1a hash.

Interfaces
Specify the interfaces used to establish peering connections with other BGP nodes. These interfaces run BGP unnumbered (no IP address assignment needed). When a node IP is configured, a dummy "loopback" interface is automatically created with that IP.

Note
Unlike OSPF and OpenFabric, BGP unnumbered interfaces do not need IP addresses. Peering is established using IPv6 link-local addresses automatically.

Note
In an eBGP unnumbered fabric, directly peering nodes must have different ASNs for BGP sessions to establish.

Using BGP Fabrics with EVPN

When configuring an EVPN controller, a BGP fabric can be selected as the underlay instead of manually specifying peer addresses. The default configuration runs the EVPN overlay (VTEP) sessions as iBGP, using the EVPN controller's ASN for the router process. The per-node fabric ASN is automatically applied via `local-as` on the underlay neighbor group.

This means the EVPN controller ASN and the per-node fabric ASNs should be different. For example, with three nodes using ASNs 65001, 65002, and 65003 for the underlay, the EVPN controller could use ASN 65000 for the overlay.

Alternatively, setting BGP Mode to "external" on the EVPN controller runs the VTEP sessions as eBGP. The per-node fabric ASN is then used as the local ASN for the VTEP peer-group as well, so the VTEPs naturally peer with each other under different ASNs without needing a separate overlay ASN. The EVPN controller ASN is still used for auto-derived route-target values to keep them consistent across the fabric.

Note
Using a BGP fabric for an EVPN underlay requires each node to have an IPv4 address, since EVPN uses it as the VTEP address.

12.12 IPAM

IP Address Management (IPAM) tools manage the IP addresses of clients on the network. SDN in Proxmox VE uses IPAM for example to find free IP addresses for new guests.

A single IPAM instance can be associated with one or more zones.

12.12.1 PVE IPAM Plugin

The default built-in IPAM for your Proxmox VE cluster.

You can inspect the current status of the PVE IPAM Plugin via the IPAM panel in the SDN section of the datacenter configuration. This UI can be used to create, update and delete IP mappings. This is particularly convenient in conjunction with the DHCP feature.

If you are using DHCP, you can use the IPAM panel to create or edit leases for specific VMs, which enables you to change the IPs allocated via DHCP. When editing an IP of a VM that is using DHCP you must make sure to force the guest to acquire a new DHCP leases. This can usually be done by reloading the network stack of the guest or rebooting it.

12.12.2 NetBox IPAM Plugin

NetBox is an open-source IP Address Management (IPAM) and datacenter infrastructure management (DCIM) tool.

To integrate NetBox with Proxmox VE SDN, create an API token in NetBox as described here: https://docs.netbox.de
en/stable/integrations/rest-api/#tokens

The NetBox configuration properties are:

URL
The NetBox REST API endpoint: `http://yournetbox.domain.com/api`

Token
An API access token

Fingerprint
The SHA-256 fingerprint of the NetBox API. Can be retrieved with `openssl x509 -in /etc/ssl/ce -noout -fingerprint -sha256` when using the default certificate.

12.12.3 phpIPAM Plugin

In phpIPAM you need to create an "application" and add an API token with admin privileges to the application.

The phpIPAM configuration properties are:

URL
The REST-API endpoint: `http://phpipam.domain.com/api/<appname>/`

Token
An API access token

Section
An integer ID. Sections are a group of subnets in phpIPAM. Default installations use `sectionid=1` for customers.

12.13 DNS

The DNS plugin in Proxmox VE SDN is used to define a DNS API server for registration of your hostname and IP address. A DNS configuration is associated with one or more zones, to provide DNS registration for all the subnet IPs configured for a zone.

12.13.1 PowerDNS Plugin

https://doc.powerdns.com/authoritative/http-api/index.html

You need to enable the web server and the API in your PowerDNS config:

```
api=yes
api-key=arandomgeneratedstring
webserver=yes
webserver-port=8081
```

The PowerDNS configuration options are:

url
The REST API endpoint: http://yourpowerdnserver.domain.com:8081/api/v1/servers/localhost

key
An API access key

ttl
The default TTL for records

12.14 DHCP

The DHCP plugin in Proxmox VE SDN can be used to automatically deploy a DHCP server for a Zone. It provides DHCP for all Subnets in a Zone that have a DHCP range configured. Currently the only available backend plugin for DHCP is the dnsmasq plugin.

The DHCP plugin works by allocating an IP in the IPAM plugin configured in the Zone when adding a new network interface to a VM/CT. You can find more information on how to configure an IPAM in the respective section of our documentation.

When the VM starts, a mapping for the MAC address and IP gets created in the DHCP plugin of the zone. When the network interfaces is removed or the VM/CT are destroyed, then the entry in the IPAM and the DHCP server are deleted as well.

Note
Some features (adding/editing/removing IP mappings) are currently only available when using the PVE IPAM plugin.

12.14.1 Configuration

You can enable automatic DHCP for a zone in the Web UI via the Zones panel and enabling DHCP in the advanced options of a zone.

Note
Currently only Simple Zones have support for automatic DHCP

After automatic DHCP has been enabled for a Zone, DHCP Ranges need to be configured for the subnets in a Zone. In order to that, go to the Vnets panel and select the Subnet for which you want to configure DHCP ranges. In the edit dialogue you can configure DHCP ranges in the respective Tab. Alternatively you can set DHCP ranges for a Subnet via the following CLI command:

```
pvesh set /cluster/sdn/vnets/<vnet>/subnets/<subnet>
 -dhcp-range start-address=10.0.1.100,end-address=10.0.1.200
 -dhcp-range start-address=10.0.2.100,end-address=10.0.2.200
```

You also need to have a gateway configured for the subnet - otherwise automatic DHCP will not work.

The DHCP plugin will then allocate IPs in the IPAM only in the configured ranges.

Do not forget to follow the installation steps for the dnsmasq DHCP plugin as well.

12.14.2 Plugins

Dnsmasq Plugin

Currently this is the only DHCP plugin and therefore the plugin that gets used when you enable DHCP for a zone.

Installation

For installation see the DHCP IPAM section.

Configuration

The plugin will create a new systemd service for each zone that dnsmasq gets deployed to. The name for the service is `dnsmasq@<zone>`. The lifecycle of this service is managed by the DHCP plugin.

The plugin automatically generates the following configuration files in the folder `/etc/dnsmasq.d/<zone>`:

`00-default.conf`
: This contains the default global configuration for a dnsmasq instance.

`10-<zone>-<subnet_cidr>.conf`
: This file configures specific options for a subnet, such as the DNS server that should get configured via DHCP.

`10-<zone>-<subnet_cidr>.ranges.conf`
: This file configures the DHCP ranges for the dnsmasq instance.

`ethers`
: This file contains the MAC-address and IP mappings from the IPAM plugin. In order to override those mappings, please use the respective IPAM plugin rather than editing this file, as it will get overwritten by the dnsmasq plugin.

You must not edit any of the above files, since they are managed by the DHCP plugin. In order to customize the dnsmasq configuration you can create additional files (e.g. `90-custom.conf`) in the configuration folder - they will not get changed by the dnsmasq DHCP plugin.

Configuration files are read in order, so you can control the order of the configuration directives by naming your custom configuration files appropriately.

DHCP leases are stored in the file `/var/lib/misc/dnsmasq.<zone>.leases`.

When using the PVE IPAM plugin, you can update, create and delete DHCP leases. For more information please consult the documentation of the PVE IPAM plugin. Changing DHCP leases is currently not supported for the other IPAM plugins.

12.15 Firewall Integration

SDN integrates with the Proxmox VE firewall by automatically generating IPSets which can then be referenced in the source / destination fields of firewall rules. This happens automatically for VNets and IPAM entries.

12.15.1 VNets and Subnets

The firewall automatically generates the following IPSets in the SDN scope for every VNet:

vnet-all
Contains the CIDRs of all subnets in a VNet

vnet-gateway
Contains the IPs of the gateways of all subnets in a VNet

vnet-no-gateway
Contains the CIDRs of all subnets in a VNet, but excludes the gateways

vnet-dhcp
Contains all DHCP ranges configured in the subnets in a VNet

When making changes to your configuration, the IPSets update automatically, so you do not have to update your firewall rules when changing the configuration of your Subnets.

Simple Zone Example

Assuming the configuration below for a VNet and its contained subnets:

```
# /etc/pve/sdn/vnets.cfg

vnet: vnet0
        zone simple

# /etc/pve/sdn/subnets.cfg

subnet: simple-192.0.2.0-24
        vnet vnet0
        dhcp-range start-address=192.0.2.100,end-address=192.0.2.199
        gateway 192.0.2.1

subnet: simple-2001:db8::-64
        vnet vnet0
        dhcp-range start-address=2001:db8::1000,end-address=2001:db8::1999
        gateway 2001:db8::1
```

In this example we configured an IPv4 subnet in the VNet `vnet0`, with *192.0.2.0/24* as its IP Range, *192.0.2.1* as the gateway and the DHCP range is *192.0.2.100* - *192.0.2.199*.

Additionally we configured an IPv6 subnet with *2001:db8::/64* as the IP range, *2001:db8::1* as the gateway and a DHCP range of *2001:db8::1000* - *2001:db8::1999*.

The respective auto-generated IPsets for vnet0 would then contain the following elements:

vnet0-all

- *192.0.2.0/24*
- *2001:db8::/64*

vnet0-gateway

- *192.0.2.1*
- *2001:db8::1*

vnet0-no-gateway

- *192.0.2.0/24*
- *2001:db8::/64*
- *!192.0.2.1*
- *!2001:db8::1*

vnet0-dhcp

- *192.0.2.100 - 192.0.2.199*
- *2001:db8::1000 - 2001:db8::1999*

12.15.2 IPAM

If you are using the built-in PVE IPAM, then the firewall automatically generates an IPset for every guest that has entries in the IPAM. The respective IPset for a guest with ID 100 would be `guest-ipam-100`. It contains all IP addresses from all IPAM entries. So if guest 100 is member of multiple VNets, then the IPset would contain the IPs from **all** VNets.

When entries get added / updated / deleted, then the respective IPSets will be updated accordingly.



Warning
When removing all entries for a guest and there are firewall rules still referencing the auto-generated IPSet then the firewall will fail to update the ruleset, since it references a non-existing IPSet.

12.16 Examples

This section presents multiple configuration examples tailored for common SDN use cases. It aims to offer tangible implementations, providing additional details to enhance comprehension of the available configuration options.

12.16.1 Simple Zone Example

Simple zone networks create an isolated network for guests on a single host to connect to each other.

Tip
connection between guests are possible if all guests reside on a same host but cannot be reached on other nodes.

- Create a simple zone named `simple`.
- Add a VNet names `vnet1`.
- Create a Subnet with a gateway and the SNAT option enabled.
- This creates a network bridge `vnet1` on the node. Assign this bridge to the guests that shall join the network and configure an IP address.

The network interface configuration in two VMs may look like this which allows them to communicate via the 10.0.1.0/24 network.

```
allow-hotplug ens19
iface ens19 inet static
        address 10.0.1.14/24
```

```
allow-hotplug ens19
iface ens19 inet static
        address 10.0.1.15/24
```

12.16.2 Source NAT Example

If you want to allow outgoing connections for guests in the simple network zone the simple zone offers a Source NAT (SNAT) option.

Starting from the configuration above, Add a Subnet to the VNet `vnet1`, set a gateway IP and enable the SNAT option.

```
Subnet: 172.16.0.0/24
Gateway: 172.16.0.1
SNAT: checked
```

In the guests configure the static IP address inside the subnet's IP range.

The node itself will join this network with the Gateway IP *172.16.0.1* and function as the NAT gateway for guests within the subnet range.

12.16.3 VLAN Setup Example

When VMs on different nodes need to communicate through an isolated network, the VLAN zone allows network level isolation using VLAN tags.

Create a VLAN zone named `myvlanzone`:

```
ID: myvlanzone
Bridge: vmbr0
```

Create a VNet named `myvnet1` with VLAN tag 10 and the previously created `myvlanzone`.

```
ID: myvnet1
Zone: myvlanzone
Tag: 10
```

Apply the configuration through the main SDN panel, to create VNets locally on each node.

Create a Debian-based virtual machine (*vm1*) on node1, with a vNIC on `myvnet1`.

Use the following network configuration for this VM:

```
auto eth0
iface eth0 inet static
        address 10.0.3.100/24
```

Create a second virtual machine (*vm2*) on node2, with a vNIC on the same VNet `myvnet1` as vm1.

Use the following network configuration for this VM:

```
auto eth0
iface eth0 inet static
        address 10.0.3.101/24
```

Following this, you should be able to ping between both VMs using that network.

12.16.4 QinQ Setup Example

This example configures two QinQ zones and adds two VMs to each zone to demonstrate the additional layer of VLAN tags which allows the configuration of more isolated VLANs.

A typical use case for this configuration is a hosting provider that provides an isolated network to customers for VM communication but isolates the VMs from other customers.

Create a QinQ zone named `qinqzone1` with service VLAN 20

```
ID: qinqzone1
Bridge: vmbr0
Service VLAN: 20
```

Create another QinQ zone named `qinqzone2` with service VLAN 30

```
ID: qinqzone2
Bridge: vmbr0
Service VLAN: 30
```

Create a VNet named `myvnet1` with VLAN-ID 100 on the previously created `qinqzone1` zone.

```
ID: qinqvnet1
Zone: qinqzone1
Tag: 100
```

Create a `myvnet2` with VLAN-ID 100 on the `qinqzone2` zone.

```
ID: qinqvnet2
Zone: qinqzone2
Tag: 100
```

Apply the configuration on the main SDN web interface panel to create VNets locally on each node.

Create four Debian-bases virtual machines (vm1, vm2, vm3, vm4) and add network interfaces to vm1 and vm2 with bridge `qinqvnet1` and vm3 and vm4 with bridge `qinqvnet2`.

Inside the VM, configure the IP addresses of the interfaces, for example via `/etc/network/interfaces`:

```
auto eth0
iface eth0 inet static
        address 10.0.3.101/24
```

Configure all four VMs to have IP addresses from the *10.0.3.101* to *10.0.3.104* range.

Now you should be able to ping between the VMs *vm1* and *vm2*, as well as between *vm3* and *vm4*. However, neither of VMs *vm1* or *vm2* can ping VMs *vm3* or *vm4*, as they are on a different zone with a different service-VLAN.

12.16.5 VXLAN Setup Example

The example assumes a cluster with three nodes, with the node IP addresses 192.168.0.1, 192.168.0.2 and 192.168.0.3.

Create a VXLAN zone named `myvxlanzone` and add all IPs from the nodes to the peer address list. Use the default MTU of 1450 or configure accordingly.

```
ID: myvxlanzone
Peers Address List: 192.168.0.1,192.168.0.2,192.168.0.3
```

Create a VNet named `vxvnet1` using the VXLAN zone `myvxlanzone` created previously.

```
ID: vxvnet1
Zone: myvxlanzone
Tag: 100000
```

Apply the configuration on the main SDN web interface panel to create VNets locally on each nodes.

Create a Debian-based virtual machine (*vm1*) on node1, with a vNIC on `vxvnet1`.

Use the following network configuration for this VM (note the lower MTU).

```
auto eth0
iface eth0 inet static
        address 10.0.3.100/24
        mtu 1450
```

Create a second virtual machine (*vm2*) on node3, with a vNIC on the same VNet `vxvnet1` as vm1.

Use the following network configuration for this VM:

```
auto eth0
iface eth0 inet static
        address 10.0.3.101/24
        mtu 1450
```

Then, you should be able to ping between between *vm1* and *vm2*.

12.16.6 EVPN Setup Example

The example assumes a cluster with three nodes (node1, node2, node3) with IP addresses 192.168.0.1, 192.168.0.2 and 192.168.0.3.

Create an EVPN controller, using a private ASN and the above node addresses as peers.

```
ID: myevpnctl
ASN: 65000
Peers: 192.168.0.1,192.168.0.2,192.168.0.3
```

Create an EVPN zone named `myevpnzone`, assign the previously created EVPN-controller and define *node1* and *node2* as exit nodes.

```
ID: myevpnzone
VRF VXLAN Tag: 10000
Controller: myevpnctl
MTU: 1450
VNet MAC Address: 32:F4:05:FE:6C:0A
Exit Nodes: node1,node2
```

Create the first VNet named `myvnet1` using the EVPN zone `myevpnzone`.

```
ID: myvnet1
Zone: myevpnzone
Tag: 11000
```

Create a subnet on `myvnet1`:

```
Subnet: 10.0.1.0/24
Gateway: 10.0.1.1
```

Create the second VNet named `myvnet2` using the same EVPN zone `myevpnzone`.

```
ID: myvnet2
Zone: myevpnzone
Tag: 12000
```

Create a different subnet on `myvnet2``:

```
Subnet: 10.0.2.0/24
Gateway: 10.0.2.1
```

Apply the configuration from the main SDN web interface panel to create VNets locally on each node and generate the FRR configuration.

Create a Debian-based virtual machine (*vm1*) on node1, with a vNIC on `myvnet1`.

Use the following network configuration for *vm1*:

```
auto eth0
iface eth0 inet static
        address 10.0.1.100/24
        gateway 10.0.1.1
        mtu 1450
```

Create a second virtual machine (*vm2*) on node2, with a vNIC on the other VNet `myvnet2`.

Use the following network configuration for *vm2*:

```
auto eth0
iface eth0 inet static
        address 10.0.2.100/24
        gateway 10.0.2.1
        mtu 1450
```

Now you should be able to ping vm2 from vm1, and vm1 from vm2.

If you ping an external IP from *vm2* on the non-gateway node3, the packet will go to the configured *myvnet2* gateway, then will be routed to the exit nodes (*node1* or *node2*) and from there it will leave those nodes over the default gateway configured on node1 or node2.

Note
You need to add reverse routes for the *10.0.1.0/24* and *10.0.2.0/24* networks to node1 and node2 on your external gateway, so that the public network can reply back.

If you have configured an external BGP router, the BGP-EVPN routes (10.0.1.0/24 and 10.0.2.0/24 in this example), will be announced dynamically.

12.16.7 WireGuard Setup Example

The example assumes a 3-node Proxmox cluster (*sdn1*, *sdn2* and *sdn3*) with the IP addresses `192.0.2.1`, `192.0.2.2` and `192.0.2.3`, as well as an external WireGuard peer (*sdn-router*) with IP address `192.0.2.1`

In this example the Proxmox nodes as well as the external peer will be connected full-mesh via WireGuard in the `198.51.100.0/24` subnet and additionally the `203.0.113.0/24` subnet will be routed via the external WireGuard peer, `198.51.100.10`.

Set Up WireGuard Fabric



Click on *Datacenter* in the left-hand resource tree then navigate to *SDN* > *Fabrics* and create a new WireGuard fabric by clicking *Create* and selecting *WireGuard*.

Choose a name for the fabric, in this case *example* has been chosen.

Set Up WireGuard Interfaces



Each participating node requires a WireGuard interface. This can be configured by adding a new node with type *Internal* to the WireGuard fabric, selecting the respective node and then creating a new WireGuard interface.

On the node itself, two properties can be configured: *Endpoint* and *Allowed IPs*. *Endpoint* refers to the IP/hostname that will be used for connecting to this node, `192.0.2.1` in the case of sdn1. Since no additional subnets should be routed via this node in this example, leave the *Allowed IPs* field empty.

Create a new WireGuard interface, `wg0`, and configure the IP address that should be configured on the WireGuard interface, `198.51.100.1/24` in the case of sdn1. The default listen port is `51820`, but can be manually changed via the *Listen Port* field. A public/private key pair will be automatically created for every new WireGuard interface.

Set Up External Node



In order to add an external node, add another node to the WireGuard fabric, but select type *External* in the node creation dialog. Enter the public key of the interface of the external node, as well as the IP/hostname + port that can be used to reach this external peer (`192.0.2.10:51820` in this example). Add the IP of the node, `198.51.100.10/32`, as well as the `203.0.113.0/24` subnet to the allowed IPs field.

Set Up WireGuard Peerings



Now that all interfaces and external peers have been set up, they can be selected as peers in the WireGuard interface configuration. Add the nodes *sdn2* and *sdn3*, as well as *sdn-router* to the peers of the interface `wg0` on node *sdn1*:

This will generate the following `wg0.conf` file in `/etc/wireguard/proxmox`:

```
root@sdn1:~# cat /etc/wireguard/proxmox/wg0.conf
[Interface]
PrivateKey = EpP9R0kqNA1UjGGeDL0/y9Ok66G44dqa2ALYJ0jTWwQ=
ListenPort = 51820

[Peer]
PublicKey = xIlHE6ZA25Qnpa+HYT1un3fbjO5/0A9YUbbRmTyLWW4=
AllowedIPs = 198.51.100.10/32, 203.0.113.0/24
Endpoint = 192.0.2.10:51820

[Peer]
PublicKey = CKClJbQ42U1pQM8MqMGCa1IpZbNcqb+OJBxVWJHIrx4=
AllowedIPs = 198.51.100.2/32
Endpoint = 192.0.2.2:51820

[Peer]
PublicKey = gCXBt+n2VNBR6RiUmUxG3+15G0qnXUzsSxEQvmwGMkw=
AllowedIPs = 198.51.100.3/32
Endpoint = 192.0.2.3:51820
```

There is a `[Peer]` section for each selected peer. The IP configured on the WireGuard interfaces will be added to the *Allowed IPs* of a peer as well.

Verifying the Setup

Verify connectivity to the other participants in the WireGuard fabric by pinging:

```
root@sdn1:~# ping -c1 198.51.100.2
PING 198.51.100.2 (198.51.100.2) 56(84) bytes of data.
64 bytes from 198.51.100.2: icmp_seq=1 ttl=64 time=2.08 ms

--- 198.51.100.2 ping statistics ---
1 packets transmitted, 1 received, 0% packet loss, time 0ms
rtt min/avg/max/mdev = 2.083/2.083/2.083/0.000 ms


root@sdn1:~# ping -c1 198.51.100.3
PING 198.51.100.3 (198.51.100.3) 56(84) bytes of data.
64 bytes from 198.51.100.3: icmp_seq=1 ttl=64 time=2.26 ms

--- 198.51.100.3 ping statistics ---
1 packets transmitted, 1 received, 0% packet loss, time 0ms
rtt min/avg/max/mdev = 2.255/2.255/2.255/0.000 ms


root@sdn1:~# ping -c1 198.51.100.10
PING 198.51.100.10 (198.51.100.10) 56(84) bytes of data.
64 bytes from 198.51.100.10: icmp_seq=1 ttl=64 time=1.29 ms

--- 198.51.100.10 ping statistics ---
1 packets transmitted, 1 received, 0% packet loss, time 0ms
rtt min/avg/max/mdev = 1.286/1.286/1.286/0.000 ms
```

12.17 Notes

12.17.1 Multiple EVPN Exit Nodes

If you have multiple gateway nodes, you should disable the `rp_filter` (Strict Reverse Path Filter) option, because packets can arrive at one node but go out from another node.

Create a drop-in sysctl file `/etc/sysctl.d/99-rp-filter.conf`:

```
net.ipv4.conf.default.rp_filter=0
net.ipv4.conf.all.rp_filter=0
```

12.17.2 VXLAN IPSEC Encryption

To add IPSEC encryption on top of a VXLAN, this example shows how to use `strongswan`.

You`ll need to reduce the *MTU* by additional 60 bytes for IPv4 or 80 bytes for IPv6 to handle encryption.

So with default real 1500 MTU, you need to use a MTU of 1370 (1370 + 80 (IPSEC) + 50 (VXLAN) == 1500).

Install strongswan on the host.

```
apt install strongswan
```

Add configuration to `/etc/ipsec.conf`. We only need to encrypt traffic from the VXLAN UDP port *4789*.

```
conn %default
    ike=aes256-sha1-modp1024!  # the fastest, but reasonably secure cipher  ↩
       on modern HW
    esp=aes256-sha1!
    leftfirewall=yes           # this is necessary when using Proxmox VE  ↩
       firewall rules

conn output
    rightsubnet=%dynamic[udp/4789]
    right=%any
    type=transport
    authby=psk
    auto=route

conn input
    leftsubnet=%dynamic[udp/4789]
    type=transport
    authby=psk
    auto=route
```

Generate a pre-shared key with:

```
openssl rand -base64 128
```

and add the key to `/etc/ipsec.secrets`, so that the file contents looks like:

```
: PSK <generatedbase64key>
```

Copy the PSK and the configuration to all nodes participating in the VXLAN network.

Chapter 13

Proxmox VE Firewall

Proxmox VE Firewall provides an easy way to protect your IT infrastructure. You can setup firewall rules for all hosts inside a cluster, or define rules for virtual machines and containers. Features like firewall macros, security groups, IP sets and aliases help to make that task easier.

While all configuration is stored on the cluster file system, the `iptables`-based firewall service runs on each cluster node, and thus provides full isolation between virtual machines. The distributed nature of this system also provides much higher bandwidth than a central firewall solution.

The firewall has full support for IPv4 and IPv6. IPv6 support is fully transparent, and we filter traffic for both protocols by default. So there is no need to maintain a different set of rules for IPv6.

13.1 Directions & Zones

The Proxmox VE firewall groups the network into multiple logical zones. You can define rules for each zone independently. Depending on the zone, you can define rules for incoming, outgoing or forwarded traffic.

13.1.1 Directions

There are 3 directions that you can choose from when defining rules for a zone:

In
Traffic that is arriving in a zone.

Out
Traffic that is leaving a zone.

Forward
Traffic that is passing through a zone. In the host zone this can be routed traffic (when the host is acting as a gateway or performing NAT). At a VNet-level this affects all traffic that is passing by a VNet, including traffic from/to bridged network interfaces.



Important
Creating rules for forwarded traffic is currently only possible when using the new nftables-based proxmox-firewall. Any forward rules will be ignored by the stock `pve-firewall` and have no effect!

13.1.2 Zones

There are 3 different zones that you can define firewall rules for:

Host
Traffic going from/to a host, or traffic that is forwarded by a host. You can define rules for this zone either at the datacenter level or at the host level. Rules at host level take precedence over rules at datacenter level.

VM
Traffic going from/to a VM or CT. You cannot define rules for forwarded traffic, only for incoming / outgoing traffic.

VNet
Traffic passing through a SDN VNet, either from guest to guest or from host to guest and vice-versa. Since this traffic is always forwarded traffic, it is only possible to create rules with direction forward.



Important
Creating rules on a VNet-level is currently only possible when using the new nftables-based proxmox-firewall. Any VNet-level rules will be ignored by the stock `pve-firewall` and have no effect!

13.2 Configuration Files

All firewall related configuration is stored on the proxmox cluster file system. So those files are automatically distributed to all cluster nodes, and the `pve-firewall` service updates the underlying `iptables` rules automatically on changes.

You can configure anything using the GUI (i.e. **Datacenter** → **Firewall**, or on a **Node** → **Firewall**), or you can edit the configuration files directly using your preferred editor.

Firewall configuration files contain sections of key-value pairs. Lines beginning with a `#` and blank lines are considered comments. Sections start with a header line containing the section name enclosed in `[` and `]`.

13.2.1 Cluster Wide Setup

The cluster-wide firewall configuration is stored at:

`/etc/pve/firewall/cluster.fw`

The configuration can contain the following sections:

[OPTIONS]
This is used to set cluster-wide firewall options.

ebtables: <boolean> (*default =* 1)
Enable ebtables rules cluster wide.

enable: <integer> (0 - N) (*default =* 0)
Enable or disable the firewall cluster wide.

log_ratelimit: [enable=]<1|0> [,burst=<integer>] [,rate=<rate>]
Log ratelimiting settings

burst=<integer> (0 - 10000) (*default =* 5)
Initial burst of packages which will always get logged before the rate is applied

enable=<boolean> (*default =* 1)
Enable or disable log rate limiting

rate=<rate> (*default =* 1/second)
Frequency with which the burst bucket gets refilled

policy_forward: <ACCEPT | DROP>
Forward policy.

policy_in: <ACCEPT | DROP | REJECT>
Input policy.

policy_out: <ACCEPT | DROP | REJECT>
Output policy.

[RULES]
This sections contains cluster-wide firewall rules for all nodes.

[IPSET <name>]
Cluster wide IP set definitions.

[GROUP <name>]
Cluster wide security group definitions.

[ALIASES]
Cluster wide Alias definitions.

Enabling the Firewall

The firewall is completely disabled by default, so you need to set the enable option here:

```
[OPTIONS]
# enable firewall (cluster-wide setting, default is disabled)
enable: 1
```



Important
If you enable the firewall, traffic to all hosts will be blocked by default - with some exceptions for traffic coming from the local network to the WebUI, SSH and other important services. A full list of the default firewall rules can be found at xref:pve_firewall_default_rules.

Should you have other services running which communicate over the network, you will have to allow them seperately. For some common services there are `macros` available.

If you want to administrate your Proxmox VE hosts from remote, you need to create rules to allow traffic from those remote IPs to the web GUI (port 8006). You may also want to allow ssh (port 22), and maybe SPICE (port 3128).

Tip
Please open a SSH connection to one of your Proxmox VE hosts before enabling the firewall. That way you still have access to the host if something goes wrong .

To simplify that task, you can instead create an IPSet called “management”, and add all remote IPs there. This creates all required firewall rules to access the GUI from remote.

13.2.2 Host Specific Configuration

Host related configuration is read from:

`/etc/pve/nodes/<nodename>/host.fw`

This is useful if you want to overwrite rules from `cluster.fw` config. You can also increase log verbosity, and set netfilter related options. The configuration can contain the following sections:

`[OPTIONS]`
This is used to set host related firewall options.

`enable`: <boolean> (*default* = 1)
Enable host firewall rules.

`log_level_forward`: <alert | crit | debug | emerg | err | info | nolog | notice | warning>
Log level for forwarded traffic.

log_level_in: **<alert | crit | debug | emerg | err | info | nolog | notice | warning>**
Log level for incoming traffic.

log_level_out: **<alert | crit | debug | emerg | err | info | nolog | notice | warning>**
Log level for outgoing traffic.

log_nf_conntrack: **<boolean>** (***default =*** 0)
Enable logging of conntrack information.

ndp: **<boolean>** (***default =*** 1)
Enable NDP (Neighbor Discovery Protocol).

nf_conntrack_allow_invalid: **<boolean>** (***default =*** 0)
Allow invalid packets on connection tracking.

nf_conntrack_helpers: **<string>** (***default =*** ``)
Enable conntrack helpers for specific protocols. Supported protocols: amanda, ftp, irc, netbios-ns, pptp, sane, sip, snmp, tftp

nf_conntrack_max: **<integer> (32768 - N)** (***default =*** 262144)
Maximum number of tracked connections.

nf_conntrack_tcp_timeout_established: **<integer> (7875 - N)** (***default =*** 432000)
Conntrack established timeout.

nf_conntrack_tcp_timeout_syn_recv: **<integer> (30 - 60)** (***default =*** 60)
Conntrack syn recv timeout.

nftables: **<boolean>** (***default =*** 0)
Enable nftables based firewall.

nosmurfs: **<boolean>**
Enable SMURFS filter.

protection_synflood: **<boolean>** (***default =*** 0)
Enable synflood protection

protection_synflood_burst: **<integer> (-N - 1000000)** (***default =*** 1000)
Synflood protection rate burst by ip src.

protection_synflood_rate: **<integer> (-N - 1000000)** (***default =*** 200)
Synflood protection rate syn/sec by ip src.

smurf_log_level: <alert | crit | debug | emerg | err | info | nolog | notice | warning>
Log level for SMURFS filter.

tcp_flags_log_level: <alert | crit | debug | emerg | err | info | nolog | notice | warning>
Log level for illegal tcp flags filter.

tcpflags: <boolean> (*default =* 0)
Filter illegal combinations of TCP flags.

[RULES]
This sections contains host specific firewall rules.

13.2.3 VM/Container Configuration

VM firewall configuration is read from:

`/etc/pve/firewall/<VMID>.fw`

and contains the following data:

[OPTIONS]
This is used to set VM/Container related firewall options.

dhcp: <boolean> (*default =* 0)
Enable DHCP.

enable: <boolean> (*default =* 0)
Enable/disable firewall rules.

ipfilter: <boolean>
Enable default IP filters. This is equivalent to adding an empty ipfilter-net<id> ipset for every interface. Such ipsets implicitly contain sane default restrictions such as restricting IPv6 link local addresses to the one derived from the interface's MAC address. For containers the configured IP addresses will be implicitly added.

log_level_in: <alert | crit | debug | emerg | err | info | nolog | notice | warning>
Log level for incoming traffic.

log_level_out: <alert | crit | debug | emerg | err | info | nolog | notice | warning>
Log level for outgoing traffic.

macfilter: <boolean> (*default* = 1)
Enable/disable MAC address filter.

ndp: <boolean> (*default* = 1)
Enable NDP (Neighbor Discovery Protocol).

policy_in: <ACCEPT | DROP | REJECT>
Input policy.

policy_out: <ACCEPT | DROP | REJECT>
Output policy.

radv: <boolean>
Allow sending Router Advertisement.

[RULES]
This sections contains VM/Container firewall rules.

[IPSET <name>]
IP set definitions.

[ALIASES]
IP Alias definitions.

Enabling the Firewall for VMs and Containers

Each virtual network device has its own firewall enable flag. So you can selectively enable the firewall for each interface. This is required in addition to the general firewall `enable` option.

13.2.4 VNet Configuration

VNet related configuration is read from:

`/etc/pve/sdn/firewall/<vnet_name>.fw`

This can be used for setting firewall configuration globally on a VNet level, without having to set firewall rules for each VM inside the VNet separately. It can only contain rules for the `FORWARD` direction, since there is no notion of incoming or outgoing traffic. This affects all traffic travelling from one bridge port to another, including the host interface.



Warning
This feature is currently only available for the new nftables-based proxmox-firewall

Since traffic passing the `FORWARD` chain is bi-directional, you need to create rules for both directions if you want traffic to pass both ways. For instance if HTTP traffic for a specific host should be allowed, you would need to create the following rules:

```
FORWARD ACCEPT -dest 10.0.0.1 -dport 80
FORWARD ACCEPT -source 10.0.0.1 -sport 80
```

[OPTIONS]
This is used to set VNet related firewall options.

enable: <boolean> (*default =* 0)
Enable/disable firewall rules.

log_level_forward: <alert | crit | debug | emerg | err | info | nolog | notice | warning>
Log level for forwarded traffic.

policy_forward: <ACCEPT | DROP>
Forward policy.

[RULES]
This section contains VNet specific firewall rules.

13.3 Firewall Rules

Firewall rules consists of a direction (`IN`, `OUT` or `FORWARD`) and an action (`ACCEPT`, `DENY`, `REJECT`). You can also specify a macro name. Macros contain predefined sets of rules and options. Rules can be disabled by prefixing them with `|`.

Firewall rules syntax

```
[RULES]

DIRECTION ACTION [OPTIONS]
|DIRECTION ACTION [OPTIONS] # disabled rule

DIRECTION MACRO(ACTION) [OPTIONS] # use predefined macro
```

The following options can be used to refine rule matches.

--dest <string>
Restrict packet destination address. This can refer to a single IP address, an IP set (*+ipsetname*) or an IP alias definition. You can also specify an address range like *20.34.101.207-201.3.9.99*, or a list of IP addresses and networks (entries are separated by comma). Please do not mix IPv4 and IPv6 addresses inside such lists.

--dport <string>
Restrict TCP/UDP destination port. You can use service names or simple numbers (0-65535), as defined in */etc/services*. Port ranges can be specified with *\d+:\d+*, for example *80:85*, and you can use comma separated list to match several ports or ranges.

--icmp-type <string>
Specify icmp-type. Only valid if proto equals *icmp* or *icmpv6*/*ipv6-icmp*.

--iface <string>
Network interface name. You have to use network configuration key names for VMs and containers (*net\d+*). Host related rules can use arbitrary strings.

--log <alert | crit | debug | emerg | err | info | nolog | notice | warning>
Log level for firewall rule.

--proto <string>
IP protocol. You can use protocol names (*tcp*/*udp*) or simple numbers, as defined in */etc/protocols*.

--source <string>
Restrict packet source address. This can refer to a single IP address, an IP set (*+ipsetname*) or an IP alias definition. You can also specify an address range like *20.34.101.207-201.3.9.99*, or a list of IP addresses and networks (entries are separated by comma). Please do not mix IPv4 and IPv6 addresses inside such lists.

--sport <string>
Restrict TCP/UDP source port. You can use service names or simple numbers (0-65535), as defined in */etc/services*. Port ranges can be specified with *\d+:\d+*, for example *80:85*, and you can use comma separated list to match several ports or ranges.

Here are some examples:

```
[RULES]
IN SSH(ACCEPT) -i net0
IN SSH(ACCEPT) -i net0 # a comment
IN SSH(ACCEPT) -i net0 -source 192.168.2.192 # only allow SSH from ↩
   192.168.2.192
IN SSH(ACCEPT) -i net0 -source 10.0.0.1-10.0.0.10 # accept SSH for IP range
IN SSH(ACCEPT) -i net0 -source 10.0.0.1,10.0.0.2,10.0.0.3 #accept ssh for ↩
   IP list
IN SSH(ACCEPT) -i net0 -source +mynetgroup # accept ssh for ipset ↩
   mynetgroup
IN SSH(ACCEPT) -i net0 -source myserveralias #accept ssh for alias ↩
   myserveralias

|IN SSH(ACCEPT) -i net0 # disabled rule

IN  DROP # drop all incoming packages
OUT ACCEPT # accept all outgoing packages
```

13.4 Security Groups

A security group is a collection of rules, defined at cluster level, which can be used in all VMs' rules. For example you can define a group named "webserver" with rules to open the *http* and *https* ports.

```
# /etc/pve/firewall/cluster.fw

[group webserver]
IN  ACCEPT -p tcp -dport 80
IN  ACCEPT -p tcp -dport 443
```

Then, you can add this group to a VM's firewall

```
# /etc/pve/firewall/<VMID>.fw

[RULES]
GROUP webserver
```

13.5 IP Aliases

IP Aliases allow you to associate IP addresses of networks with a name. You can then refer to those names:

- inside IP set definitions
- in `source` and `dest` properties of firewall rules

13.5.1 Standard IP Alias `local_network`

This alias is automatically defined. Please use the following command to see assigned values:

```
# pve-firewall localnet
local hostname: example
local IP address: 192.168.2.100
network auto detect: 192.168.0.0/20
using detected local_network: 192.168.0.0/20
```

The firewall automatically sets up rules to allow everything needed for cluster communication (corosync, API, SSH) using this alias.

The user can overwrite these values in the `cluster.fw` alias section. If you use a single host on a public network, it is better to explicitly assign the local IP address

```
#  /etc/pve/firewall/cluster.fw
[ALIASES]
local_network 1.2.3.4 # use the single IP address
```

13.6 IP Sets

IP sets can be used to define groups of networks and hosts. You can refer to them with '+name` in the firewall rules' `source` and `dest` properties.

The following example allows HTTP traffic from the `management` IP set.

```
IN HTTP(ACCEPT) -source +management
```

13.6.1 Standard IP set `management`

This IP set applies only to host firewalls (not VM firewalls). Those IPs are allowed to do normal management tasks (Proxmox VE GUI, VNC, SPICE, SSH).

The local cluster network is automatically added to this IP set (alias `cluster_network`), to enable inter-host cluster communication. (multicast,ssh,...)

```
# /etc/pve/firewall/cluster.fw

[IPSET management]
192.168.2.10
192.168.2.10/24
```

13.6.2 Standard IP set `blacklist`

Traffic from these IPs is dropped by every host's and VM's firewall.

```
# /etc/pve/firewall/cluster.fw

[IPSET blacklist]
77.240.159.182
213.87.123.0/24
```

13.6.3 Standard IP set `ipfilter-net*`

These filters belong to a VM's network interface and are mainly used to prevent IP spoofing. If such a set exists for an interface then any outgoing traffic with a source IP not matching its interface's corresponding ipfilter set will be dropped.

For containers with configured IP addresses these sets, if they exist (or are activated via the general `IP Filter` option in the VM's firewall's **options** tab), implicitly contain the associated IP addresses.

For both virtual machines and containers they also implicitly contain the standard MAC-derived IPv6 link-local address in order to allow the neighbor discovery protocol to work.

```
/etc/pve/firewall/<VMID>.fw

[IPSET ipfilter-net0] # only allow specified IPs on net0
192.168.2.10
```

13.7 Services and Commands

The firewall runs two service daemons on each node:

- pvefw-logger: NFLOG daemon (ulogd replacement).
- pve-firewall: updates iptables rules

There is also a CLI command named `pve-firewall`, which can be used to start and stop the firewall service:

```
# pve-firewall start
# pve-firewall stop
```

To get the status use:

```
# pve-firewall status
```

The above command reads and compiles all firewall rules, so you will see warnings if your firewall configuration contains any errors.

If you want to see the generated iptables rules you can use:

```
# iptables-save
```

13.8 Default firewall rules

The following traffic is filtered by the default firewall configuration:

13.8.1 Datacenter incoming/outgoing DROP/REJECT

If the input or output policy for the firewall is set to DROP or REJECT, the following traffic is still allowed for all Proxmox VE hosts in the cluster:

- traffic over the loopback interface
- already established connections
- traffic using the IGMP protocol
- TCP traffic from management hosts to port 8006 in order to allow access to the web interface
- TCP traffic from management hosts to the port range 5900 to 5999 allowing traffic for the VNC web console
- TCP traffic from management hosts to port 3128 for connections to the SPICE proxy
- TCP traffic from management hosts to port 22 to allow ssh access
- TCP traffic from management hots to the port range 60000 to 60050 allowing traffic for migrations
- UDP traffic in the cluster network to ports 5405-5412 for corosync

- UDP multicast traffic in the cluster network
- ICMP traffic type 3 (Destination Unreachable), 4 (congestion control) or 11 (Time Exceeded)

The following traffic is dropped, but not logged even with logging enabled:

- TCP connections with invalid connection state
- Broadcast, multicast and anycast traffic not related to corosync, i.e., not coming through ports 5405-5412
- TCP traffic to port 43
- UDP traffic to ports 135 and 445
- UDP traffic to the port range 137 to 139
- UDP traffic form source port 137 to port range 1024 to 65535
- UDP traffic to port 1900
- TCP traffic to port 135, 139 and 445
- UDP traffic originating from source port 53

The rest of the traffic is dropped or rejected, respectively, and also logged. This may vary depending on the additional options enabled in **Firewall** → **Options**, such as NDP, SMURFS and TCP flag filtering.

Please inspect the output of the

```
# iptables-save
```

system command to see the firewall chains and rules active on your system. This output is also included in a `System Report`, accessible over a node's subscription tab in the web GUI, or through the `pvereport` command-line tool.

13.8.2 VM/CT incoming/outgoing DROP/REJECT

This drops or rejects all the traffic to the VMs, with some exceptions for DHCP, NDP, Router Advertisement, MAC and IP filtering depending on the set configuration. The same rules for dropping/rejecting packets are inherited from the datacenter, while the exceptions for accepted incoming/outgoing traffic of the host do not apply.

Again, you can use iptables-save (see above) to inspect all rules and chains applied.

13.9 Logging of firewall rules

By default, all logging of traffic filtered by the firewall rules is disabled. To enable logging, the `loglevel` for incoming and/or outgoing traffic has to be set in **Firewall** → **Options**. This can be done for the host as well as for the VM/CT firewall individually. By this, logging of Proxmox VE's standard firewall rules is enabled and the output can be observed in **Firewall** → **Log**. Further, only some dropped or rejected packets are logged for the standard rules (see default firewall rules).

`loglevel` does not affect how much of the filtered traffic is logged. It changes a `LOGID` appended as prefix to the log output for easier filtering and post-processing.

`loglevel` is one of the following flags:

loglevel	LOGID
nolog	—
emerg	0
alert	1
crit	2
err	3
warning	4
notice	5
info	6
debug	7

A typical firewall log output looks like this:

```
VMID LOGID CHAIN TIMESTAMP POLICY: PACKET_DETAILS
```

In case of the host firewall, `VMID` is equal to 0.

13.9.1 Logging of user defined firewall rules

In order to log packets filtered by user-defined firewall rules, it is possible to set a log-level parameter for each rule individually. This allows to log in a fine grained manner and independent of the log-level defined for the standard rules in **Firewall** → **Options**.

While the `loglevel` for each individual rule can be defined or changed easily in the web UI during creation or modification of the rule, it is possible to set this also via the corresponding `pvesh` API calls.

Further, the log-level can also be set via the firewall configuration file by appending a `-log <loglevel>` to the selected rule (see possible log-levels).

For example, the following two are identical:

```
IN REJECT -p icmp -log nolog
IN REJECT -p icmp
```

whereas

```
IN REJECT -p icmp -log debug
```

produces a log output flagged with the `debug` level.

13.10 Tips and Tricks

13.10.1 How to allow FTP

FTP is an old style protocol which uses port 21 and several other dynamic ports. So you need a rule to accept port 21. In addition, you need to load the `ip_conntrack_ftp` module. So please run:

```
modprobe ip_conntrack_ftp
```

and add `ip_conntrack_ftp` to `/etc/modules` (so that it works after a reboot).

13.10.2 Suricata IPS integration

If you want to use the Suricata IPS (Intrusion Prevention System), it's possible.

Packets will be forwarded to the IPS only after the firewall ACCEPTed them.

Rejected/Dropped firewall packets don't go to the IPS.

Install suricata on proxmox host:

```
# apt-get install suricata
# modprobe nfnetlink_queue
```

Don't forget to add `nfnetlink_queue` to `/etc/modules` for next reboot.

Then, enable IPS for a specific VM with:

```
# /etc/pve/firewall/<VMID>.fw

[OPTIONS]
ips: 1
ips_queues: 0
```

`ips_queues` will bind a specific cpu queue for this VM.

Available queues are defined in

```
# /etc/default/suricata
NFQUEUE=0
```

13.11 Notes on IPv6

The firewall contains a few IPv6 specific options. One thing to note is that IPv6 does not use the ARP protocol anymore, and instead uses NDP (Neighbor Discovery Protocol) which works on IP level and thus needs IP addresses to succeed. For this purpose link-local addresses derived from the interface's MAC address are used. By default the `NDP` option is enabled on both host and VM level to allow neighbor discovery (NDP) packets to be sent and received.

Beside neighbor discovery NDP is also used for a couple of other things, like auto-configuration and advertising routers.

By default VMs are allowed to send out router solicitation messages (to query for a router), and to receive router advertisement packets. This allows them to use stateless auto configuration. On the other hand VMs cannot advertise themselves as routers unless the "Allow Router Advertisement" (`radv: 1`) option is set.

As for the link local addresses required for NDP, there's also an "IP Filter" (`ipfilter: 1`) option which can be enabled which has the same effect as adding an `ipfilter-net*` ipset for each of the VM's network interfaces containing the corresponding link local addresses. (See the Standard IP set ipfilter-net* section for details.)

13.12 Ports used by Proxmox VE

- Web interface: 8006 (TCP, HTTP/1.1 over TLS)

- VNC Web console: 5900-5999 (TCP, WebSocket)
- SPICE proxy: 3128 (TCP)
- sshd (used for cluster actions): 22 (TCP)
- rpcbind: 111 (UDP)
- sendmail: 25 (TCP, outgoing)
- corosync cluster traffic: 5405-5412 UDP
- live migration (VM memory and local-disk data): 60000-60050 (TCP)

13.13 nftables

As an alternative to `pve-firewall` we offer `proxmox-firewall`, which is an implementation of the Proxmox VE firewall based on the newer nftables rather than iptables.

This implementation uses the same configuration files and configuration format, so you can use your old configuration when switching. It provides the exact same functionality with a few exceptions:

- When using Linux bridges, no additional firewall bridges (fwbrX) will be created. Guest interfaces using OVS bridges will still have firewall bridges.
- REJECT is currently not possible for guest traffic (traffic will instead be dropped).
- Using the `NDP`, `Router Advertisement` or `DHCP` options will **always** create firewall rules, irregardless of your default policy.
- firewall rules for guests are evaluated even for connections that have conntrack table entries.

13.13.1 Installation and Usage

Install the `proxmox-firewall` package:

```
apt install proxmox-firewall
```

Enable the nftables backend via the Web UI on your hosts (Host > Firewall > Options > nftables), or by enabling it in the configuration file for your hosts (`/etc/pve/nodes/<node_name>/host.fw`):

```
[OPTIONS]

nftables: 1
```

Note
After enabling/disabling `proxmox-firewall`, all running VMs and containers need to be restarted for the old/new firewall to work properly.

After setting the `nftables` configuration key, the new `proxmox-firewall` service will take over. You can check if the new service is working by checking the systemctl status of `proxmox-firewall`:

```
systemctl status proxmox-firewall
```

You can also examine the generated ruleset. You can find more information about this in the section Helpful Commands. You should also check whether `pve-firewall` is no longer generating iptables rules, you can find the respective commands in the Services and Commands section.

Switching back to the old firewall can be done by simply setting the configuration value back to 0 / No.

13.13.2 Usage

`proxmox-firewall` will create two tables that are managed by the `proxmox-firewall` service: `proxmox-firewall` and `proxmox-firewall-guests`. If you want to create custom rules that live outside the Proxmox VE firewall configuration you can create your own tables to manage your custom firewall rules. `proxmox-firewall` will only touch the tables it generates, so you can easily extend and modify the behavior of the `proxmox-firewall` by adding your own tables.

Instead of using the `pve-firewall` command, the nftables-based firewall uses `proxmox-firewall`. It is a systemd service, so you can start and stop it via `systemctl`:

```
systemctl start proxmox-firewall
systemctl stop proxmox-firewall
```

Stopping the firewall service will remove all generated rules.

To query the status of the firewall, you can query the status of the systemctl service:

```
systemctl status proxmox-firewall
```

13.13.3 Helpful Commands

You can check the generated ruleset via the following command:

```
nft list ruleset
```

If you want to debug `proxmox-firewall` you can dump the commands generated by the firewall via the `compile` subcommand. Additionally, setting the PVE_LOG environment variable will print log output to STDERR, which can be useful for debugging issues during the generation of the nftables ruleset:

```
PVE_LOG=trace /usr/libexec/proxmox/proxmox-firewall compile > firewall.json
```

The nftables ruleset consists of the skeleton ruleset, that is included in the proxmox-firewall binary, as well as the rules generated from the firewall configuration. You can obtain the base ruleset via the `skeleton` subcommand:

```
/usr/libexec/proxmox/proxmox-firewall skeleton
```

The output of both commands can be piped directly to the `nft` executable. The following commands will re-create the whole nftables ruleset from scratch:

```
/usr/libexec/proxmox/proxmox-firewall skeleton | nft -f -
/usr/libexec/proxmox/proxmox-firewall compile | nft -j -f -
```

You can also edit the systemctl service if you want to have detailed output for your firewall daemon while it is running:

```
systemctl edit proxmox-firewall
```

Then you need to add the override for the `PVE_LOG` environment variable:

```
[Service]
Environment="PVE_LOG=trace"
```

This will generate a large amount of logs very quickly, so only use this for debugging purposes. Other, less verbose, log levels are `info` and `debug`.

It can be helpful to trace packet flow through the different chains in order to debug firewall rules. This can be achieved by setting `nftrace` to 1 for packets that you want to track. It is advisable that you do not set this flag for **all** packets, in the example below we only examine ICMP packets.

```
#!/usr/sbin/nft -f
table bridge tracebridge
delete table bridge tracebridge

table bridge tracebridge {
    chain trace {
        meta l4proto icmp meta nftrace set 1
    }

    chain prerouting {
        type filter hook prerouting priority -350; policy accept;
        jump trace
    }

    chain postrouting {
        type filter hook postrouting priority -350; policy accept;
        jump trace
    }
}
```

Saving this file, making it executable, and then running it once will create the respective tracing chains. You can then inspect the tracing output via the Proxmox VE Web UI (Firewall > Log) or via `nft monitor trace`.

The above example traces traffic on all bridges, which is usually where guest traffic flows through. If you want to examine host traffic, create those chains in the `inet` table instead of the `bridge` table.

Note
Be aware that this can generate a **lot** of log spam and slow down the performance of your networking stack significantly.

You can remove the tracing rules via running the following command:

```
nft delete table bridge tracebridge
```

Chapter 14

User Management

Proxmox VE supports multiple authentication sources, for example Linux PAM, an integrated Proxmox VE authentication server, LDAP, Microsoft Active Directory and OpenID Connect.

By using role-based user and permission management for all objects (VMs, Storage, nodes, etc.), granular access can be defined.

14.1 Users

Proxmox VE stores user attributes in `/etc/pve/user.cfg`. Passwords are not stored here; users are instead associated with the authentication realms described below. Therefore, a user is often internally identified by their username and realm in the form `<userid>@<realm>`.

Each user entry in this file contains the following information:

- First name
- Last name
- E-mail address
- Group memberships
- An optional expiration date
- A comment or note about this user
- Whether this user is enabled or disabled
- Optional two-factor authentication keys



Caution
When you disable or delete a user, or if the expiry date set is in the past, this user will not be able to log in to new sessions or start new tasks. All tasks which have already been started by this user (for example, terminal sessions) will **not** be terminated automatically by any such event.

14.1.1 System administrator

The system's root user can always log in via the Linux PAM realm and is an unconfined administrator. This user cannot be deleted, but attributes can still be changed. System mails will be sent to the email address assigned to this user.

14.2 Groups

Each user can be a member of several groups. Groups are the preferred way to organize access permissions. You should always grant permissions to groups instead of individual users. That way you will get a much more maintainable access control list.

14.3 API Tokens

API tokens allow stateless access to most parts of the REST API from another system, software, or API client. Exceptions are endpoints that provide access to the virtual machine or system console. These endpoints require user privileges and cannot be accessed via an API token.

Tokens can be generated for individual users and can be given separate permissions and expiration dates to limit the scope and duration of the access. Should the API token get compromised, it can be revoked without disabling the user itself.

API tokens come in two basic types:

- Separated privileges: The token needs to be given explicit access with ACLs. Its effective permissions are calculated by intersecting user and token permissions. **This is the default** for newly created tokens.
- Full privileges: The token's permissions are identical to that of the associated user. Disable Privilege Separation only when the integration genuinely needs the user's full permissions.

Set an `expire` timestamp (Unix epoch seconds) when creating a token so that abandoned automation does not silently keep working. The authentication code refuses requests once the deadline has passed.



Caution
The token value is only displayed/returned once when the token is generated. It cannot be retrieved again over the API at a later time!

To use an API token, set the HTTP header *Authorization* to the displayed value of the form `PVEAPIToken=USER@` when making API requests, or refer to your API client's documentation.

14.3.1 Token Policy

The optional `token-policy` datacenter option sets cluster-wide rules for creating and updating API tokens, as compliance standards like PCI DSS, SOC 2, or ISO 27001 often require, most notably a limited credential lifetime. The policy can require an expiration date for new tokens, limit how far in the future the expiration date can be set, forbid extending the expiration date of existing tokens, and require privilege separation.



Warning
The policy is enforced by the nodes that handle a token request, so in a cluster, only configure it once all nodes run a version supporting it. Nodes running an older version ignore the policy, and changing datacenter options on such a node removes it from the configuration.

Changing the policy requires `Sys.Modify` on `/`, like any other datacenter option. Configure it in the web interface under **Datacenter** → **Options** → **API Token Policy**, or on the command line:

```
pvesh set /cluster/options --token-policy max-lifetime=7776000
```

`max-lifetime` is set in seconds (7776000 above is 90 days), while the web interface takes days. It counts from when the expiration date is set, that is on token creation or when an update changes it, and implies `require-expiry`, as a token without an expiration date would exceed any maximum lifetime.

The policy only applies when a token is created or updated, and only to values that actually change. Existing tokens stay valid even if they do not conform to a policy configured later, and unrelated updates of such tokens keep working. A new expiration date must be within the limit. With `disallow-expiry-extension`, the expiration date of an existing token can only be shortened, or set if it has none. Tokens can always be deleted and recreated.

With `allow-extension-on-regenerate`, an existing token can still be extended within the limit when its secret is regenerated in the same request. The old secret stops working, like it would when recreating the token, so tools can rotate their tokens in place without setting up the permissions again. In the web interface, enable **Regenerate Secret** in the token edit dialog and set the new expiration date. On the command line, pass the new expiration date in Unix epoch seconds:

```
pveum user token modify <userid> <tokenid> --expire <timestamp> -- ↩
   regenerate 1
```

Like on creation, the new secret is only displayed once, so update the tool to use it right away.

Note
The policy also applies to tokens that other tools create through the API, for example when adding the cluster as a remote to Proxmox Datacenter Manager. For tools that do not set an expiration date, set `default-to-max-lifetime` together with `max-lifetime`, so that their tokens get the maximum lifetime instead of being rejected. If a tool still cannot create a compliant token, for example because it disables privilege separation, create one manually and use that in the tool instead.

14.4 Resource Pools



A resource pool is a set of virtual machines, containers, storage devices and SDN VNets. It is useful for permission handling in cases where certain users should have controlled access to a specific set of resources, as it allows for a single permission to be applied to a set of elements, rather than having to manage this on a per-resource basis. Resource pools are often used in tandem with groups, so that the members of a group have permissions on a set of machines and storage.

14.5 Authentication Realms

As Proxmox VE users are just counterparts for users existing on some external realm, the realms have to be configured in `/etc/pve/domains.cfg`. The following realms (authentication methods) are available:

Linux PAM Standard Authentication
Linux PAM is a framework for system-wide user authentication. These users are created on the host system with commands such as `adduser`. If PAM users exist on the Proxmox VE host system, corresponding entries can be added to Proxmox VE, to allow these users to log in via their system username and password.

Proxmox VE Authentication Server
This is a Unix-like password store, which stores hashed passwords in `/etc/pve/priv/shadow.cfg`. Passwords are hashed and salted using the yescrypt algorithm [1]. It provides strong protections against offline password cracking attempts. This realm is the most convenient realm for small-scale (or even mid-scale) installations, where users do not need access to anything outside of Proxmox VE. In this case, users are fully managed by Proxmox VE and are able to change their own passwords via the GUI.

Note
Passwords created with older versions of Proxmox VE used a hashing scheme based on SHA-256 that is now considered insecure. If the file `/etc/pve/priv/shadow.cfg` shows a password hash starting with `$5$` for an account, that account still uses such a password. The hash is updated when a new password is set, and on the next login of that user as long as the cluster is quorate.

LDAP
LDAP (Lightweight Directory Access Protocol) is an open, cross-platform protocol for authentication using directory services. OpenLDAP is a popular open-source implementations of the LDAP protocol.

Microsoft Active Directory (AD)
Microsoft Active Directory (AD) is a directory service for Windows domain networks and is supported as an authentication realm for Proxmox VE. It supports LDAP as an authentication protocol.

OpenID Connect
OpenID Connect is implemented as an identity layer on top of the OAuth 2.0 protocol. It allows clients to verify the identity of the user, based on authentication performed by an external authorization server.

14.5.1 Linux PAM Standard Authentication

As Linux PAM corresponds to host system users, a system user must exist on each node which the user is allowed to log in on. The user authenticates with their usual system password. This realm is added by default and can't be removed.

[1] yescrypt https://www.openwall.com/yescrypt/

Password changes via the GUI or, equivalently, the `/access/password` API endpoint only apply to the local node and not cluster-wide. Even though Proxmox VE has a multi-master design, using different passwords for different nodes can still offer a security benefit.

In terms of configurability, an administrator can choose to require two-factor authentication with logins from the realm and to set the realm as the default authentication realm.

14.5.2 Proxmox VE Authentication Server

The Proxmox VE authentication server realm is a simple Unix-like password store. The realm is created by default, and as with Linux PAM, the only configuration items available are the ability to require two-factor authentication for users of the realm, and to set it as the default realm for login.

Unlike the other Proxmox VE realm types, users are created and authenticated entirely through Proxmox VE, rather than authenticating against another system. Hence, you are required to set a password for this type of user upon creation.

14.5.3 LDAP

You can also use an external LDAP server for user authentication (for example, OpenLDAP). In this realm type, users are searched under a *Base Domain Name* (`base_dn`), using the username attribute specified in the *User Attribute Name* (`user_attr`) field.

A server and optional fallback server can be configured, and the connection can be encrypted via SSL. Furthermore, filters can be configured for directories and groups. Filters allow you to further limit the scope of the realm.

For instance, if a user is represented via the following LDIF dataset:

```
# user1 of People at ldap-test.com
dn: uid=user1,ou=People,dc=ldap-test,dc=com
objectClass: top
objectClass: person
objectClass: organizationalPerson
objectClass: inetOrgPerson
uid: user1
cn: Test User 1
sn: Testers
description: This is the first test user.
```

The *Base Domain Name* would be `ou=People,dc=ldap-test,dc=com` and the user attribute would be `uid`.

If Proxmox VE needs to authenticate (bind) to the LDAP server before being able to query and authenticate users, a bind domain name can be configured via the `bind_dn` property in `/etc/pve/domains.cfg`. Its password then has to be stored in `/etc/pve/priv/realm/<realmname>.pw` (for example, `/etc/pve`
This file should contain a single line with the raw password.

To verify certificates, you need to set `capath`. You can set it either directly to the CA certificate of your LDAP server, or to the system path containing all trusted CA certificates (`/etc/ssl/certs`). Additionally, you need to set the `verify` option, which can also be done over the web interface.

The main configuration options for an LDAP server realm are as follows:

- `Realm` (`realm`): The realm identifier for Proxmox VE users
- `Base Domain Name` (`base_dn`): The directory which users are searched under
- `User Attribute Name` (`user_attr`): The LDAP attribute containing the username that users will log in with
- `Server` (`server1`): The server hosting the LDAP directory
- `Fallback Server` (`server2`): An optional fallback server address, in case the primary server is unreachable
- `Port` (`port`): The port that the LDAP server listens on

Note
In order to allow a particular user to authenticate using the LDAP server, you must also add them as a user of that realm from the Proxmox VE server. This can be carried out automatically with syncing.

14.5.4 Microsoft Active Directory (AD)

To set up Microsoft AD as a realm, a server address and authentication domain need to be specified. Active Directory supports most of the same properties as LDAP, such as an optional fallback server, port, and SSL encryption. Furthermore, users can be added to Proxmox VE automatically via sync operations, after configuration.

As with LDAP, if Proxmox VE needs to authenticate before it binds to the AD server, you must configure the *Bind User* (`bind_dn`) property. This property is typically required by default for Microsoft AD.

The main configuration settings for Microsoft Active Directory are:

- `Realm` (`realm`): The realm identifier for Proxmox VE users
- `Domain` (`domain`): The AD domain of the server
- `Server` (`server1`): The FQDN or IP address of the server
- `Fallback Server` (`server2`): An optional fallback server address, in case the primary server is unreachable
- `Port` (`port`): The port that the Microsoft AD server listens on

Note
Microsoft AD normally checks values like usernames without case sensitivity. To make Proxmox VE do the same, you can disable the default `case-sensitive` option by editing the realm in the web UI, or using the CLI (change the `ID` with the realm ID): `pveum realm modify ID --case-sensitive 0`

14.5.5 Syncing LDAP-Based Realms



It's possible to automatically sync users and groups for LDAP-based realms (LDAP & Microsoft Active Directory), rather than having to add them to Proxmox VE manually. You can access the sync options from the Add/Edit window of the web interface's `Authentication` panel or via the `pveum realm add/modify` commands. You can then carry out the sync operation from the `Authentication` panel of the GUI or using the following command:

```
pveum realm sync <realm>
```

Users and groups are synced to the cluster-wide configuration file, `/etc/pve/user.cfg`.

Attributes to Properties

If the sync response includes user attributes, they will be synced into the matching user property in the `user.cfg`. For example: `firstname` or `lastname`.

If the names of the attributes are not matching the Proxmox VE properties, you can set a custom field-to-field map in the config by using the `sync_attributes` option.

How such properties are handled if anything vanishes can be controlled via the sync options, see below.

Sync Configuration

The configuration options for syncing LDAP-based realms can be found in the `Sync Options` tab of the Add/Edit window.

The configuration options are as follows:

- `Bind User` (`bind_dn`): Refers to the LDAP account used to query users and groups. This account needs access to all desired entries. If it's set, the search will be carried out via binding; otherwise, the search will be carried out anonymously. The user must be a complete LDAP formatted distinguished name (DN), for example, `cn=admin,dc=example,dc=com`.
- Groupname attr. (group_name_attr): Represents the users' groups. Only entries which adhere to the usual character limitations of the `user.cfg` are synced. Groups are synced with `-$realm` attached to the name, in order to avoid naming conflicts. Please ensure that a sync does not overwrite manually created groups.
- `User classes` (`user_classes`): Objects classes associated with users.

- `Group classes` (`group_classes`): Objects classes associated with groups.
- `E-Mail attribute`: If the LDAP-based server specifies user email addresses, these can also be included in the sync by setting the associated attribute here. From the command line, this is achievable through the `--sync_attributes` parameter.
- `User Filter` (`filter`): For further filter options to target specific users.
- `Group Filter` (`group_filter`): For further filter options to target specific groups.

Note
Filters allow you to create a set of additional match criteria, to narrow down the scope of a sync. Information on available LDAP filter types and their usage can be found at ldap.com.

Sync Options



In addition to the options specified in the previous section, you can also configure further options that describe the behavior of the sync operation.

These options are either set as parameters before the sync, or as defaults via the realm option `sync-defaults-`

The main options for syncing are:

- `Scope` (`scope`): The scope of what to sync. It can be either `users`, `groups` or `both`.
- `Enable new` (`enable-new`): If set, the newly synced users are enabled and can log in. The default is `true`.
- `Remove Vanished` (`remove-vanished`): This is a list of options which, when activated, determine if they are removed when they are not returned from the sync response. The options are:
  - `ACL` (`acl`) : Remove ACLs of users and groups which were not returned returned in the sync response. This most often makes sense together with `Entry`.
  - `Entry` (`entry`): Removes entries (i.e. users and groups) when they are not returned in the sync response.
  - `Properties` (`properties`): Removes properties of entries where the user in the sync response did not contain those attributes. This includes all properties, even those never set by a sync. Exceptions are tokens and the enable flag, these will be retained even with this option enabled.
- `Preview` (`dry-run`): No data is written to the config. This is useful if you want to see which users and groups would get synced to the `user.cfg`.

Reserved characters

Certain characters are reserved (see RFC2253) and cannot be easily used in attribute values in DNs without being escaped properly.

Following characters need escaping:

- Space ( ) at the beginning or end
- Number sign (#) at the beginning
- Comma (,)
- Plus sign (+)
- Double quote (")
- Forward slashes (/)
- Angle brackets (<>)
- Semicolon (;)
- Equals sign (=)

To use such characters in DNs, surround the attribute value in double quotes. For example, to bind with a user with the CN (Common Name) `Example, User`, use `CN="Example, User",OU=people,DC=example` as value for `bind_dn`.

This applies to the `base_dn`, `bind_dn`, and `group_dn` attributes.

Note
Users with colons and forward slashes cannot be synced since these are reserved characters in usernames.

14.5.6 OpenID Connect

The main OpenID Connect configuration options are:

- `Issuer URL` (`issuer-url`): This is the URL of the authorization server. Proxmox VE uses the OpenID Connect Discovery protocol to automatically configure further details.

  While it is possible to use unencrypted `http://` URLs, we strongly recommend to use encrypted `https://` connections.

- `Realm` (`realm`): The realm identifier for Proxmox VE users
- `Client ID` (`client-id`): OpenID Client ID.
- `Client Key` (`client-key`): Optional OpenID Client Key.
- `Autocreate Users` (`autocreate`): Automatically create users if they do not exist. While authentication is done at the OpenID server, all users still need an entry in the Proxmox VE user configuration. You can either add them manually, or use the `autocreate` option to automatically add new users.

- Username Claim (username-claim): OpenID claim used to generate the unique username (subject, username or email).
- Autocreate Groups (groups-autocreate): Create all groups in the claim instead of using existing PVE groups (default behavior).
- Groups Claim (groups-claim): OpenID claim used to retrieve the groups from the ID token or userinfo endpoint.
- Overwrite Groups (groups-overwrite): Overwrite all groups assigned to user instead of appending to existing groups (default behavior).

Username mapping

The OpenID Connect specification defines a single unique attribute (*claim* in OpenID terms) named subject. By default, we use the value of this attribute to generate Proxmox VE usernames, by simple adding @ and the realm name: ${subject}@${realm}.

Unfortunately, most OpenID servers use random strings for subject, like DGH76OKH34BNG3245SB, so a typical username would look like DGH76OKH34BNG3245SB@yourrealm. While unique, it is difficult for humans to remember such random strings, making it quite impossible to associate real users with this.

The username-claim setting allows you to use other attributes for the username mapping. Setting it to username is preferred if the OpenID Connect server provides that attribute and guarantees its uniqueness.

Another option is to use email, which also yields human readable usernames. Again, only use this setting if the server guarantees the uniqueness of this attribute.

Groups mapping

Specifying the groups-claim setting in the OpenID configuration enables group mapping functionality. The data provided in the groups-claim should be a list of strings that correspond to groups that a user should be a member of in Proxmox VE. To prevent collisions, group names from the OpenID claim are suffixed with -<realm name> (e.g. for the OpenID group name my-openid-group in the realm oidc, the group name in Proxmox VE would be my-openid-group-oidc).

Any groups reported by the OpenID provider that do not exist in Proxmox VE are ignored by default. If all groups reported by the OpenID provider should exist in Proxmox VE, the groups-autocreate option may be used to automatically create these groups on user logins.

By default, groups are appended to the user's existing groups. It may be desirable to overwrite any groups that the user is already a member in Proxmox VE with those from the OpenID provider. Enabling the groups-overwrite setting removes all groups from the user in Proxmox VE before adding the groups reported by the OpenID provider.

In some cases, OpenID servers may send groups claims which include invalid characters for Proxmox VE group IDs. Any groups that contain characters not allowed in a Proxmox VE group name are not included and a warning will be sent to the logs.

Advanced settings

- Query userinfo endpoint (query-userinfo): Enabling this option requires the OpenID Connect authenticator to query the "userinfo" endpoint for claim values. Disabling this option is useful for some identity providers that do not support the "userinfo" endpoint (e.g. ADFS).

Examples

Here is an example of creating an OpenID realm using Google. You need to replace `--client-id` and `--client-key` with the values from your Google OpenID settings.

```
pveum realm add myrealm1 --type openid --issuer-url  https://accounts. ↩
   google.com --client-id XXXX --client-key YYYY --username-claim email
```

The above command uses `--username-claim email`, so that the usernames on the Proxmox VE side look like `example.user@google.com@myrealm1`.

Keycloak (https://www.keycloak.org/) is a popular open source Identity and Access Management tool, which supports OpenID Connect. In the following example, you need to replace the `--issuer-url` and `--client-i` with your information:

```
pveum realm add myrealm2 --type openid --issuer-url  https://your.server ↩
   :8080/realms/your-realm --client-id XXX --username-claim username
```

Using `--username-claim username` enables simple usernames on the Proxmox VE side, like `example.u`



Warning
You need to ensure that the user is not allowed to edit the username setting themselves (on the Keycloak server).

14.6 Two-Factor Authentication

There are two ways to use two-factor authentication:

It can be required by the authentication realm, either via *TOTP* (Time-based One-Time Password) or *YubiKey OTP*. In this case, a newly created user needs to have their keys added immediately, as there is no way to log in without the second factor. In the case of *TOTP*, users can also change the *TOTP* later on, provided they can log in first.

Alternatively, users can choose to opt-in to two-factor authentication later on, even if the realm does not enforce it.

14.6.1 Available Second Factors

You can set up multiple second factors, in order to avoid a situation in which losing your smartphone or security key locks you out of your account permanently.

The following two-factor authentication methods are available in addition to realm-enforced TOTP and YubiKey OTP:

- User configured TOTP (Time-based One-Time Password). A short code derived from a shared secret and the current time, it changes every 30 seconds.
- WebAuthn (Web Authentication). A general standard for authentication. It is implemented by various security devices, like hardware keys or trusted platform modules (TPM) from a computer or smart phone.

- Single use Recovery Keys. A list of keys which should either be printed out and locked in a secure place or saved digitally in an electronic vault. Each key can be used only once. These are perfect for ensuring that you are not locked out, even if all of your other second factors are lost or corrupt.

Before WebAuthn was supported, U2F could be setup by the user. Existing U2F factors can still be used, but it is recommended to switch to WebAuthn, once it is configured on the server.

14.6.2 Realm Enforced Two-Factor Authentication

This can be done by selecting one of the available methods via the *TFA* dropdown box when adding or editing an Authentication Realm. When a realm has TFA enabled, it becomes a requirement, and only users with configured TFA will be able to log in.

Currently there are two methods available:

Time-based OATH (TOTP)
: This uses the standard HMAC-SHA1 algorithm, where the current time is hashed with the user's configured key. The time step and password length parameters are configurable.

  A user can have multiple keys configured (separated by spaces), and the keys can be specified in Base32 (RFC3548) or hexadecimal notation.

  Proxmox VE provides a key generation tool (`oathkeygen`) which prints out a random key in Base32 notation, that can be used directly with various OTP tools, such as the `oathtool` command-line tool, or on Android Google Authenticator, FreeOTP, andOTP or similar applications.

YubiKey OTP
: For authenticating via a YubiKey a Yubico API ID, API KEY and validation server URL must be configured, and users must have a YubiKey available. In order to get the key ID from a YubiKey, you can trigger the YubiKey once after connecting it via USB, and copy the first 12 characters of the typed password into the user's *Key IDs* field.

Please refer to the YubiKey OTP documentation for how to use the YubiCloud or host your own verification server.

14.6.3 Limits and Lockout of Two-Factor Authentication

A second factor is meant to protect users if their password is somehow leaked or guessed. However, some factors could still be broken by brute force. For this reason, users will be locked out after too many failed 2nd factor login attempts.

For TOTP, 8 failed attempts will disable the user's TOTP factors. They are unlocked when logging in with a recovery key. If TOTP was the only available factor, admin intervention is required, and it is highly recommended to require the user to change their password immediately.

Since FIDO2/Webauthn and recovery keys are less susceptible to brute force attacks, the limit there is higher (100 tries), but all second factors are blocked for an hour when exceeded.

An admin can unlock a user's Two-Factor Authentication at any time via the user list in the UI or the command line:

```
pveum user tfa unlock joe@pve
```

14.6.4 User Configured TOTP Authentication

Users can choose to enable *TOTP* or *WebAuthn* as a second factor on login, via the *TFA* button in the user list (unless the realm enforces *YubiKey OTP*).

Users can always add and use one time *Recovery Keys*.



After opening the *TFA* window, the user is presented with a dialog to set up *TOTP* authentication. The *Secret* field contains the key, which can be randomly generated via the *Randomize* button. An optional *Issuer Name* can be added to provide information to the *TOTP* app about what the key belongs to. Most *TOTP* apps will show the issuer name together with the corresponding *OTP* values. The username is also included in the QR code for the *TOTP* app.

After generating a key, a QR code will be displayed, which can be used with most OTP apps such as FreeOTP. The user then needs to verify the current user password (unless logged in as *root*), as well as the ability to correctly use the *TOTP* key, by typing the current *OTP* value into the *Verification Code* field and pressing the *Apply* button.

14.6.5 TOTP



There is no server setup required. Simply install a TOTP app on your smartphone (for example, FreeOTP) and use the Proxmox VE web interface to add a TOTP factor.

14.6.6 WebAuthn

For WebAuthn to work, you need to have two things:

- A trusted HTTPS certificate (for example, by using Let's Encrypt). While it probably works with an untrusted certificate, some browsers may warn or refuse WebAuthn operations if it is not trusted.
- Setup the WebAuthn configuration (see **Datacenter** → **Options** → **WebAuthn Settings** in the Proxmox VE web interface). This can be auto-filled in most setups.

Once you have fulfilled both of these requirements, you can add a WebAuthn configuration in the **Two Factor** panel under **Datacenter** → **Permissions** → **Two Factor**.

14.6.7 Recovery Keys



Recovery key codes do not need any preparation; you can simply create a set of recovery keys in the **Two Factor** panel under **Datacenter** → **Permissions** → **Two Factor**.

Note
There can only be one set of single-use recovery keys per user at any time.

14.6.8 Server Side Webauthn Configuration



To allow users to use *WebAuthn* authentication, it is necessary to use a valid domain with a valid SSL certificate, otherwise some browsers may warn or refuse to authenticate altogether.

Note
Changing the *WebAuthn* configuration may render all existing *WebAuthn* registrations unusable!

This is done via `/etc/pve/datacenter.cfg`. For instance:

```
webauthn: rp=mypve.example.com,origin=https://mypve.example.com:8006,id= ↩
   mypve.example.com
```

14.6.9 Server Side U2F Configuration

Note
It is recommended to use WebAuthn instead.

To allow users to use *U2F* authentication, it may be necessary to use a valid domain with a valid SSL certificate, otherwise, some browsers may print a warning or reject U2F usage altogether. Initially, an *AppId* [2] needs to be configured.

Note
Changing the *AppId* will render all existing *U2F* registrations unusable!

This is done via `/etc/pve/datacenter.cfg`. For instance:

```
u2f: appid=https://mypve.example.com:8006
```

[2] AppId https://developers.yubico.com/U2F/App_ID.html

For a single node, the *AppId* can simply be the address of the web interface, exactly as it is used in the browser, including the *https://* and the port, as shown above. Please note that some browsers may be more strict than others when matching *AppIds*.

When using multiple nodes, it is best to have a separate `https` server providing an `appid.json` [3] file, as it seems to be compatible with most browsers. If all nodes use subdomains of the same top level domain, it may be enough to use the TLD as *AppId*. It should however be noted that some browsers may not accept this.

Note
A bad *AppId* will usually produce an error, but we have encountered situations when this does not happen, particularly when using a top level domain *AppId* for a node that is accessed via a subdomain in Chromium. For this reason it is recommended to test the configuration with multiple browsers, as changing the *AppId* later will render existing *U2F* registrations unusable.

14.6.10 Activating U2F as a User

To enable *U2F* authentication, open the *TFA* window's *U2F* tab, type in the current password (unless logged in as root), and press the *Register* button. If the server is set up correctly and the browser accepts the server's provided *AppId*, a message will appear prompting the user to press the button on the *U2F* device (if it is a *YubiKey*, the button light should be toggling on and off steadily, roughly twice per second).

Firefox users may need to enable *security.webauth.u2f* via *about:config* before they can use a *U2F* token.

14.7 Permission Management

In order for a user to perform an action (such as listing, modifying or deleting parts of a VM's configuration), the user needs to have the appropriate permissions.

Proxmox VE uses a role and path based permission management system. An entry in the permissions table allows a user, group or token to take on a specific role when accessing an *object* or *path*. This means that such an access rule can be represented as a triple of *(path, user, role)*, *(path, group, role)* or *(path, token, role)*, with the role containing a set of allowed actions, and the path representing the target of these actions.

14.7.1 Roles

A role is simply a list of privileges. Proxmox VE comes with a number of predefined roles, which satisfy most requirements.

- `Administrator`: has full privileges
- `NoAccess`: has no privileges (used to forbid access)
- `PVEAdmin`: can do most tasks, but has no rights to modify system settings (`Sys.PowerMgmt`, `Sys.Modify` `Realm.Allocate`) or permissions (`Permissions.Modify`)
- `PVEAuditor`: has read only access

[3] Multi-facet apps: https://developers.yubico.com/U2F/App_ID.html

- `PVEDatastoreAdmin`: create and allocate backup space and templates
- `PVEDatastoreUser`: allocate backup space and view storage
- `PVEMappingAdmin`: manage resource mappings
- `PVEMappingUser`: view and use resource mappings
- `PVEPoolAdmin`: allocate pools
- `PVEPoolUser`: view pools
- `PVESDNAdmin`: manage SDN configuration
- `PVESDNUser`: access to bridges/vnets
- `PVESysAdmin`: audit, system console and system logs
- `PVETemplateUser`: view and clone templates
- `PVEUserAdmin`: manage users
- `PVEVMAdmin`: fully administer VMs
- `PVEVMUser`: view, backup, configure CD-ROM, VM console, VM power management

You can see the whole set of predefined roles in the GUI.

You can add new roles via the GUI or the command line.



From the GUI, navigate to the *Permissions* → *Roles* tab from *Datacenter* and click on the *Create* button. There you can set a role name and select any desired privileges from the *Privileges* drop-down menu.

To add a role through the command line, you can use the *pveum* CLI tool, for example:

```
pveum role add VM_Power-only --privs "VM.PowerMgmt VM.Console"
pveum role add Sys_Power-only --privs "Sys.PowerMgmt Sys.Console"
```

Note
Roles starting with `PVE` are always builtin, custom roles are not allowed use this reserved prefix.

14.7.2 Privileges

A privilege is the right to perform a specific action. To simplify management, lists of privileges are grouped into roles, which can then be used in the permission table. Note that privileges cannot be directly assigned to users and paths without being part of a role.

We currently support the following privileges:

Node / System related privileges

- `Group.Allocate`: create/modify/remove groups
- `Mapping.Audit`: view resource mappings
- `Mapping.Modify`: manage resource mappings
- `Mapping.Use`: use resource mappings
- `Permissions.Modify`: modify access permissions
- `Pool.Allocate`: create/modify/remove a pool
- `Pool.Audit`: view a pool
- `Realm.AllocateUser`: assign user to a realm
- `Realm.Allocate`: create/modify/remove authentication realms
- `SDN.Allocate`: manage SDN configuration
- `SDN.Audit`: view SDN configuration
- `Sys.Audit`: view node status/config, Corosync cluster config, and HA config
- `Sys.Console`: console access to node
- `Sys.Incoming`: allow incoming data streams from other clusters (experimental)
- `Sys.Modify`: create/modify/remove node network parameters
- `Sys.PowerMgmt`: node power management (start, stop, reset, shutdown, ...)
- `Sys.Syslog`: view syslog
- `User.Modify`: create/modify/remove user access and details.

Virtual machine related privileges

- `SDN.Use`: access SDN vnets and local network bridges
- `VM.Allocate`: create/remove VM on a server
- `VM.Audit`: view VM config
- `VM.Backup`: backup/restore VMs
- `VM.Clone`: clone/copy a VM
- `VM.Config.CDROM`: eject/change CD-ROM
- `VM.Config.CPU`: modify CPU settings
- `VM.Config.Cloudinit`: modify Cloud-init parameters
- `VM.Config.Disk`: add/modify/remove disks
- `VM.Config.HWType`: modify emulated hardware types
- `VM.Config.Memory`: modify memory settings
- `VM.Config.Network`: add/modify/remove network devices
- `VM.Config.Options`: modify any other VM configuration
- `VM.Console`: console access to VM
- `VM.GuestAgent.Audit`: issue informational QEMU guest agent commands
- `VM.GuestAgent.FileRead`: read files from the guest via QEMU guest agent

- `VM.GuestAgent.FileSystemMgmt`: freeze/thaw/trim file systems via QEMU guest agent
- `VM.GuestAgent.FileWrite`: write files in the guest via QEMU guest agent
- `VM.GuestAgent.Unrestricted`: issue arbitrary QEMU guest agent commands
- `VM.Migrate`: migrate VM to alternate server on cluster
- `VM.PowerMgmt`: power management (start, stop, reset, shutdown, ...)
- `VM.Replicate`: configure and run guest replication
- `VM.Snapshot.Rollback`: rollback VM to one of its snapshots
- `VM.Snapshot`: create/delete VM snapshots

Storage related privileges

- `Datastore.Allocate`: create/modify/remove a datastore and delete volumes
- `Datastore.AllocateSpace`: allocate space on a datastore
- `Datastore.AllocateTemplate`: allocate/upload templates and ISO images
- `Datastore.Audit`: view/browse a datastore



Warning
Both `Permissions.Modify` and `Sys.Modify` should be handled with care, as they allow modifying aspects of the system and its configuration that are dangerous or sensitive.



Warning
Carefully read the section about inheritance below to understand how assigned roles (and their privileges) are propagated along the ACL tree.

14.7.3 Objects and Paths

Access permissions are assigned to objects, such as virtual machines, storages or resource pools. We use file system like paths to address these objects. These paths form a natural tree, and permissions of higher levels (shorter paths) can optionally be propagated down within this hierarchy.

Paths can be templated. When an API call requires permissions on a templated path, the path may contain references to parameters of the API call. These references are specified in curly braces. Some parameters are implicitly taken from the API call's URI. For instance, the permission path `/nodes/{node}` when calling */nodes/mynode/status* requires permissions on `/nodes/mynode`, while the path `{path}` in a PUT request to `/access/acl` refers to the method's `path` parameter.

Some examples are:

- `/nodes/{node}`: Access to Proxmox VE server machines
- `/vms`: Covers all VMs
- `/vms/{vmid}`: Access to specific VMs

- `/storage/{storeid}`: Access to a specific storage
- `/pool/{poolname}`: Access to resources contained in a specific pool
- `/access/groups`: Group administration
- `/access/realms/{realmid}`: Administrative access to realms

Inheritance

As mentioned earlier, object paths form a file system like tree, and permissions can be inherited by objects down that tree (the propagate flag is set by default). We use the following inheritance rules:

- Permissions for individual users always replace group permissions.
- Permissions for groups apply when the user is member of that group.
- Permissions on deeper levels replace those inherited from an upper level.
- `NoAccess` cancels all other roles on a given path.

Additionally, privilege separated tokens can never have permissions on any given path that their associated user does not have.

14.7.4 Pools

Pools can be used to group a set of virtual machines and datastores. You can then simply set permissions on pools (`/pool/{poolid}`), which are inherited by all pool members. This is a great way to simplify access control.

Pools can also contain SDN VNets. To add one, open *Members* of the pool, click *Add* and select *VNet*. Without *VLAN Tag*, the member allows network devices on the VNet without VLAN tag. With a *VLAN Tag*, it allows that tag, and with *Propagate*, the VNet with or without any VLAN tag. This only controls the configuration of network devices. Unlike guests, a VNet can be in several pools. All nodes of the cluster need to run `pve-manager` 9.2.34 or newer.

Adding a VNet requires *Pool.Allocate* on the pool, and *Permissions.Modify* or *SDN.Allocate* on the VNet, or on its VLAN tag if one is selected. For *Propagate*, *SDN.Allocate* needs to be propagated.

14.7.5 Which Permissions Do I Need?

The required API permissions are documented for each individual method, and can be found at https://pve.proxmox.com/pve-docs/api-viewer/.

The permissions are specified as a list, which can be interpreted as a tree of logic and access-check functions:

`["and", <subtests>...]` and `["or", <subtests>...]`
: Each(`and`) or any(`or`) further element in the current list has to be true.

["perm", <path>, [<privileges>...], <options>...]
The path is a templated parameter (see Objects and Paths). All (or, if the any option is used, any) of the listed privileges must be allowed on the specified path. If a require-param option is specified, then its specified parameter is required even if the API call's schema otherwise lists it as being optional.

["userid-group", [<privileges>...], <options>...]
The caller must have any of the listed privileges on /access/groups. In addition, there are two possible checks, depending on whether the groups_param option is set:

- groups_param is set: The API call has a non-optional groups parameter and the caller must have any of the listed privileges on all of the listed groups.
- groups_param is not set: The user passed via the userid parameter must exist and be part of a group on which the caller has any of the listed privileges (via the /access/groups/<group> path).

["userid-param", "self"]
The value provided for the API call's userid parameter must refer to the user performing the action (usually in conjunction with or, to allow users to perform an action on themselves, even if they don't have elevated privileges).

["userid-param", "Realm.AllocateUser"]
The user needs Realm.AllocateUser access to /access/realm/<realm>, with <realm> referring to the realm of the user passed via the userid parameter. Note that the user does not need to exist in order to be associated with a realm, since user IDs are passed in the form of <username>@<realm>.

["perm-modify", <path>]
The path is a templated parameter (see Objects and Paths). The user needs either the Permissions.Mo privilege or, depending on the path, the following privileges as a possible substitute:

- /storage/...: requires 'Datastore.Allocate`
- /vms/...: requires 'VM.Allocate`
- /sdn/...: requires SDN.Allocate
- /pool/...: requires 'Pool.Allocate`

  If the path is empty, Permissions.Modify on /access is required.

  If the user does not have the Permissions.Modify privilege, they can only delegate subsets of their own privileges on the given path (e.g., a user with PVEVMAdmin could assign PVEVMUser, but not PVEAdmin).

14.8 Command-line Tool

Most users will simply use the GUI to manage users. But there is also a fully featured command-line tool called pveum (short for "**P**roxmox **VE U**ser **M**anager"). Please note that all Proxmox VE command-line tools are wrappers around the API, so you can also access those functions through the REST API.

Here are some simple usage examples. To show help, type:

```
pveum
```

or (to show detailed help about a specific command)

```
pveum help user add
```

Create a new user:

```
pveum user add testuser@pve -comment "Just a test"
```

Set or change the password (not all realms support this):

```
pveum passwd testuser@pve
```

Disable a user:

```
pveum user modify testuser@pve -enable 0
```

Create a new group:

```
pveum group add testgroup
```

Create a new role:

```
pveum role add PVE_Power-only -privs "VM.PowerMgmt VM.Console"
```

14.9 Real World Examples

14.9.1 Administrator Group

It is possible that an administrator would want to create a group of users with full administrator rights (without using the root account).

To do this, first define the group:

```
pveum group add admin -comment "System Administrators"
```

Then assign the role:

```
pveum acl modify / -group admin -role Administrator
```

Finally, you can add users to the new *admin* group:

```
pveum user modify testuser@pve -group admin
```

14.9.2 Auditors

You can give read only access to users by assigning the `PVEAuditor` role to users or groups.

Example 1: Allow user `joe@pve` to see everything

```
pveum acl modify / -user joe@pve -role PVEAuditor
```

Example 2: Allow user `joe@pve` to see all virtual machines

```
pveum acl modify /vms -user joe@pve -role PVEAuditor
```

14.9.3 Delegate User Management

If you want to delegate user management to user `joe@pve`, you can do that with:

```
pveum acl modify /access -user joe@pve -role PVEUserAdmin
```

User `joe@pve` can now add and remove users, and change other user attributes, such as passwords. This is a very powerful role, and you most likely want to limit it to selected realms and groups. The following example allows `joe@pve` to modify users within the realm `pve`, if they are members of group `customers`:

```
pveum acl modify /access/realm/pve -user joe@pve -role PVEUserAdmin
pveum acl modify /access/groups/customers -user joe@pve -role PVEUserAdmin
```

Note
The user is able to add other users, but only if they are members of the group `customers` and within the realm `pve`.

14.9.4 Limited API Token for Monitoring

Permissions on API tokens are always a subset of those of their corresponding user, meaning that an API token can't be used to carry out a task that the backing user has no permission to do. This section will demonstrate how you can use an API token with separate privileges, to limit the token owner's permissions further.

Give the user `joe@pve` the role PVEVMAdmin on all VMs:

```
pveum acl modify /vms -user joe@pve -role PVEVMAdmin
```

Add a new API token with separate privileges, which is only allowed to view VM information (for example, for monitoring purposes):

```
pveum user token add joe@pve monitoring -privsep 1
pveum acl modify /vms -token 'joe@pve!monitoring' -role PVEAuditor
```

Verify the permissions of the user and token:

```
pveum user permissions joe@pve
pveum user token permissions joe@pve monitoring
```

14.9.5 Resource Pools

An enterprise is usually structured into several smaller departments, and it is common that you want to assign resources and delegate management tasks to each of these. Let's assume that you want to set up a pool for a software development department. First, create a group:

```
pveum group add developers -comment "Our software developers"
```

Now we create a new user which is a member of that group:

```
pveum user add developer1@pve -group developers -password
```

Note
The "-password" parameter will prompt you for a password

Then we create a resource pool for our development department to use:

```
pveum pool add dev-pool --comment "IT development pool"
```

Finally, we can assign permissions to that pool:

```
pveum acl modify /pool/dev-pool/ -group developers -role PVEAdmin
```

Our software developers can now administer the resources assigned to that pool.

Chapter 15

High Availability

Our modern society depends heavily on information provided by computers over the network. Mobile devices amplified that dependency, because people can access the network any time from anywhere. If you provide such services, it is very important that they are available most of the time.

We can mathematically define the availability as the ratio of (A), the total time a service is capable of being used during a given interval to (B), the length of the interval. It is normally expressed as a percentage of uptime in a given year.

Table 15.1: Availability - Downtime per Year

Availability %	Downtime per year
99	3.65 days
99.9	8.76 hours
99.99	52.56 minutes
99.999	5.26 minutes
99.9999	31.5 seconds
99.99999	3.15 seconds

There are several ways to increase availability. The most elegant solution is to rewrite your software, so that you can run it on several hosts at the same time. The software itself needs to have a way to detect errors and do failover. If you only want to serve read-only web pages, then this is relatively simple. However, this is generally complex and sometimes impossible, because you cannot modify the software yourself. The following solutions works without modifying the software:

- Use reliable “server” components

  Note
  Computer components with the same functionality can have varying reliability numbers, depending on the component quality. Most vendors sell components with higher reliability as “server” components - usually at higher price.

- Eliminate single point of failure (redundant components)

  - use an uninterruptible power supply (UPS)
  - use redundant power supplies in your servers
  - use ECC-RAM
  - use redundant network hardware
  - use RAID for local storage
  - use distributed, redundant storage for VM data

- Reduce downtime
  - rapidly accessible administrators (24/7)
  - availability of spare parts (other nodes in a Proxmox VE cluster)
  - automatic error detection (provided by `ha-manager`)
  - automatic failover (provided by `ha-manager`)

Virtualization environments like Proxmox VE make it much easier to reach high availability because they remove the “hardware” dependency. They also support the setup and use of redundant storage and network devices, so if one host fails, you can simply start those services on another host within your cluster.

Better still, Proxmox VE provides a software stack called `ha-manager`, which can do that automatically for you. It is able to automatically detect errors and do automatic failover.

Proxmox VE `ha-manager` works like an “automated” administrator. First, you configure what resources (VMs, containers, ...) it should manage. Then, `ha-manager` observes the correct functionality, and handles service failover to another node in case of errors. `ha-manager` can also handle normal user requests which may start, stop, relocate and migrate a service.

But high availability comes at a price. High quality components are more expensive, and making them redundant doubles the costs at least. Additional spare parts increase costs further. So you should carefully calculate the benefits, and compare with those additional costs.

Tip
Increasing availability from 99% to 99.9% is relatively simple. But increasing availability from 99.9999% to 99.99999% is very hard and costly. `ha-manager` has typical error detection and failover times of about 2 minutes, so you can get no more than 99.999% availability.

15.1 Requirements

You must meet the following requirements before you start with HA:

- at least three cluster nodes (to get reliable quorum)
- shared storage for VMs and containers
- hardware redundancy (everywhere)
- use reliable “server” components

Optionally, a hardware watchdog can be used - if not available we fall back to the linux kernel software watchdog (`softdog`).

15.2 Resources

The HA Manager's primary management unit is called an HA resource (or "HA service"). Currently, an HA resource can be either a Virtual Machine (VM) or a Linux Container (CT).

Each HA resource is uniquely identified by a service ID (`sid`), which consists of the resource type and a type-specific ID, which is the VMID for VMs and containers. For example, for the VM with VMID `100`, the service ID is `vm:100`.

An HA resource can only run on nodes where all of its dependencies are available. By default, the HA Manager treats every cluster node as eligible. To keep this default, a VM or container should:

- use options that are compatible with all cluster nodes
- use only shared storage that is accessible from all cluster nodes
- use only network interfaces that exist on all cluster nodes
- use only device passthroughs that are present on all cluster nodes

If any of these dependencies is only available on a subset of nodes, restrict the HA resource to that subset with a strict node affinity rule. The HA Manager then limits placement, recovery, and migration to the rule's nodes.

15.3 Management Tasks

This section provides a short overview of common management tasks. The first step is to enable HA for a resource. This is done by adding the resource to the HA resource configuration. You can do this using the GUI, or simply use the command-line tool, for example:

```
# ha-manager add vm:100
```

The HA stack now tries to start the resources and keep them running. Please note that you can configure the "requested" resources state. For example you may want the HA stack to stop the resource:

```
# ha-manager set vm:100 --state stopped
```

and start it again later:

```
# ha-manager set vm:100 --state started
```

You can also use the normal VM and container management commands. They automatically forward the commands to the HA stack, so

```
# qm start 100
```

simply sets the requested state to `started`. The same applies to `qm stop`, which sets the requested state to `stopped`.

Note
The HA stack works fully asynchronous and needs to communicate with other cluster members. Therefore, it takes some seconds until you see the result of such actions.

To view the current HA resource configuration use:

```
# ha-manager config
vm:100
        state stopped
```

And you can view the actual HA manager and resource state with:

```
# ha-manager status
quorum OK
master node1 (active, Wed Nov 23 11:07:23 2016)
lrm elsa (active, Wed Nov 23 11:07:19 2016)
service vm:100 (node1, started)
```

You can also initiate resource migration to other nodes:

```
# ha-manager migrate vm:100 node2
```

This uses online migration and tries to keep the VM running. Online migration needs to transfer all used memory over the network, so it is sometimes faster to stop the VM, then restart it on the new node. This can be done using the `relocate` command:

```
# ha-manager relocate vm:100 node2
```

Finally, you can remove the resource from the HA configuration using the following command:

```
# ha-manager remove vm:100
```

By default, this will also remove the resource from any rule that references it and will delete rules that only reference this resource. You can override this behavior using *--purge 0*.

Note
This does not start or stop the resource.

But all HA related tasks can be done in the GUI, so there is no need to use the command line at all.

15.4 How It Works

This section provides a detailed description of the Proxmox VE HA manager internals. It describes all involved daemons and how they work together. To provide HA, two daemons run on each node:

pve-ha-lrm
The local resource manager (LRM), which controls the services running on the local node. It reads the requested states for its services from the current manager status file and executes the respective commands.

pve-ha-crm
The cluster resource manager (CRM), which makes the cluster-wide decisions. It sends commands to the LRM, processes the results, and moves resources to other nodes if something fails. The CRM also handles node fencing.

Note
Locks are provided by our distributed configuration file system (pmxcfs). They are used to guarantee that each LRM is active once and working. As an LRM only executes actions when it holds its lock, we can mark a failed node as fenced if we can acquire its lock. This then lets us recover any failed HA services securely without any interference from the now unknown failed node. This all gets supervised by the CRM which currently holds the manager master lock.

15.4.1 Service States

The CRM uses a service state enumeration to record the current service state. This state is displayed on the GUI and can be queried using the `ha-manager` command-line tool:

```
# ha-manager status
quorum OK
master elsa (active, Mon Nov 21 07:23:29 2016)
lrm elsa (active, Mon Nov 21 07:23:22 2016)
service ct:100 (elsa, stopped)
service ct:102 (elsa, started)
service vm:501 (elsa, started)
```

Here is the list of possible states:

stopped
Service is stopped (confirmed by LRM). If the LRM detects a stopped service is still running, it will stop it again.

request_stop
Service should be stopped. The CRM waits for confirmation from the LRM.

stopping
Pending stop request. But the CRM did not get the request so far.

started
Service is active an LRM should start it ASAP if not already running. If the Service fails and is detected to be not running the LRM restarts it (see Start Failure Policy).

starting
Pending start request. But the CRM has not got any confirmation from the LRM that the service is running.

fence
Wait for node fencing as the service node is not inside the quorate cluster partition (see Fencing). As soon as node gets fenced successfully the service will be placed into the recovery state.

recovery
Wait for recovery of the service. The HA manager tries to find a new node where the service can run on. This search depends on the list of online and quorate nodes as well as the affinity rules the service

is part of, if any. As soon as a new available node is found, the service will be moved there and initially placed into stopped state. If it's configured to run the new node will do so.

freeze
Do not touch the service state. We use this state while we reboot a node, or when we restart the LRM daemon (see Package Updates).

ignored
Act as if the service were not managed by HA at all. Useful, when full control over the service is desired temporarily, without removing it from the HA configuration.

migrate
Migrate service (live) to other node.

error
Service is disabled because of LRM errors. Needs manual intervention (see Error Recovery).

queued
Service is newly added, and the CRM has not seen it so far.

disabled
Service is stopped and marked as `disabled`

15.4.2 Local Resource Manager

The local resource manager (`pve-ha-lrm`) is started as a daemon on boot and waits until the HA cluster is quorate and thus cluster-wide locks are working.

It can be in three states:

wait for agent lock
The LRM waits for our exclusive lock. This is also used as idle state if no service is configured.

active
The LRM holds its exclusive lock and has services configured.

lost agent lock
The LRM lost its lock, this means a failure happened and quorum was lost.

After the LRM gets in the active state it reads the manager status file in `/etc/pve/ha/manager_status` and determines the commands it has to execute for the services it owns. For each command a worker gets started, these workers are running in parallel and are limited to at most 4 by default. This default setting may be changed through the datacenter configuration key `max_worker`. When finished the worker process gets collected and its result saved for the CRM.

Note
The default value of at most 4 concurrent workers may be unsuited for a specific setup. For example, 4 live migrations may occur at the same time, which can lead to network congestions with slower networks and/or big (memory wise) services. Also, ensure that in the worst case, congestion is at a minimum, even if this means lowering the `max_worker` value. On the contrary, if you have a particularly powerful, high-end setup you may also want to increase it.

Each command requested by the CRM is uniquely identifiable by a UID. When the worker finishes, its result will be processed and written in the LRM status file `/etc/pve/nodes/<nodename>/lrm_status`. There the CRM may collect it and let its state machine - respective to the commands output - act on it.

The actions on each service between CRM and LRM are normally always synced. This means that the CRM requests a state uniquely marked by a UID, the LRM then executes this action **one time** and writes back the result, which is also identifiable by the same UID. This is needed so that the LRM does not execute an outdated command. The only exceptions to this behaviour are the `stop` and `error` commands; these two do not depend on the result produced and are executed always in the case of the stopped state and once in the case of the error state.

Note
The HA Stack logs every action it makes. This helps to understand what and also why something happens in the cluster. Here its important to see what both daemons, the LRM and the CRM, did. You may use `journalctl -u pve-ha-lrm` on the node(s) where the service is and the same command for the pve-ha-crm on the node which is the current master.

15.4.3 Cluster Resource Manager

The cluster resource manager (`pve-ha-crm`) starts on each node and waits there for the manager lock, which can only be held by one node at a time. The node which successfully acquires the manager lock gets promoted to the CRM master.

It can be in three states:

wait for agent lock
The CRM waits for our exclusive lock. This is also used as idle state if no service is configured

active
The CRM holds its exclusive lock and has services configured

lost agent lock
The CRM lost its lock, this means a failure happened and quorum was lost.

Its main task is to manage the services which are configured to be highly available and try to always enforce the requested state. For example, a service with the requested state *started* will be started if its not already running. If it crashes it will be automatically started again. Thus the CRM dictates the actions the LRM needs to execute.

When a node leaves the cluster quorum, its state changes to unknown. If the current CRM can then secure the failed node's lock, the services will be *stolen* and restarted on another node.

When a cluster member determines that it is no longer in the cluster quorum, the LRM waits for a new quorum to form. Until there is a cluster quorum, the node cannot reset the watchdog. If there are active services on the node, or if the LRM or CRM process is not scheduled or is killed, this will trigger a reboot after the watchdog has timed out (this happens after 60 seconds).

Note that if a node has an active CRM but the LRM is idle, a quorum loss will not trigger a self-fence reset. The reason for this is that all state files and configurations that the CRM accesses are backed up by the clustered configuration file system, which becomes read-only upon quorum loss. This means that the CRM only needs to protect itself against its process being scheduled for too long, in which case another CRM could take over unaware of the situation, causing corruption of the HA state. The open watchdog ensures that this cannot happen.

If no service is configured for more than 15 minutes, the CRM automatically returns to the idle state and closes the watchdog completely.

15.5 HA Simulator



By using the HA simulator you can test and learn all functionalities of the Proxmox VE HA solutions.

By default, the simulator allows you to watch and test the behaviour of a real-world 3 node cluster with 6 VMs. You can also add or remove additional VMs or Container.

You do not have to setup or configure a real cluster, the HA simulator runs out of the box.

Install with apt:

```
apt install pve-ha-simulator
```

You can even install the package on any Debian-based system without any other Proxmox VE packages. For that you will need to download the package and copy it to the system you want to run it on for installation. When you install the package with apt from the local file system it will also resolve the required dependencies for you.

To start the simulator on a remote machine you must have an X11 redirection to your current system.

If you are on a Linux machine you can use:

```
ssh root@<IPofPVE> -Y
```

On Windows it works with mobaxterm.

After connecting to an existing Proxmox VE with the simulator installed or installing it on your local Debian-based system manually, you can try it out as follows.

First you need to create a working directory where the simulator saves its current state and writes its default config:

```
mkdir working
```

Then, simply pass the created directory as a parameter to *pve-ha-simulator*:

```
pve-ha-simulator working/
```

You can then start, stop, migrate the simulated HA services, or even check out what happens on a node failure.

15.6 Configuration

The HA stack is well integrated into the Proxmox VE API. So, for example, HA can be configured via the `ha-manager` command-line interface, or the Proxmox VE web interface - both interfaces provide an easy way to manage HA. Automation tools can use the API directly.

All HA configuration files are within `/etc/pve/ha/`, so they get automatically distributed to the cluster nodes, and all nodes share the same HA configuration.

15.6.1 Resources



The resource configuration file `/etc/pve/ha/resources.cfg` stores the list of resources managed by `ha-manager`. A resource configuration inside that list looks like this:

```
<type>: <name>
        <property> <value>
        ...
```

It starts with a resource type followed by a resource specific name, separated with colon. Together this forms the HA resource ID, which is used by all `ha-manager` commands to uniquely identify a resource (example: `vm:100` or `ct:101`). The next lines contain additional properties:

auto-rebalance: <boolean> (*default =* 1)
: HA resource may be migrated during automatic rebalancing

comment: <string>
: Description.

failback: <boolean> (*default =* 1)
: Automatically migrate HA resource to the node with the highest priority according to their node affinity rules, if a node with a higher priority than the current node comes online.

group: <string>
: The HA group identifier.

max_relocate: <integer> (0 - N) (*default =* 1)
: Maximal number of resource relocate tries when a resource fails to start.

max_restart: <integer> (0 - N) (*default =* 1)
: Maximal number of tries to restart the resource on a node after its start failed. When reached, the HA manager will try to relocate the resource to an eligible node.

state: <disabled | enabled | ignored | started | stopped> (*default =* started)
: Requested resource state. The CRM reads this state and acts accordingly. Please note that `enabled` is just an alias for `started`.

  started
  : The CRM tries to start the resource. Service state is set to `started` after successful start. On node failures, or when start fails, it tries to recover the resource. If everything fails, service state it set to `error`.

  stopped
  : The CRM tries to keep the resource in `stopped` state, but it still tries to relocate the resources on node failures.

  disabled
  : The CRM tries to put the resource in `stopped` state, but does not try to relocate the resources on node failures. The main purpose of this state is error recovery, because it is the only way to move a resource out of the `error` state.

ignored
: The resource gets removed from the manager status and so the CRM and the LRM do not touch the resource anymore. All {pve} API calls affecting this resource will be executed, directly bypassing the HA stack. CRM commands will be thrown away while the resource is in this state. The resource will not get relocated on node failures.

Here is a real world example with one VM and one container. As you see, the syntax of those files is really simple, so it is even possible to read or edit those files using your favorite editor:

Configuration Example (/etc/pve/ha/resources.cfg)

```
vm: 501
    state started
    max_relocate 2

ct: 102
    # Note: use default settings for everything
```



The above config was generated using the `ha-manager` command-line tool:

```
# ha-manager add vm:501 --state started --max_relocate 2
# ha-manager add ct:102
```

15.6.2 Groups

Note
HA Groups are deprecated and migrated to HA Node Affinity rules since Proxmox VE 9.0.



The HA group configuration file `/etc/pve/ha/groups.cfg` is used to define groups of cluster nodes. A resource can be restricted to run only on the members of such group. A group configuration look like this:

```
group: <group>
       nodes <node_list>
       <property> <value>
       ...
```

comment: <string>
: Description.

nodes: <node>[:<pri>]{,<node>[:<pri>]}*
: List of cluster node members, where a priority can be given to each node. A resource will run on the available nodes with the highest priority. If there are more nodes in the highest priority class, the resources will get distributed to those nodes. The priorities have a relative meaning only. The higher the number, the higher the priority.

nofailback: <boolean> (*default* = 0)
: The CRM tries to run services on the node with the highest priority. If a node with higher priority comes online, the CRM migrates the service to that node. Enabling nofailback prevents that behavior.

restricted: <boolean> (*default* = 0)
: Resources bound to restricted groups may only run on nodes defined by the group. The resource will be placed in the stopped state if no group node member is online. Resources on unrestricted groups may run on any cluster node if all group members are offline, but they will migrate back as soon as a group member comes online. One can implement a *preferred node* behavior using an unrestricted group with only one member.



A common requirement is that a resource should run on a specific node. Usually the resource is able to run on other nodes, so you can define an unrestricted group with a single member:

```
# ha-manager groupadd prefer_node1 --nodes node1
```

For bigger clusters, it makes sense to define a more detailed failover behavior. For example, you may want to run a set of services on `node1` if possible. If `node1` is not available, you want to run them equally split on `node2` and `node3`. If those nodes also fail, the services should run on `node4`. To achieve this you could set the node list to:

```
# ha-manager groupadd mygroup1 -nodes "node1:2,node2:1,node3:1,node4"
```

Another use case is if a resource uses other resources only available on specific nodes, lets say `node1` and `node2`. We need to make sure that HA manager does not use other nodes, so we need to create a restricted group with said nodes:

```
# ha-manager groupadd mygroup2 -nodes "node1,node2" -restricted
```

The above commands created the following group configuration file:

Configuration Example (/etc/pve/ha/groups.cfg)

```
group: prefer_node1
       nodes node1

group: mygroup1
       nodes node2:1,node4,node1:2,node3:1

group: mygroup2
       nodes node2,node1
       restricted 1
```

The `nofailback` options is mostly useful to avoid unwanted resource movements during administration tasks. For example, if you need to migrate a service to a node which doesn't have the highest priority in the

group, you need to tell the HA manager not to instantly move this service back by setting the `nofailback` option.

Another scenario is when a service was fenced and it got recovered to another node. The admin tries to repair the fenced node and brings it up online again to investigate the cause of failure and check if it runs stably again. Setting the `nofailback` flag prevents the recovered services from moving straight back to the fenced node.

15.6.3 Rules

HA rules are used to put certain constraints on HA-managed resources, which are defined in the HA rules configuration file `/etc/pve/ha/rules.cfg`.

```
<type>: <rule>
        resources <resources_list>
        <property> <value>
        ...
```

comment: **<string>**
HA rule description.

disable: **<boolean>**
Whether the HA rule is disabled.

resources: **<type>:<name>{,<type>:<name>}***
List of HA resource IDs. This consists of a list of resource types followed by a resource specific name separated with a colon (example: vm:100,ct:101).

Table 15.2: Available HA Rule Types

HA Rule Type	Description
`node-affinity`	Places affinity from one or more HA resources to one or more nodes. The affinity `positive` specifies that HA resources should or must be kept on one of the specified nodes, while the affinity `negative` specifies that the HA resources should or must avoid the specified nodes. The strictness attribute `strict` specifies whether it is a soft constraint ("should") or whether it is a hard constraint ("must").
`resource-affinity`	Places affinity between two or more HA resources. The affinity `positive` specifies that HA resources must be kept on the same node, while the affinity `negative` specifies that HA resources must be kept on separate nodes.

Node Affinity Rules

By default, an HA resource is able to run on any cluster node, but a common requirement is that an HA resource should run on a specific node. That can be implemented by defining an HA node affinity rule to make the HA resource `vm:100` prefer the node `node1`:

```
# ha-manager rules add node-affinity ha-rule-vm100 --resources vm:100 -- ↩
   nodes node1
```

By default, node affinity rules are not strict, i.e., if there is none of the specified nodes available, the HA resource can also be moved to other nodes. If, on the other hand, an HA resource must be restricted to the specified nodes, then the node affinity rule must be set to be strict.

In the previous example, the node affinity rule can be modified to restrict the resource `vm:100` to be only on `node1`:

```
# ha-manager rules set node-affinity ha-rule-vm100 --strict 1
```

Furthermore, node affinity rules use positive affinity by default, meaning that the preferred cluster nodes must be explicitly specified. However, in larger clusters, it is often more practical to define node affinity using an opt-out approach to avoid long and verbose lists of cluster nodes. For example, the following command defines an HA node affinity rule that makes the HA resources `ct:200` and `vm:300` avoid the node `node3`:

```
# ha-manager rules add node-affinity ha-rule-negative \
        --affinity negative --resources ct:200,vm:300 --nodes node3
```

Moreover, specific use cases might require defining a more detailed failover behavior. For example, the resources `vm:400` and `ct:500` should run on `node1`. If `node1` becomes unavailable, the resources should be distributed on `node2` and `node3`. If `node2` and `node3` are also unavailable, the resources should run on `node4`.

To implement this behavior in a node affinity rule, nodes can be paired with priorities to order the preference for nodes. If two or more nodes have the same priority, the resources can run on any of them. For the above example, `node1` gets the highest priority, `node2` and `node3` get the same priority, and at last `node4` gets the lowest priority, which can be omitted to default to `0`:

```
# ha-manager rules add node-affinity priority-cascade \
        --resources vm:400,ct:500 --nodes "node1:2,node2:1,node3:1,node4"
```

The above commands create the following rules in the rules configuration file:

Node Affinity Rules Configuration Example (/etc/pve/ha/rules.cfg)

```
node-affinity: ha-rule-vm100
        nodes node1
        resources vm:100
        strict 1

node-affinity: ha-rule-negative
        nodes node3
        resources ct:200,vm:300
        affinity negative

node-affinity: priority-cascade
```

```
        nodes node1:2,node2:1,node3:1,node4
        resources vm:400,ct:500
```

Node Affinity Rule Properties

affinity: <negative | positive> (*default* = positive)
: Describes whether the HA resources are supposed to be placed on the given nodes (*positive*), or are supposed to be placed on any but the given nodes (*negative*).

nodes: <node>[:<pri>]{,<node>[:<pri>]}*
: List of cluster node members, where a priority can be given to each node. A resource will run on the available nodes with the highest priority. If there are more nodes in the highest priority class, the resources will get distributed to those nodes. The priorities have a relative meaning only. The higher the number, the higher the priority.

resources: <type>:<name>{,<type>:<name>}*
: List of HA resource IDs. This consists of a list of resource types followed by a resource specific name separated with a colon (example: vm:100,ct:101).

strict: <boolean> (*default* = 0)
: Describes whether the node affinity rule is strict or non-strict.

  A non-strict node affinity rule makes resources prefer to be on the defined nodes. If none of the defined nodes are available, the resource may run on any other node.

  A strict node affinity rule makes resources be restricted to the defined nodes. If none of the defined nodes are available, the resource will be stopped.

Resource Affinity Rules

Another common requirement is that two or more HA resources should run on either the same node, or should be distributed on separate nodes. These are also commonly called "Affinity/Anti-Affinity constraints".

For example, suppose there is a lot of communication traffic between the HA resources `vm:100` and `vm:200`, for example, a web server communicating with a database server. If those HA resources are on separate nodes, this could potentially result in a higher latency and unnecessary network load. Resource affinity rules with the affinity `positive` implement the constraint to keep the HA resources on the same node:

```
# ha-manager rules add resource-affinity keep-together \
    --affinity positive --resources vm:100,vm:200
```

Note
If there are two or more positive resource affinity rules, which have common HA resources, then these are treated as a single positive resource affinity rule. For example, if the HA resources `vm:100` and `vm:101` and the HA resources `vm:101` and `vm:102` are each in a positive resource affinity rule, then it is the same as if `vm:100`, `vm:101` and `vm:102` would have been in a single positive resource affinity rule.

Note
If the HA resources of a positive resource affinity rule are currently running on different nodes, the CRS will move the HA resources to the node, where most of them are running already. If there is a tie in the HA resource count, the node whose name appears first in alphabetical order is selected.

However, suppose there are computationally expensive, and/or distributed programs running on the HA resources `vm:200` and `ct:300`, for example, sharded database instances. In that case, running them on the same node could potentially result in pressure on the hardware resources of the node and will slow down the operations of these HA resources. Resource affinity rules with the affinity `negative` implement the constraint to spread the HA resources on separate nodes:

```
# ha-manager rules add resource-affinity keep-separate \
    --affinity negative --resources vm:200,ct:300
```

Other than node affinity rules, resource affinity rules are strict by default, i.e., if the constraints imposed by the resource affinity rules cannot be met for an HA resource, the HA Manager will put the HA resource in recovery state in case of a failover or in error state elsewhere.

The above commands created the following rules in the rules configuration file:

Resource Affinity Rules Configuration Example (/etc/pve/ha/rules.cfg)

```
resource-affinity: keep-together
        affinity positive
        resources vm:100,vm:200

resource-affinity: keep-separate
        affinity negative
        resources vm:200,ct:300
```

Interactions between Positive and Negative Resource Affinity Rules

If there are HA resources in a positive resource affinity rule, which are also part of a negative resource affinity rule, then all the other HA resources in the positive resource affinity rule are in negative affinity with the HA resources of these negative resource affinity rules as well.

For example, if the HA resources `vm:100`, `vm:101`, and `vm:102` are in a positive resource affinity rule, and `vm:100` is in a negative resource affinity rule with the HA resource `ct:200`, then `vm:101` and `vm:102` are each in negative resource affinity with `ct:200` as well.

Note that if there are two or more HA resources in both a positive and negative resource affinity rule, then those will be disabled as they cause a conflict: Two or more HA resources cannot be kept on the same node and separated on different nodes at the same time. For more information on these cases, see the section about rule conflicts and errors below.

Interactions between Node and Positive Resource Affinity Rules

If there are HA resources in a node affinity rule, which are also part of a positive resource affinity rule, then all the other HA resources in the positive resource affinity rule inherit the node affinity rule as well.

For example, if the HA resources `vm:100`, `vm:101`, and `vm:102` are in a positive resource affinity rule, and `vm:102` is in a node affinity rule, which restricts `vm:102` to be only on `node3`, then `vm:100` and `vm:101` are restricted to be only on `node3` as well.

Please note that if there are two or more HA resources in a positive resource affinity rule and in different node affinity rules, then those rules will cause an error and will be disabled as this is currently not supported. For more information on these cases, see the section about rule conflicts and errors below.

Resource Affinity Rule Properties

affinity: <negative | positive>
: Describes whether the HA resources are supposed to be kept on the same node (*positive*), or are supposed to be kept on separate nodes (*negative*).

resources: <type>:<name>{,<type>:<name>}*
: List of HA resource IDs. This consists of a list of resource types followed by a resource specific name separated with a colon (example: vm:100,ct:101).

15.6.4 Rule Conflicts and Errors

HA rules can impose rather complex constraints on the HA resources. To ensure that a new or modified HA rule does not introduce uncertainty into the HA stack's CRS scheduler, HA rules are tested for feasibility before these are applied. For any rules that fail these tests, these rules are disabled until the conflicts and errors have been resolved.

Currently, HA rules are checked for the following feasibility tests:

- An HA resource can only be part of a single HA node affinity rule.
- Negative HA node affinity rules cannot specify node priorities.
- Negative HA node affinity rules cannot specify all cluster nodes.
- An HA resource affinity rule must have at least two HA resources.
- A negative HA resource affinity rule cannot specify more HA resources than there are nodes in the cluster. Otherwise, the HA resources do not have enough nodes to be separated.
- A positive HA resource affinity rule cannot specify the same two or more HA resources as a negative HA resources affinity rule. That is, two or more HA resources cannot be kept together and separate at the same time.
- An HA resource can only be part of an HA node affinity rule and an HA resource affinity rule at the same time, if the HA node affinity rule has a single priority class.
- The HA resources of a positive HA resource affinity rule can only be part of a single HA node affinity rule at most.
- The HA resources of a negative HA resource affinity rule cannot be restricted to less nodes than HA resources by their node affinity rules. Otherwise, the HA resources do not have enough nodes to be separated.

15.7 Fencing

On node failures, fencing ensures that the erroneous node is guaranteed to be offline. This is required to make sure that no resource runs twice when it gets recovered on another node. This is a really important task, because without this, it would not be possible to recover a resource on another node.

If a node did not get fenced, it would be in an unknown state where it may have still access to shared resources. This is really dangerous! Imagine that every network but the storage one broke. Now, while not reachable from the public network, the VM still runs and writes to the shared storage.

If we then simply start up this VM on another node, we would get a dangerous race condition, because we write from both nodes. Such conditions can destroy all VM data and the whole VM could be rendered unusable. The recovery could also fail if the storage protects against multiple mounts.

15.7.1 How Proxmox VE Fences

There are different methods to fence a node, for example, fence devices which cut off the power from the node or disable their communication completely. Those are often quite expensive and bring additional critical components into a system, because if they fail you cannot recover any service.

We thus wanted to integrate a simpler fencing method, which does not require additional external hardware. This can be done using watchdog timers.

POSSIBLE FENCING METHODS

- external power switches
- isolate nodes by disabling complete network traffic on the switch
- self fencing using watchdog timers

Watchdog timers have been widely used in critical and dependable systems since the beginning of micro-controllers. They are often simple, independent integrated circuits which are used to detect and recover from computer malfunctions.

During normal operation, `ha-manager` regularly resets the watchdog timer to prevent it from elapsing. If, due to a hardware fault or program error, the computer fails to reset the watchdog, the timer will elapse and trigger a reset of the whole server (reboot).

Recent server motherboards often include such hardware watchdogs, but these need to be configured. If no watchdog is available or configured, we fall back to the Linux Kernel *softdog*. While still reliable, it is not independent of the servers hardware, and thus has a lower reliability than a hardware watchdog.

15.7.2 Configure Hardware Watchdog

By default, all hardware watchdog modules are blocked for security reasons. They are like a loaded gun if not correctly initialized. To enable a hardware watchdog, you need to specify the module to load in */etc/default/pve-ha-manager*, for example:

```
# select watchdog module (default is softdog)
WATCHDOG_MODULE=iTCO_wdt
```

This configuration is read by the *watchdog-mux* service, which loads the specified module at startup.

15.7.3 Recover Fenced Services

After a node failed and its fencing was successful, the CRM tries to move services from the failed node to nodes which are still online.

The selection of the recovery nodes is influenced by the list of currently active nodes, their respective loads depending on the used scheduler, and the affinity rules the service is part of, if any.

First, the CRM builds a set of nodes available to the service. If the service is part of a node affinity rule, the set is reduced to the highest priority nodes in the node affinity rule. If the service is part of a resource affinity rule, the set is further reduced to fulfill their constraints, which is either keeping the service on the same node as some other services or keeping the service on a different node than some other services. Finally, the CRM selects the node with the lowest load according to the used scheduler to minimize the possibility of an overloaded node.



Caution
On node failure, the CRM distributes services to the remaining nodes. This increases the service count on those nodes, and can lead to high load, especially on small clusters. Please design your cluster so that it can handle such worst case scenarios.

15.7.4 Fencing & Watchdog Status

The `ha-manager status` output includes a fencing entry that shows the CRM watchdog state. Each LRM entry additionally shows its own watchdog state.

armed
The CRM is actively managing services and has its watchdog open. Each node's LRM also holds a watchdog while it has its agent lock. On quorum loss or daemon failure, the respective watchdog triggers a node reset to ensure safe failover.

standby
The HA stack is ready but no CRM is actively running as master, for example when no HA resources are configured yet or the cluster just started. The CRM watchdog is not open. Fencing automatically transitions to `armed` once a CRM takes over as master.

disarming
A `disarm-ha` command was issued. The CRM is freezing or suspending services from tracking and waiting for all LRMs to release their watchdogs. The CRM watchdog is still active during this phase. Each LRM entry's watchdog status changes to `released` as it acknowledges the disarm.

disarmed
All watchdogs have been released cluster-wide. No automatic fencing, failover, or recovery takes place. See Disarming HA for Cluster Maintenance.

Note
The `watchdog-mux` service keeps the underlying `/dev/watchdog` device open for its entire lifetime, even when no HA client is connected. This prevents other processes from claiming the device and ensures the HA stack can always re-acquire it. Not all hardware watchdog drivers support magic close, so closing the device could trigger an unintended reset.

15.8 Start Failure Policy

The start failure policy comes into effect if a service failed to start on a node one or more times. It can be used to configure how often a restart should be triggered on the same node and how often a service should be relocated, so that it has an attempt to be started on another node. The aim of this policy is to circumvent temporary unavailability of shared resources on a specific node. For example, if a shared storage isn't available on a quorate node anymore, for instance due to network problems, but is still available on other nodes, the relocate policy allows the service to start nonetheless.

There are two service start recover policy settings which can be configured specific for each resource.

max_restart
: Maximum number of attempts to restart a failed service on the actual node. The default is set to one.

max_relocate
: Maximum number of attempts to relocate the service to a different node. A relocate only happens after the max_restart value is exceeded on the actual node. The default is set to one.

Note
The relocate count state will only reset to zero when the service had at least one successful start. That means if a service is re-started without fixing the error only the restart policy gets repeated.

15.9 Error Recovery

If, after all attempts, the service state could not be recovered, it gets placed in an error state. In this state, the service won't get touched by the HA stack anymore. The only way out is disabling a service:

```
# ha-manager set vm:100 --state disabled
```

This can also be done in the web interface.

To recover from the error state you should do the following:

- bring the resource back into a safe and consistent state (e.g.: kill its process if the service could not be stopped)
- disable the resource to remove the error flag
- fix the error which led to this failures
- **after** you fixed all errors you may request that the service starts again

15.10 Package Updates

When updating the ha-manager, you should do one node after the other, never all at once for various reasons. First, while we test our software thoroughly, a bug affecting your specific setup cannot totally be ruled out. Updating one node after the other and checking the functionality of each node after finishing the update

helps to recover from eventual problems, while updating all at once could result in a broken cluster and is generally not good practice.

Also, the Proxmox VE HA stack uses a request acknowledge protocol to perform actions between the cluster and the local resource manager. For restarting, the LRM makes a request to the CRM to freeze all its services. This prevents them from getting touched by the Cluster during the short time the LRM is restarting. After that, the LRM may safely close the watchdog during a restart. Such a restart happens normally during a package update and, as already stated, an active master CRM is needed to acknowledge the requests from the LRM. If this is not the case the update process can take too long which, in the worst case, may result in a reset triggered by the watchdog.

15.11 Node Maintenance

Sometimes it is necessary to perform maintenance on a node, such as replacing hardware or simply installing a new kernel image. This also applies while the HA stack is in use.

The HA stack can support you mainly in two types of maintenance:

- for general shutdowns or reboots, the behavior can be configured, see Shutdown Policy.
- for maintenance that does not require a shutdown or reboot, or that should not be switched off automatically after only one reboot, you can enable the manual maintenance mode.

15.11.1 Maintenance Mode

You can use the manual maintenance mode to mark the node as unavailable for HA operation, prompting all services managed by HA to migrate to other nodes.

The target nodes for these migrations are selected from the other currently available nodes, and determined by the HA rules configuration and the configured cluster resource scheduler (CRS) mode. During each migration, the original node will be recorded in the HA managers' state, so that the service can be moved back again automatically once the maintenance mode is disabled and the node is back online.

You can enable or disable the maintenance mode using the web interface or the `ha-manager` CLI tool. In the web interface, select the `lrm` entry of the node in the status panel under *Datacenter* → *HA* and use the **Node Maintenance** menu. Requests to enable the maintenance mode are rejected while HA is disarmed or if the node is not online, except for a node that shuts down with the `migrate` shutdown policy, see below.

Enabling maintenance mode for a node

```
# ha-manager crm-command node-maintenance enable NODENAME
```

This will queue a CRM command, when the manager processes this command it will record the request for maintenance-mode in the manager status. This allows you to submit the command on any node, not just on the one you want to place in, or out of the maintenance mode.

Once the LRM on the respective node picks the command up it will mark itself as unavailable, but still process all migration commands. This means that the LRM self-fencing watchdog will stay active until all active services got moved, and all running workers finished.

Note that the LRM status will read `maintenance` mode as soon as the LRM picked the requested state up, not only when all services got moved away, this user experience is planned to be improved in the future. For now, you can check for any active HA service left on the node, or watching out for a log line like: `pve-ha-lrm[PID]: watchdog closed (disabled)` to know when the node finished its transition into the maintenance mode.

Note
The manual maintenance mode is not automatically deleted on node reboot, but only if it is either manually deactivated or if the manager-status is manually cleared.

A node that shuts down with the `migrate` shutdown policy stays in maintenance mode only until it is back online. To keep it in maintenance mode after that, enable the manual maintenance mode while it is shutting down or offline.

Disabling maintenance mode for a node

```
# ha-manager crm-command node-maintenance disable NODENAME
```

The process of disabling the manual maintenance mode is similar to enabling it. Using the web interface or the `ha-manager` CLI command shown above will queue a CRM command that, once processed, marks the respective LRM node as available again.

If you deactivate the maintenance mode, all services that were on the node when the maintenance mode was activated will be moved back.

15.11.2 Shutdown Policy

Below you will find a description of the different HA policies for a node shutdown. Currently *Conditional* is the default due to backward compatibility. Some users may find that *Migrate* behaves more as expected.

The shutdown policy can be configured in the Web UI (`Datacenter` → `Options` → `HA Settings`), or directly in `datacenter.cfg`:

```
ha: shutdown_policy=<value>
```

Migrate

Once the Local Resource manager (LRM) gets a shutdown request and this policy is enabled, it will mark itself as unavailable for the current HA manager. This triggers a migration of all HA Services currently located on this node. The LRM will try to delay the shutdown process, until all running services get moved away. But, this expects that the running services **can** be migrated to another node. In other words, the service must not be locally bound, for example by using hardware passthrough. For example, strict node affinity rules tell the HA Manager that the service cannot run outside of the chosen set of nodes. If all of these nodes are unavailable, the shutdown will hang until you manually intervene. Once the shut down node comes back online again, the previously displaced services will be moved back, if they were not already manually migrated in-between. To keep the services away from the node, enable the manual maintenance mode for it before it is back online, see Node Maintenance.

Note
The watchdog is still active during the migration process on shutdown. If the node loses quorum it will be fenced and the services will be recovered.

If you start a (previously stopped) service on a node which is currently being maintained, the node needs to be fenced to ensure that the service can be moved and started on another available node.

Failover

This mode ensures that all services get stopped, but that they will also be recovered, if the current node is not online soon. It can be useful when doing maintenance on a cluster scale, where live-migrating VMs may not be possible if too many nodes are powered off at a time, but you still want to ensure HA services get recovered and started again as soon as possible.

Freeze

This mode ensures that all services get stopped and frozen, so that they won't get recovered until the current node is online again.

Conditional

The *Conditional* shutdown policy automatically detects if a shutdown or a reboot is requested, and changes behaviour accordingly.

Shutdown

A shutdown (*poweroff*) is usually done if it is planned for the node to stay down for some time. The LRM stops all managed services in this case. This means that other nodes will take over those services afterwards.

Note
Recent hardware has large amounts of memory (RAM). So we stop all resources, then restart them to avoid online migration of all that RAM. If you want to use online migration, you need to invoke that manually before you shutdown the node.

Reboot

Node reboots are initiated with the *reboot* command. This is usually done after installing a new kernel. Please note that this is different from "shutdown", because the node immediately starts again.

The LRM tells the CRM that it wants to restart, and waits until the CRM puts all resources into the `freeze` state (same mechanism is used for Package Updates). This prevents those resources from being moved to other nodes. Instead, the CRM starts the resources after the reboot on the same node.

Manual Resource Movement

Last but not least, you can also manually move resources to other nodes, before you shutdown or restart a node. The advantage is that you have full control, and you can decide if you want to use online migration or not.

Note
Please do not *kill* services like `pve-ha-crm`, `pve-ha-lrm` or `watchdog-mux`. They manage and use the watchdog, so this can result in an immediate node reboot or even reset.

15.12 Disarming HA for Cluster Maintenance

Certain cluster maintenance tasks, such as reconfiguring the network or the cluster communication stack (corosync), can cause temporary quorum loss or network partitions. Normally, HA would interpret this as a node failure and trigger self-fencing, disrupting services unnecessarily.

The disarm mechanism releases all CRM and LRM watchdogs cluster-wide, allowing you to perform such maintenance safely without the risk of nodes being fenced.



Important
While disarmed, HA does not protect your services. Failures during this period are not automatically recovered. Keep the disarm window as short as possible.

Resource Modes

When disarming HA, you must choose a resource mode that controls how HA managed resources are handled while disarmed. The current state of resources is not affected.

freeze
: New commands and state changes are not applied. Services stay in their current state, but the HA stack does not react to failures or process new requests. This is the safest choice when you expect all nodes to remain running.

ignore
: Resources are suspended from HA tracking and can be managed as if they were not HA managed. This allows you to manually start, stop, or migrate services while HA is disarmed. Use this when you need to manually relocate services during maintenance. When re-arming, the CRM rechecks service locations against the configuration to pick up any manual migrations.

Disarming and Re-Arming

To disarm HA with the desired resource mode:

```
# ha-manager crm-command disarm-ha freeze
```

or:

```
# ha-manager crm-command disarm-ha ignore
```

To re-arm HA after maintenance is complete:

```
# ha-manager crm-command arm-ha
```

You can monitor the current state with:

```
# ha-manager status
```

The fencing status line shows the current state of the fencing mechanism (see Fencing Status), including the CRM and LRM watchdog states.

The Disarm Process

After you request disarm, the following sequence happens:

1. The CRM freezes all services or suspends them from tracking, depending on the chosen resource mode.
2. Each LRM finishes its active workers, then releases its agent lock and watchdog.
3. Once all online LRMs are idle, the CRM releases its own watchdog too.

The CRM keeps the manager lock throughout this process, so it can accept and process the `arm-ha` command to reverse it.

If any services are currently being fenced, recovered, or migrated, the disarm is deferred until these operations complete. This ensures that services in the middle of a transition do not end up in an inconsistent state.

Nodes Offline During Disarm

If a node is offline when HA is disarmed, its LRM cannot process the disarm request. The CRM proceeds to the disarmed state once all **online** LRMs have completed their part. The offline node does not block this.

When the offline node comes back online while HA is still disarmed, its LRM picks up the disarm state and releases its watchdog without attempting any service recovery.

When you re-arm HA, any services that were on the offline node are handled according to normal HA recovery rules: they are fenced and recovered if the node is still unreachable, or restarted on the node if it has come back online.

Interaction with Maintenance Mode

If a node is already in maintenance mode when disarm is requested, the maintenance migration continues until all services have been moved away. Once no active services and workers remain, the LRM releases its lock and watchdog as part of the disarm process.

When HA is re-armed, the maintenance mode state is preserved. The node remains in maintenance and services are not moved back until maintenance mode is explicitly disabled.



Caution
While the HA stack is disarmed, no automatic recovery, failover, or fencing takes place. A node failure during this window is not detected or handled by HA. Keep the disarm window as short as possible and ensure that the cluster is in a healthy state before re-arming.

15.13 Cluster Resource Scheduling

The Cluster Resource Scheduler (CRS) is responsible for selecting new node placements for HA resources and keeping HA resources on their allowed nodes.

In every HA Manager round, the scheduler goes through every HA resource and checks whether the HA resource needs any new node placement. This new node placement can be caused by different actions, such as recovering HA resources from a fenced node or a new HA affinity rule. See the section CRS Scheduling Points for a more thorough description of which actions the CRS takes for specific changes in the cluster.

15.13.1 CRS Scheduling Mode



The CRS scheduling mode controls how the CRS will calculate the usage information for the cluster. This usage information is used as a basis for the scheduling decisions. The CRS mode can be changed in the web interface (`Datacenter` → `Options` → `Cluster Resource Scheduling`). The default mode is `basic`. The change will take effect starting with the next HA Manager round, which should take no longer than 10 seconds.

Basic Scheduler

The number of active guests on each node is used to choose the best-fitting node for an HA resource.

Static-Load Scheduler

Static usage information from active guests on each node is used to choose the best-fitting node for an HA resource. This includes the configured CPU and memory quotas for the active guests.

Dynamic-Load Scheduler

Dynamic usage information from active guests on each node is used to choose the best-fitting node for an HA resource. This includes the average CPU and memory usage as well as the configured CPU and memory quotas for the active guests.

15.13.2 CRS Scheduling Points

In every HA Manager round, the CRS checks whether any HA resources need a new node placement, which can be caused by any of the following scheduling points:

HA resource recovery (always active)

When a node with active HA resources fails, all its HA resources need to be recovered to other nodes. The CRS algorithm will be used here to balance that recovery over the remaining nodes.

HA rule config changes (always active)

If a rule imposes different constraints on the HA resources, the HA stack will use the CRS algorithm to find a new target node for the HA resources affected by these rules depending on the type of the new rules:

- Node affinity rules: If a node affinity rule is created or HA resources/nodes are added to an existing node affinity rule, the HA stack will use the CRS algorithm to ensure that these HA resources are assigned according to their node and priority constraints.
- Positive resource affinity rules: If a positive resource affinity rule is created or HA resources are added to an existing positive resource affinity rule, the HA stack will use the CRS algorithm to ensure that these HA resources are moved to a common node.
- Negative resource affinity rules: If a negative resource affinity rule is created or HA resources are added to an existing negative resource affinity rule, the HA stack will use the CRS algorithm to ensure that these HA resources are moved to separate nodes.

HA resource rebalance on start (opt-in)

When starting an HA resource with rebalance on start enabled, the CRS will select the node best suited for the HA resource. If the selected node is not the current node, the HA resource will be migrated to the selected node.

For the basic scheduler mode, the node with the fewest active guests is considered the best-suited node.

For the static-load and dynamic-load scheduler modes, each node in turn is considered as if the HA resource was already running on it, using CPU and memory usage from the associated guest configuration. Then for each such alternative, CPU and memory usage of all nodes are considered, with memory being weighted much more, because it's a truly limited resource. For both, CPU and memory, highest usage among nodes (weighted more, as ideally no node should be overcommitted) and average usage of all nodes (to still be able to distinguish in case there already is a more highly committed node) are considered.

This setting can be enabled with the CRS option `ha-rebalance-on-start` in the web interface under `Datacenter` → `Options` → `Cluster Resource Scheduling`.



Important
For the static-load and dynamic-load scheduler modes, this functionality is still in technology preview. The more HA resources the more possible combinations there are, so it's currently not recommended to use it if you have thousands of HA resources.

15.13.3 CRS Load Balancer

The utilization of individual cluster nodes can vary greatly depending on where guests are currently running and how much load these exert at any moment. This can cause the node utilizations to become imbalanced over time, where HA resources on one node become bottlenecked due to resource contention, while another node is barely utilized.

The HA Manager's automatic load balancer can lower the overall cluster imbalance by automatically issuing rebalancing migrations. Currently, these migrations are issued only for HA resources and executed sequentially. Furthermore, these migrations always obey the current HA affinity rules.

Disabling `auto-rebalance` for an HA resource prevents the resource from being part of automatically issued rebalancing migrations.

Note
Any HA resource with a positive affinity for an HA resource with `auto-rebalance` disabled won't be part of rebalancing migrations either.

The automatic load balancing system can be enabled and configured in the web interface under `Datacenter` → `Options` → `Cluster Resource Scheduling`. This allows fine-tuning the various parameters as described in the next paragraph for different cluster setups and requirements. The load balancer requires either the static-load or dynamic-load scheduler mode to be in use.

In every HA Manager round, each of which lasts around 10 seconds, the automatic load balancer checks whether the cluster imbalance exceeds the *imbalance threshold*. If the cluster imbalance stays above the threshold for at least as many consecutive HA Manager rounds as the *hold duration*, then the load balancer will select the rebalancing migration for an HA resource, which lowers the overall cluster imbalance the most. The method used to select the best rebalancing migration can be set with the *rebalancing method* option. Finally, if the selected migration reduces the current cluster imbalance by at least the percentage given by the *imbalance improvement* option, the load balancer issues the selected migration.

The cluster imbalance is derived from the standard deviation and mean of the individual node loads and is normalized to a 0-100% range. Both the *imbalance threshold* and the *imbalance improvement* are configured in percent. The *imbalance threshold* defaults to 30% and controls the sensitivity of the load balancer; with a value of `0` it will try to select a rebalancing migration every time the *hold duration* is exceeded. The *imbalance improvement* defaults to 10% and filters what constitutes an acceptable rebalancing migration; with a value of `0` it will always commit to a migration even if the expected imbalance does not change at all. The value can never be negative, so the balancer will never commit to a migration with an expected imbalance worse than the current one. If both the *imbalance threshold* and the *imbalance improvement* are set to `0`, the load balancer issues no migrations and logs a warning instead, as it could otherwise keep migrating HA resources without improving the cluster imbalance.

Note
It is planned that load balancing will also include non-HA resources in the future.

Cluster Imbalance

The cluster imbalance describes how unevenly the load is spread across the nodes. The load of a node is the mean of its CPU load and its memory usage, relative to the CPU cores and the memory of the node. Which usage is considered depends on the static-load or dynamic-load scheduler mode.

The cluster imbalance is the population standard deviation of the node loads divided by their mean, which is also known as the coefficient of variation. For `n` nodes, this value is at most `sqrt(n - 1)`, so it is divided by that to get a value between 0% and 100%.

The cluster imbalance is 0% if all nodes have the same load, and 100% if a single node carries all the load while all other nodes are idle. If there are fewer than two nodes or no load at all, the cluster imbalance is 0%.

As the standard deviation is divided by the mean, the cluster imbalance describes how unevenly the load is spread relative to the average node load, not how high the node loads are. For example, in a cluster with three nodes, node loads of 60%, 30% and 30% result in a cluster imbalance of 25%, just like node loads of 30%, 15% and 15%. So, a lightly loaded cluster can exceed the *imbalance threshold* even if no node is close to its limits.

As the load of a node combines its CPU load and its memory usage, the cluster imbalance can be low even if the CPU load or the memory usage alone is spread unevenly. For example, a node with a CPU load of 80% and a memory usage of 20% has the same load as a node with a CPU load of 20% and a memory usage of 80%.

To select a rebalancing migration, the load balancer calculates the expected cluster imbalance as if the HA resource was already running on the target node. If automatic rebalancing is enabled, the current cluster imbalance is shown in the status of the HA manager's `master` entry, both in the `Status` panel under `Datacenter` → `HA` in the web interface and in the output of `ha-manager status`.

Chapter 16

Backup and Restore

Backups are a requirement for any sensible IT deployment, and Proxmox VE provides a fully integrated solution, using the capabilities of each storage and each guest system type. This allows the system administrator to fine tune via the `mode` option between consistency of the backups and downtime of the guest system.

Proxmox VE backups are always full backups - containing the VM/CT configuration and all data. Backups can be started via the GUI or via the `vzdump` command-line tool.

Backup Storage

Before a backup can run, a backup storage must be defined. Refer to the storage documentation on how to add a storage. It can either be a Proxmox Backup Server storage, where backups are stored as deduplicated chunks and metadata, or a file-level storage, where backups are stored as regular files. Using Proxmox Backup Server on a dedicated host is recommended, because of its advanced features. Using an NFS server is a good alternative. In both cases, you might want to save those backups later to a tape drive, for off-site archiving.

Scheduled Backup

Backup jobs can be scheduled so that they are executed automatically on specific days and times, for selectable nodes and guest systems. See the Backup Jobs section for more.

16.1 Backup Modes

There are several ways to provide consistency (option `mode`), depending on the guest type.

BACKUP MODES FOR VMS:

`stop` mode
: This mode provides the highest consistency of the backup, at the cost of a short downtime in the VM operation. It works by executing an orderly shutdown of the VM, and then runs a background QEMU process to backup the VM data. After the backup is started, the VM goes to full operation mode if it was previously running. Consistency is guaranteed by using the live backup feature.

`suspend` mode
This mode is provided for compatibility reason, and suspends the VM before calling the `snapshot` mode. Since suspending the VM results in a longer downtime and does not necessarily improve the data consistency, the use of the `snapshot` mode is recommended instead.

`snapshot` mode
This mode provides the lowest operation downtime, at the cost of a small inconsistency risk. It works by performing a Proxmox VE live backup, in which data blocks are copied while the VM is running. If the guest agent is enabled (`agent: 1`) and running, it calls `guest-fsfreeze-freeze` and `guest-fsfreeze-thaw` to improve consistency.

Note
On Windows guests it is necessary to configure the guest agent if another backup software is used within the guest. See Freeze & Thaw in the guest agent section for more details.

A technical overview of the Proxmox VE live backup for QemuServer can be found online here.

Note
Proxmox VE live backup provides snapshot-like semantics on any storage type. It does not require that the underlying storage supports snapshots. Also please note that since the backups are done via a background QEMU process, a stopped VM will appear as running for a short amount of time while the VM disks are being read by QEMU. However the VM itself is not booted, only its disk(s) are read.

BACKUP MODES FOR CONTAINERS:

`stop` mode
Stop the container for the duration of the backup. This potentially results in a very long downtime.

`suspend` mode
This mode uses rsync to copy the container data to a temporary location (see option `--tmpdir`). Then the container is suspended and a second rsync copies changed files. After that, the container is started (resumed) again. This results in minimal downtime, but needs additional space to hold the container copy.

When the container is on a local file system and the target storage of the backup is an NFS/CIFS server, you should set `--tmpdir` to reside on a local file system too, as this will result in a many fold performance improvement. Use of a local `tmpdir` is also required if you want to backup a local container using ACLs in suspend mode if the backup storage is an NFS server.

`snapshot` mode
This mode uses the snapshotting facilities of the underlying storage. First, the container will be suspended to ensure data consistency. A temporary snapshot of the container's volumes will be made and the snapshot content will be archived in a tar file. Finally, the temporary snapshot is deleted again.

Note
`snapshot` mode requires that all backed up volumes are on a storage that supports snapshots. Using the `backup=no` mount point option individual volumes can be excluded from the backup (and thus this requirement).

Note
By default additional mount points besides the Root Disk mount point are not included in backups. For volume mount points you can set the **Backup** option to include the mount point in the backup. Device and bind mounts are never backed up as their content is managed outside the Proxmox VE storage library.

16.1.1 VM Backup Fleecing

When a backup for a VM is started, QEMU will install a "copy-before-write" filter in its block layer. This filter ensures that upon new guest writes, old data still needed for the backup is sent to the backup target first. The guest write blocks until this operation is finished so guest IO to not-yet-backed-up sectors will be limited by the speed of the backup target.

With backup fleecing, such old data is cached in a fleecing image rather than sent directly to the backup target. This can help guest IO performance and even prevent hangs in certain scenarios, at the cost of requiring more storage space.

To manually start a backup of VM `123` with fleecing images created on the storage `local-lvm`, run

```
vzdump 123 --fleecing enabled=1,storage=local-lvm
```

As always, you can set the option for specific backup jobs, or as a node-wide fallback via the configuration options. In the UI, fleecing can be configured in the *Advanced* tab when editing a backup job.

The fleecing storage should be a fast local storage, with thin provisioning and discard support. Examples are LVM-thin, RBD, ZFS with `sparse 1` in the storage configuration, many file-based storages. Ideally, the fleecing storage is a dedicated storage, so it running full will not affect other guests and just fail the backup. Parts of the fleecing image that have been backed up will be discarded to try and keep the space usage low.

For file-based storages that do not support discard (for example, NFS before version 4.2), you should set `preallocation off` in the storage configuration. In combination with `qcow2` (used automatically as the format for the fleecing image when the storage supports it), this has the advantage that already allocated parts of the image can be re-used later, which can still help save quite a bit of space.



Warning
On a storage that's not thinly provisioned, for example, LVM or ZFS without the `sparse` option, the full size of the original disk needs to be reserved for the fleecing image up-front. On a thinly provisioned storage, the fleecing image can grow to the same size as the original image only if the guest re-writes a whole disk while the backup is busy with another disk.

16.1.2 CT Change Detection Mode

Setting the change detection mode defines the encoding format for the pxar archives and how changed, and unchanged files are handled for container backups with Proxmox Backup Server as the target.

The change detection mode option can be configured for individual backup jobs in the *Advanced* tab while editing a job. Further, this option can be set as node-wide fallback via the configuration options.

There are 3 change detection modes available:

Mode	Description
`Default`	Read and encode all files into a single archive, using the pxar format version 1.
`Data`	Read and encode all files, but split data and metadata into separate streams, using the pxar format version 2.
`Metadata`	Split streams and use archive format version 2 like `Data`, but use the metadata archive of the previous snapshot (if one exists) to detect unchanged files, and reuse their data chunks without reading file contents from disk, whenever possible.

To perform a backup using the change detecation mode `metadata` you can run

```
vzdump 123 --storage pbs-storage --pbs-change-detection-mode ↩
  metadata
```

Note
Backups of VMs or to storage backends other than Proxmox Backup Server are not affected by this setting.

16.2 Backup File Names

Newer versions of vzdump encode the guest type and the backup time into the filename, for example

```
vzdump-lxc-105-2009_10_09-11_04_43.tar
```

That way it is possible to store several backup in the same directory. You can limit the number of backups that are kept with various retention options, see the Backup Retention section below.

16.3 Backup File Compression

The backup file can be compressed with one of the following algorithms: `lzo` [1], `gzip` [2] or `zstd` [3].

Currently, Zstandard (zstd) is the fastest of these three algorithms. Multi-threading is another advantage of zstd over lzo and gzip. Lzo and gzip are more widely used and often installed by default.

You can install pigz [4] as a drop-in replacement for gzip to provide better performance due to multi-threading. For pigz & zstd, the amount of threads/cores can be adjusted. See the configuration options below.

The extension of the backup file name can usually be used to determine which compression algorithm has been used to create the backup.

[1] Lempel–Ziv–Oberhumer a lossless data compression algorithm https://en.wikipedia.org/wiki/Lempel-Ziv-Oberhumer
[2] gzip - based on the DEFLATE algorithm https://en.wikipedia.org/wiki/Gzip
[3] Zstandard a lossless data compression algorithm https://en.wikipedia.org/wiki/Zstandard
[4] pigz - parallel implementation of gzip https://zlib.net/pigz/

.zst	Zstandard (zstd) compression
.gz or .tgz	gzip compression
.lzo	lzo compression

If the backup file name doesn't end with one of the above file extensions, then it was not compressed by vzdump.

16.4 Backup Encryption

For Proxmox Backup Server storages, you can optionally set up client-side encryption of backups, see the corresponding section.

16.5 Backup Jobs



Besides triggering a backup manually, you can also setup periodic jobs that backup all, or a selection of virtual guest to a storage. You can manage the jobs in the UI under *Datacenter* → *Backup* or via the `/cluster/backup` API endpoint. Both will generate job entries in `/etc/pve/jobs.cfg`, which are parsed and executed by the `pvescheduler` daemon.



A job is either configured for all cluster nodes or a specific node, and is executed according to a given schedule. The format for the schedule is very similar to `systemd` calendar events, see the calendar events section for details. The *Schedule* field in the UI can be freely edited, and it contains several examples that can be used as a starting point in its drop-down list.

You can configure job-specific retention options overriding those from the storage or node configuration, as well as a template for notes for additional information to be saved together with the backup.

Since scheduled backups miss their execution when the host was offline or the pvescheduler was disabled during the scheduled time, it is possible to configure the behaviour for catching up. By enabling the `Repeat missed` option (in the *Advanced* tab in the UI, `repeat-missed` in the config), you can tell the scheduler that it should run missed jobs as soon as possible.



There are a few settings for tuning backup performance (some of which are exposed in the *Advanced* tab in the UI). The most notable is `bwlimit` for limiting IO bandwidth. The amount of threads used for the compressor can be controlled with the `pigz` (replacing `gzip`), respectively, `zstd` setting. Furthermore, there

are `ionice` (when the BFQ scheduler is used) and, as part of the `performance` setting, `max-workers` (affects VM backups only) and `pbs-entries-max` (affects container backups only). See the configuration options for details.

16.6 Backup Retention

With the `prune-backups` option you can specify which backups you want to keep in a flexible manner.



The following retention options are available:

`keep-all <boolean>`
: Keep all backups. If this is `true`, no other options can be set.

`keep-last <N>`
: Keep the last `<N>` backups.

`keep-hourly <N>`
: Keep backups for the last `<N>` hours. If there is more than one backup for a single hour, only the latest is kept.

`keep-daily <N>`
: Keep backups for the last `<N>` days. If there is more than one backup for a single day, only the latest is kept.

`keep-weekly <N>`
: Keep backups for the last `<N>` weeks. If there is more than one backup for a single week, only the latest is kept.

Note
Weeks start on Monday and end on Sunday. The software uses the `ISO week date`-system and handles weeks at the end of the year correctly.

`keep-monthly <N>`
: Keep backups for the last `<N>` months. If there is more than one backup for a single month, only the latest is kept.

keep-yearly <N>
: Keep backups for the last <N> years. If there is more than one backup for a single year, only the latest is kept.

The retention options are processed in the order given above. Each option only covers backups within its time period. The next option does not take care of already covered backups. It will only consider older backups.

Specify the retention options you want to use as a comma-separated list, for example:

```
# vzdump 777 --prune-backups keep-last=3,keep-daily=13,keep-yearly=9
```

While you can pass `prune-backups` directly to `vzdump`, it is often more sensible to configure the setting on the storage level, which can be done via the web interface.

16.6.1 Prune Simulator

You can use the prune simulator of the Proxmox Backup Server documentation to explore the effect of different retention options with various backup schedules.

16.6.2 Retention Settings Example

The backup frequency and retention of old backups may depend on how often data changes, and how important an older state may be, in a specific work load. When backups act as a company's document archive, there may also be legal requirements for how long backups must be kept.

For this example, we assume that you are doing daily backups, have a retention period of 10 years, and the period between backups stored gradually grows.

`keep-last=3` - even if only daily backups are taken, an admin may want to create an extra one just before or after a big upgrade. Setting keep-last ensures this.

`keep-hourly` is not set - for daily backups this is not relevant. You cover extra manual backups already, with keep-last.

`keep-daily=13` - together with keep-last, which covers at least one day, this ensures that you have at least two weeks of backups.

`keep-weekly=8` - ensures that you have at least two full months of weekly backups.

`keep-monthly=11` - together with the previous keep settings, this ensures that you have at least a year of monthly backups.

`keep-yearly=9` - this is for the long term archive. As you covered the current year with the previous options, you would set this to nine for the remaining ones, giving you a total of at least 10 years of coverage.

We recommend that you use a higher retention period than is minimally required by your environment; you can always reduce it if you find it is unnecessarily high, but you cannot recreate backups once they have been removed.

16.7 Backup Protection

You can mark a backup as `protected` to prevent its removal. Attempting to remove a protected backup via Proxmox VE's UI, CLI or API will fail. However, this is enforced by Proxmox VE and not the file-system, that means that a manual removal of a backup file itself is still possible for anyone with write access to the underlying backup storage.

Note
Protected backups are ignored by pruning and do not count towards the retention settings.

For filesystem-based storages, the protection is implemented via a sentinel file `<backup-name>.protected`. For Proxmox Backup Server, it is handled on the server side (available since Proxmox Backup Server version 2.1).

Use the storage option `max-protected-backups` to control how many protected backups per guest are allowed on the storage. Use `-1` for unlimited. The default is unlimited for users with `Datastore.Allocate` privilege and `5` for other users.

16.8 Backup Notes

You can add notes to backups using the *Edit Notes* button in the UI or via the storage content API.



It is also possible to specify a template for generating notes dynamically for a backup job and for manual backup. The template string can contain variables, surrounded by two curly braces, which will be replaced by the corresponding value when the backup is executed.

Currently supported are:

- `{{cluster}}` the cluster name, if any
- `{{guestname}}` the virtual guest's assigned name
- `{{node}}` the host name of the node the backup is being created
- `{{uid}}` the `uid` of the guest identity in the backup, if any
- `{{vmid}}` the numerical VMID of the guest



Warning
Nodes running a Proxmox VE version older than 9.3 refuse a backup job whose notes template contains `{{uid}}` and back up none of their guests for it. Use the variable only once all nodes are upgraded.

When specified via API or CLI, it needs to be a single line, where newline and backslash need to be escaped as literal `\n` and `\\` respectively.

16.9 Restore

A backup archive can be restored through the Proxmox VE web GUI or through the following CLI tools:

`pct restore`
Container restore utility

`qmrestore`
Virtual Machine restore utility

For details see the corresponding manual pages.

When you restore a backup over an existing guest, Proxmox VE compares the `uid` of the backup and of the guest. If they differ, the restore is refused, unless you set the `allow-identity-mismatch` option. The existing guest then keeps its identity. See Restore Over an Existing Guest for details and exceptions.

16.9.1 Bandwidth Limit

Restoring one or more big backups may need a lot of resources, especially storage bandwidth for both reading from the backup storage and writing to the target storage. This can negatively affect other virtual guests as access to storage can get congested.

To avoid this you can set bandwidth limits for a backup job. Proxmox VE implements two kinds of limits for restoring and archive:

- per-restore limit: denotes the maximal amount of bandwidth for reading from a backup archive
- per-storage write limit: denotes the maximal amount of bandwidth used for writing to a specific storage

The read limit indirectly affects the write limit, as we cannot write more than we read. A smaller per-job limit will overwrite a bigger per-storage limit. A bigger per-job limit will only overwrite the per-storage limit if you have ‘Data.Allocate’ permissions on the affected storage.

You can use the ‘--bwlimit <integer>` option from the restore CLI commands to set up a restore job specific bandwidth limit. KiB/s is used as unit for the limit, this means passing `10240’ will limit the read speed of the backup to 10 MiB/s, ensuring that the rest of the possible storage bandwidth is available for the already running virtual guests, and thus the backup does not impact their operations.

Note
You can use ‘0` for the `bwlimit` parameter to disable all limits for a specific restore job. This can be helpful if you need to restore a very important virtual guest as fast as possible. (Needs `Data.Allocate’ permissions on storage)

Most times your storage’s generally available bandwidth stays the same over time, thus we implemented the possibility to set a default bandwidth limit per configured storage, this can be done with:

```
# pvesm set STORAGEID --bwlimit restore=KIBs
```

16.9.2 Live-Restore

Restoring a large backup can take a long time, in which a guest is still unavailable. For VM backups stored on a Proxmox Backup Server, this wait time can be mitigated using the live-restore option.

Enabling live-restore via either the checkbox in the GUI or the `--live-restore` argument of `qmrestore` causes the VM to start as soon as the restore begins. Data is copied in the background, prioritizing chunks that the VM is actively accessing.

Note that this comes with two caveats:

- During live-restore, the VM will operate with limited disk read speeds, as data has to be loaded from the backup server (once loaded, it is immediately available on the destination storage however, so accessing data twice only incurs the penalty the first time). Write speeds are largely unaffected.
- If the live-restore fails for any reason, the VM will be left in an undefined state - that is, not all data might have been copied from the backup, and it is *most likely* not possible to keep any data that was written during the failed restore operation.

This mode of operation is especially useful for large VMs, where only a small amount of data is required for initial operation, e.g. web servers - once the OS and necessary services have been started, the VM is operational, while the background task continues copying seldom used data.

16.9.3 Single File Restore

The *File Restore* button in the *Backups* tab of the storage GUI can be used to open a file browser directly on the data contained in a backup. This feature is only available for backups on a Proxmox Backup Server.

For containers, the first layer of the file tree shows all included *pxar* archives, which can be opened and browsed freely. For VMs, the first layer shows contained drive images, which can be opened to reveal a list of supported storage technologies found on the drive. In the most basic case, this will be an entry called *part*, representing a partition table, which contains entries for each partition found on the drive. Note that for VMs, not all data might be accessible (unsupported guest file systems, storage technologies, etc. . .).

Files and directories can be downloaded using the *Download* button, the latter being compressed into a zip archive on the fly.

To enable secure access to VM images, which might contain untrusted data, a temporary VM (not visible as a guest) is started. This does not mean that data downloaded from such an archive is inherently safe, but it avoids exposing the hypervisor system to danger. The VM will stop itself after a timeout. This entire process happens transparently from a user’s point of view.

Note
For troubleshooting purposes, each temporary VM instance generates a log file in `/var/log/proxmox-backup/file-restore/`. The log file might contain additional information in case an attempt to restore individual files or accessing file systems contained in a backup archive fails.

16.9.4 Failed Restores

A restore that fails or is canceled can leave one of the following leftover artifacts for its VMID:

- The guest itself, possibly locked. This happens after a VM restore over an existing VM, after a container restore over an existing container that fails before it destroyed the old container, after a VM restore to a free VMID that fails once the data is restored or in the live phase of a live restore, and if the restore task was killed.
- A locked container, after a container restore that fails after it destroyed the old container, if the cleanup could not remove the firewall config or a volume. That can be a volume of the restore or of the old container.
- A locked placeholder without data, after a restore to a free VMID, if the restore task was killed or the cleanup could not remove a volume or the firewall config.

In the other cases nothing is left. A restore to a free VMID that fails before it restored the data removes the guest again. A container restore that fails after it destroyed the old container removes the container, so the old container is gone then as well.

To clean up and retry:

1. Make sure that no task of the guest is still running, then remove the lock with `qm unlock <vmid>` or `pct unlock <vmid>`.
2. If a placeholder was left behind, remove it, for example with `qm destroy <vmid>` or `pct destroy <vmid>`. With `--destroy-unreferenced-disks 1`, the command also removes all other volumes with that VMID on the enabled storages. These include volumes that a killed restore created or that the cleanup could not remove, but can also be volumes of an earlier guest, so check them first with `pvesm list <storage> --vmid <vmid>`.
3. Restore again, over the guest that was left behind or to its VMID if nothing is left there. If the VMID is free by then, use another one if the next-id setting of the datacenter has the `unique` and `enforce` options set, as the first VMID then counts as used.

For how a retry handles the guest identity, see Retrying a Failed Restore.

16.10 Guest Identity

Since Proxmox VE 9.3, each virtual machine and container gets a guest identity: a random identifier, `uid`, and a registration time, `rtime`. Unlike a VMID, which can be reused after a guest is destroyed, the `uid` lets backup software and other tools recognize the same logical guest across restores and migrations, even under a different VMID.

Backups are still grouped by guest type and VMID, also for retention. If a new guest reuses the VMID of a removed guest of the same type, pruning handles the backups of both guests together.

16.10.1 Identity Values

The guest identity is part of the `meta` property in the guest configuration. This property also contains the creation time `ctime` and, for VMs, the QEMU version that the VM was created with, `creation-qemu`:

```
meta: creation-qemu=10.1.2,ctime=1772444467,rtime=1794320571482,uid= ↩
   w5qczgiem26qnwzwsoil
```

`uid`
: A random identifier of 20 lowercase letters and digits that encode 100 random bits, so two guests practically never get the same `uid` by chance.

`rtime`
: The time at which the guest was registered in this cluster, in milliseconds since the UNIX epoch. It is set whenever the guest gets its `uid` in this cluster, so a guest restored to a free VMID gets a new `rtime`, even if it keeps the `uid` of the backup. The creation time `ctime`, in contrast, stays with the guest: a clone has the `ctime` of its source, and a restored guest or a guest migrated from another cluster has that of the backup or of the source guest. As a timestamp, the `rtime` is not guaranteed to be unique.

Proxmox VE manages the `meta` property automatically. It is read-only through the API, even for `root@pam`.



Important
The `uid` helps to correlate a guest with its backups and copies, but does not prove where a guest comes from. Whoever restores a backup or migrates a guest into the cluster supplies the `uid` of that guest, which Proxmox VE adopts if no other guest in the cluster has it. Proxmox VE keeps a `uid` unique within a cluster only for operations through its API. A configuration file copied by hand has the same `uid` as the original, and guests in different clusters can have the same `uid`.

16.10.2 Reading the Identity

The following places show the guest identity. All of them require the `VM.Audit` privilege on the guest.

- In the web interface, the *Summary* panel of the guest shows the `uid` as *Unique ID*. The *Details* button next to it, which has an info icon, opens the *Guest Identity* window. This window additionally shows the `rtime` as *Registered* and the creation information.
- The guest configuration, for example with `qm config <vmid>` or `pct config <vmid>`, and through the API paths `/nodes/<node>/qemu/<vmid>/config` and `/nodes/<node>/lxc/<vmid>/confi`
- The guest status at the API paths `/nodes/<node>/qemu/<vmid>/status/current` and `/nodes/<n` which contains the `uid`.
- The cluster resources at the API path `/cluster/resources`, which contain the `uid` and `rtime` of each guest that has a guest identity, for example:

```
# pvesh get /cluster/resources --type vm --output-format json-pretty
```

The configuration in a backup contains the `meta` property as well. You can show it with `pvesm extractconfi <volume>`, for example.

To tell apart guests with the same `uid` in different clusters, combine the `uid` with the cluster ID.

16.10.3 Lifecycle

The following table shows how operations affect the identity of a guest.

Operation	`uid`	`rtime`
Create, including import	new	current time
Clone, including linked clones and clones from snapshots	new	current time
Restore to a free VMID	the backup's `uid` if present and not used by another guest in the cluster; otherwise new	current time
Restore to a free VMID with `unique` set	new	current time
Restore over an existing guest that has a `uid`, with or without `unique` set	kept, see Restore Over an Existing Guest; the retry of a failed restore can adopt the backup's `uid` instead, see Retrying a Failed Restore	kept; current time if the retry adopts the `uid`
Restore over an existing guest without a `uid`	as for a free VMID	current time
Migration to another cluster, on the target	the source guest's `uid`; new if another guest in the target cluster has it and `allow-new-uid` is set, or if the source node runs a Proxmox VE version older than 9.3, see Migration to Another Cluster	current time
Migration to another cluster, on the source if the guest is kept	kept	kept
Snapshot rollback	kept, not taken from the snapshot	kept
Migration within the cluster, HA recovery, configuration change, backup, replication, conversion to a template	kept	kept
Destroy	removed	removed

Restores and migrations from another cluster report the outcome in their task log, in a line with `guest identity:`, for example:

```
guest identity: backup uid w5qczgiem26qnwzwsoil is in use by guest 100,  ↩
   keeping uid er3n3wqoqgcl362ep3da
```

Guests that existed before the upgrade to Proxmox VE 9.3 get their identity the first time a node running Proxmox VE 9.3 or later writes their configuration. This happens, for example, when their configuration changes, when they are backed up, or when they are migrated to such a node. Their `rtime` is the time of that write. Backups made before that have no `uid`.

Note

For tools that track guests by their `uid`: a restore that adopts the `uid` of the backup first assigns a new `uid` to the guest and replaces it at its end, which can be after the guest got unlocked. A migration from another cluster adopts the `uid` of the source guest right at its start. A changed `uid`, for example in `/cluster/resources`, therefore does not mean that the task has finished. A guest that a tool restores by removing it and creating a new one through the API gets a new `uid`. To keep the identity, change the existing guest in place, or let Proxmox VE restore the guest.

16.10.4 Restore Over an Existing Guest

If the existing guest already has a guest identity, restoring a backup over it keeps the `uid` and `rtime` of that guest, unless the guest is left over from a failed restore of that backup, see Retrying a Failed Restore. When both the guest and the backup have a `uid` and the values differ, Proxmox VE treats the backup as belonging to another guest. This can happen when a VMID was reused. Proxmox VE refuses such a restore before it overwrites the guest:

```
backup belongs to another guest: its uid 'w5qczgiem26qnwzwsoil' differs  ↩
   from uid 'er3n3wqoqgcl362ep3da' of the existing VM 100 - use 'allow- ↩
   identity-mismatch' to overwrite the VM anyway
```

To restore such a backup anyway, set the `allow-identity-mismatch` option. The existing guest then keeps its identity. In the web interface, select *Allow restoring a backup of another guest* in the restore window, which you open from the *Backup* panel of the guest. On the command line, use for example:

```
# qmrestore <archive> <vmid> --force 1 --allow-identity-mismatch 1
# pct restore <vmid> <archive> --force 1 --allow-identity-mismatch 1
```

Backups without a `uid`, such as backups made with Proxmox VE versions older than 9.3, are not refused. Container restores from standard input (`pct restore <vmid> -`) are an exception: the `uid` of such a backup is only known once the container has been overwritten. A restore from standard input over a container with a `uid` therefore always requires `allow-identity-mismatch`.

16.10.5 Retrying a Failed Restore

For locks and leftovers of a failed restore, see Failed Restores.

If the failed restore was to a free VMID or over a guest without a `uid`, and it had already read a backup that has a `uid`, `qm pending <vmid>` or `pct pending <vmid>` lists an entry for `meta` with the `uid` of the backup. As long as this entry exists, retrying the same restore over the guest left behind is accepted. Starting the guest or changing its options removes the entry and logs a warning that names the `uid`. The retry is then refused like a restore of another guest's backup.

A successful retry adopts the `uid` of the backup and sets a new `rtime`, as a restore to a free VMID does. The guest keeps its `uid` and `rtime` instead if another guest in the cluster has the `uid` of the backup, or if the retry sets `unique`.

A guest that had a `uid` and no such entry before the failed restore keeps its `uid` and gets no entry. A retry is checked like the first attempt: a backup with the same `uid` is accepted, also after the guest was started or changed, and a backup with another `uid` requires `allow-identity-mismatch`.

If a restore over an existing guest without a `uid` stopped before it read the backup, for example because the backup storage was unreachable, the guest now has a new `uid`. Retry with `allow-identity-mismatch`. The guest then keeps the new `uid`.

A restore can also complete with a warning starting with `guest identity: unable to adopt backup uid`, for example if the cluster-wide lock for this step could not be taken in time. The guest is then restored completely, but keeps its new `uid`. To adopt the `uid` of the backup, repeat the restore over the guest before you start it or change its configuration.

16.10.6 Migration to Another Cluster

A migration to another cluster (`qm remote-migrate`, `pct remote-migrate`) keeps the `uid` of the guest. The target adopts it at the start of the migration, before any data is transferred.

If another guest in the target cluster already has that `uid`, the migration is refused at that point. Typical cases are:

- the guest gets migrated back to a cluster that still has the source guest of an earlier migration, which stays there unless `delete` was set,
- a copy of the guest was restored in the target cluster from a backup,
- an earlier migration of the guest broke off after it had transferred the configuration and left a locked guest in the target cluster,
- the target is the cluster that the guest is in.

The error ends with:

```
guest 105 in the target cluster already has the uid 'w5qczgiem26qnwzwsoil' ↩
   of this guest - use 'allow-new-uid' to migrate it with a new uid
```

If the reported guest is the source guest itself, do not remove it. To keep the `uid`, migrate the guest within the cluster instead, with `qm migrate` or `pct migrate`.

Otherwise, to keep the `uid`, remove the other guest in the target cluster if you no longer need it, and migrate again. To migrate anyway, set the `allow-new-uid` option. The migrated guest then gets a new `uid`, and the other guest keeps the old one. In both cases, use another target VMID if the next-id setting of the target cluster has the `unique` and `enforce` options set, as the refused migration already used the first one. For example:

```
# qm remote-migrate <vmid> <target-vmid> <target-endpoint> --target-bridge ↩
   <bridge> --target-storage <storage> --allow-new-uid 1
```

A migration to another cluster is refused right after connecting to a target node with a version older than 9.3, before any data is transferred. The error is `Remote tunnel endpoint too old, upgrade required`.

16.10.7 Mixed Versions in a Cluster

Proxmox VE versions older than 9.3 ignore the whole `meta` property of a guest that has a guest identity, including the creation information. A VM started on a node running such a version can therefore get different virtual hardware, see Machine Type. When such a node writes the configuration, the property is lost.

Therefore, while some nodes of a cluster still run such a version, migrating or cloning a guest to one of these nodes is refused. The guest keeps running on its current node. The error message shows the version of the target node and the minimum required version. The *Migrate* window of the web interface shows the reason for the selected target node.

Moves of HA-managed guests to such nodes are refused in the same way. A running VM that the HA stack migrates keeps running. The HA stack stops a container, and a VM that it relocates, before it migrates the guest, so such a guest is stopped although the move is then refused. The HA stack retries automatic moves as long as it selects such a node, and such a guest can stay stopped in the meantime. This includes moves for:

- the maintenance mode,
- a node shutdown with the `migrate` shutdown policy,
- node affinity rules,
- the CRS load balancer.

Such moves complete only after the target nodes that the HA stack selects run Proxmox VE 9.3 or later.

To avoid refused moves while you upgrade a cluster, do one of the following:

- Move all guests away from a node before you upgrade it.
- Upgrade the packages on all nodes, one node at a time, before you reboot any node or enable the maintenance mode.

The check covers migrations and clones started on a node running Proxmox VE 9.3 or later. It does not cover:

- the HA recovery of guests from a fenced node,
- configuration files moved by hand,
- operations started on a node with an older version.

If an older node writes the configuration of a guest in one of these cases, the guest loses its `meta` property. In an HA recovery, such a node can also be the node of the active HA manager (CRM), which writes the configuration when it removes a leftover lock, for example of a backup. The guest gets a new identity the next time a node running Proxmox VE 9.3 or later writes its configuration.

Backups made with Proxmox VE 9.3 or later contain the guest identity. Restore them only on nodes running Proxmox VE 9.3 or later, because older versions ignore the `meta` property of such backups in the same way.

16.11 Configuration

Global configuration is stored in `/etc/vzdump.conf`. The file uses a simple colon separated key/value format. Each line has the following format:

```
OPTION: value
```

Blank lines in the file are ignored, and lines starting with a `#` character are treated as comments and are also ignored. Values from this file are used as default, and can be overwritten on the command line.

We currently support the following options:

bwlimit: <integer> (0 - N) (*default* = 0)
: Limit I/O bandwidth (in KiB/s).

compress: **<0 | 1 | gzip | lzo | zstd>** (***default =*** **0**)
Compress dump file.

dumpdir: **<string>**
Store resulting files to specified directory.

exclude-path: **<array>**
Exclude certain files/directories (shell globs). Paths starting with / are anchored to the container's root, other paths match relative to each subdirectory.

fleecing: **[[enabled=]<1|0>] [,storage=<storage ID>]**
Options for backup fleecing (VM only).

enabled=<boolean> (***default =*** **0**)
Enable backup fleecing. Cache backup data from blocks where new guest writes happen on specified storage instead of copying them directly to the backup target. This can help guest IO performance and even prevent hangs, at the cost of requiring more storage space.

storage=<storage ID>
Use this storage to storage fleecing images. For efficient space usage, it's best to use a local storage that supports discard and either thin provisioning or sparse files.

ionice: **<integer> (0 - 8)** (***default =*** **7**)
Set IO priority when using the BFQ scheduler. For snapshot and suspend mode backups of VMs, this only affects the compressor. A value of 8 means the idle priority is used, otherwise the best-effort priority is used with the specified value.

lockwait: **<integer> (0 - N)** (***default =*** **180**)
Maximal time to wait for the global lock (minutes).

mailnotification: **<always | failure>** (***default =*** **always**)
Deprecated: use notification targets/matchers instead. Specify when to send a notification mail

mailto: **<string>**
Deprecated: Use notification targets/matchers instead. Comma-separated list of email addresses or users that should receive email notifications.

mode: **<snapshot | stop | suspend>** (***default =*** **snapshot**)
Backup mode.

notes-template: **<string>**
Template string for generating notes for the backup(s). It can contain variables which will be replaced by their values. Currently supported are {\{\cluster}}, {\{\guestname}}, {\{\node}}, {\{\uid}}, and {\{\vmid}}, but more might be added in the future. Needs to be a single line, newline and backslash need to be escaped as *\n* and \\ respectively.

Note
Requires option(s): `storage`

notification-mode: <auto | legacy-sendmail | none | notification-system> (*default =* auto)
Determine which notification system to use. If set to *legacy-sendmail*, vzdump will consider the mailto/-mailnotification parameters and send emails to the specified address(es) via the *sendmail* command. If set to *notification-system*, a notification will be sent via PVE's notification system, and the mailto and mailnotification will be ignored. If set to *auto* (default setting), an email will be sent if mailto is set, and the notification system will be used if not. If set to *none*, no notification will be sent.

pbs-change-detection-mode: <data | legacy | metadata>
PBS mode used to detect file changes and switch encoding format for container backups.

performance: [max-workers=<integer>] [,pbs-entries-max=<integer>]
Other performance-related settings.

max-workers=<integer> (1 - 256) (*default =* 16)
Applies to VMs. Allow up to this many IO workers at the same time.

pbs-entries-max=<integer> (1 - N) (*default =* 1048576)
Applies to container backups sent to PBS. Limits the number of entries allowed in memory at a given time to avoid unintended OOM situations. Increase it to enable backups of containers with a large amount of files.

pigz: <integer> (*default =* 0)
Use pigz instead of gzip when N>0. N=1 uses half of cores, N>1 uses N as thread count.

pool: <string>
Backup all known guest systems included in the specified pool.

protected: <boolean>
If true, mark backup(s) as protected.

Note
Requires option(s): `storage`

prune-backups: [keep-all=<1|0>] [,keep-daily=<N>] [,keep-hourly=<N>] [,keep-last=<N>] [,keep-monthly=<N>] [,keep-weekly=<N>] [,keep-yearly=<N>] (*default =* keep-all=1)
Use these retention options instead of those from the storage configuration.

keep-all=<boolean>
Keep all backups. Conflicts with the other options when true.

keep-daily=<N>
Keep backups for the last <N> different days. If there is more than one backup for a single day, only the latest one is kept.

keep-hourly=<N>
Keep backups for the last <N> different hours. If there is more than one backup for a single hour, only the latest one is kept.

keep-last=<N>
Keep the last <N> backups.

keep-monthly=<N>
Keep backups for the last <N> different months. If there is more than one backup for a single month, only the latest one is kept.

keep-weekly=<N>
Keep backups for the last <N> different weeks. If there is more than one backup for a single week, only the latest one is kept.

keep-yearly=<N>
Keep backups for the last <N> different years. If there is more than one backup for a single year, only the latest one is kept.

remove: <boolean> (*default =* 1)
Prune older backups according to *prune-backups*.

script: <string>
Use specified hook script.

stdexcludes: <boolean> (*default =* 1)
Exclude temporary files and logs.

stopwait: <integer> (0 - N) (*default =* 10)
Maximal time to wait until a guest system is stopped (minutes).

storage: <storage ID>
Store resulting file to this storage.

tmpdir: <string>
Store temporary files to specified directory.

zstd: <integer> (*default =* 1)
Zstd threads. N=0 uses half of the available cores, if N is set to a value bigger than 0, N is used as thread count.

Example vzdump.conf Configuration

```
tmpdir: /mnt/fast_local_disk
storage: my_backup_storage
mode: snapshot
bwlimit: 10000
```

16.12 Hook Scripts

You can specify a hook script with option `--script`. This script is called at various phases of the backup process, with parameters accordingly set. You can find an example in the documentation directory (`vzdump-hook-script.pl`).

16.13 File Exclusions

Note
this option is only available for container backups.

`vzdump` skips the following files by default (disable with the option `--stdexcludes 0`)

```
/tmp/?*
/var/tmp/?*
/var/run/?*pid
```

You can also manually specify (additional) exclude paths, for example:

```
# vzdump 777 --exclude-path /tmp/ --exclude-path '/var/foo*'
```

excludes the directory `/tmp/` and any file or directory named `/var/foo`, `/var/foobar`, and so on.



Warning
For backups to Proxmox Backup Server (PBS) and `suspend` mode backups, patterns with a trailing slash will match directories, but not files. On the other hand, for non-PBS `snapshot` mode and `stop` mode backups, patterns with a trailing slash currently do not match at all, because the `tar` command does not support that.

Paths that do not start with a `/` are not anchored to the container's root, but will match relative to any subdirectory. For example:

```
# vzdump 777 --exclude-path bar
```

excludes any file or directory named `/bar`, `/var/bar`, `/var/foo/bar`, and so on, but not `/bar2`.

Configuration files are also stored inside the backup archive (in `./etc/vzdump/`) and will be correctly restored.

16.14 Examples

Simply dump guest 777 - no snapshot, just archive the guest private area and configuration files to the default dump directory (usually `/var/lib/vz/dump/`).

```
# vzdump 777
```

Use rsync and suspend/resume to create a snapshot (minimal downtime).

```
# vzdump 777 --mode suspend
```

Backup all guest systems and send notification mails to root and admin. Due to `mailto` being set and `notification-mode` being set to `auto` by default, the notification mails are sent via the system's `sendmail` command instead of the notification system.

```
# vzdump --all --mode suspend --mailto root --mailto admin
```

Use snapshot mode (no downtime) and non-default dump directory.

```
# vzdump 777 --dumpdir /mnt/backup --mode snapshot
```

Backup more than one guest (selectively)

```
# vzdump 101 102 103 --mailto root
```

Backup all guests excluding 101 and 102

```
# vzdump --mode suspend --exclude 101,102
```

Restore a container to a new CT 600

```
# pct restore 600 /mnt/backup/vzdump-lxc-777.tar
```

Restore a QemuServer VM to VM 601

```
# qmrestore /mnt/backup/vzdump-qemu-888.vma 601
```

Clone an existing container 101 to a new container 300 with a 4GB root file system, using pipes

```
# vzdump 101 --stdout | pct restore --rootfs 4 300 -
```

Chapter 17

Notifications

17.1 Overview

- Proxmox VE emits Notification Events in case of storage replication failures, node fencing, finished/failed backups and other events. These events are processed based on the global notification settings. Each notification event includes metadata, such as a timestamp, severity level, type, and additional event-specific fields.
- Notification Matchers route a notification event to one or more notification targets. A matcher can have match rules to selectively route based on the metadata of a notification event.
- Notification Targets are a destination to which a notification event is routed to by a matcher. There are multiple types of target, mail-based (Sendmail and SMTP) and Gotify.

The global notification settings can be configured in the GUI under Datacenter → Notifications. The configuration is stored in `/etc/pve/notifications.cfg` and `/etc/pve/priv/notifications.cfg` - the latter contains sensitive configuration options such as passwords or authentication tokens for notification targets and can only be read by `root`.

17.2 Notification Targets

Proxmox VE offers multiple types of notification targets.

17.2.1 Sendmail



The sendmail binary is a program commonly found on Unix-like operating systems that handles the sending of email messages. It is a command-line utility that allows users and applications to send emails directly from the command line or from within scripts.

The sendmail notification target uses the `sendmail` binary to send emails to a list of configured users or email addresses. If a user is selected as a recipient, the email address configured in user's settings will be used. For the `root@pam` user, this is the email address entered during installation. A user's email address can be configured in `Datacenter` → `Permissions` → `Users`. If a user has no associated email address, no email will be sent.

Note
In standard Proxmox VE installations, the `sendmail` binary is provided by Postfix. It may be necessary to configure Postfix so that it can deliver mails correctly - for example by setting an external mail relay (smart host). In case of failed delivery, check the system logs for messages logged by the Postfix daemon.

The configuration for Sendmail target plugins has the following options:

- `mailto`: E-Mail address to which the notification shall be sent to. Can be set multiple times to accommodate multiple recipients.
- `mailto-user`: Users to which emails shall be sent to. The user's email address will be looked up in `users.cfg`. Can be set multiple times to accommodate multiple recipients.
- `author`: Sets the author of the E-Mail. Defaults to `Proxmox VE`.
- `from-address`: Sets the from address of the E-Mail. If the parameter is not set, the plugin will fall back to the `email_from` setting from `datacenter.cfg`. If that is also not set, the plugin will default to `root@$hostname`, where `$hostname` is the hostname of the node. The `From` header in the email will be set to `$author <$from-address>`.
- `comment`: Comment for this target

Example configuration (`/etc/pve/notifications.cfg`):

```
sendmail: example
        mailto-user root@pam
        mailto-user admin@pve
        mailto max@example.com
        from-address pve1@example.com
        comment Send to multiple users/addresses
```

17.2.2 SMTP



SMTP notification targets can send emails directly to an SMTP mail relay. This target does not use the system's MTA to deliver emails. Similar to sendmail targets, if a user is selected as a recipient, the user's configured email address will be used.

Note
Unlike sendmail targets, SMTP targets do not have any queuing/retry mechanism in case of a failed mail delivery.

The configuration for SMTP target plugins has the following options:

- `mailto`: E-Mail address to which the notification shall be sent to. Can be set multiple times to accommodate multiple recipients.
- `mailto-user`: Users to which emails shall be sent to. The user's email address will be looked up in `users.cfg`. Can be set multiple times to accommodate multiple recipients.
- `author`: Sets the author of the E-Mail. Defaults to `Proxmox VE`.
- `from-address`: Sets the From-address of the email. SMTP relays might require that this address is owned by the user in order to avoid spoofing. The `From` header in the email will be set to `$author <$from-address>`.
- `username`: Username to use during authentication. If no username is set, no authentication will be performed. The PLAIN and LOGIN authentication methods are supported.
- `password`: Password to use when authenticating.
- `mode`: Sets the encryption mode (`insecure`, `starttls` or `tls`). Defaults to `tls`.
- `server`: Address/IP of the SMTP relay.
- `port`: The port to connect to. If not set, the used port defaults to 25 (`insecure`), 465 (`tls`) or 587 (`starttls`), depending on the value of `mode`.
- `comment`: Comment for this target

Example configuration (`/etc/pve/notifications.cfg`):

```
smtp: example
        mailto-user root@pam
        mailto-user admin@pve
        mailto max@example.com
        from-address pve1@example.com
        username pve1
        server mail.example.com
        mode starttls
```

The matching entry in `/etc/pve/priv/notifications.cfg`, containing the password:

```
smtp: example
        password somepassword
```

17.2.3 Gotify



Gotify is an open-source self-hosted notification server that allows you to send and receive push notifications to various devices and applications. It provides a simple API and web interface, making it easy to integrate with different platforms and services.

The configuration for Gotify target plugins has the following options:

- `server`: The base URL of the Gotify server, e.g. `http://<ip>:8888`
- `token`: The authentication token. Tokens can be generated within the Gotify web interface.
- `comment`: Comment for this target

Note
The Gotify target plugin will respect the HTTP proxy settings from the datacenter configuration

Example configuration (`/etc/pve/notifications.cfg`):

```
gotify: example
        server http://gotify.example.com:8888
        comment Send to multiple users/addresses
```

The matching entry in `/etc/pve/priv/notifications.cfg`, containing the secret token:

```
gotify: example
        token somesecrettoken
```

17.2.4 Webhook

Webhook notification targets perform HTTP requests to a configurable URL.

The following configuration options are available:

- `url`: The URL to which to perform the HTTP requests. Supports templating to inject message contents, metadata and secrets.
- `method`: HTTP Method to use (POST/PUT/GET)
- `header`: Array of HTTP headers that should be set for the request. Supports templating to inject message contents, metadata and secrets.
- `body`: HTTP body that should be sent. Supports templating to inject message contents, metadata and secrets.
- `secret`: Array of secret key-value pairs. These will be stored in a protected configuration file only readable by root. Secrets can be accessed in body/header/URL templates via the `secrets` namespace.
- `comment`: Comment for this target.

For configuration options that support templating, the Handlebars syntax can be used to access the following properties:

- `{{ title }}`: The rendered notification title
- `{{ message }}`: The rendered notification body
- `{{ severity }}`: The severity of the notification (`info`, `notice`, `warning`, `error`, `unknown`)
- `{{ timestamp }}`: The notification's timestamp as a UNIX epoch (in seconds).
- `{{ fields.<name> }}`: Sub-namespace for any metadata fields of the notification. For instance, `fields.type` contains the notification type - for all available fields refer to Notification Events.
- `{{ secrets.<name> }}`: Sub-namespace for secrets. For instance, a secret named `token` is accessible via `secrets.token`.

For convenience, the following helpers are available:

- `{{ url-encode <value/property> }}`: URL-encode a property/literal.
- `{{ escape <value/property> }}`: Escape any control characters that cannot be safely represented as a JSON string.
- `{{ json <value/property> }}`: Render a value as JSON. This can be useful to pass a whole sub-namespace (e.g. `fields`) as a part of a JSON payload (e.g. `{{ json fields }}`).

Examples

ntfy.sh

- Method: `POST`
- URL: `https://ntfy.sh/{{ secrets.channel }}`
- Headers:
  - `Markdown`: `Yes`
- Body:

```
```
{{ message }}
```
```

- Secrets:
  - `channel`: `<your ntfy.sh channel>`

Discord

- Method: `POST`
- URL: `https://discord.com/api/webhooks/{{ secrets.token }}`
- Headers:
  - `Content-Type`: `application/json`
- Body:

```
{
  "content": "``` {{ escape message }}```"
}
```

- Secrets:
  - `token`: `<token>`

Slack

- Method: `POST`
- URL: `https://hooks.slack.com/services/{{ secrets.token }}`
- Headers:
  - `Content-Type: application/json`
- Body:

```
{
  "text": "``` {{escape message}}```",
  "type": "mrkdwn"
}
```

- Secrets:
  - `token: <token>`

17.3 Notification Matchers



Notification matchers route notifications to notification targets based on their matching rules. These rules can match certain properties of a notification, such as the timestamp, the severity of the notification or metadata fields, as well as arbitrary combinations of these. If a notification is matched by a matcher, all targets configured for the matcher will receive the notification.

An arbitrary number of matchers can be created, each with their own match rules and targets to notify. Every target is notified at most once for every notification, even if the target is used in multiple matchers.

17.3.1 Match Rules

Notification matchers can be configured in the Proxmox VE Web UI under Datacenter → Notifications. Matchers can be created, modified and deleted from this view.

When editing a matcher, match rules can be edited under the *Match Rules* tab. Rules are represented as a tree. Each tree node can either match on properties of a notification (fields, severity or timestamp) or combine the results of child nodes (e.g. *All sub-rules match*). Combinator nodes can be nested, which makes it possible to compose arbitrarily complex matching behavior.

The following node types are available:

- **Always match**: Match any notification.
- **All sub-rules match**: All direct children of this node must match.
- **At least one sub-rule matches**: At least one direct child of this node must match.
- **Exactly one sub-rule matches**: Exactly one direct child of this node must match.
- **Match Field**: Match a metadata field of a notification. This node can either match if the field value matches one of the values provided, or, alternatively, if it matches a regular expression. Available fields are listed in Notification Events.
- **Match Calendar**: Check if the timestamp of a notification is within a configured time range, based on a selection of weekdays and one contiguous time range within each day (e.g. Monday to Friday, 09:00 to 17:00). If multiple time ranges within a day must be matched, use an **At least one sub-rule matches** node with one **Match Calendar** child per time range.
- **Match Severity**: Match the severity of a notification. The following severity levels are available: `info`, `notice`, `warning`, `error` and `unknown`. Each **Match Severity** node can specify multiple severity levels it matches on, for instance `info` and `notice`.

Each node in the tree can be inverted by checking **Invert Rule**. For instance, for a **Match Severity** node matching on `info`, checking **Invert Rule** lets the node match on `notice`, `warning`, `error` and `unknown`.

Under the *Targets to Notify* tab, one or more notification targets can be selected. All selected targets are notified if a notification is matched.

17.3.2 Matcher Configuration Options

This section gives an overview of the options used by matchers in the configuration file and in the API.

The following options are used in configuration entries for matchers:

- `target`: Determine which target should be notified if the matcher matches. Can be used multiple times to notify multiple targets.
- `disable`: Don't evaluate this matcher.
- `comment`: Comment for this matcher.

- The matching behavior is defined either by the `expression` option or by the deprecated options below; the two cannot be combined.
  - Expression-based matchers (preferred):
    - `expression`: Ruleset for this matcher as a single JSON-serialized object (Match Expression Reference).
  - Deprecated matcher options:
    - `invert-match`: Inverts the result of the whole matcher.
    - `mode`: Determines how the individual match rules are evaluated to compute the result for the whole matcher. If set to `all`, all matching rules must match. If set to `any`, at least one rule must match. Defaults to `all`.
    - `match-calendar`: Match the notification's timestamp against a schedule. Days can be specified as an inclusive range (e.g. `mon..wed`) or enumerated (e.g. `mon,wed,sat`). If no days are specified, the time range applies to every day of the week (e.g. `08:00-12:00`).
      Examples:
      ```
      match-calendar mon..wed 9-12
      match-calendar mon,wed,sat 08:15-12:35
      match-calendar 04:15-16:35
      ```
    - `match-field`: Match a notification's metadata field, either against a list of matched values, or as a regular expression. If the field does not exist, the notification will not be matched.
      Examples:
      ```
      match-field exact:type=vzdump
      match-field exact:type=replication,fencing
      match-field regex:hostname=^pve[0-9]+$
      ```
    - `match-severity`: Match the notification's severity.
      Examples:
      ```
      match-severity error
      match-severity warning,error,unknown
      ```

A matcher without any matching rules always matches; the configured targets will always be notified.

Starting with Proxmox VE 9.3, match rules created and edited via the UI are stored as a single option `expression` in the respective matcher configuration entry. The previously used options (`match-field`, `match-calendar`, `match-severity`, `mode` and `invert-match`) will continue to be supported at least until the next major release.

Note
Any existing matcher will be migrated to use the newer `expression` option when edited through the UI.

17.3.3 Match Expression Reference

This section describes the representation used to encode rules in the `expression` parameter.

The `expression` option contains a JSON-formatted tree structure of rules, with leaf nodes matching on the properties of a notification (`field`, `severity`, `calendar`) or representing constants (`constant`). Intermediate nodes and the root node encode the relationship between them (`all-of`, `any-of`, `one-of`, `not`).

Node Type	Description	Leaf Node	Example
`all-of`	Match if all child nodes match	No	`{"all-of": [<expr>]}`
`any-of`	Match if any child node matches	No	`{"any-of": [<expr>]}`
`one-of`	Match if exactly one child node matches	No	`{"one-of": [<expr>]}`
`not`	Invert the result of a single child node	No	`{"not": <expr>}`
`constant`	Always or never matches, depending on the boolean value	Yes	`{"constant": true|false}`
`match`	Match on a property of a notification	Yes	`{"match": <match-expr>}`

`match` leaf nodes can have the following variants (`<match-expr>`):

Match Type	Description	Example
`calendar`	Check if the notification's timestamp is within a configured time range	`{"type": "calendar", "schedule": "mon..fri 9-17"}`
`field`	Check a notification's fields against a regex or a list of permitted values	`{"type": "field", "field": "job-id", "values": ["a", "b"]}` or `{"type": "field", "field": "hostname", "regex": "^pve[0-9]+$"}`
`severity`	Check a notification's severity against a list of permitted values	`{"type": "severity", "severities": ["info", "notice"]}`

A pretty-printed, full example of a non-trivial expression is shown below. It encodes an expression matching on backup jobs (`vzdump`), but only within a given time range (`mon..fri 09:00-17:00`) or if it has a severity of `warning` or `error`. In the API and configuration file, the JSON is expected to be stored as a single line, as the value of the `expression` option; the line breaks and indentation are only for demonstration purposes.

```
{
  "all-of": [
    {
      "any-of": [
        {
          "match": {
            "type": "calendar",
            "schedule": "mon..fri 09:00-17:00"
          }
        },
        {
          "match": {
            "type": "severity",
            "severities": [
```

```
              "warning",
              "error"
            ]
          }
        }
      ]
    },
    {
      "match": {
        "type": "field",
        "field": "type",
        "values": [
          "vzdump"
        ]
      }
    }
  ]
}
```

17.4 Notification Events

Event	`type`	Severity	Metadata fields (in addition to `type`)
System updates available	`package-updates`	`info`	`hostname`
Cluster node fenced	`fencing`	`error`	`hostname`
Storage replication job failed	`replication`	`error`	`hostname`, `job-id`
Multipath paths lost	`multipath`	`warning`	`hostname`
Multipath LUN failed	`multipath`	`error`	`hostname`
Multipath paths restored	`multipath`	`info`	`hostname`
Multipath alert cleared	`multipath`	`info`	`hostname`
Backup succeeded	`vzdump`	`info`	`hostname`, `job-id` (only for backup jobs)
Backup failed	`vzdump`	`error`	`hostname`, `job-id` (only for backup jobs)
Mail for root	`system-mail`	`unknown`	`hostname`

Field name	Description
`type`	Type of the notification
`hostname`	Hostname, without domain (e.g. `pve1`)
`job-id`	Job ID

A `multipath` notification groups the affected LUNs and NVMe namespaces of a node. If any of them in a problem notification is **Failed**, the severity is `error`.

Note
Backup job notifications only have `job-id` set if the backup job was executed automatically based on its schedule, but not if it was triggered manually by the *Run now* button in the UI.

17.5 Notification Queue

Notification events are not sent directly by the process that emits them. Instead, they are put into a local queue and sent by the `pve-notify-worker` service within a few seconds. Errors while sending, for example an unreachable mail server, are therefore logged to the system journal of that service, not to the task log of the job that emitted the event. Test notifications for a target are the exception: these are sent directly, so that their result can be reported.

Logs for the `pve-notify-worker` service can be viewed in the web interface under the **System** tab for the node that emitted the notification event, by selecting the `pve-notify-worker` service and clicking the **Service System Log** button. Alternatively, run `journalctl -u pve-notify-worker` on that node.

If the service is shut down gracefully while sending a notification (e.g. due to a `systemctl stop pve-notify-worker`), the service attempts to finish sending before shutting down. If the service is stopped irregularly, e.g. due to a crash or being killed, it sends the notification again after it has been restarted. There can be up to 2 retries after the initial attempt, after which the notification is dropped by the worker. Targets that have already been notified during a prior attempt may be notified again. The retries only cover interruptions of the service. Failed deliveries to individual targets, for example due to an unreachable email server, are not retried.

If the notification configuration cannot be loaded, for example while the `pve-cluster` service is not running, notifications stay in the queue. The service tries again periodically and sends them once the configuration can be loaded. These attempts do not count towards the retry limit.

The local notification queue is located at `/var/lib/pve-manager/notifications/queue`, with each queued notification being a file in this directory. Notification files follow the naming scheme `notification-` with an optional appended attempt counter, for instance `notification-46516f7e-7eb7-43e7-b776-60` for a freshly queued notification or `notification-46516f7e-7eb7-43e7-b776-6048f144a6fe.att` for a notification that is either currently being handled or was interrupted during the first attempt. Attempts that do not count towards the retry limit are not counted here either, so a notification waiting to be sent can also end in `.attempt-0`.

Generally, this directory should be empty if all queued notifications have been sent. Notification files with a `.broken` suffix could not be processed by the `pve-notify-worker` service, for example because the file is not a regular file, is too large, or does not contain a valid notification. The service keeps such files for inspection and never removes them itself. It is safe to delete `.broken` files at any time.

17.6 System Mail Forwarding

Certain local system daemons, such as `smartd`, generate notification emails that are initially directed to the local `root` user. These mails are converted into notification events with the type `system-mail` and a severity of `unknown` and are processed based on the global notification settings.

When the email is forwarded to a sendmail target, the mail's content and headers are forwarded as-is. For all other targets, the system tries to extract both a subject line and the main text body from the email content. In

instances where emails solely consist of HTML content, they will be transformed into plain text format during this process.

If Proxmox Backup Server is installed on the same host, system mails are only handled by the notification system of Proxmox VE. Mails larger than 1 MiB are rejected and bounce. If a mail cannot be queued, the local mail system keeps it and tries again later.

17.7 Permissions

To modify/view the configuration for notification targets, the `Mapping.Modify/Mapping.Audit` permissions are required for the `/mapping/notifications` ACL node.

Testing a target requires `Mapping.Use`, `Mapping.Audit` or `Mapping.Modify` permissions on `/mapping`

17.8 Notification Mode

Backup jobs allow to choose between two modes for sending backup related notifications. This is controlled by the `notification-mode` option in the backup job configuration.

- Send notifications based on the global notification settings (`notification-system`).
- Send notification emails via the system's `sendmail` command to the email address configured in the backup job (`legacy-sendmail`). This mode also allows to select whether the email should be sent always or only on failure of the backup. Any targets or matchers from the global notification settings are ignored. This mode is equivalent to the notification behavior for Proxmox VE versions before 8.1. This mode might be removed in a later release of Proxmox VE.

17.9 Overriding Notification Templates

Proxmox VE uses Handlebars templates to render notifications. The original templates provided by Proxmox VE are stored in `/usr/share/pve-manager/templates/default/`.

Notification templates can be overridden by providing a custom template file in the override directory at `/etc/pve/notification-templates/default/`. When rendering a notification of a given type, Proxmox VE will first attempt to load a template from the override directory. If this one does not exist or fails to render, the original template will be used.

The template files follow the naming convention of `<type>-<body|subject>.<html|txt>.hbs`. For instance, the file `vzdump-body.html.hbs` contains the template for rendering the HTML version for backup notifications, while `package-updates-subject.txt.hbs` is used to render the subject line of notifications for available package updates.

Email-based notification targets, such as `sendmail` and `smtp`, always send multi-part messages with an HTML and a plain text part. As a result, both the `<type>-body.html.hbs` as well as the `<type>-body.txt` template will be used when rendering the email message. All other notification target types only use the `<type>-body.txt.hbs` template.

Chapter 18

Important Service Daemons

18.1 pvedaemon - Proxmox VE API Daemon

This daemon exposes the whole Proxmox VE API on `127.0.0.1:85`. It runs as `root` and has permission to do all privileged operations.

Note
The daemon listens to a local address only, so you cannot access it from outside. The `pveproxy` daemon exposes the API to the outside world.

18.1.1 Number of Workers

`pvedaemon` delegates handling of incoming requests to worker processes. By default, `pvedaemon` spawns 3 worker processes, which is sufficient for most workloads. For automation-heavy workloads that issue a huge volume of API requests and that experience slow request handling or timeouts, the number of worker processes can be increased by setting `MAX_WORKERS` in `/etc/default/pvedaemon`, for example:

```
MAX_WORKERS=5
```

Note that a higher number of worker processes may result in higher CPU usage. The number of worker processes must be greater than 0 and smaller than 128.

The same setting exists for pveproxy.

18.2 pveproxy - Proxmox VE API Proxy Daemon

This daemon exposes the whole Proxmox VE API on TCP port 8006 using HTTPS. It runs as user `www-data` and has very limited permissions. Operation requiring more permissions are forwarded to the local `pvedaemon`.

Requests targeted for other nodes are automatically forwarded to those nodes. This means that you can manage your whole cluster by connecting to a single Proxmox VE node.

18.2.1 Host based Access Control

It is possible to configure “apache2”-like access control lists. Values are read from file /etc/default/pvepro
For example:

```
ALLOW_FROM="10.0.0.1-10.0.0.5,192.168.0.0/22"
DENY_FROM="all"
POLICY="allow"
```

IP addresses can be specified using any syntax understood by Net::IP. The name all is an alias for 0/0 and ::/0 (meaning all IPv4 and IPv6 addresses).

The default policy is allow.

Match	POLICY=deny	POLICY=allow
Match Allow only	allow	allow
Match Deny only	deny	deny
No match	deny	allow
Match Both Allow & Deny	deny	allow

18.2.2 Listening IP Address

By default the pveproxy and spiceproxy daemons listen on the wildcard address and accept connections from both IPv4 and IPv6 clients.

By setting LISTEN_IP in /etc/default/pveproxy you can control to which IP address the pveproxy and spiceproxy daemons bind. The IP-address needs to be configured on the system.

Setting the sysctl net.ipv6.bindv6only to the non-default 1 will cause the daemons to only accept connection from IPv6 clients, while usually also causing lots of other issues. If you set this configuration we recommend to either remove the sysctl setting, or set the LISTEN_IP to 0.0.0.0 (which will only allow IPv4 clients).

LISTEN_IP can be used to only to restricting the socket to an internal interface and thus have less exposure to the public internet, for example:

```
LISTEN_IP="192.0.2.1"
```

Similarly, you can also set an IPv6 address:

```
LISTEN_IP="2001:db8:85a3::1"
```

Note that if you want to specify a link-local IPv6 address, you need to provide the interface name itself. For example:

```
LISTEN_IP="fe80::c463:8cff:feb9:6a4e%vmbr0"
```



Warning
The nodes in a cluster need access to pveproxy for communication, possibly on different subnets. It is **not recommended** to set LISTEN_IP on clustered systems.

To apply the change you need to either reboot your node or fully restart the `pveproxy` and `spiceproxy` service:

```
systemctl restart pveproxy.service spiceproxy.service
```

Note
Unlike `reload`, a `restart` of the pveproxy service can interrupt some long-running worker processes, for example a running console or shell from a virtual guest. So, please use a maintenance window to bring this change in effect.

18.2.3 SSL Cipher Suite

You can define the cipher list in `/etc/default/pveproxy` via the `CIPHERS` (TLS ⇐ 1.2) and `CIPHERSUITE` (TLS >= 1.3) keys. For example

```
CIPHERS="ECDHE-ECDSA-AES256-GCM-SHA384:ECDHE-RSA-AES256-GCM-SHA384: ↩
   ECDHE-ECDSA-CHACHA20-POLY1305:ECDHE-RSA-CHACHA20-POLY1305:ECDHE- ↩
   ECDSA-AES128-GCM-SHA256:ECDHE-RSA-AES128-GCM-SHA256:ECDHE-ECDSA- ↩
   AES256-SHA384:ECDHE-RSA-AES256-SHA384:ECDHE-ECDSA-AES128-SHA256: ↩
   ECDHE-RSA-AES128-SHA256"
CIPHERSUITES="TLS_AES_256_GCM_SHA384:TLS_CHACHA20_POLY1305_SHA256: ↩
   TLS_AES_128_GCM_SHA256"
```

Above is the default. See the ciphers(1) man page from the openssl package for a list of all available options.

Additionally, you can set the client to choose the cipher used in `/etc/default/pveproxy` (default is the first cipher in the list available to both client and `pveproxy`):

```
HONOR_CIPHER_ORDER=0
```

18.2.4 Supported TLS versions

The insecure SSL versions 2 and 3 are unconditionally disabled for pveproxy. TLS versions below 1.1 are disabled by default on recent OpenSSL versions, which is honored by `pveproxy` (see `/etc/ssl/openssl.cnf`).

To disable TLS version 1.2 or 1.3, set the following in `/etc/default/pveproxy`:

```
DISABLE_TLS_1_2=1
```

or, respectively:

```
DISABLE_TLS_1_3=1
```

Note
Unless there is a specific reason to do so, it is not recommended to manually adjust the supported TLS versions.

18.2.5 Diffie-Hellman Parameters

You can define the used Diffie-Hellman parameters in `/etc/default/pveproxy` by setting `DHPARAMS` to the path of a file containing DH parameters in PEM format, for example

```
DHPARAMS="/path/to/dhparams.pem"
```

If this option is not set, the built-in `skip2048` parameters will be used.

Note
DH parameters are only used if a cipher suite utilizing the DH key exchange algorithm is negotiated.

18.2.6 Alternative HTTPS certificate

You can change the certificate used to an external one or to one obtained via ACME.

pveproxy uses `/etc/pve/local/pveproxy-ssl.pem` and `/etc/pve/local/pveproxy-ssl.key`, if present, and falls back to `/etc/pve/local/pve-ssl.pem` and `/etc/pve/local/pve-ssl.key`. The private key may not use a passphrase.

It is possible to override the location of the certificate private key `/etc/pve/local/pveproxy-ssl.key` by setting `TLS_KEY_FILE` in `/etc/default/pveproxy`, for example:

```
TLS_KEY_FILE="/secrets/pveproxy.key"
```

Note
The included ACME integration does not honor this setting.

See the Host System Administration chapter of the documentation for details.

18.2.7 Response Compression

By default `pveproxy` uses gzip HTTP-level compression for compressible content, if the client supports it. This can be disabled in `/etc/default/pveproxy`:

```
COMPRESSION=0
```

Note
Disabling compression mitigates BREACH-class side-channel attacks against authenticated session cookies, at the cost of slightly more bandwidth used by the web interface. Most deployments do not need to change the default; consider it on hosts where the web interface is exposed across networks you do not fully control.

18.2.8 Real Client IP Logging

By default, `pveproxy` logs the IP address of the client that sent the request. In cases where a proxy server is in front of `pveproxy`, it may be desirable to log the IP of the client making the request instead of the proxy IP.

To enable processing of a HTTP header set by the proxy for logging purposes, set `PROXY_REAL_IP_HEADER` to the name of the header to retrieve the client IP from. For example:

```
PROXY_REAL_IP_HEADER="X-Forwarded-For"
```

Any invalid values passed in this header will be ignored.

The default behavior is log the value in this header on all incoming requests. To define a list of proxy servers that should be trusted to set the above HTTP header, set `PROXY_REAL_IP_ALLOW_FROM`, for example:

```
PROXY_REAL_IP_ALLOW_FROM="192.168.0.2"
```

The `PROXY_REAL_IP_ALLOW_FROM` setting also supports values similar to the `ALLOW_FROM` and `DENY_FROM` settings.

IP addresses can be specified using any syntax understood by `Net::IP`. The name `all` is an alias for `0/0` and `::/0` (meaning all IPv4 and IPv6 addresses).

18.2.9 Number of Workers

`pveproxy` delegates handling of incoming requests to worker processes. By default, `pveproxy` spawns 3 worker processes, which is sufficient for most workloads. For automation-heavy workloads that issue a huge volume of API requests and that experience slow request handling or timeouts, the number of worker processes can be increased by setting `MAX_WORKERS` in `/etc/default/pveproxy`, for example:

```
MAX_WORKERS=5
```

Note that a higher number of worker processes may result in higher CPU usage. The number of worker processes must be greater than 0 and smaller than 128.

The same setting exists for pvedaemon.

18.3 pvestatd - Proxmox VE Status Daemon

This daemon queries the status of VMs, storages and containers at regular intervals. The result is sent to all nodes in the cluster.

The daemon also reports the multipath status of the node to the cluster. On nodes with `multipath-tools` installed, it first applies the cluster-wide multipath configuration: it writes the `/etc/multipath/conf.d/pve-` files, adds the WWIDs of managed LUNs to `/etc/multipath/wwids`, and reloads `multipathd` after a change.

18.4 spiceproxy - SPICE Proxy Service

SPICE (the Simple Protocol for Independent Computing Environments) is an open remote computing solution, providing client access to remote displays and devices (e.g. keyboard, mouse, audio). The main use case is to get remote access to virtual machines and container.

This daemon listens on TCP port 3128, and implements an HTTP proxy to forward *CONNECT* request from the SPICE client to the correct Proxmox VE VM. It runs as user `www-data` and has very limited permissions.

18.4.1 Host based Access Control

It is possible to configure "apache2" like access control lists. Values are read from file `/etc/default/pveprox`
See `pveproxy` documentation for details.

18.5 pvescheduler - Proxmox VE Scheduler Daemon

This daemon is responsible for starting jobs according to the schedule, such as replication and vzdump jobs.

For vzdump jobs, it gets its configuration from the file `/etc/pve/jobs.cfg`

Chapter 19

Useful Command-line Tools

19.1 pvesubscription - Subscription Management

This tool is used to handle Proxmox VE subscriptions.

19.2 pveperf - Proxmox VE Benchmark Script

Tries to gather some CPU/hard disk performance data on the hard disk mounted at `PATH` (`/` is used as default):

CPU BOGOMIPS
bogomips sum of all CPUs

REGEX/SECOND
regular expressions per second (perl performance test), should be above 300000

HD SIZE
hard disk size

BUFFERED READS
simple HD read test. Modern HDs should reach at least 40 MB/sec

AVERAGE SEEK TIME
tests average seek time. Fast SCSI HDs reach values < 8 milliseconds. Common IDE/SATA disks get values from 15 to 20 ms.

FSYNCS/SECOND
value should be greater than 200 (you should enable `write back` cache mode on you RAID controller - needs a battery backed cache (BBWC)).

DNS EXT
average time to resolve an external DNS name

DNS INT
average time to resolve a local DNS name

19.3 Shell interface for the Proxmox VE API

The Proxmox VE management tool (`pvesh`) allows to directly invoke API function, without using the REST/HTTPS server.

Note
Only *root* is allowed to do that.

19.3.1 EXAMPLES

Get the list of nodes in my cluster

```
# pvesh get /nodes
```

Get a list of available options for the datacenter

```
# pvesh usage cluster/options -v
```

Set the HTMl5 NoVNC console as the default console for the datacenter

```
# pvesh set cluster/options -console html5
```

Chapter 20

Frequently Asked Questions

Note
New FAQs are appended to the bottom of this section.

1. *What distribution is Proxmox VE based on?*

   Proxmox VE is based on Debian GNU/Linux

2. *What license does the Proxmox VE project use?*

   Proxmox VE code is licensed under the GNU Affero General Public License, version 3.

3. *Will Proxmox VE run on a 32bit processor?*

   Proxmox VE works only on 64-bit CPUs. The supported architectures are x86_64 (AMD64 or Intel 64) and aarch64 on the NVIDIA Grace Hopper and NVIDIA Vera platforms. There is no plan to support 32-bit hosts.

   Note
   VMs and Containers can be both 32-bit and 64-bit.

4. *Does my CPU support virtualization?*

   To check if your CPU is virtualization compatible, check for the `vmx` or `svm` tag in this command output:

   ```
   egrep '(vmx|svm)' /proc/cpuinfo
   ```

   Note
   This check applies to x86 hosts only. On the supported arm64 platforms, KVM hardware-assisted virtualization is available and reports no equivalent CPU flag.

5. *Supported Intel CPUs*

   64-bit processors with Intel Virtualization Technology (Intel VT-x) support. (List of processors with Intel VT and 64-bit)

6. *Supported AMD CPUs*

   64-bit processors with AMD Virtualization Technology (AMD-V) support.

7. *Supported arm64 platforms*

   The NVIDIA Grace Hopper and NVIDIA Vera platforms. See 64-bit ARM (arm64) Support for details.

8. *What is a container/virtual environment (VE)/virtual private server (VPS)?*

   In the context of containers, these terms all refer to the concept of operating-system-level virtualization. Operating-system-level virtualization is a method of virtualization, in which the kernel of an operating system allows for multiple isolated instances, that all share the kernel. When referring to LXC, we call such instances containers. Because containers use the host's kernel rather than emulating a full operating system, they require less overhead, but are limited to Linux guests.

9. *What is a QEMU/KVM guest (or VM)?*

   A QEMU/KVM guest (or VM) is a guest system running virtualized under Proxmox VE using QEMU and the Linux KVM kernel module.

10. *What is QEMU?*

    QEMU is a generic and open source machine emulator and virtualizer. QEMU uses the Linux KVM kernel module to achieve near native performance by executing the guest code directly on the host CPU. It is not limited to Linux guests but allows arbitrary operating systems to run.

11. *How long will my Proxmox VE version be supported?*

    Proxmox VE versions are supported **at least as long** as the corresponding Debian version is supported by the Debian Security Team, i.e. approximately 3 years after its initial release, see Debian lifespan. Proxmox VE uses a rolling release model and using the latest stable version is always recommended.

Proxmox VE Version	Debian Version	First Release	Debian EOL	Proxmox EOL
Proxmox VE 9	Debian 13 (Trixie)	2025-08	tba	tba
Proxmox VE 8	Debian 12 (Bookworm)	2023-06	2026-07	2026-08
Proxmox VE 7	Debian 11 (Bullseye)	2021-07	2024-07	2024-07
Proxmox VE 6	Debian 10 (Buster)	2019-07	2022-09	2022-09
Proxmox VE 5	Debian 9 (Stretch)	2017-07	2020-07	2020-07
Proxmox VE 4	Debian 8 (Jessie)	2015-10	2018-06	2018-06
Proxmox VE 3	Debian 7 (Wheezy)	2013-05	2016-04	2017-02
Proxmox VE 2	Debian 6 (Squeeze)	2012-04	2014-05	2014-05
Proxmox VE 1	Debian 5 (Lenny)	2008-10	2012-03	2013-01

12. *How can I upgrade Proxmox VE to the next point release?*

    Minor version upgrades, for example upgrading from Proxmox VE in version 8.1 to 8.2 or 8.3, can be done just like any normal update. But you should still check the release notes for any relevant notable, or breaking change.

    For the update itself use either the Web UI *Node* → *Updates* panel or through the CLI with:

    ```
    apt update
    apt full-upgrade
    ```

    Note
    Always ensure you correctly setup the package repositories and only continue with the actual upgrade if `apt update` did not hit any error.

13. *How can I upgrade Proxmox VE to the next major release?*

    Major version upgrades, for example going from Proxmox VE 8.4 to 9.0, are also supported. They must be carefully planned and tested and should **never** be started without having a current backup ready.

    Although the specific upgrade steps depend on your respective setup, we provide general instructions and advice on how an upgrade should be performed:

    - Upgrade from Proxmox VE 8 to 9
    - Upgrade from Proxmox VE 7 to 8
    - Upgrade from Proxmox VE 6 to 7
    - Upgrade from Proxmox VE 5 to 6
    - Upgrade from Proxmox VE 4 to 5
    - Upgrade from Proxmox VE 3 to 4

14. *LXC vs LXD vs Proxmox Containers vs Docker*

    LXC is a userspace interface for the Linux kernel containment features. Through a powerful API and simple tools, it lets Linux users easily create and manage system containers. LXC, as well as the former OpenVZ, aims at **system virtualization**. Thus, it allows you to run a complete OS inside a container, where you log in using ssh, add users, run apache, etc. . .

    LXD is built on top of LXC to provide a new, better user experience. Under the hood, LXD uses LXC through `liblxc` and its Go binding to create and manage the containers. It's basically an alternative to LXC's tools and distribution template system with the added features that come from being controllable over the network.

    Proxmox Containers are how we refer to containers that are created and managed using the Proxmox Container Toolkit (`pct`). They also target **system virtualization** and use LXC as the basis of the container offering. With the addition of OCI image support (technology preview), Proxmox VE can also create containers from OCI images, including full system containers but also application containers (tech preview). The Proxmox Container Toolkit (`pct`) is tightly coupled with Proxmox VE. This means that it is aware of cluster setups, and it can use the same network and storage resources as QEMU virtual machines (VMs). You can even use the Proxmox VE firewall, create and restore backups, or manage containers using the HA framework. Everything can be controlled over the network using the Proxmox VE API.

Docker aims at running a **single** application in an isolated, self-contained environment. These are generally referred to as “Application Containers”, rather than “System Containers”. You manage a Docker instance from the host, using the Docker Engine command-line interface. It is not recommended to run docker directly on your Proxmox VE host.

Note
While it can be convenient to run “Application Containers” directly as Proxmox Containers, doing so is currently a tech preview. For use cases requiring container orchestration or live migration, it is still recommended to run them inside a Proxmox QEMU virtual machine.

Chapter 21

Bibliography

21.1 Books about Proxmox VE

[1] [Ahmed16] Wasim Ahmed. Mastering Proxmox - Third Edition. Packt Publishing, 2017. ISBN 978-1788397605

[2] [Ahmed15] Wasim Ahmed. Proxmox Cookbook. Packt Publishing, 2015. ISBN 978-1783980901

[3] [Cheng14] Simon M.C. Cheng. Proxmox High Availability. Packt Publishing, 2014. ISBN 978-1783980888

[4] [Goldman16] Rik Goldman. Learning Proxmox VE. Packt Publishing, 2016. ISBN 978-1783981786

[5] [Surber16]] Lee R. Surber. Virtualization Complete: Business Basic Edition. Linux Solutions (LRS-TEK), 2016. ASIN B01BBVQZT6

21.2 Books about related technology

[6] [Hertzog13] Raphaël Hertzog, Roland Mas., Freexian SARL The Debian Administrator's Handbook: Debian Bullseye from Discovery to Mastery, Freexian, 2021. ISBN 979-10-91414-20-3

[7] [Bir96] Kenneth P. Birman. Building Secure and Reliable Network Applications. Manning Publications Co, 1996. ISBN 978-1884777295

[8] [Walsh10] Norman Walsh. DocBook 5: The Definitive Guide. O'Reilly & Associates, 2010. ISBN 978-0596805029

[9] [Richardson07] Leonard Richardson & Sam Ruby. RESTful Web Services. O'Reilly Media, 2007. ISBN 978-0596529260

[10] [Singh15] Karan Singh. Learning Ceph. Packt Publishing, 2015. ISBN 978-1783985623

[11] [Singh16] Karan Signh. Ceph Cookbook Packt Publishing, 2016. ISBN 978-1784393502

[12] [Mauerer08] Wolfgang Mauerer. Professional Linux Kernel Architecture. John Wiley & Sons, 2008. ISBN 978-0470343432

[13] [Loshin03] Pete Loshin, IPv6: Theory, Protocol, and Practice, 2nd Edition. Morgan Kaufmann, 2003. ISBN 978-1558608108

[14] [Loeliger12] Jon Loeliger & Matthew McCullough. Version Control with Git: Powerful tools and techniques for collaborative software development. O'Reilly and Associates, 2012. ISBN 978-1449316389

[15] [Kreibich10] Jay A. Kreibich. Using SQLite, O'Reilly and Associates, 2010. ISBN 978-0596521189

21.3 Books about related topics

[16] [Bessen09] James Bessen & Michael J. Meurer, Patent Failure: How Judges, Bureaucrats, and Lawyers Put Innovators at Risk. Princeton Univ Press, 2009. ISBN 978-0691143217

Appendix A

Command-line Interface

A.1 General

Regarding the historically non-uniform casing style for options, see the related section for configuration files.

A.2 Output format options `[FORMAT_OPTIONS]`

It is possible to specify the output format using the `--output-format` parameter. The default format *text* uses ASCII-art to draw nice borders around tables. It additionally transforms some values into human-readable text, for example:

- Unix epoch is displayed as ISO 8601 date string.
- Durations are displayed as week/day/hour/minute/second count, i.e `1d 5h`.
- Byte sizes value include units (`B`, `KiB`, `MiB`, `GiB`, `TiB`, `PiB`).
- Fractions are display as percentage, i.e. 1.0 is displayed as 100%.

You can also completely suppress output using option `--quiet`.

`--human-readable <boolean>` (*default* = `1`)
Call output rendering functions to produce human readable text.

`--noborder <boolean>` (*default* = 0)
Do not draw borders (for *text* format).

`--noheader <boolean>` (*default* = 0)
Do not show column headers (for *text* format).

`--output-format <json | json-pretty | text | yaml>` (*default* = `text`)
Output format.

`--quiet <boolean>`
Suppress printing results.

A.3 pvesm - Proxmox VE Storage Manager

pvesm <COMMAND> [ARGS] [OPTIONS]

pvesm add <type> <storage> [OPTIONS]

Create a new storage.

<type>: <btrfs | cephfs | cifs | dir | esxi | iscsi | iscsidirect | lvm | lvmthin | nfs | nvmeof | pbs | rbd | zfs | zfspool>
Storage type.

<storage>: <storage ID>
The storage identifier.

--content <string>
Allowed content types.

> **Note**
> the value *rootdir* is used for Containers, and value *images* for VMs. A storage can instead be restricted to some of their volume types: *vm-vol* for the disks of VMs, *vm-state* for the saved states of VMs, and *ct-vol* for the volumes of Containers.

--disable <boolean>
Flag to disable the storage.

--nodes <string>
List of nodes for which the storage configuration applies.

Conditional options:

--base <string>
Volume ID of the base volume (automatically activated).

[type=lvm]

--blocksize <a power of 2 with optional k or m suffix>
ZFS block size.

[type=zfs, zfspool]

--bwlimit [clone=<LIMIT>] [,default=<LIMIT>] [,migration=<LIMIT>] [,move=<LIMIT>] [,restore=<LIMIT>]
Set I/O bandwidth limit for various operations (in KiB/s).

[type=cephfs, cifs, dir, iscsi, iscsidirect, lvm, lvmthin, nfs, nvmeof, rbd, zfs, zfspool]

--comstar_hg <string>
Host group for COMSTAR views.

[type=zfs]

--comstar_tg <string>
Target group for COMSTAR views.

[type=zfs]

--content-dirs <string>
Overrides for default content type directories.

[type=cephfs, cifs, dir, nfs]

--create-base-path <boolean> (*default* = yes)
Create the base directory if it doesn't exist.

[type=btrfs, cephfs, cifs, dir, nfs]

--create-subdirs <boolean> (*default* = yes)
Populate the base directory with the default structure.

[type=btrfs, cephfs, cifs, dir, nfs]

--data-pool <string>
Data pool name for erasure-coded images.

[type=rbd]

--datastore <string>
Proxmox Backup Server datastore name.

[type=pbs]

--domain <string>
The name of the user domain (workgroup) to use.

[type=cifs]

--encryption-key a file containing an encryption key, or the special value "autogen"
Encryption key. Use *autogen* to generate one automatically without passphrase.

[type=pbs]

--export <string>
Path exported by the NFS server (e.g., /srv/nfs).

[type=nfs]

--fast-io-fail-tmo <integer> (-1 - N) (*default* = 120)
Seconds before I/O through a reconnecting path fails. -1 disables this timeout; I/O can remain queued while paths reconnect.

[type=nvmeof]

--fingerprint ([A-Fa-f0-9]{2}:){31}[A-Fa-f0-9]{2}
Certificate SHA 256 fingerprint.

[type=pbs]

--format <qcow2 | raw | subvol | vmdk>
Default image format.

[type=btrfs, cephfs, cifs, dir, nfs]

--fs-name <string>
The name or identifier of the filesystem.

[type=cephfs]

--fuse <boolean>
Mount the filesystem through FUSE.

[type=cephfs]

--is_mountpoint <string> (*default =* no)
Assume the given path is an externally managed mountpoint and consider the storage offline if it is not mounted. Using a boolean (yes/no) value serves as a shortcut to using the target path in this field.

[type=btrfs, dir]

--iscsiprovider <string>
The iSCSI target implementation used on the remote machine.

[type=zfs]

--keyring file containing the keyring to authenticate in the Ceph cluster
Client keyring contents (for external clusters).

[type=cephfs, rbd]

--krbd <boolean> (*default =* 0)
Always access rbd through krbd kernel module.

[type=rbd]

--lio_tpg <string>
Target portal group for Linux LIO targets.

[type=zfs]

--managed-multipath <boolean>
Manage multipath access to the storage's LUNs and include them in the cluster-wide path-health monitoring.

[type=iscsi]

--master-pubkey a file containing a PEM-formatted master public key
Base64-encoded, PEM-formatted public RSA key. Used to encrypt a copy of the encryption-key which will be added to each encrypted backup.

[type=pbs]

--max-protected-backups <integer> (-1 - N) (*default* = Unlimited for users with Datastore.Allocate privilege, 5 for other users)
Maximal number of protected backups per guest. Use *-1* for unlimited.

[type=btrfs, cephfs, cifs, dir, nfs, pbs]

--mkdir <boolean> (*default* = yes)
Create the directory if it doesn't exist and populate it with default sub-dirs. NOTE: Deprecated, use the *create-base-path* and *create-subdirs* options instead.

[type=btrfs, cephfs, cifs, dir, nfs]

--monhost <string>
IP addresses of monitors (for external clusters).

[type=cephfs, rbd]

--mountpoint <string>
Path to the directory where the storage is mounted.

[type=zfspool]

--namespace <string>
The namespace used for grouping, isolation, or partitioning purposes.

[type=pbs, rbd]

--nocow <boolean> (*default* = 0)
Set the NOCOW flag on files. Disables data checksumming and causes data errors to be unrecoverable from while allowing direct I/O. Only use this if data does not need to be any more safe than on a single ext4 formatted disk with no underlying raid system.

[type=btrfs]

--nowritecache <boolean>
Disable write caching on the iSCSI target.

[type=zfs]

--on-volume-remove [discard=<1|0>]
Optional actions when removing LVs.

[type=lvm]

--options <string>
Comma-separated list of mount options. See *man nfs*, *man mount.cifs*, or *man mount.ceph* for more information.

[type=cephfs, cifs, nfs]

--password <password>
The password used for authentication.

[type=cifs, esxi, pbs]

--path <string>
Path of the storage in the local file system, for example its base directory or mount point.

[type=btrfs, cephfs, cifs, dir, nfs]

--pool <string>
Name of the pool that stores images.

[type=rbd, zfs, zfspool]

--port <integer> (1 - 65535)
Use this port to connect to the storage instead of the default one (for example, with PBS or ESXi). For NFS and CIFS, use the *options* option to configure the port via the mount options.

[type=esxi, pbs]

--portal <string>
iSCSI portal (IP or hostname, optionally with port).

[type=iscsi, iscsidirect, zfs]

--portals <string>
TCP portals of the NVMe subsystem, as IPv4 or bracketed IPv6 addresses with an optional port (default 4420).

[type=nvmeof]

--preallocation <falloc | full | metadata | off> (*default* = metadata)
Preallocation mode for raw and qcow2 images. Using *metadata* on raw images results in preallocation=off.

[type=btrfs, cifs, dir, nfs]

--prune-backups [keep-all=<1|0>] [,keep-daily=<N>] [,keep-hourly=<N>] [,keep-last=<N>] [,keep-monthly=<N>] [,keep-weekly=<N>] [,keep-yearly=<N>]
The retention options with shorter intervals are processed first with --keep-last being the very first one. Each option covers a specific period of time. We say that backups within this period are covered by this option. The next option does not take care of already covered backups and only considers older backups.

[type=btrfs, cephfs, cifs, dir, nfs, pbs]

--saferemove <boolean>
Zero-out data when removing LVs.

[type=lvm]

--saferemove-stepsize <1 | 16 | 2 | 32 | 4 | 8> (*default =* 32)
Wipe step size in MiB. It will be capped to the maximum supported by the storage.

[type=lvm]

--saferemove_throughput -?\d+[kmgKMG]?
Wipe throughput in bytes per second (optional suffix: k, m, or g).

[type=lvm]

--server <string>
IP address or hostname of the server.

[type=cifs, esxi, nfs, pbs]

--share <string>
The name of the share to use.

[type=cifs]

--shared <boolean>
Indicate that this is a single storage with the same contents on all nodes (or all listed in the *nodes* option). It will not make the contents of a local storage automatically accessible to other nodes, it just marks an already shared storage as such!

[type=btrfs, dir, esxi, lvm]

--skip-cert-verification <boolean> (*default =* false)
Disable TLS certificate verification, only enable on fully trusted networks!

[type=esxi]

--smbversion <2.0 | 2.1 | 3 | 3.0 | 3.11 | default> (*default =* default)
SMB protocol version. *default* if not set, negotiates the highest SMB2+ version supported by both the client and server.

[type=cifs]

--snapshot-as-volume-chain <boolean> (*default =* 0)
Enable support for creating storage-vendor agnostic snapshot through volume backing-chains.

[type=cifs, dir, lvm, nfs]

--sparse <boolean>
Use sparse (thin-provisioned) volumes.

[type=zfs, zfspool]

--subdir <string>
Subdir to mount.

[type=cephfs, cifs]

--subsysnqn nqn\.[^\s\x00-\x1f\x7f,=]+
The NQN of the NVMe subsystem.

`[type=nvmeof]`

--tagged_only <boolean>
Only list logical volumes tagged with *pve-vm-ID*.

`[type=lvm]`

--target <string>
iSCSI target name (an iSCSI Qualified Name - IQN).

`[type=iscsi, iscsidirect, zfs]`

--thinpool <string>
Name of the LVM thin pool logical volume.

`[type=lvmthin]`

--username <string>
The username for authentication. For RBD and CephFS, the Ceph client ID without the *client.* prefix.

`[type=cephfs, cifs, esxi, pbs, rbd]`

--vgname <string>
LVM volume group name.

`[type=lvm, lvmthin]`

--zfs-base-path <string>
Base path where to look for the created ZFS block devices. Set automatically during creation if not specified. Usually */dev/zvol*.

`[type=zfs]`

pvesm alloc `<storage> <vmid> <filename> <size> [OPTIONS]`

Allocate disk images.

<storage>: <storage ID>
The storage identifier.

<vmid>: <integer> (100 - 999999999)
Specify owner VM

<filename>: <string>
The name of the file to create.

<size>: \d+[MG]?
Size in kilobyte (1024 bytes). Optional suffixes *M* (megabyte, 1024K) and *G* (gigabyte, 1024M)

--format <qcow2 | raw | subvol | vmdk>
Format of the image.

> **Note**
> Requires option(s): `size`

pvesm apiinfo

Returns APIVER and APIAGE.

pvesm cifsscan

An alias for *pvesm scan cifs*.

pvesm export `<volume> <format> <filename> [OPTIONS]`

Used internally to export a volume.

<volume>: <string>
Volume identifier

<format>: <btrfs | qcow2+size | raw+size | tar+size | vmdk+size | zfs>
Export stream format

<filename>: <string>
Destination file name

--base (?^i:[a-z0-9_\-]{1,40})
Snapshot to start an incremental stream from

--snapshot (?^i:[a-z0-9_\-]{1,40})
Snapshot to export

--snapshot-list <string>
Ordered list of snapshots to transfer

--with-snapshots <boolean> (*default =* 0)
Whether to include intermediate snapshots in the stream

pvesm extractconfig `<volume>`

Extract configuration from vzdump backup archive.

<volume>: <string>
Volume identifier

pvesm free `<volume> [OPTIONS]`

Delete volume

<volume>: <string>
Volume identifier

--delay <integer> (1 - 30)
Time to wait for the task to finish. We return *null* if the task finish within that time.

--storage <storage ID>
The storage identifier.

pvesm help `[OPTIONS]`

Get help about specified command.

--extra-args <array>
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
Verbose output format.

pvesm import `<volume> <format> <filename> [OPTIONS]`

Used internally to import a volume.

<volume>: <string>
Volume identifier

<format>: <btrfs | qcow2+size | raw+size | tar+size | vmdk+size | zfs>
Import stream format

<filename>: <string>
Source file name. For - stdin is used, the tcp://<IP-or-CIDR> format allows to use a TCP connection, the unix://PATH-TO-SOCKET format a UNIX socket as input.Else, the file is treated as common file.

--allow-rename <boolean> (*default =* 0)
Choose a new volume ID if the requested volume ID already exists, instead of throwing an error.

--base (?^i:[a-z0-9_\-]{1,40})
Base snapshot of an incremental stream

--delete-snapshot (?^i:[a-z0-9_\-]{1,80})
A snapshot to delete on success

--snapshot (?^i:[a-z0-9_\-]{1,40})
The current-state snapshot if the stream contains snapshots

--with-snapshots <boolean> (*default =* 0)
Whether the stream includes intermediate snapshots

pvesm iscsiscan

An alias for *pvesm scan iscsi*.

pvesm list <storage> [OPTIONS]

List storage content.

<storage>: <storage ID>
The storage identifier.

--content <string>
Only list content of this type.

--vmid <integer> (100 - 999999999)
Only list images for this VM

pvesm lvmscan

An alias for *pvesm scan lvm*.

pvesm lvmthinscan

An alias for *pvesm scan lvmthin*.

pvesm nfsscan

An alias for *pvesm scan nfs*.

pvesm path <volume>

Get filesystem path for specified volume

<volume>: <string>
Volume identifier

pvesm prune-backups <storage> [OPTIONS]

Prune backups. Only those using the standard naming scheme are considered. If no keep options are specified, those from the storage configuration are used.

<storage>: <storage ID>
The storage identifier.

--dry-run <boolean>
Only show what would be pruned, don't delete anything.

--keep-all <boolean>
Keep all backups. Conflicts with the other options when true.

--keep-daily <N>
Keep backups for the last <N> different days. If there is more than one backup for a single day, only the latest one is kept.

--keep-hourly <N>
Keep backups for the last <N> different hours. If there is more than one backup for a single hour, only the latest one is kept.

--keep-last <N>
Keep the last <N> backups.

--keep-monthly <N>
Keep backups for the last <N> different months. If there is more than one backup for a single month, only the latest one is kept.

--keep-weekly <N>
Keep backups for the last <N> different weeks. If there is more than one backup for a single week, only the latest one is kept.

--keep-yearly <N>
Keep backups for the last <N> different years. If there is more than one backup for a single year, only the latest one is kept.

--type <lxc | qemu>
Either *qemu* or *lxc*. Only consider backups for guests of this type.

--vmid <integer> (100 - 999999999)
Only consider backups for this guest.

pvesm remove <storage> [OPTIONS]

Delete storage configuration.

<storage>: <storage ID>
The storage identifier.

--digest <string>
Prevent changes if current configuration file has a different digest. This can be used to prevent concurrent modifications.

pvesm scan cifs <server> [OPTIONS]

Scan remote CIFS server.

<server>: <string>
The server address (name or IP).

--domain <string>
SMB domain (Workgroup).

--password <password>
User password.

--username <string>
User name.

pvesm scan iscsi <portal>

Scan remote iSCSI server.

<portal>: <string>
The iSCSI portal (IP or DNS name with optional port).

pvesm scan lvm

List local LVM volume groups.

pvesm scan lvmthin <vg>

List local LVM Thin Pools.

<vg>: [a-zA-Z0-9\.\+_][a-zA-Z0-9\.\+_\-]+
no description available

pvesm scan nfs <server>

Scan remote NFS server.

<server>: <string>
The server address (name or IP).

pvesm scan nvmeof <portal> [FORMAT_OPTIONS]

List the NVMe over TCP subsystems offered to this node by a discovery controller.

<portal>: <string>
IPv4 or bracketed IPv6 discovery address with an optional port. Without a port, try 8009 then 4420.

pvesm scan pbs <server> <username> --password <string> [OPTIONS] [FORMAT_OPTIONS

Scan remote Proxmox Backup Server.

<server>: <string>
The server address (name or IP).

<username>: <string>
User-name or API token-ID.

--fingerprint ([A-Fa-f0-9]{2}:){31}[A-Fa-f0-9]{2}
Certificate SHA 256 fingerprint.

--password <string>
User password or API token secret.

--port <integer> (1 - 65535) (*default* = 8007)
Optional port.

pvesm scan san-luns [FORMAT_OPTIONS]

List the SAN LUNs of the node with their paths and cached usage.

pvesm scan zfs

Scan zfs pool list on local node.

pvesm set <storage> [OPTIONS]

Update storage configuration.

<storage>: <storage ID>
The storage identifier.

--content <string>
Allowed content types.

> **Note**
> the value *rootdir* is used for Containers, and value *images* for VMs. A storage can instead be restricted to some of their volume types: *vm-vol* for the disks of VMs, *vm-state* for the saved states of VMs, and *ct-vol* for the volumes of Containers.

--delete <string>
A list of settings you want to delete.

--digest <string>
Prevent changes if current configuration file has a different digest. This can be used to prevent concurrent modifications.

--disable <boolean>
Flag to disable the storage.

--nodes <string>
List of nodes for which the storage configuration applies.

--type <btrfs | cephfs | cifs | dir | esxi | iscsi | iscsidirect | lvm | lvmthin | nfs | nvmeof | pbs | rbd | zfs | zfspool>
Storage type.

Conditional options:

--blocksize <a power of 2 with optional k or m suffix>
ZFS block size.

[type=zfspool]

--bwlimit [clone=<LIMIT>] [,default=<LIMIT>] [,migration=<LIMIT>] [,move=<LIMIT>] [,restore=<LIMIT>]
Set I/O bandwidth limit for various operations (in KiB/s).

[type=cephfs, cifs, dir, iscsi, iscsidirect, lvm, lvmthin, nfs, nvmeof, rbd, zfs, zfspool]

--comstar_hg <string>
Host group for COMSTAR views.

[type=zfs]

--comstar_tg <string>
Target group for COMSTAR views.

[type=zfs]

--content-dirs <string>
Overrides for default content type directories.

[type=cephfs, cifs, dir, nfs]

--create-base-path <boolean> (*default* = yes)
Create the base directory if it doesn't exist.

[type=btrfs, cephfs, cifs, dir, nfs]

--create-subdirs <boolean> (*default* = yes)
Populate the base directory with the default structure.

[type=btrfs, cephfs, cifs, dir, nfs]

--data-pool <string>
Data pool name for erasure-coded images.

[type=rbd]

--domain <string>
The name of the user domain (workgroup) to use.

[type=cifs]

--encryption-key a file containing an encryption key, or the special value "autogen"
Encryption key. Use *autogen* to generate one automatically without passphrase.

[type=pbs]

--fast_io_fail_tmo <integer> (-1 - N) (*default* = 120)
Seconds before I/O through a reconnecting path fails. -1 disables this timeout; I/O can remain queued while paths reconnect.

[type=nvmeof]

--fingerprint ([A-Fa-f0-9]{2}:){31}[A-Fa-f0-9]{2}
Certificate SHA 256 fingerprint.

[type=pbs]

--format <qcow2 | raw | subvol | vmdk>
Default image format.

[type=btrfs, cephfs, cifs, dir, nfs]

--fs-name <string>
The name or identifier of the filesystem.

[type=cephfs]

--fuse <boolean>
Mount the filesystem through FUSE.

[type=cephfs]

--is_mountpoint <string> (*default* = no)
Assume the given path is an externally managed mountpoint and consider the storage offline if it is not mounted. Using a boolean (yes/no) value serves as a shortcut to using the target path in this field.

[type=btrfs, dir]

--keyring file containing the keyring to authenticate in the Ceph cluster
Client keyring contents (for external clusters).

[type=cephfs, rbd]

--krbd <boolean> (*default* = 0)
Always access rbd through krbd kernel module.

[type=rbd]

--lio_tpg <string>
Target portal group for Linux LIO targets.

[type=zfs]

--managed-multipath <boolean>
Manage multipath access to the storage's LUNs and include them in the cluster-wide path-health monitoring.

[type=iscsi]

--master-pubkey a file containing a PEM-formatted master public key
Base64-encoded, PEM-formatted public RSA key. Used to encrypt a copy of the encryption-key which will be added to each encrypted backup.

[type=pbs]

--max-protected-backups <integer> (-1 - N) (*default =* Unlimited for users with Datastore.Allocate privilege, 5 for other users)
Maximal number of protected backups per guest. Use *-1* for unlimited.

[type=btrfs, cephfs, cifs, dir, nfs, pbs]

--mkdir <boolean> (*default =* yes)
Create the directory if it doesn't exist and populate it with default sub-dirs. NOTE: Deprecated, use the *create-base-path* and *create-subdirs* options instead.

[type=btrfs, cephfs, cifs, dir, nfs]

--monhost <string>
IP addresses of monitors (for external clusters).

[type=cephfs, rbd]

--mountpoint <string>
Path to the directory where the storage is mounted.

[type=zfspool]

--namespace <string>
The namespace used for grouping, isolation, or partitioning purposes.

[type=pbs, rbd]

--nocow <boolean> (*default =* 0)
Set the NOCOW flag on files. Disables data checksumming and causes data errors to be unrecoverable from while allowing direct I/O. Only use this if data does not need to be any more safe than on a single ext4 formatted disk with no underlying raid system.

[type=btrfs]

--nowritecache <boolean>
Disable write caching on the iSCSI target.

[type=zfs]

--on-volume-remove [discard=<1|0>]
Optional actions when removing LVs.

[type=lvm]

--options <string>
Comma-separated list of mount options. See *man nfs*, *man mount.cifs*, or *man mount.ceph* for more information.

[type=cephfs, cifs, nfs]

--password <password>
The password used for authentication.

[type=cifs, esxi, pbs]

--pool <string>
Name of the pool that stores images.

[type=rbd]

--port <integer> (1 - 65535)
Use this port to connect to the storage instead of the default one (for example, with PBS or ESXi). For NFS and CIFS, use the *options* option to configure the port via the mount options.

[type=esxi, pbs]

--portals <string>
TCP portals of the NVMe subsystem, as IPv4 or bracketed IPv6 addresses with an optional port (default 4420).

[type=nvmeof]

--preallocation <falloc | full | metadata | off> (*default* = metadata)
Preallocation mode for raw and qcow2 images. Using *metadata* on raw images results in preallocation=off.

[type=btrfs, cifs, dir, nfs]

--prune-backups [keep-all=<1|0>] [,keep-daily=<N>] [,keep-hourly=<N>] [,keep-last=<N>] [,keep-monthly=<N>] [,keep-weekly=<N>] [,keep-yearly=<N>]
The retention options with shorter intervals are processed first with --keep-last being the very first one. Each option covers a specific period of time. We say that backups within this period are covered by this option. The next option does not take care of already covered backups and only considers older backups.

[type=btrfs, cephfs, cifs, dir, nfs, pbs]

--saferemove <boolean>
Zero-out data when removing LVs.

[type=lvm]

--saferemove-stepsize <1 | 16 | 2 | 32 | 4 | 8> (*default =* 32)
Wipe step size in MiB. It will be capped to the maximum supported by the storage.

[type=lvm]

--saferemove_throughput -?\d+[kmgKMG]?
Wipe throughput in bytes per second (optional suffix: k, m, or g).

[type=lvm]

--shared <boolean>
Indicate that this is a single storage with the same contents on all nodes (or all listed in the *nodes* option). It will not make the contents of a local storage automatically accessible to other nodes, it just marks an already shared storage as such!

[type=btrfs, dir, esxi, lvm]

--skip-cert-verification <boolean> (*default =* false)
Disable TLS certificate verification, only enable on fully trusted networks!

[type=esxi]

--smbversion <2.0 | 2.1 | 3 | 3.0 | 3.11 | default> (*default =* default)
SMB protocol version. *default* if not set, negotiates the highest SMB2+ version supported by both the client and server.

[type=cifs]

--snapshot-as-volume-chain <boolean> (*default =* 0)
Enable support for creating storage-vendor agnostic snapshot through volume backing-chains.

[type=lvm]

--sparse <boolean>
Use sparse (thin-provisioned) volumes.

[type=zfs, zfspool]

--subdir <string>
Subdir to mount.

[type=cephfs, cifs]

--tagged_only <boolean>
Only list logical volumes tagged with *pve-vm-ID*.

[type=lvm]

--username <string>
The username for authentication. For RBD and CephFS, the Ceph client ID without the *client.* prefix.

[type=cephfs, cifs, esxi, pbs, rbd]

--zfs-base-path <string>
Base path where to look for the created ZFS block devices. Set automatically during creation if not specified. Usually */dev/zvol*.

`[type=zfs]`

pvesm status `[OPTIONS]`

Get status for all datastores.

--content <string>
Only list stores which support this content type.

--enabled <boolean> (*default =* 0)
Only list stores which are enabled (not disabled in config).

--format <boolean> (*default =* 0)
Include information about formats

--storage <storage ID>
Only list status for specified storage

--target <string>
If target is different to *node*, we only lists shared storages which content is accessible on this *node* and the specified *target* node.

pvesm zfsscan

An alias for *pvesm scan zfs*.

A.4 pvesubscription - Proxmox VE Subscription Manager

pvesubscription `<COMMAND> [ARGS] [OPTIONS]`

pvesubscription delete

Delete subscription key of this node.

pvesubscription get

Read subscription info.

pvesubscription help `[OPTIONS]`

Get help about specified command.

--extra-args <array>
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
Verbose output format.

pvesubscription set <key>

Set subscription key.

<key>: \s*pve([1248])([cbsp])-(arm-)?[0-9a-f]{10}\s*
Proxmox VE subscription key

pvesubscription set-offline-key <data>

Internal use only! To set an offline key, use the package proxmox-offline-mirror-helper instead.

<data>: <string>
A signed subscription info blob

pvesubscription update [OPTIONS]

Update subscription info.

--force <boolean> (***default =*** 0)
Always connect to server, even if local cache is still valid.

A.5 pveperf - Proxmox VE Benchmark Script

pveperf [PATH]

A.6 pveceph - Manage CEPH Services on Proxmox VE Nodes

pveceph <COMMAND> [ARGS] [OPTIONS]

pveceph auth status [FORMAT_OPTIONS]

Show current and pending cephx key ciphers and aes256k migration prerequisites.

pveceph createmgr

An alias for *pveceph mgr create*.

pveceph createmon

An alias for *pveceph mon create*.

pveceph createosd

An alias for *pveceph osd create*.

pveceph createpool

An alias for *pveceph pool create*.

pveceph destroymgr

An alias for *pveceph mgr destroy*.

pveceph destroymon

An alias for *pveceph mon destroy*.

pveceph destroyosd

An alias for *pveceph osd destroy*.

pveceph destroypool

An alias for *pveceph pool destroy*.

pveceph fs create `[OPTIONS]`

Create a Ceph filesystem

`--add-storage <boolean>` (*default =* 0)
Configure the created CephFS as storage for this cluster.

`--name (?^:^[^:/\s]+$)` (*default =* `cephfs`)
The ceph filesystem name.

`--pg_num <integer> (8 - 32768)` (*default =* `128`)
Number of placement groups for the backing data pool. The metadata pool will use a quarter of this.

pveceph fs destroy `<name> [OPTIONS]`

Destroy a Ceph filesystem. Refuses if any PVE storage entry of type *cephfs* still references the filesystem and is not disabled. Optionally also removes the storage entries and/or the underlying metadata and data pools.

`<name>: <string>`
The Ceph filesystem name.

`--remove-pools <boolean>` (*default =* 0)
Remove the metadata and data pools used by this filesystem.

`--remove-storages <boolean>` (*default =* 0)
Remove pveceph-managed storages configured for this filesystem.

pveceph help `[OPTIONS]`

Get help about specified command.

`--extra-args <array>`
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
Verbose output format.

pveceph init [OPTIONS]

Create the initial Ceph default configuration and set up symlinks. Idempotent on re-call: if a [global] section already exists in ceph.conf, the existing fsid / auth / pool defaults are preserved and most parameters are silently ignored.

--cluster-network <string>
Declare a separate cluster network, OSDs will route heartbeat, object replication and recovery traffic over it

Note
Requires option(s): network

--disable_cephx <boolean> (*default =* 0)
Disable cephx authentication.

Warning
cephx is a security feature protecting against man-in-the-middle attacks. Only consider disabling cephx if your network is private!

--min_size <integer> (1 - 7) (*default =* 2)
Minimum number of available replicas per object to allow I/O

--network <string>
Use specific network for all ceph related traffic

--pg_bits <integer> (6 - 14) (*default =* 6)
Placement group bits, used to specify the default number of placement groups.

Deprecated. This setting has been ignored since Ceph Nautilus.

--size <integer> (1 - 7) (*default =* 3)
Targeted number of replicas per object

pveceph install [OPTIONS]

Install ceph related packages.

--allow-experimental <boolean> (*default =* 0)
Allow experimental versions. Use with care!

--repository <enterprise | manual | no-subscription | test> (*default* = enterprise)
Ceph repository to use. The *manual* option will not configure any repositories. Use it if the host cannot access the public repositories, for example if Proxmox Offline Mirror is used. A repository that contains the Ceph packages for the version needs to be manually configured before starting the installation!

--version <squid | tentacle | umbrella> (*default* = tentacle)
Ceph version to install. Defaults to the newest version running on other cluster nodes, if any.

pveceph lspools

An alias for *pveceph pool ls*.

pveceph mds create [OPTIONS]

Create Ceph Metadata Server (MDS)

--hotstandby <boolean> (*default* = 0)
Determines whether a ceph-mds daemon should poll and replay the log of an active MDS. Faster switch on MDS failure, but needs more idle resources. Deprecated: the setting was removed in Ceph 14.1.1.

--name [a-zA-Z0-9]([a-zA-Z0-9\-]*[a-zA-Z0-9])? (*default* = nodename)
The ID for the mds, when omitted the same as the nodename

pveceph mds destroy <name>

Destroy Ceph Metadata Server

<name>: [a-zA-Z0-9]([a-zA-Z0-9\-]*[a-zA-Z0-9])?
The name (ID) of the mds

pveceph mgr create [OPTIONS]

Create Ceph Manager

--id [a-zA-Z0-9]([a-zA-Z0-9\-]*[a-zA-Z0-9])? (*default* = nodename)
The ID for the manager, when omitted the same as the nodename.

pveceph mgr destroy <id>

Destroy Ceph Manager.

<id>: [a-zA-Z0-9]([a-zA-Z0-9\-]*[a-zA-Z0-9])?
The ID of the manager

pveceph mon create [OPTIONS]

Create a Ceph Monitor. Also auto-creates a Manager for the first monitor.

--mon-address <string>
Overwrites autodetected monitor IP address(es). Must be in the public network(s) of Ceph.

--monid [a-zA-Z0-9]([a-zA-Z0-9\-]*[a-zA-Z0-9])? (*default =* nodename)
The ID for the monitor, when omitted the same as the nodename.

pveceph mon destroy <monid>

Destroy a Ceph Monitor. Refuses to remove the last monitor of the cluster. Does not destroy any Manager on the same node; use

<monid>: [a-zA-Z0-9]([a-zA-Z0-9\-]*[a-zA-Z0-9])?
Monitor ID

pveceph osd create <dev> [OPTIONS]

Create OSD

<dev>: <string>
Block device name.

--crush-device-class <string>
Set the device class of the OSD in crush.

--db_dev <string>
Block device name for block.db.

--db_dev_size <number> (1 - N)
Size in GiB for block.db.

> **Note**
> Requires option(s): db_dev

--encrypted <boolean> (*default =* 0)
Enables encryption of the OSD.

--osds-per-device <integer> (1 - N)
OSD services per physical device. Only useful for fast NVMe devices to utilize their performance better. Mutually exclusive with *db_dev* and *wal_dev*.

--wal_dev <string>
Block device name for block.wal.

--wal_dev_size <number> (0.5 - N)
Size in GiB for block.wal.

Note
Requires option(s): `wal_dev`

pveceph osd destroy `<osdid> [OPTIONS]`

Destroy OSD

<osdid>: <integer>
OSD ID

--cleanup <boolean> (*default =* 0)
If set, also destroy the underlying logical volumes via *ceph-volume lvm zap --destroy*, remove the volume group's physical volume with pvremove, and wipe any journal/block.db/block.wal partitions left over from filestore OSDs. Without this flag the LVs and partitions are left intact for inspection.

pveceph osd details `<osdid> [OPTIONS] [FORMAT_OPTIONS]`

Get OSD details.

<osdid>: <string>
ID of the OSD

--verbose <boolean> (*default =* 0)
Print verbose information, same as json-pretty output format.

pveceph pool create `<name> [OPTIONS]`

Create Ceph pool

<name>: (?^:^[^:/\s]+$)
The name of the pool. It must be unique.

--add_storages <boolean> (*default =* 0)
Configure VM and CT storage using the new pool. Defaults to false for replicated pools and to true for erasure-coded pools (since EC pools are typically only useful when wired up to storage).

--application <cephfs | rbd | rgw> (*default =* rbd)
The application of the pool.

--crush_rule <string>
The rule to use for mapping object placement in the cluster.

--erasure-coding k=<integer> ,m=<integer> [,device-class=<class>] [,failure-domain=<domain>] [,profile=<profile>]
Create an erasure coded pool for RBD with an accompaning replicated pool for metadata storage. With EC, the common ceph options *size*, *min_size* and *crush_rule* parameters will be applied to the metadata pool.

--min_size **<integer> (1 - 7)** (***default =*** **2**)
Minimum number of replicas per object

--pg_autoscale_mode **<off | on | warn>** (***default =*** **warn**)
The automatic PG scaling mode of the pool.

--pg_num **<integer> (1 - 32768)** (***default =*** **128**)
Number of placement groups.

--pg_num_min **<integer> (-N - 32768)**
Minimal number of placement groups.

--size **<integer> (1 - 7)** (***default =*** **3**)
Number of replicas per object

--target_size **^(\d+(\.\d+)?)([KMGT])?$**
The estimated target size of the pool for the PG autoscaler.

--target_size_ratio **<number>**
The estimated target ratio of the pool for the PG autoscaler.

pveceph pool destroy <name> [OPTIONS]

Destroy pool

<name>: **<string>**
The name of the pool. It must be unique.

--force **<boolean>** (***default =*** **0**)
If true, destroys pool even if in use

--remove_ecprofile **<boolean>** (***default =*** **1**)
Remove the erasure code profile. Defaults to true, if applicable.

--remove_storages **<boolean>** (***default =*** **0**)
Remove all pveceph-managed storages configured for this pool

pveceph pool get <name> [OPTIONS] [FORMAT_OPTIONS]

Show the current pool status.

<name>: **<string>**
The name of the pool. It must be unique.

--verbose **<boolean>** (***default =*** **0**)
If enabled, will display additional data(eg. statistics).

pveceph pool ls [FORMAT_OPTIONS]

List all pools and their settings (which are settable by the POST/PUT endpoints).

pveceph pool set <name> [OPTIONS]

Change POOL settings

<name>: (?^:^[^:/\s]+$)
The name of the pool. It must be unique.

--application <cephfs | rbd | rgw>
The application of the pool.

--crush_rule <string>
The rule to use for mapping object placement in the cluster.

--min_size <integer> (1 - 7)
Minimum number of replicas per object

--pg_autoscale_mode <off | on | warn>
The automatic PG scaling mode of the pool.

--pg_num <integer> (1 - 32768)
Number of placement groups.

--pg_num_min <integer> (-N - 32768)
Minimal number of placement groups.

--size <integer> (1 - 7)
Number of replicas per object

--target_size ^(\d+(\.\d+)?)([KMGT])?$
The estimated target size of the pool for the PG autoscaler.

--target_size_ratio <number>
The estimated target ratio of the pool for the PG autoscaler.

pveceph purge [OPTIONS]

Destroy ceph related data and configuration files.

--crash <boolean>
Additionally purge Ceph crash logs, /var/lib/ceph/crash.

--logs <boolean>
Additionally purge Ceph logs, /var/log/ceph.

pveceph start [OPTIONS]

Start ceph services.

--service **(ceph|mon|mds|osd|mgr)(\.[a-zA-Z0-9]([a-zA-Z0-9\-]*[a-zA-Z0-9])?)?** **(*default* = ceph.target)**
: Ceph service name.

pveceph status

Get Ceph Status.

pveceph stop [OPTIONS]

Stop ceph services.

--service **(ceph|mon|mds|osd|mgr)(\.[a-zA-Z0-9]([a-zA-Z0-9\-]*[a-zA-Z0-9])?)?** **(*default* = ceph.target)**
: Ceph service name.

A.7 pvenode - Proxmox VE Node Management

pvenode <COMMAND> [ARGS] [OPTIONS]

pvenode acme account deactivate [<name>]

Deactivate existing ACME account at CA.

<name>: <name> **(*default* = default)**
: ACME account config file name.

pvenode acme account info [<name>] [FORMAT_OPTIONS]

Return existing ACME account information.

<name>: <name> **(*default* = default)**
: ACME account config file name.

pvenode acme account list

ACMEAccount index.

pvenode acme account register [<name>] {<contact>} [OPTIONS]

Register a new ACME account with a compatible CA.

<name>: <name> **(*default* = default)**
: ACME account config file name.

<contact>: <string>
Contact email addresses.

--directory ^https?://.*
URL of ACME CA directory endpoint.

pvenode acme account update [<name>] [OPTIONS]

Update existing ACME account information with CA. Note: not specifying any new account information triggers a refresh.

<name>: <name> (*default* = default)
ACME account config file name.

--contact <string>
Contact email addresses.

pvenode acme cert order [OPTIONS]

Order a new certificate from ACME-compatible CA.

--force <boolean> (*default* = 0)
Overwrite existing custom certificate.

pvenode acme cert renew [OPTIONS]

Renew existing certificate from CA.

--force <boolean> (*default* = 0)
Force renewal even if the certificate is not yet due for renewal.

pvenode acme cert revoke

Revoke existing certificate from CA.

pvenode acme plugin add <type> <id> [OPTIONS]

Add ACME plugin configuration.

<type>: <dns | standalone>
ACME challenge type.

<id>: <string>
ACME Plugin ID name

--api **<1984hosting | acmedns | acmeproxy | active24 | ad | ali | alviy | anx | artfiles | arubabusiness | arvan | aurora | autodns | aws | azion | azure | baidu | beget | bh | bhosted | bookmyname | bunny | calrissia | cdmon | cf | clouddns | cloudns | cn | comlaude | conoha | constellix | cpanel | cpanel_uapi | creoline | curanet | cyon | czechia | da | ddnss | desec | df | dgon | dnsexit | dnshome | dnsimple | dnsmint | dnsservices | doapi | domeneshop | dp | dpi | dreamhost | duckdns | durabledns | dyn | dynu | dynv6 | easydns | edgecenter | edgedns | efficientip | eurodns | euserv | exoscale | firestorm | fornex | freedns | freemyip | gandi_livedns | gcloud | gcore | gd | geoscaling | glesys | gname | googledomains | he | he_ddns | hestiacp | hetznercloud | hexonet | hostingde | hostinger | hostup | huaweicloud | hw | infoblox | infoblox_uddi | infomaniak | internetbs | inwx | ionos | ionos_cloud | ipprojects | ipv64 | ispconfig | jd | joker | kappernet | kas | kinghost | knot | la | laodc | leaseweb | level27 | lexicon | limacity | linode_v4 | loopia | lua | maradns | me | mgwm | miab | mijnhost | misaka | muumuu | myapi | mydevil | mydnsjp | myloc | mythic_beasts | namecheap | namecom | namesilo | nanelo | nederhost | neodigit | netcup | netlify | nexdns | nic | njalla | nm | nsd | nsone | nsupdate | nw | oci | omglol | one | online | openprovider | openprovider_rest | openstack | opnsense | opteamax | optidata | opusdns | ovh | pdns | pleskxml | pointhq | porkbun | poweradmin | qc | rackcorp | rackspace | rage4 | rcode0 | regru | rltx | scaleway | schlundtech | selectel | selfhost | servercow | simply | sitehost | sotoon | spaceship | subreg | technitium | tele3 | tencent | timeweb | transip | udr | ultra | unoeuro | variomedia | veesp | vercel | virakcloud | volcengine | vscale | vultr | websupport | wedos | west_cn | world4you | yandex360 | yc | zilore | zone | zoneedit | zonomi>**

API plugin name

--data **File with one key-value pair per line, will be base64url encode for storage in plugin config.**

DNS plugin data. (base64 encoded)

--disable **<boolean>**

Flag to disable the config.

--nodes **<string>**

List of cluster node names.

--validation-delay **<integer> (0 - 172800) (*default =* 30)**

Extra delay in seconds to wait before requesting validation. Allows to cope with a long TTL of DNS records.

pvenode acme plugin config <id> [FORMAT_OPTIONS]

Get ACME plugin configuration.

<id>: <string>
Unique identifier for ACME plugin instance.

pvenode acme plugin list [OPTIONS] [FORMAT_OPTIONS]

ACME plugin index.

--type <dns | standalone>
Only list ACME plugins of a specific type

pvenode acme plugin remove <id>

Delete ACME plugin configuration.

<id>: <string>
Unique identifier for ACME plugin instance.

pvenode acme plugin set <id> [OPTIONS]

Update ACME plugin configuration.

<id>: <string>
ACME Plugin ID name

--api <1984hosting | acmedns | acmeproxy | active24 | ad | ali | alviy | anx | artfiles | arubabusiness | arvan | aurora | autodns | aws | azion | azure | baidu | beget | bh | bhosted | bookmyname | bunny | calrissia | cdmon | cf | clouddns | cloudns | cn | comlaude | conoha | constellix | cpanel | cpanel_uapi | creoline | curanet | cyon | czechia | da | ddnss | desec | df | dgon | dnsexit | dnshome | dnsimple | dnsmint | dnsservices | doapi | domeneshop | dp | dpi | dreamhost | duckdns | durabledns | dyn | dynu | dynv6 | easydns | edgecenter | edgedns | efficientip | eurodns | euserv | exoscale | firestorm | fornex | freedns | freemyip | gandi_livedns | gcloud | gcore | gd | geoscaling | glesys | gname | googledomains | he | he_ddns | hestiacp | hetznercloud | hexonet | hostingde | hostinger | hostup | huaweicloud | hw | infoblox | infoblox_uddi | infomaniak | internetbs | inwx | ionos | ionos_cloud | ipprojects | ipv64 | ispconfig | jd | joker | kappernet | kas | kinghost | knot | la | laodc | leaseweb | level27 | lexicon | limacity | linode_v4 | loopia | lua | maradns | me | mgwm | miab | mijnhost | misaka | muumuu | myapi | mydevil | mydnsjp | myloc | mythic_beasts | namecheap | namecom | namesilo | nanelo | nederhost | neodigit | netcup | netlify | nexdns | nic | njalla | nm | nsd | nsone | nsupdate | nw | oci | omglol | one | online | openprovider | openprovider_rest | openstack | opnsense | opteamax | optidata | opusdns | ovh | pdns | pleskxml | pointhq | porkbun | poweradmin | qc | rackcorp | rackspace | rage4 | rcode0 | regru | rltx | scaleway | schlundtech | selectel | selfhost | servercow | simply | sitehost | sotoon | spaceship | subreg | technitium | tele3 | tencent | timeweb | transip | udr | ultra | unoeuro | variomedia | veesp | vercel | virakcloud | volcengine | vscale | vultr | websupport | wedos | west_cn | world4you | yandex360 | yc | zilore | zone | zoneedit | zonomi>

API plugin name

--data File with one key-value pair per line, will be base64url encode for storage in plugin config.

DNS plugin data. (base64 encoded)

--delete <string>

A list of settings you want to delete.

--digest <string>

Prevent changes if current configuration file has a different digest. This can be used to prevent concurrent modifications.

--disable <boolean>

Flag to disable the config.

--nodes <string>

List of cluster node names.

--validation-delay <integer> (0 - 172800) (*default =* 30)
Extra delay in seconds to wait before requesting validation. Allows to cope with a long TTL of DNS records.

pvenode apt history [OPTIONS] [FORMAT_OPTIONS]

List past APT transactions and their package changes, newest first.

--limit <integer> (1 - N)
List at most this many transactions.

--package <package>
Only list transactions that changed this package.

--since <integer>
Only list transactions that started at or after this Unix epoch.

--until <integer>
Only list transactions that started at or before this Unix epoch.

pvenode cert delete [<restart>]

DELETE custom certificate chain and key.

<restart>: <boolean> (*default =* 0)
Restart pveproxy.

pvenode cert info [FORMAT_OPTIONS]

Get information about node's certificates.

pvenode cert set <certificates> [<key>] [OPTIONS] [FORMAT_OPTIONS]

Upload or update custom certificate chain and key.

<certificates>: <string>
PEM encoded certificate (chain).

<key>: <string>
PEM encoded private key.

--force <boolean> (*default =* 0)
Overwrite existing custom or ACME certificate files.

--restart <boolean> (*default =* 0)
Restart pveproxy.

pvenode config get [OPTIONS]

Get node configuration options.

--property <acme | acmedomain0 | acmedomain1 | acmedomain2 | acmedomain3 | acmedomain4 | acmedomain5 | ballooning-target | description | location | startall-onboot-delay | wakeonlan> (*default =* all)
Return only a specific property from the node configuration.

pvenode config set [OPTIONS]

Set node configuration options.

--acme [account=<name>] [,domains=<domain[;domain;...]>]
Node specific ACME settings.

--acmedomain[n] [domain=]<domain> [,alias=<domain>] [,plugin=<name of the plugin configuration>]
ACME domain and validation plugin

--ballooning-target <integer> (0 - 100) (*default =* 80)
RAM usage target for ballooning (in percent of total memory)

--delete <string>
A list of settings you want to delete.

--description <string>
Description for the Node. Shown in the web-interface node notes panel. This is saved as comment inside the configuration file.

--digest <string>
Prevent changes if current configuration file has different SHA1 digest. This can be used to prevent concurrent modifications.

--location latitude=<number> ,longitude=<number> [,name=<name>]
The location of the node. Overrides the default from the datacenter config.

--startall-onboot-delay <integer> (0 - 300) (*default =* 0)
Initial delay in seconds, before starting all the Virtual Guests with on-boot enabled.

--wakeonlan [mac=]<MAC address> [,bind-interface=<bind interface>] [,broadcast-address=<IPv4 broadcast address>]
Node specific wake on LAN settings.

pvenode help [OPTIONS]

Get help about specified command.

--extra-args <array>
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
Verbose output format.

pvenode migrateall `<target> [OPTIONS]`

Migrate all VMs and Containers.

<target>: <string>
Target node.

--max-workers <integer> (1 - 64)
Maximal number of parallel migration job. If not set, uses'max_workers' from datacenter.cfg. One of both must be set!

--maxworkers <integer> (1 - 64)
Maximal number of parallel migration job. If not set, uses'max_workers' from datacenter.cfg. One of both must be set!Deprecated, use *max-workers* instead.

--vms <string>
Only consider Guests with these IDs.

--with-local-disks <boolean>
Enable live storage migration for local disk

pvenode startall `[OPTIONS]`

Start all VMs and containers located on this node (by default only those with onboot=1).

--force <boolean> (*default =* off)
Issue start command even if virtual guest have *onboot* not set or set to off.

--max-workers <integer> (1 - 64)
Defines the maximum number of tasks running concurrently. If not set, uses *max_workers* from datacenter.cfg, and if that's not set, the available CPU threads, clamped to a maximum of 8, are used.

--vms <string>
Only consider guests from this comma separated list of VMIDs.

pvenode stopall `[OPTIONS]`

Stop all VMs and Containers.

--force-stop <boolean> (*default =* 1)
Force a hard-stop after the timeout.

--max-workers <integer> (1 - 64)
Defines the maximum number of tasks running concurrently. If not set, uses *max_workers* from datacenter.cfg, and if that's not set, the available CPU threads, clamped to a maximum of 8, are used.

--timeout <integer> (0 - 7200) (*default =* 180)
Timeout for each guest shutdown task. Depending on `force-stop`, the shutdown gets then simply aborted or a hard-stop is forced.

--vms <string>
Only consider Guests with these IDs.

pvenode task list `[OPTIONS] [FORMAT_OPTIONS]`

Read task list for one node (finished tasks).

--errors <boolean> (*default =* 0)
Only list tasks with a status of ERROR.

--limit <integer> (0 - N) (*default =* 50)
Only list this number of tasks.

--since <integer>
Only list tasks since this UNIX epoch.

--source <active | all | archive> (*default =* archive)
List archived, active or all tasks.

--start <integer> (0 - N) (*default =* 0)
List tasks beginning from this offset.

--statusfilter <string>
List of Task States that should be returned.

--typefilter <string>
Only list tasks of this type (e.g., vzstart, vzdump).

--until <integer>
Only list tasks until this UNIX epoch.

--userfilter <string>
Only list tasks from this user.

--vmid <integer> (100 - 999999999)
Only list tasks for this VM.

pvenode task log `<upid> [OPTIONS]`

Read task log.

<upid>: <string>
The task's unique ID.

--download <boolean>
Whether the tasklog file should be downloaded. This parameter can't be used in conjunction with other parameters

--start <integer> (0 - N) (*default =* 0)
Start at this line when reading the tasklog

pvenode task status <upid> [FORMAT_OPTIONS]

Read task status.

<upid>: <string>
The task's unique ID.

pvenode wakeonlan <node>

Try to wake a node via *wake on LAN* network packet.

<node>: <string>
target node for wake on LAN packet

A.8 pvesh - Shell interface for the Proxmox VE API

pvesh <COMMAND> [ARGS] [OPTIONS]

pvesh create <api_path> [OPTIONS] [FORMAT_OPTIONS]

Call API POST on <api_path>.

<api_path>: <string>
API path.

--noproxy <boolean>
Disable automatic proxying.

pvesh delete <api_path> [OPTIONS] [FORMAT_OPTIONS]

Call API DELETE on <api_path>.

<api_path>: <string>
API path.

--noproxy <boolean>
Disable automatic proxying.

pvesh get <api_path> [OPTIONS] [FORMAT_OPTIONS]

Call API GET on <api_path>.

<api_path>: <string>
API path.

--noproxy <boolean>
Disable automatic proxying.

pvesh help [OPTIONS]

Get help about specified command.

--extra-args <array>
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
Verbose output format.

pvesh ls <api_path> [OPTIONS] [FORMAT_OPTIONS]

List child objects on <api_path>.

<api_path>: <string>
API path.

--noproxy <boolean>
Disable automatic proxying.

pvesh set <api_path> [OPTIONS] [FORMAT_OPTIONS]

Call API PUT on <api_path>.

<api_path>: <string>
API path.

--noproxy <boolean>
Disable automatic proxying.

pvesh usage <api_path> [OPTIONS]

print API usage information for <api_path>.

<api_path>: <string>
API path.

--command <create | delete | get | set>
API command.

--returns <boolean>
Including schema for returned data.

--verbose <boolean>
Verbose output format.

A.9 qm - QEMU/KVM Virtual Machine Manager

qm <COMMAND> [ARGS] [OPTIONS]

qm agent

An alias for *qm guest cmd*.

qm cleanup <vmid> <clean-shutdown> <guest-requested>

Cleans up resources like tap devices, vgpus, etc. Called after a vm shuts down, crashes, etc.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<clean-shutdown>: <boolean>
Indicates if qemu shutdown cleanly.

<guest-requested>: <boolean>
Indicates if the shutdown was requested by the guest or via qmp.

qm clone <vmid> <newid> [OPTIONS]

Create a copy of virtual machine/template.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<newid>: <integer> (100 - 999999999)
VMID for the clone.

--bwlimit <integer> (0 - N) (*default =* clone limit from datacenter or storage config)
Override I/O bandwidth limit (in KiB/s).

--description <string>
Description for the new VM.

--format <qcow2 | raw | vmdk>
Target disk format. Only valid for full clone. If the target storage does not support the format, the storage's default format is used instead.

--full <boolean>
Create a full copy of all disks. This is always done when you clone a normal VM. For VM templates, we try to create a linked clone by default.

--name <string>
Set a name for the new VM.

--pool <string>
Add the new VM to the specified pool.

--snapname <string>
The name of the snapshot.

--storage <storage ID>
Target storage for full clone.

--target <string>
Target node. Only allowed if the original VM is on shared storage.

qm cloudinit dump <vmid> <type>

Get automatically generated cloudinit config.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<type>: <meta | network | user>
Config type.

qm cloudinit pending <vmid>

Get the cloudinit configuration with both current and pending values.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

qm cloudinit update <vmid>

Regenerate and change cloudinit config drive.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

qm config <vmid> [OPTIONS]

Get the virtual machine configuration with pending configuration changes applied. Set the *current* parameter to get the current configuration instead.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--current <boolean> (*default =* 0)
Get current values (instead of pending values).

--snapshot <string>
Fetch config values from given snapshot.

qm create <vmid> [OPTIONS]

Create or restore a virtual machine.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--acpi <boolean> (*default =* 1)
Enable/disable ACPI.

--affinity <string>
List of host cores used to execute guest processes, for example: 0,5,8-11

--agent [enabled=]<1|0> [,freeze-fs=<1|0>]
[,fstrim_cloned_disks=<1|0>] [,sync-time-on-resume=<1|0>]
[,type=<virtio|isa>]
Enable/disable communication with the QEMU Guest Agent and its properties.

--allow-identity-mismatch <boolean> (*default =* 0)
Allow overwriting an existing guest with a backup of another guest, as detected by a different *uid* in *meta*. The guest then keeps its own uid. Not needed to restore a backup again over a guest that an unfinished restore of that backup left behind.

Note
Requires option(s): archive

--allow-ksm <boolean> (*default =* 1)
Allow memory pages of this guest to be merged via KSM (Kernel Samepage Merging).

--amd-sev [type=]<sev-type> [,allow-smt=<1|0>]
[,kernel-hashes=<1|0>] [,no-debug=<1|0>] [,no-key-sharing=<1|0>]
Secure Encrypted Virtualization (SEV) features by AMD CPUs

--arch <aarch64 | x86_64>
Virtual processor architecture. Defaults to the host architecture.

--archive <string>
The backup archive. Either the file system path to a .tar or .vma file (use - to pipe data from stdin) or a proxmox storage backup volume identifier.

--args <string>
Arbitrary arguments passed to kvm.

--audio0 device=<ich9-intel-hda|intel-hda|AC97>
[,driver=<spice|none>]
Configure a audio device, useful in combination with QXL/Spice.

--autostart <boolean> (*default =* 0)
Automatic restart after crash (currently ignored).

--balloon <integer> (0 - N)
Amount of target RAM for the VM in MiB. The balloon driver is enabled by default, unless it is explicitly disabled by setting the value to zero.

--bios <ovmf | seabios> (*default =* seabios)
Select BIOS implementation.

--boot [[legacy=]<[acdn]{1,4}>] [,order=<device[;device...]>]
Specify guest boot order. Use the *order=* sub-property as usage with no key or *legacy=* is deprecated.

--bootdisk (ide|sata|scsi|virtio)\d+
Enable booting from specified disk. Deprecated: Use *boot: order=foo;bar* instead.

--bwlimit <integer> (0 - N) (*default =* restore limit from datacenter or storage config)
Override I/O bandwidth limit (in KiB/s).

--cdrom <volume>
This is an alias for option -ide2

--cicustom [meta=<volume>] [,network=<volume>] [,user=<volume>]
[,vendor=<volume>]
cloud-init: Specify custom files to replace the automatically generated ones at start.

--cipassword <password>
cloud-init: Password to assign the user. Using this is generally not recommended. Use ssh keys instead. Also note that older cloud-init versions do not support hashed passwords.

--citype <configdrive2 | nocloud | opennebula>
Specifies the cloud-init configuration format. The default depends on the configured operating system type (`ostype`. We use the `nocloud` format for Linux, and `configdrive2` for windows.

--ciupgrade <boolean> (*default =* 1)
cloud-init: do an automatic package upgrade after the first boot.

--ciuser <string>
cloud-init: User name to change ssh keys and password for instead of the image's configured default user.

--cores <integer> (1 - N) (*default =* 1)
The number of cores per socket.

--cpu [[cputype=]<string>] [,flags=<+FLAG[;-FLAG...]>]
[,guest-phys-bits=<integer>] [,hidden=<1|0>]
[,hv-vendor-id=<vendor-id>] [,level=<integer>]
[,phys-bits=<8-64|host>] [,reported-model=<enum>]
Emulated CPU type.

--cpulimit <number> (0 - 128) (*default =* 0)
Limit of CPU usage.

--cpuunits <integer> (1 - 262144) (*default =* cgroup v1: 1024, cgroup v2: 100)
CPU weight for a VM, will be clamped to [1, 10000] in cgroup v2.

--description <string>
Description for the VM. Shown in the web-interface VM's summary. This is saved as comment inside the configuration file.

--efidisk0 [file=]<volume> [,efitype=<2m|4m>] [,format=<enum>]
[,import-from=<source volume>] [,ms-cert=<enum>]
[,pre-enrolled-keys=<1|0>] [,size=<DiskSize>]
Configure a disk for storing EFI vars. Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Note that SIZE_IN_GiB is ignored here and that the default EFI vars are copied to the volume instead. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

--force <boolean>
Allow to overwrite existing VM.

> **Note**
> Requires option(s): `archive`

--freeze <boolean>
Freeze CPU at startup (use *c* monitor command to start execution).

--ha-managed <boolean> (*default =* 0)
Add the VM as a HA resource after it was created.

--hookscript <string>
Script that will be executed during various steps in the vms lifetime.

--hostpci[n] [[host=]<HOSTPCIID[;HOSTPCIID2...]>] [,device-id=<hex id>] [,driver=<vfio|keep>] [,legacy-igd=<1|0>] [,mapping=<mapping-id>] [,mdev=<string>] [,pcie=<1|0>] [,rombar=<1|0>] [,romfile=<string>] [,sub-device-id=<hex id>] [,sub-vendor-id=<hex id>] [,vendor-id=<hex id>] [,x-vga=<1|0>]
Map host PCI devices into guest.

--hotplug <string> (*default =* network,disk,usb)
Selectively enable hotplug features. This is a comma separated list of hotplug features: *network*, *disk*, *cpu*, *memory*, *usb* and *cloudinit*. Use *0* to disable hotplug completely. Using *1* as value is an alias for the default `network,disk,usb`. USB hotplugging is possible for guests with machine version >= 7.1 and ostype l26 or windows > 7.

--hugepages <1024 | 2 | any>
Enables hugepages memory.

Sets the size of hugepages in MiB. If the value is set to *any* then 1 GiB hugepages will be used if possible, otherwise the size will fall back to 2 MiB.

--ide[n] [file=]<volume> [,aio=<native|threads|io_uring>] [,backup=<1|0>] [,bps=<bps>] [,bps_max_length=<seconds>] [,bps_rd=<bps>] [,bps_rd_max_length=<seconds>] [,bps_wr=<bps>] [,bps_wr_max_length=<seconds>] [,cache=<enum>] [,detect_zeroes=<1|0>] [,discard=<ignore|on>] [,format=<enum>] [,import-from=<source volume>] [,iops=<iops>] [,iops_max=<iops>] [,iops_max_length=<seconds>] [,iops_rd=<iops>] [,iops_rd_max=<iops>] [,iops_rd_max_length=<seconds>] [,iops_wr=<iops>] [,iops_wr_max=<iops>] [,iops_wr_max_length=<seconds>] [,mbps=<mbps>] [,mbps_max=<mbps>] [,mbps_rd=<mbps>] [,mbps_rd_max=<mbps>] [,mbps_wr=<mbps>] [,mbps_wr_max=<mbps>] [,media=<cdrom|disk>] [,model=<model>] [,replicate=<1|0>] [,rerror=<ignore|report|stop>] [,serial=<serial>] [,shared=<1|0>] [,size=<DiskSize>] [,snapshot=<1|0>] [,ssd=<1|0>] [,werror=<enum>] [,wwn=<wwn>]
Use volume as IDE hard disk or CD-ROM (n is 0 to 3). Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

--import-working-storage <storage ID>
A file-based storage with *images* content-type enabled, which is used as an intermediary extraction storage during import. Defaults to the source storage.

--intel-tdx [type=]<tdx-type> [,attestation=<1|0>] [,vsock-cid=<integer>] [,vsock-port=<integer>]
Trusted Domain Extension (TDX) features by Intel CPUs

--ipconfig[n] [gw=<GatewayIPv4>] [,gw6=<GatewayIPv6>] [,ip=<IPv4Format/CIDR>] [,ip6=<IPv6Format/CIDR>]
cloud-init: Specify IP addresses and gateways for the corresponding interface.

IP addresses use CIDR notation, gateways are optional but need an IP of the same type specified.

The special string *dhcp* can be used for IP addresses to use DHCP, in which case no explicit gateway should be provided. For IPv6 the special string *auto* can be used to use stateless autoconfiguration. This requires cloud-init 19.4 or newer.

If cloud-init is enabled and neither an IPv4 nor an IPv6 address is specified, it defaults to using dhcp on IPv4.

--ivshmem size=<integer> [,name=<string>]
Inter-VM shared memory. Useful for direct communication between VMs, or to the host.

--keephugepages <boolean> (*default =* 0)
Use together with hugepages. If enabled, hugepages will not not be deleted after VM shutdown and can be used for subsequent starts.

--keyboard <da | de | de-ch | en-gb | en-us | es | fi | fr | fr-be | fr-ca | fr-ch | hu | is | it | ja | lt | mk | nl | no | pl | pt | pt-br | sl | sv | tr>
Keyboard layout for VNC server. This option is generally not required and is often better handled from within the guest OS.

--kvm <boolean> (*default =* 1)
Enable/disable KVM hardware virtualization.

--live-restore <boolean>
Start the VM immediately while importing or restoring in the background.

--localtime <boolean>
Set the real time clock (RTC) to local time. This is enabled by default if the `ostype` indicates a Microsoft Windows OS.

--lock <backup | clone | create | import | migrate | rollback | snapshot | snapshot-delete | suspended | suspending>
Lock/unlock the VM.

--machine [[type=]<machine type>] [,aw-bits=<number>] [,enable-s3=<1|0>] [,enable-s4=<1|0>] [,viommu=<intel|virtio>]
Specify the QEMU machine.

--memory [current=]<integer>
Memory properties.

--migrate_downtime <number> (0 - N) (*default =* 0.1)
Set maximum tolerated downtime (in seconds) for migrations. Should the migration not be able to converge in the very end, because too much newly dirtied RAM needs to be transferred, the limit will be increased automatically step-by-step until migration can converge. Will be capped to 2000 seconds (maximum in QEMU).

--migrate_speed <integer> (0 - N) (*default =* 0)
Set maximum speed (in MB/s) for migrations. Value 0 is no limit.

--name <string>
Set a name for the VM. Only used on the configuration web interface.

--nameserver <string>
cloud-init: Sets DNS server IP address for a container. Create will automatically use the setting from the host if neither searchdomain nor nameserver are set.

--net[n] [model=]<enum> [,bridge=<bridge>] [,firewall=<1|0>] [,host-tunnel=<1|0>] [,link_down=<1|0>] [,macaddr=<XX:XX:XX:XX:XX:XX>] [,mtu=<integer>] [,queues=<integer>] [,rate=<number>] [,tag=<integer>] [,trunks=<vlanid[;vlanid...]>] [,<model>=<macaddr>]
Specify network devices.

--numa <boolean> (*default =* 0)
Enable/disable NUMA.

--numa[n] cpus=<id[-id];...> [,hostnodes=<id[-id];...>] [,memory=<number>] [,policy=<preferred|bind|interleave>]
NUMA topology.

--onboot <boolean> (*default =* 0)
Specifies whether a VM will be started during system bootup.

--ostype <l24 | l26 | other | solaris | w2k | w2k3 | w2k8 | win10 | win11 | win7 | win8 | wvista | wxp> (*default =* other)
Specify guest operating system.

--parallel[n] /dev/parport\d+|/dev/usb/lp\d+
Map host parallel devices (n is 0 to 2).

--pool <string>
Add the VM to the specified pool.

--protection <boolean> (*default =* 0)
Sets the protection flag of the VM. This will disable the remove VM and remove disk operations.

--reboot <boolean> (*default =* 1)
Allow reboot. If set to *0* the VM exit on reboot.

--rng0 [source=]</dev/urandom|/dev/random|/dev/hwrng>
[,max_bytes=<integer>] [,period=<integer>]
Configure a VirtIO-based Random Number Generator.

--sata[n] [file=]<volume> [,aio=<native|threads|io_uring>]
[,backup=<1|0>] [,bps=<bps>] [,bps_max_length=<seconds>]
[,bps_rd=<bps>] [,bps_rd_max_length=<seconds>] [,bps_wr=<bps>]
[,bps_wr_max_length=<seconds>] [,cache=<enum>]
[,detect_zeroes=<1|0>] [,discard=<ignore|on>] [,format=<enum>]
[,import-from=<source volume>] [,iops=<iops>] [,iops_max=<iops>]
[,iops_max_length=<seconds>] [,iops_rd=<iops>]
[,iops_rd_max=<iops>] [,iops_rd_max_length=<seconds>]
[,iops_wr=<iops>] [,iops_wr_max=<iops>]
[,iops_wr_max_length=<seconds>] [,mbps=<mbps>] [,mbps_max=<mbps>]
[,mbps_rd=<mbps>] [,mbps_rd_max=<mbps>] [,mbps_wr=<mbps>]
[,mbps_wr_max=<mbps>] [,media=<cdrom|disk>] [,replicate=<1|0>]
[,rerror=<ignore|report|stop>] [,serial=<serial>] [,shared=<1|0>]
[,size=<DiskSize>] [,snapshot=<1|0>] [,ssd=<1|0>] [,werror=<enum>]
[,wwn=<wwn>]
Use volume as SATA hard disk or CD-ROM (n is 0 to 5). Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

--scsi[n] [file=]<volume> [,aio=<native|threads|io_uring>] [,backup=<1|0>] [,bps=<bps>] [,bps_max_length=<seconds>] [,bps_rd=<bps>] [,bps_rd_max_length=<seconds>] [,bps_wr=<bps>] [,bps_wr_max_length=<seconds>] [,cache=<enum>] [,detect_zeroes=<1|0>] [,discard=<ignore|on>] [,format=<enum>] [,import-from=<source volume>] [,iops=<iops>] [,iops_max=<iops>] [,iops_max_length=<seconds>] [,iops_rd=<iops>] [,iops_rd_max=<iops>] [,iops_rd_max_length=<seconds>] [,iops_wr=<iops>] [,iops_wr_max=<iops>] [,iops_wr_max_length=<seconds>] [,iothread=<1|0>] [,mbps=<mbps>] [,mbps_max=<mbps>] [,mbps_rd=<mbps>] [,mbps_rd_max=<mbps>] [,mbps_wr=<mbps>] [,mbps_wr_max=<mbps>] [,media=<cdrom|disk>] [,product=<product>] [,queues=<integer>] [,replicate=<1|0>] [,rerror=<ignore|report|stop>] [,ro=<1|0>] [,scsiblock=<1|0>] [,serial=<serial>] [,shared=<1|0>] [,size=<DiskSize>] [,snapshot=<1|0>] [,ssd=<1|0>] [,vendor=<vendor>] [,werror=<enum>] [,wwn=<wwn>]

Use volume as SCSI hard disk or CD-ROM (n is 0 to 30). Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

--scsihw <lsi | lsi53c810 | megasas | pvscsi | virtio-scsi-pci | virtio-scsi-single> (*default =* lsi)

SCSI controller model

--searchdomain <string>

cloud-init: Sets DNS search domains for a container. Create will automatically use the setting from the host if neither searchdomain nor nameserver are set.

--serial[n] (/dev/[^,]+|socket)

Create a serial device inside the VM (n is 0 to 3)

--shares <integer> (0 - 50000) (*default =* 1000)

Amount of memory shares for auto-ballooning. The larger the number is, the more memory this VM gets. Number is relative to weights of all other running VMs. Using zero disables auto-ballooning. Auto-ballooning is done by pvestatd.

--smbios1 [base64=<1|0>] [,family=<Base64 encoded string>] [,manufacturer=<Base64 encoded string>] [,product=<Base64 encoded string>] [,serial=<Base64 encoded string>] [,sku=<Base64 encoded string>] [,uuid=<UUID>] [,version=<Base64 encoded string>]

Specify SMBIOS type 1 fields.

--smp <integer> (1 - N) (*default =* 1)

The number of CPUs. Please use option -sockets instead.

--sockets <integer> (1 - N) (*default =* 1)

The number of CPU sockets.

--spice_enhancements [foldersharing=<1|0>]
[,videostreaming=<off|all|filter>]
Configure additional enhancements for SPICE.

--sshkeys <filepath>
cloud-init: Setup public SSH keys (one key per line, OpenSSH format).

--start <boolean> (*default =* 0)
Start VM after it was created successfully.

--startdate (now | YYYY-MM-DD | YYYY-MM-DDTHH:MM:SS) (*default =* now)
Set the initial date of the real time clock. Valid format for date are:'now' or *2006-06-17T16:01:21* or *2006-06-17*.

--startup `[[order=]\d+] [,up=\d+] [,down=\d+] `
Startup and shutdown behavior. Order is a non-negative number defining the general startup order. Shutdown in done with reverse ordering. Additionally you can set the *up* or *down* delay in seconds, which specifies a delay to wait before the next VM is started or stopped.

--storage <storage ID>
Default storage.

--tablet <boolean> (*default =* 1)
Enable/disable the USB tablet device.

--tags <string>
Tags of the VM. This is only meta information.

--tdf <boolean> (*default =* 0)
Enable/disable time drift fix.

--template <boolean> (*default =* 0)
Enable/disable Template.

--tpmstate0 [file=]<volume> [,format=<raw|qcow2|vmdk>]
[,import-from=<source volume>] [,size=<DiskSize>]
[,version=<v1.2|v2.0>]
Configure a Disk for storing TPM state. The format is fixed to *raw*. Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Note that SIZE_IN_GiB is ignored here and 4 MiB will be used instead. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

--unique <boolean>
Assign a unique random ethernet address and do not adopt the guest uid of the backup.

Note
Requires option(s): `archive`

--unused[n] [file=]<volume>
Reference to unused volumes. This is used internally, and should not be modified manually.

--usb[n] [[host=]<HOSTUSBDEVICE|spice>] [,mapping=<mapping-id>] [,usb3=<1|0>]
Configure an USB device (n is 0 to 4, for machine version >= 7.1 and ostype l26 or windows > 7, n can be up to 14).

--vcpus <integer> (1 - N) (*default =* 0)
Number of hotplugged vcpus.

--vga [[type=]<enum>] [,clipboard=<vnc>] [,memory=<integer>]
Configure the VGA hardware.

--virtio[n] [file=]<volume> [,aio=<native|threads|io_uring>] [,backup=<1|0>] [,bps=<bps>] [,bps_max_length=<seconds>] [,bps_rd=<bps>] [,bps_rd_max_length=<seconds>] [,bps_wr=<bps>] [,bps_wr_max_length=<seconds>] [,cache=<enum>] [,detect_zeroes=<1|0>] [,discard=<ignore|on>] [,format=<enum>] [,import-from=<source volume>] [,iops=<iops>] [,iops_max=<iops>] [,iops_max_length=<seconds>] [,iops_rd=<iops>] [,iops_rd_max=<iops>] [,iops_rd_max_length=<seconds>] [,iops_wr=<iops>] [,iops_wr_max=<iops>] [,iops_wr_max_length=<seconds>] [,iothread=<1|0>] [,mbps=<mbps>] [,mbps_max=<mbps>] [,mbps_rd=<mbps>] [,mbps_rd_max=<mbps>] [,mbps_wr=<mbps>] [,mbps_wr_max=<mbps>] [,media=<cdrom|disk>] [,replicate=<1|0>] [,rerror=<ignore|report|stop>] [,ro=<1|0>] [,serial=<serial>] [,shared=<1|0>] [,size=<DiskSize>] [,snapshot=<1|0>] [,werror=<enum>]
Use volume as VIRTIO hard disk (n is 0 to 15). Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

--virtiofs[n] [dirid=]<mapping-id> [,cache=<enum>] [,direct-io=<1|0>] [,expose-acl=<1|0>] [,expose-xattr=<1|0>]
Configuration for sharing a directory between host and guest using Virtio-fs.

--vmgenid <UUID> (*default =* 1 (autogenerated))
Set VM Generation ID. Use *1* to autogenerate on create or update, pass *0* to disable explicitly.

--vmstatestorage <storage ID>
Default storage for VM state volumes/files.

--watchdog [[model=]<i6300esb>] [,action=<enum>]
Create a virtual hardware watchdog device.

qm delsnapshot <vmid> <snapname> [OPTIONS]

Delete a VM snapshot.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<snapname>: <string>
The name of the snapshot.

--force <boolean>
For removal from config file, even if removing disk snapshots fails.

qm destroy <vmid> [OPTIONS]

Destroy the VM and all used/owned volumes. Removes any VM specific permissions and firewall rules

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--destroy-unreferenced-disks <boolean> (*default =* 0)
If set, destroy additionally all disks not referenced in the config but with a matching VMID from all enabled storages.

--purge <boolean>
Remove VMID from configurations, like backup & replication jobs and HA.

--skiplock <boolean>
Ignore locks - only root is allowed to use this option.

qm disk import <vmid> <source> <storage> [OPTIONS]

Import an external disk image as an unused disk in a VM. The image format has to be supported by qemu-img(1).

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<source>: <string>
Path to the disk image to import

<storage>: <storage ID>
Target storage ID

--format <qcow2 | raw | vmdk>
Target format

```
--target-disk <efidisk0 | ide0 | ide1 | ide2 | ide3 | sata0 | sata1
| sata2 | sata3 | sata4 | sata5 | scsi0 | scsi1 | scsi10 | scsi11 |
scsi12 | scsi13 | scsi14 | scsi15 | scsi16 | scsi17 | scsi18 |
scsi19 | scsi2 | scsi20 | scsi21 | scsi22 | scsi23 | scsi24 |
scsi25 | scsi26 | scsi27 | scsi28 | scsi29 | scsi3 | scsi30 | scsi4
| scsi5 | scsi6 | scsi7 | scsi8 | scsi9 | tpmstate0 | unused0 |
unused1 | unused10 | unused100 | unused101 | unused102 | unused103
| unused104 | unused105 | unused106 | unused107 | unused108 |
unused109 | unused11 | unused110 | unused111 | unused112 |
unused113 | unused114 | unused115 | unused116 | unused117 |
unused118 | unused119 | unused12 | unused120 | unused121 |
unused122 | unused123 | unused124 | unused125 | unused126 |
unused127 | unused128 | unused129 | unused13 | unused130 |
unused131 | unused132 | unused133 | unused134 | unused135 |
unused136 | unused137 | unused138 | unused139 | unused14 |
unused140 | unused141 | unused142 | unused143 | unused144 |
unused145 | unused146 | unused147 | unused148 | unused149 |
unused15 | unused150 | unused151 | unused152 | unused153 |
unused154 | unused155 | unused156 | unused157 | unused158 |
unused159 | unused16 | unused160 | unused161 | unused162 |
unused163 | unused164 | unused165 | unused166 | unused167 |
unused168 | unused169 | unused17 | unused170 | unused171 |
unused172 | unused173 | unused174 | unused175 | unused176 |
unused177 | unused178 | unused179 | unused18 | unused180 |
unused181 | unused182 | unused183 | unused184 | unused185 |
unused186 | unused187 | unused188 | unused189 | unused19 |
unused190 | unused191 | unused192 | unused193 | unused194 |
unused195 | unused196 | unused197 | unused198 | unused199 | unused2
| unused20 | unused200 | unused201 | unused202 | unused203 |
unused204 | unused205 | unused206 | unused207 | unused208 |
unused209 | unused21 | unused210 | unused211 | unused212 |
unused213 | unused214 | unused215 | unused216 | unused217 |
unused218 | unused219 | unused22 | unused220 | unused221 |
unused222 | unused223 | unused224 | unused225 | unused226 |
unused227 | unused228 | unused229 | unused23 | unused230 |
unused231 | unused232 | unused233 | unused234 | unused235 |
unused236 | unused237 | unused238 | unused239 | unused24 |
unused240 | unused241 | unused242 | unused243 | unused244 |
unused245 | unused246 | unused247 | unused248 | unused249 |
unused25 | unused250 | unused251 | unused252 | unused253 |
unused254 | unused255 | unused26 | unused27 | unused28 | unused29 |
unused3 | unused30 | unused31 | unused32 | unused33 | unused34 |
unused35 | unused36 | unused37 | unused38 | unused39 | unused4 |
unused40 | unused41 | unused42 | unused43 | unused44 | unused45 |
unused46 | unused47 | unused48 | unused49 | unused5 | unused50 |
unused51 | unused52 | unused53 | unused54 | unused55 | unused56 |
unused57 | unused58 | unused59 | unused6 | unused60 | unused61 |
unused62 | unused63 | unused64 | unused65 | unused66 | unused67 |
unused68 | unused69 | unused7 | unused70 | unused71 | unused72 |
unused73 | unused74 | unused75 | unused76 | unused77 | unused78 |
unused79 | unused8 | unused80 | unused81 | unused82 | unused83 |
unused84 | unused85 | unused86 | unused87 | unused88 | unused89 |
unused9 | unused90 | unused91 | unused92 | unused93 | unused94 |
```

The disk name where the volume will be imported to (e.g. scsi1).

qm disk move <vmid> <disk> [<storage>] [OPTIONS]

Move volume to different storage or to a different VM.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

```
<disk>: <efidisk0 | ide0 | ide1 | ide2 | ide3 | sata0 | sata1 |
sata2 | sata3 | sata4 | sata5 | scsi0 | scsi1 | scsi10 | scsi11 |
scsi12 | scsi13 | scsi14 | scsi15 | scsi16 | scsi17 | scsi18 |
scsi19 | scsi2 | scsi20 | scsi21 | scsi22 | scsi23 | scsi24 |
scsi25 | scsi26 | scsi27 | scsi28 | scsi29 | scsi3 | scsi30 | scsi4
| scsi5 | scsi6 | scsi7 | scsi8 | scsi9 | tpmstate0 | unused0 |
unused1 | unused10 | unused100 | unused101 | unused102 | unused103
| unused104 | unused105 | unused106 | unused107 | unused108 |
unused109 | unused11 | unused110 | unused111 | unused112 |
unused113 | unused114 | unused115 | unused116 | unused117 |
unused118 | unused119 | unused12 | unused120 | unused121 |
unused122 | unused123 | unused124 | unused125 | unused126 |
unused127 | unused128 | unused129 | unused13 | unused130 |
unused131 | unused132 | unused133 | unused134 | unused135 |
unused136 | unused137 | unused138 | unused139 | unused14 |
unused140 | unused141 | unused142 | unused143 | unused144 |
unused145 | unused146 | unused147 | unused148 | unused149 |
unused15 | unused150 | unused151 | unused152 | unused153 |
unused154 | unused155 | unused156 | unused157 | unused158 |
unused159 | unused16 | unused160 | unused161 | unused162 |
unused163 | unused164 | unused165 | unused166 | unused167 |
unused168 | unused169 | unused17 | unused170 | unused171 |
unused172 | unused173 | unused174 | unused175 | unused176 |
unused177 | unused178 | unused179 | unused18 | unused180 |
unused181 | unused182 | unused183 | unused184 | unused185 |
unused186 | unused187 | unused188 | unused189 | unused19 |
unused190 | unused191 | unused192 | unused193 | unused194 |
unused195 | unused196 | unused197 | unused198 | unused199 | unused2
| unused20 | unused200 | unused201 | unused202 | unused203 |
unused204 | unused205 | unused206 | unused207 | unused208 |
unused209 | unused21 | unused210 | unused211 | unused212 |
unused213 | unused214 | unused215 | unused216 | unused217 |
unused218 | unused219 | unused22 | unused220 | unused221 |
unused222 | unused223 | unused224 | unused225 | unused226 |
unused227 | unused228 | unused229 | unused23 | unused230 |
unused231 | unused232 | unused233 | unused234 | unused235 |
unused236 | unused237 | unused238 | unused239 | unused24 |
unused240 | unused241 | unused242 | unused243 | unused244 |
unused245 | unused246 | unused247 | unused248 | unused249 |
unused25 | unused250 | unused251 | unused252 | unused253 |
unused254 | unused255 | unused26 | unused27 | unused28 | unused29 |
unused3 | unused30 | unused31 | unused32 | unused33 | unused34 |
unused35 | unused36 | unused37 | unused38 | unused39 | unused4 |
unused40 | unused41 | unused42 | unused43 | unused44 | unused45 |
unused46 | unused47 | unused48 | unused49 | unused5 | unused50 |
unused51 | unused52 | unused53 | unused54 | unused55 | unused56 |
unused57 | unused58 | unused59 | unused6 | unused60 | unused61 |
unused62 | unused63 | unused64 | unused65 | unused66 | unused67 |
unused68 | unused69 | unused7 | unused70 | unused71 | unused72 |
unused73 | unused74 | unused75 | unused76 | unused77 | unused78 |
unused79 | unused8 | unused80 | unused81 | unused82 | unused83 |
unused84 | unused85 | unused86 | unused87 | unused88 | unused89 |
unused9 | unused90 | unused91 | unused92 | unused93 | unused94 |
```

The disk you want to move.

<storage>: <storage ID>
Target storage.

--bwlimit <integer> (0 - N) (*default =* move limit from datacenter or storage config)
Override I/O bandwidth limit (in KiB/s).

--delete <boolean> (*default =* 0)
Delete the original disk after successful copy. By default the original disk is kept as unused disk.

--digest <string>
Prevent changes if current configuration file has different SHA1 digest. This can be used to prevent concurrent modifications.

--format <qcow2 | raw | vmdk>
Target disk format. Only used when moving to a different storage. If the target storage does not support the format, the storage's default format is used instead.

--target-digest <string>
Prevent changes if the current config file of the target VM has a different SHA1 digest. This can be used to detect concurrent modifications.

```
--target-disk <efidisk0 | ide0 | ide1 | ide2 | ide3 | sata0 | sata1
| sata2 | sata3 | sata4 | sata5 | scsi0 | scsi1 | scsi10 | scsi11 |
scsi12 | scsi13 | scsi14 | scsi15 | scsi16 | scsi17 | scsi18 |
scsi19 | scsi2 | scsi20 | scsi21 | scsi22 | scsi23 | scsi24 |
scsi25 | scsi26 | scsi27 | scsi28 | scsi29 | scsi3 | scsi30 | scsi4
| scsi5 | scsi6 | scsi7 | scsi8 | scsi9 | tpmstate0 | unused0 |
unused1 | unused10 | unused100 | unused101 | unused102 | unused103
| unused104 | unused105 | unused106 | unused107 | unused108 |
unused109 | unused11 | unused110 | unused111 | unused112 |
unused113 | unused114 | unused115 | unused116 | unused117 |
unused118 | unused119 | unused12 | unused120 | unused121 |
unused122 | unused123 | unused124 | unused125 | unused126 |
unused127 | unused128 | unused129 | unused13 | unused130 |
unused131 | unused132 | unused133 | unused134 | unused135 |
unused136 | unused137 | unused138 | unused139 | unused14 |
unused140 | unused141 | unused142 | unused143 | unused144 |
unused145 | unused146 | unused147 | unused148 | unused149 |
unused15 | unused150 | unused151 | unused152 | unused153 |
unused154 | unused155 | unused156 | unused157 | unused158 |
unused159 | unused16 | unused160 | unused161 | unused162 |
unused163 | unused164 | unused165 | unused166 | unused167 |
unused168 | unused169 | unused17 | unused170 | unused171 |
unused172 | unused173 | unused174 | unused175 | unused176 |
unused177 | unused178 | unused179 | unused18 | unused180 |
unused181 | unused182 | unused183 | unused184 | unused185 |
unused186 | unused187 | unused188 | unused189 | unused19 |
unused190 | unused191 | unused192 | unused193 | unused194 |
unused195 | unused196 | unused197 | unused198 | unused199 | unused2
| unused20 | unused200 | unused201 | unused202 | unused203 |
unused204 | unused205 | unused206 | unused207 | unused208 |
unused209 | unused21 | unused210 | unused211 | unused212 |
unused213 | unused214 | unused215 | unused216 | unused217 |
unused218 | unused219 | unused22 | unused220 | unused221 |
unused222 | unused223 | unused224 | unused225 | unused226 |
unused227 | unused228 | unused229 | unused23 | unused230 |
unused231 | unused232 | unused233 | unused234 | unused235 |
unused236 | unused237 | unused238 | unused239 | unused24 |
unused240 | unused241 | unused242 | unused243 | unused244 |
unused245 | unused246 | unused247 | unused248 | unused249 |
unused25 | unused250 | unused251 | unused252 | unused253 |
unused254 | unused255 | unused26 | unused27 | unused28 | unused29 |
unused3 | unused30 | unused31 | unused32 | unused33 | unused34 |
unused35 | unused36 | unused37 | unused38 | unused39 | unused4 |
unused40 | unused41 | unused42 | unused43 | unused44 | unused45 |
unused46 | unused47 | unused48 | unused49 | unused5 | unused50 |
unused51 | unused52 | unused53 | unused54 | unused55 | unused56 |
unused57 | unused58 | unused59 | unused6 | unused60 | unused61 |
unused62 | unused63 | unused64 | unused65 | unused66 | unused67 |
unused68 | unused69 | unused7 | unused70 | unused71 | unused72 |
unused73 | unused74 | unused75 | unused76 | unused77 | unused78 |
unused79 | unused8 | unused80 | unused81 | unused82 | unused83 |
unused84 | unused85 | unused86 | unused87 | unused88 | unused89 |
unused9 | unused90 | unused91 | unused92 | unused93 | unused94 |
```

The config key the disk will be moved to on the target VM (for example, ide0 or scsi1). Default is the source disk key.

--target-vmid <integer> (100 - 999999999)
The (unique) ID of the VM.

qm disk rescan [OPTIONS]

Rescan all storages and update disk sizes and unused disk images.

--dryrun <boolean> (*default* = 0)
Do not actually write changes out to VM config(s).

--vmid <integer> (100 - 999999999)
The (unique) ID of the VM.

qm disk resize <vmid> <disk> <size> [OPTIONS]

Extend volume size.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<disk>: <efidisk0 | ide0 | ide1 | ide2 | ide3 | sata0 | sata1 | sata2 | sata3 | sata4 | sata5 | scsi0 | scsi1 | scsi10 | scsi11 | scsi12 | scsi13 | scsi14 | scsi15 | scsi16 | scsi17 | scsi18 | scsi19 | scsi2 | scsi20 | scsi21 | scsi22 | scsi23 | scsi24 | scsi25 | scsi26 | scsi27 | scsi28 | scsi29 | scsi3 | scsi30 | scsi4 | scsi5 | scsi6 | scsi7 | scsi8 | scsi9 | tpmstate0 | virtio0 | virtio1 | virtio10 | virtio11 | virtio12 | virtio13 | virtio14 | virtio15 | virtio2 | virtio3 | virtio4 | virtio5 | virtio6 | virtio7 | virtio8 | virtio9>
The disk you want to resize.

<size>: \+?\d+(\.\d+)?[KMGT]?
The new size. With the + sign the value is added to the actual size of the volume and without it, the value is taken as an absolute one. Shrinking disk size is not supported.

--digest <string>
Prevent changes if current configuration file has different SHA1 digest. This can be used to prevent concurrent modifications.

--skiplock <boolean>
Ignore locks - only root is allowed to use this option.

qm disk unlink <vmid> --idlist <string> [OPTIONS]

Unlink/delete disk images.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--force <boolean>
Force physical removal. Without this, we simple remove the disk from the config file and create an additional configuration entry called *unused[n]*, which contains the volume ID. Unlink of unused[n] always cause physical removal.

--idlist <string>
A list of disk IDs you want to delete.

qm enroll-efi-keys <vmid>

Enroll important updated certificates to the EFI disk with pre-enrolled-keys. Currently, these are UEFI 2023 certificates from Microsoft. Must be called while the VM is shut down.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

qm guest cmd <vmid> <command>

Execute QEMU Guest Agent commands.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<command>: <fsfreeze-freeze | fsfreeze-status | fsfreeze-thaw | fstrim | get-cpustats | get-disks | get-diskstats | get-fsinfo | get-host-name | get-load | get-memory-block-info | get-memory-blocks | get-osinfo | get-time | get-timezone | get-users | get-vcpus | info | network-get-interfaces | ping | shutdown | suspend-disk | suspend-hybrid | suspend-ram>
The QGA command.

qm guest exec <vmid> [<extra-args>] [OPTIONS]

Executes the given command via the guest agent

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<extra-args>: <array>
Extra arguments as array

--pass-stdin <boolean> (*default =* 0)
When set, read STDIN until EOF and forward to guest agent via *input-data* (usually treated as STDIN to process launched by guest agent). Allows maximal 1 MiB.

--synchronous <boolean> (*default =* 1)
If set to off, returns the pid immediately instead of waiting for the command to finish or the timeout.

--timeout <integer> (0 - N) (*default =* 30)
The maximum time to wait synchronously for the command to finish. If reached, the pid gets returned. Set to 0 to deactivate

qm guest exec-status <vmid> <pid>

Gets the status of the given pid started by the guest-agent

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<pid>: <integer>
The PID to query

qm guest passwd <vmid> <username> [OPTIONS]

Sets the password for the given user to the given password

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<username>: <string>
The user to set the password for.

--crypted <boolean> (*default =* 0)
set to 1 if the password has already been passed through crypt()

qm help [OPTIONS]

Get help about specified command.

--extra-args <array>
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
Verbose output format.

qm import <vmid> <source> --storage <string> [OPTIONS]

Import a foreign virtual guest from a supported import source, such as an ESXi storage.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<source>: <string>
The import source volume id.

--acpi <boolean> (*default =* 1)
Enable/disable ACPI.

--affinity <string>
List of host cores used to execute guest processes, for example: 0,5,8-11

--agent [enabled=]<1|0> [,freeze-fs=<1|0>]
[,fstrim_cloned_disks=<1|0>] [,sync-time-on-resume=<1|0>]
[,type=<virtio|isa>]
Enable/disable communication with the QEMU Guest Agent and its properties.

--allow-ksm <boolean> (*default =* 1)
Allow memory pages of this guest to be merged via KSM (Kernel Samepage Merging).

--amd-sev [type=]<sev-type> [,allow-smt=<1|0>]
[,kernel-hashes=<1|0>] [,no-debug=<1|0>] [,no-key-sharing=<1|0>]
Secure Encrypted Virtualization (SEV) features by AMD CPUs

--arch <aarch64 | x86_64>
Virtual processor architecture. Defaults to the host architecture.

--args <string>
Arbitrary arguments passed to kvm.

--audio0 device=<ich9-intel-hda|intel-hda|AC97>
[,driver=<spice|none>]
Configure a audio device, useful in combination with QXL/Spice.

--autostart <boolean> (*default =* 0)
Automatic restart after crash (currently ignored).

--balloon <integer> (0 - N)
Amount of target RAM for the VM in MiB. The balloon driver is enabled by default, unless it is explicitly disabled by setting the value to zero.

--bios <ovmf | seabios> (*default =* seabios)
Select BIOS implementation.

--boot [[legacy=]<[acdn]{1,4}>] [,order=<device[;device...]>]
Specify guest boot order. Use the *order=* sub-property as usage with no key or *legacy=* is deprecated.

--bootdisk (ide|sata|scsi|virtio)\d+
Enable booting from specified disk. Deprecated: Use *boot: order=foo;bar* instead.

--cdrom <volume>
This is an alias for option -ide2

--cicustom [meta=<volume>] [,network=<volume>] [,user=<volume>] [,vendor=<volume>]
cloud-init: Specify custom files to replace the automatically generated ones at start.

--cipassword <string>
cloud-init: Password to assign the user. Using this is generally not recommended. Use ssh keys instead. Also note that older cloud-init versions do not support hashed passwords.

--citype <configdrive2 | nocloud | opennebula>
Specifies the cloud-init configuration format. The default depends on the configured operating system type (`ostype`. We use the `nocloud` format for Linux, and `configdrive2` for windows.

--ciupgrade <boolean> (*default =* 1)
cloud-init: do an automatic package upgrade after the first boot.

--ciuser <string>
cloud-init: User name to change ssh keys and password for instead of the image's configured default user.

--cores <integer> (1 - N) (*default =* 1)
The number of cores per socket.

--cpu [[cputype=]<string>] [,flags=<+FLAG[;-FLAG...]>] [,guest-phys-bits=<integer>] [,hidden=<1|0>] [,hv-vendor-id=<vendor-id>] [,level=<integer>] [,phys-bits=<8-64|host>] [,reported-model=<enum>]
Emulated CPU type.

--cpulimit <number> (0 - 128) (*default =* 0)
Limit of CPU usage.

--cpuunits <integer> (1 - 262144) (*default =* cgroup v1: 1024, cgroup v2: 100)
CPU weight for a VM, will be clamped to [1, 10000] in cgroup v2.

--delete <string>
A list of settings you want to delete.

--description <string>
Description for the VM. Shown in the web-interface VM's summary. This is saved as comment inside the configuration file.

--dryrun <boolean> (*default =* 0)
Show the create command and exit without doing anything.

--efidisk0 [file=]<volume> [,efitype=<2m|4m>] [,format=<enum>] [,import-from=<source volume>] [,ms-cert=<enum>] [,pre-enrolled-keys=<1|0>] [,size=<DiskSize>]

Configure a disk for storing EFI vars. Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Note that SIZE_IN_GiB is ignored here and that the default EFI vars are copied to the volume instead. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

--format <qcow2 | raw | vmdk>

Target format

--freeze <boolean>

Freeze CPU at startup (use *c* monitor command to start execution).

--hookscript <string>

Script that will be executed during various steps in the vms lifetime.

--hostpci[n] [[host=]<HOSTPCIID[;HOSTPCIID2...]>] [,device-id=<hex id>] [,driver=<vfio|keep>] [,legacy-igd=<1|0>] [,mapping=<mapping-id>] [,mdev=<string>] [,pcie=<1|0>] [,rombar=<1|0>] [,romfile=<string>] [,sub-device-id=<hex id>] [,sub-vendor-id=<hex id>] [,vendor-id=<hex id>] [,x-vga=<1|0>]

Map host PCI devices into guest.

--hotplug <string> (*default* = network,disk,usb)

Selectively enable hotplug features. This is a comma separated list of hotplug features: *network*, *disk*, *cpu*, *memory*, *usb* and *cloudinit*. Use *0* to disable hotplug completely. Using *1* as value is an alias for the default `network,disk,usb`. USB hotplugging is possible for guests with machine version >= 7.1 and ostype l26 or windows > 7.

--hugepages <1024 | 2 | any>

Enables hugepages memory.

Sets the size of hugepages in MiB. If the value is set to *any* then 1 GiB hugepages will be used if possible, otherwise the size will fall back to 2 MiB.

**--ide[n] [file=]<volume> [,aio=<native|threads|io_uring>]
[,backup=<1|0>] [,bps=<bps>] [,bps_max_length=<seconds>]
[,bps_rd=<bps>] [,bps_rd_max_length=<seconds>] [,bps_wr=<bps>]
[,bps_wr_max_length=<seconds>] [,cache=<enum>]
[,detect_zeroes=<1|0>] [,discard=<ignore|on>] [,format=<enum>]
[,import-from=<source volume>] [,iops=<iops>] [,iops_max=<iops>]
[,iops_max_length=<seconds>] [,iops_rd=<iops>]
[,iops_rd_max=<iops>] [,iops_rd_max_length=<seconds>]
[,iops_wr=<iops>] [,iops_wr_max=<iops>]
[,iops_wr_max_length=<seconds>] [,mbps=<mbps>] [,mbps_max=<mbps>]
[,mbps_rd=<mbps>] [,mbps_rd_max=<mbps>] [,mbps_wr=<mbps>]
[,mbps_wr_max=<mbps>] [,media=<cdrom|disk>] [,model=<model>]
[,replicate=<1|0>] [,rerror=<ignore|report|stop>]
[,serial=<serial>] [,shared=<1|0>] [,size=<DiskSize>]
[,snapshot=<1|0>] [,ssd=<1|0>] [,werror=<enum>] [,wwn=<wwn>]**

Use volume as IDE hard disk or CD-ROM (n is 0 to 3). Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

**--intel-tdx [type=]<tdx-type> [,attestation=<1|0>]
[,vsock-cid=<integer>] [,vsock-port=<integer>]**

Trusted Domain Extension (TDX) features by Intel CPUs

**--ipconfig[n] [gw=<GatewayIPv4>] [,gw6=<GatewayIPv6>]
[,ip=<IPv4Format/CIDR>] [,ip6=<IPv6Format/CIDR>]**

cloud-init: Specify IP addresses and gateways for the corresponding interface.

IP addresses use CIDR notation, gateways are optional but need an IP of the same type specified.

The special string *dhcp* can be used for IP addresses to use DHCP, in which case no explicit gateway should be provided. For IPv6 the special string *auto* can be used to use stateless autoconfiguration. This requires cloud-init 19.4 or newer.

If cloud-init is enabled and neither an IPv4 nor an IPv6 address is specified, it defaults to using dhcp on IPv4.

--ivshmem size=<integer> [,name=<string>]

Inter-VM shared memory. Useful for direct communication between VMs, or to the host.

--keephugepages <boolean> (*default =* 0)

Use together with hugepages. If enabled, hugepages will not not be deleted after VM shutdown and can be used for subsequent starts.

**--keyboard <da | de | de-ch | en-gb | en-us | es | fi | fr | fr-be
| fr-ca | fr-ch | hu | is | it | ja | lt | mk | nl | no | pl | pt |
pt-br | sl | sv | tr>**

Keyboard layout for VNC server. This option is generally not required and is often better handled from within the guest OS.

--kvm <boolean> (*default =* 1)
Enable/disable KVM hardware virtualization.

--live-import <boolean> (*default =* 0)
Immediately start the VM and copy the data in the background.

--localtime <boolean>
Set the real time clock (RTC) to local time. This is enabled by default if the `ostype` indicates a Microsoft Windows OS.

--lock <backup | clone | create | import | migrate | rollback | snapshot | snapshot-delete | suspended | suspending>
Lock/unlock the VM.

--machine [[type=]<machine type>] [,aw-bits=<number>] [,enable-s3=<1|0>] [,enable-s4=<1|0>] [,viommu=<intel|virtio>]
Specify the QEMU machine.

--memory [current=]<integer>
Memory properties.

--migrate_downtime <number> (0 - N) (*default =* 0.1)
Set maximum tolerated downtime (in seconds) for migrations. Should the migration not be able to converge in the very end, because too much newly dirtied RAM needs to be transferred, the limit will be increased automatically step-by-step until migration can converge. Will be capped to 2000 seconds (maximum in QEMU).

--migrate_speed <integer> (0 - N) (*default =* 0)
Set maximum speed (in MB/s) for migrations. Value 0 is no limit.

--name <string>
Set a name for the VM. Only used on the configuration web interface.

--nameserver <string>
cloud-init: Sets DNS server IP address for a container. Create will automatically use the setting from the host if neither searchdomain nor nameserver are set.

--net[n] [model=]<enum> [,bridge=<bridge>] [,firewall=<1|0>] [,host-tunnel=<1|0>] [,link_down=<1|0>] [,macaddr=<XX:XX:XX:XX:XX:XX>] [,mtu=<integer>] [,queues=<integer>] [,rate=<number>] [,tag=<integer>] [,trunks=<vlanid[;vlanid...]>] [,<model>=<macaddr>]
Specify network devices.

--numa <boolean> (*default =* 0)
Enable/disable NUMA.

--numa[n] cpus=<id[-id];...> [,hostnodes=<id[-id];...>]
[,memory=<number>] [,policy=<preferred|bind|interleave>]
NUMA topology.

--onboot <boolean> (*default =* 0)
Specifies whether a VM will be started during system bootup.

--ostype <l24 | l26 | other | solaris | w2k | w2k3 | w2k8 | win10 | win11 | win7 | win8 | wvista | wxp> (*default =* other)
Specify guest operating system.

--parallel[n] /dev/parport\d+|/dev/usb/lp\d+
Map host parallel devices (n is 0 to 2).

--protection <boolean> (*default =* 0)
Sets the protection flag of the VM. This will disable the remove VM and remove disk operations.

--reboot <boolean> (*default =* 1)
Allow reboot. If set to *0* the VM exit on reboot.

--rng0 [source=]</dev/urandom|/dev/random|/dev/hwrng>
[,max_bytes=<integer>] [,period=<integer>]
Configure a VirtIO-based Random Number Generator.

--sata[n] [file=]<volume> [,aio=<native|threads|io_uring>]
[,backup=<1|0>] [,bps=<bps>] [,bps_max_length=<seconds>]
[,bps_rd=<bps>] [,bps_rd_max_length=<seconds>] [,bps_wr=<bps>]
[,bps_wr_max_length=<seconds>] [,cache=<enum>]
[,detect_zeroes=<1|0>] [,discard=<ignore|on>] [,format=<enum>]
[,import-from=<source volume>] [,iops=<iops>] [,iops_max=<iops>]
[,iops_max_length=<seconds>] [,iops_rd=<iops>]
[,iops_rd_max=<iops>] [,iops_rd_max_length=<seconds>]
[,iops_wr=<iops>] [,iops_wr_max=<iops>]
[,iops_wr_max_length=<seconds>] [,mbps=<mbps>] [,mbps_max=<mbps>]
[,mbps_rd=<mbps>] [,mbps_rd_max=<mbps>] [,mbps_wr=<mbps>]
[,mbps_wr_max=<mbps>] [,media=<cdrom|disk>] [,replicate=<1|0>]
[,rerror=<ignore|report|stop>] [,serial=<serial>] [,shared=<1|0>]
[,size=<DiskSize>] [,snapshot=<1|0>] [,ssd=<1|0>] [,werror=<enum>]
[,wwn=<wwn>]
Use volume as SATA hard disk or CD-ROM (n is 0 to 5). Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

--scsi[n] [file=]<volume> [,aio=<native|threads|io_uring>] [,backup=<1|0>] [,bps=<bps>] [,bps_max_length=<seconds>] [,bps_rd=<bps>] [,bps_rd_max_length=<seconds>] [,bps_wr=<bps>] [,bps_wr_max_length=<seconds>] [,cache=<enum>] [,detect_zeroes=<1|0>] [,discard=<ignore|on>] [,format=<enum>] [,import-from=<source volume>] [,iops=<iops>] [,iops_max=<iops>] [,iops_max_length=<seconds>] [,iops_rd=<iops>] [,iops_rd_max=<iops>] [,iops_rd_max_length=<seconds>] [,iops_wr=<iops>] [,iops_wr_max=<iops>] [,iops_wr_max_length=<seconds>] [,iothread=<1|0>] [,mbps=<mbps>] [,mbps_max=<mbps>] [,mbps_rd=<mbps>] [,mbps_rd_max=<mbps>] [,mbps_wr=<mbps>] [,mbps_wr_max=<mbps>] [,media=<cdrom|disk>] [,product=<product>] [,queues=<integer>] [,replicate=<1|0>] [,rerror=<ignore|report|stop>] [,ro=<1|0>] [,scsiblock=<1|0>] [,serial=<serial>] [,shared=<1|0>] [,size=<DiskSize>] [,snapshot=<1|0>] [,ssd=<1|0>] [,vendor=<vendor>] [,werror=<enum>] [,wwn=<wwn>]

Use volume as SCSI hard disk or CD-ROM (n is 0 to 30). Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

--scsihw <lsi | lsi53c810 | megasas | pvscsi | virtio-scsi-pci | virtio-scsi-single> (*default =* lsi)

SCSI controller model

--searchdomain <string>

cloud-init: Sets DNS search domains for a container. Create will automatically use the setting from the host if neither searchdomain nor nameserver are set.

--serial[n] (/dev/[^,]+|socket)

Create a serial device inside the VM (n is 0 to 3)

--shares <integer> (0 - 50000) (*default =* 1000)

Amount of memory shares for auto-ballooning. The larger the number is, the more memory this VM gets. Number is relative to weights of all other running VMs. Using zero disables auto-ballooning. Auto-ballooning is done by pvestatd.

--smbios1 [base64=<1|0>] [,family=<Base64 encoded string>] [,manufacturer=<Base64 encoded string>] [,product=<Base64 encoded string>] [,serial=<Base64 encoded string>] [,sku=<Base64 encoded string>] [,uuid=<UUID>] [,version=<Base64 encoded string>]

Specify SMBIOS type 1 fields.

--smp <integer> (1 - N) (*default =* 1)

The number of CPUs. Please use option -sockets instead.

--sockets <integer> (1 - N) (*default =* 1)

The number of CPU sockets.

--spice_enhancements [foldersharing=<1|0>] [,videostreaming=<off|all|filter>]
Configure additional enhancements for SPICE.

--sshkeys <string>
cloud-init: Setup public SSH keys (one key per line, OpenSSH format).

--startdate (now | YYYY-MM-DD | YYYY-MM-DDTHH:MM:SS) (*default =* now)
Set the initial date of the real time clock. Valid format for date are:'now' or *2006-06-17T16:01:21* or *2006-06-17*.

--startup `[[order=]\d+] [,up=\d+] [,down=\d+] `
Startup and shutdown behavior. Order is a non-negative number defining the general startup order. Shutdown in done with reverse ordering. Additionally you can set the *up* or *down* delay in seconds, which specifies a delay to wait before the next VM is started or stopped.

--storage <storage ID>
Default storage.

--tablet <boolean> (*default =* 1)
Enable/disable the USB tablet device.

--tags <string>
Tags of the VM. This is only meta information.

--tdf <boolean> (*default =* 0)
Enable/disable time drift fix.

--template <boolean> (*default =* 0)
Enable/disable Template.

--tpmstate0 [file=]<volume> [,format=<raw|qcow2|vmdk>] [,import-from=<source volume>] [,size=<DiskSize>] [,version=<v1.2|v2.0>]
Configure a Disk for storing TPM state. The format is fixed to *raw*. Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Note that SIZE_IN_GiB is ignored here and 4 MiB will be used instead. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

--unused[n] [file=]<volume>
Reference to unused volumes. This is used internally, and should not be modified manually.

--usb[n] [[host=]<HOSTUSBDEVICE|spice>] [,mapping=<mapping-id>] [,usb3=<1|0>]
Configure an USB device (n is 0 to 4, for machine version >= 7.1 and ostype l26 or windows > 7, n can be up to 14).

--vcpus <integer> (1 - N) (*default* = 0)
Number of hotplugged vcpus.

--vga [[type=]<enum>] [,clipboard=<vnc>] [,memory=<integer>]
Configure the VGA hardware.

--virtio[n] [file=]<volume> [,aio=<native|threads|io_uring>]
[,backup=<1|0>] [,bps=<bps>] [,bps_max_length=<seconds>]
[,bps_rd=<bps>] [,bps_rd_max_length=<seconds>] [,bps_wr=<bps>]
[,bps_wr_max_length=<seconds>] [,cache=<enum>]
[,detect_zeroes=<1|0>] [,discard=<ignore|on>] [,format=<enum>]
[,import-from=<source volume>] [,iops=<iops>] [,iops_max=<iops>]
[,iops_max_length=<seconds>] [,iops_rd=<iops>]
[,iops_rd_max=<iops>] [,iops_rd_max_length=<seconds>]
[,iops_wr=<iops>] [,iops_wr_max=<iops>]
[,iops_wr_max_length=<seconds>] [,iothread=<1|0>] [,mbps=<mbps>]
[,mbps_max=<mbps>] [,mbps_rd=<mbps>] [,mbps_rd_max=<mbps>]
[,mbps_wr=<mbps>] [,mbps_wr_max=<mbps>] [,media=<cdrom|disk>]
[,replicate=<1|0>] [,rerror=<ignore|report|stop>] [,ro=<1|0>]
[,serial=<serial>] [,shared=<1|0>] [,size=<DiskSize>]
[,snapshot=<1|0>] [,werror=<enum>]
Use volume as VIRTIO hard disk (n is 0 to 15). Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

--virtiofs[n] [dirid=]<mapping-id> [,cache=<enum>]
[,direct-io=<1|0>] [,expose-acl=<1|0>] [,expose-xattr=<1|0>]
Configuration for sharing a directory between host and guest using Virtio-fs.

--vmgenid <UUID> (*default* = 1 (autogenerated))
Set VM Generation ID. Use *1* to autogenerate on create or update, pass *0* to disable explicitly.

--vmstatestorage <storage ID>
Default storage for VM state volumes/files.

--watchdog [[model=]<i6300esb>] [,action=<enum>]
Create a virtual hardware watchdog device.

qm importdisk

An alias for *qm disk import*.

qm importovf <vmid> <manifest> <storage> [OPTIONS]

Create a new VM using parameters read from an OVF manifest

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<manifest>: <string>
path to the ovf file

<storage>: <storage ID>
Target storage ID

--dryrun <boolean>
Print a parsed representation of the extracted OVF parameters, but do not create a VM

--format <qcow2 | raw | vmdk>
Target format

qm list [OPTIONS]

Virtual machine index (per node).

--full <boolean>
Determine the full status of active VMs.

qm listsnapshot <vmid>

List all snapshots.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

qm migrate <vmid> <target> [OPTIONS]

Migrate virtual machine. Creates a new migration task.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<target>: <string>
Target node.

--bwlimit <integer> (0 - N) (*default =* migrate limit from datacenter or storage config)
Override I/O bandwidth limit (in KiB/s).

--force <boolean>
Allow to migrate VMs which use local devices. Only root may use this option.

--migration_network <string>
CIDR of the (sub) network that is used for migration.

--migration_type <insecure | secure>
Migration traffic is encrypted using an SSH tunnel by default. On secure, completely private networks this can be disabled to increase performance.

--online <boolean>
Use online/live migration if VM is running. Ignored if VM is stopped.

--skip-config-check <boolean> (*default =* 0)
For intra-cluster migration. Skip checking if the configuration can be parsed successfully by the target. Using this flag can lead to dropped configuration options if the target is too old to parse them.

--targetstorage <string>
Mapping from source to target storages. Providing only a single storage ID maps all source storages to that storage. Providing the special value *1* will map each source storage to itself.

--with-conntrack-state <boolean> (*default =* 0)
Whether to migrate conntrack entries for running VMs.

--with-local-disks <boolean>
Enable live storage migration for local disk

qm monitor <vmid>

Enter QEMU Monitor interface.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

qm move-disk

An alias for *qm disk move*.

qm move_disk

An alias for *qm disk move*.

qm mtunnel

Used by qmigrate - do not use manually.

qm nbdstop <vmid>

Stop embedded nbd server.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

qm pending <vmid>

Get the virtual machine configuration with both current and pending values.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

qm reboot <vmid> [OPTIONS]

Reboot the VM by shutting it down, and starting it again. Applies pending changes.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--timeout <integer> (0 - N)
Wait maximal timeout seconds for the shutdown.

qm remote-migrate <vmid> [<target-vmid>] <target-endpoint> --target-bridge <str
--target-storage <string> [OPTIONS]

Migrate virtual machine to a remote cluster. Creates a new migration task. EXPERIMENTAL feature!

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<target-vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

**<target-endpoint>: apitoken=<PVEAPIToken=user@realm!token=SECRET>
,host=<ADDRESS> [,fingerprint=<FINGERPRINT>] [,port=<PORT>]**
Remote target endpoint

--allow-new-uid <boolean> (*default =* 0)
Allow the migration if another guest in the target cluster already has the uid of this guest. The migrated guest then gets a new uid.

--bwlimit <integer> (0 - N) (*default =* migrate limit from datacenter or storage config)
Override I/O bandwidth limit (in KiB/s).

--delete <boolean> (*default =* 0)
Delete the original VM and related data after successful migration. By default the original VM is kept on the source cluster in a stopped state.

--online <boolean>
Use online/live migration if VM is running. Ignored if VM is stopped.

--target-bridge <string>
Mapping from source to target bridges. Providing only a single bridge ID maps all source bridges to that bridge. Providing the special value *1* will map each source bridge to itself.

--target-storage <string>
Mapping from source to target storages. Providing only a single storage ID maps all source storages to that storage. Providing the special value *1* will map each source storage to itself.

qm rescan

An alias for *qm disk rescan*.

qm reset <vmid> [OPTIONS]

Reset virtual machine.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--skiplock <boolean>
Ignore locks - only root is allowed to use this option.

qm resize

An alias for *qm disk resize*.

qm resume <vmid> [OPTIONS]

Resume virtual machine.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--nocheck <boolean>
Do not check whether the VM is running, used internally during migration. Only root may use this option.

--skiplock <boolean>
Ignore locks - only root is allowed to use this option.

--sync-time-on-resume <boolean>
Override the *sync-time-on-resume* setting from the VM's guest agent (QGA) config for this resume only. Controls whether the guest's clock is synchronized after resuming the VM.

qm rollback <vmid> <snapname> [OPTIONS]

Rollback VM state to specified snapshot.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<snapname>: <string>
The name of the snapshot.

--start <boolean> (*default =* 0)
Whether the VM should get started after rolling back successfully. (Note: VMs will be automatically started if the snapshot includes RAM.)

--sync-time-on-resume <boolean>
Override the *sync-time-on-resume* setting from the VM's guest agent (QGA) config for this rollback only. Controls whether the guest's clock is synchronized after the RAM state is restored.

qm sendkey <vmid> <key> [OPTIONS]

Send key event to virtual machine.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<key>: <string>
The key (qemu monitor encoding).

--skiplock <boolean>
Ignore locks - only root is allowed to use this option.

qm set <vmid> [OPTIONS]

Set virtual machine options (synchronous API) - You should consider using the POST method instead for any actions involving hotplug or storage allocation.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--acpi <boolean> (*default =* 1)
Enable/disable ACPI.

--affinity <string>
List of host cores used to execute guest processes, for example: 0,5,8-11

--agent [enabled=]<1|0> [,freeze-fs=<1|0>]
[,fstrim_cloned_disks=<1|0>] [,sync-time-on-resume=<1|0>]
[,type=<virtio|isa>]
Enable/disable communication with the QEMU Guest Agent and its properties.

--allow-ksm <boolean> (*default =* 1)
Allow memory pages of this guest to be merged via KSM (Kernel Samepage Merging).

--amd-sev [type=]<sev-type> [,allow-smt=<1|0>]
[,kernel-hashes=<1|0>] [,no-debug=<1|0>] [,no-key-sharing=<1|0>]
Secure Encrypted Virtualization (SEV) features by AMD CPUs

--arch <aarch64 | x86_64>
Virtual processor architecture. Defaults to the host architecture.

--args <string>
Arbitrary arguments passed to kvm.

--audio0 device=<ich9-intel-hda|intel-hda|AC97>
[,driver=<spice|none>]
Configure a audio device, useful in combination with QXL/Spice.

--autostart <boolean> (*default =* 0)
Automatic restart after crash (currently ignored).

--balloon <integer> (0 - N)
Amount of target RAM for the VM in MiB. The balloon driver is enabled by default, unless it is explicitly disabled by setting the value to zero.

--bios <ovmf | seabios> (*default =* seabios)
Select BIOS implementation.

--boot [[legacy=]<[acdn]{1,4}>] [,order=<device[;device...]>]
Specify guest boot order. Use the *order=* sub-property as usage with no key or *legacy=* is deprecated.

--bootdisk (ide|sata|scsi|virtio)\d+
Enable booting from specified disk. Deprecated: Use *boot: order=foo;bar* instead.

--cdrom <volume>
This is an alias for option -ide2

--cicustom [meta=<volume>] [,network=<volume>] [,user=<volume>]
[,vendor=<volume>]
cloud-init: Specify custom files to replace the automatically generated ones at start.

--cipassword <password>
cloud-init: Password to assign the user. Using this is generally not recommended. Use ssh keys instead. Also note that older cloud-init versions do not support hashed passwords.

--citype <configdrive2 | nocloud | opennebula>
Specifies the cloud-init configuration format. The default depends on the configured operating system type (`ostype`. We use the `nocloud` format for Linux, and `configdrive2` for windows.

--ciupgrade <boolean> (*default =* 1)
cloud-init: do an automatic package upgrade after the first boot.

--ciuser <string>
cloud-init: User name to change ssh keys and password for instead of the image's configured default user.

--cores <integer> (1 - N) (*default* = 1)
The number of cores per socket.

--cpu [[cputype=]<string>] [,flags=<+FLAG[;-FLAG...]>]
[,guest-phys-bits=<integer>] [,hidden=<1|0>]
[,hv-vendor-id=<vendor-id>] [,level=<integer>]
[,phys-bits=<8-64|host>] [,reported-model=<enum>]
Emulated CPU type.

--cpulimit <number> (0 - 128) (*default* = 0)
Limit of CPU usage.

--cpuunits <integer> (1 - 262144) (*default* = cgroup v1: 1024, cgroup v2: 100)
CPU weight for a VM, will be clamped to [1, 10000] in cgroup v2.

--delete <string>
A list of settings you want to delete.

--description <string>
Description for the VM. Shown in the web-interface VM's summary. This is saved as comment inside the configuration file.

--digest <string>
Prevent changes if current configuration file has different SHA1 digest. This can be used to prevent concurrent modifications.

--efidisk0 [file=]<volume> [,efitype=<2m|4m>] [,format=<enum>]
[,import-from=<source volume>] [,ms-cert=<enum>]
[,pre-enrolled-keys=<1|0>] [,size=<DiskSize>]
Configure a disk for storing EFI vars. Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Note that SIZE_IN_GiB is ignored here and that the default EFI vars are copied to the volume instead. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

--force <boolean>
Force physical removal. Without this, we simple remove the disk from the config file and create an additional configuration entry called *unused[n]*, which contains the volume ID. Unlink of unused[n] always cause physical removal.

> **Note**
> Requires option(s): `delete`

--freeze <boolean>
Freeze CPU at startup (use *c* monitor command to start execution).

--hookscript <string>
Script that will be executed during various steps in the vms lifetime.

--hostpci[n] [[host=]<HOSTPCIID[;HOSTPCIID2...]>] [,device-id=<hex id>] [,driver=<vfio|keep>] [,legacy-igd=<1|0>] [,mapping=<mapping-id>] [,mdev=<string>] [,pcie=<1|0>] [,rombar=<1|0>] [,romfile=<string>] [,sub-device-id=<hex id>] [,sub-vendor-id=<hex id>] [,vendor-id=<hex id>] [,x-vga=<1|0>]
Map host PCI devices into guest.

--hotplug <string> (*default =* network,disk,usb)
Selectively enable hotplug features. This is a comma separated list of hotplug features: *network*, *disk*, *cpu*, *memory*, *usb* and *cloudinit*. Use *0* to disable hotplug completely. Using *1* as value is an alias for the default `network,disk,usb`. USB hotplugging is possible for guests with machine version >= 7.1 and ostype l26 or windows > 7.

--hugepages <1024 | 2 | any>
Enables hugepages memory.

Sets the size of hugepages in MiB. If the value is set to *any* then 1 GiB hugepages will be used if possible, otherwise the size will fall back to 2 MiB.

--ide[n] [file=]<volume> [,aio=<native|threads|io_uring>] [,backup=<1|0>] [,bps=<bps>] [,bps_max_length=<seconds>] [,bps_rd=<bps>] [,bps_rd_max_length=<seconds>] [,bps_wr=<bps>] [,bps_wr_max_length=<seconds>] [,cache=<enum>] [,detect_zeroes=<1|0>] [,discard=<ignore|on>] [,format=<enum>] [,import-from=<source volume>] [,iops=<iops>] [,iops_max=<iops>] [,iops_max_length=<seconds>] [,iops_rd=<iops>] [,iops_rd_max=<iops>] [,iops_rd_max_length=<seconds>] [,iops_wr=<iops>] [,iops_wr_max=<iops>] [,iops_wr_max_length=<seconds>] [,mbps=<mbps>] [,mbps_max=<mbps>] [,mbps_rd=<mbps>] [,mbps_rd_max=<mbps>] [,mbps_wr=<mbps>] [,mbps_wr_max=<mbps>] [,media=<cdrom|disk>] [,model=<model>] [,replicate=<1|0>] [,rerror=<ignore|report|stop>] [,serial=<serial>] [,shared=<1|0>] [,size=<DiskSize>] [,snapshot=<1|0>] [,ssd=<1|0>] [,werror=<enum>] [,wwn=<wwn>]
Use volume as IDE hard disk or CD-ROM (n is 0 to 3). Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

--intel-tdx [type=]<tdx-type> [,attestation=<1|0>] [,vsock-cid=<integer>] [,vsock-port=<integer>]
Trusted Domain Extension (TDX) features by Intel CPUs

--ipconfig[n] [gw=<GatewayIPv4>] [,gw6=<GatewayIPv6>] [,ip=<IPv4Format/CIDR>] [,ip6=<IPv6Format/CIDR>]
cloud-init: Specify IP addresses and gateways for the corresponding interface.

IP addresses use CIDR notation, gateways are optional but need an IP of the same type specified.

The special string *dhcp* can be used for IP addresses to use DHCP, in which case no explicit gateway should be provided. For IPv6 the special string *auto* can be used to use stateless autoconfiguration. This requires cloud-init 19.4 or newer.

If cloud-init is enabled and neither an IPv4 nor an IPv6 address is specified, it defaults to using dhcp on IPv4.

--ivshmem size=<integer> [,name=<string>]
Inter-VM shared memory. Useful for direct communication between VMs, or to the host.

--keephugepages <boolean> (*default =* 0)
Use together with hugepages. If enabled, hugepages will not not be deleted after VM shutdown and can be used for subsequent starts.

--keyboard <da | de | de-ch | en-gb | en-us | es | fi | fr | fr-be | fr-ca | fr-ch | hu | is | it | ja | lt | mk | nl | no | pl | pt | pt-br | sl | sv | tr>
Keyboard layout for VNC server. This option is generally not required and is often better handled from within the guest OS.

--kvm <boolean> (*default =* 1)
Enable/disable KVM hardware virtualization.

--localtime <boolean>
Set the real time clock (RTC) to local time. This is enabled by default if the `ostype` indicates a Microsoft Windows OS.

--lock <backup | clone | create | import | migrate | rollback | snapshot | snapshot-delete | suspended | suspending>
Lock/unlock the VM.

--machine [[type=]<machine type>] [,aw-bits=<number>] [,enable-s3=<1|0>] [,enable-s4=<1|0>] [,viommu=<intel|virtio>]
Specify the QEMU machine.

--memory [current=]<integer>
Memory properties.

--migrate_downtime <number> (0 - N) (*default =* 0.1)
Set maximum tolerated downtime (in seconds) for migrations. Should the migration not be able to converge in the very end, because too much newly dirtied RAM needs to be transferred, the limit will be increased automatically step-by-step until migration can converge. Will be capped to 2000 seconds (maximum in QEMU).

--migrate_speed <integer> (0 - N) (*default =* 0)
Set maximum speed (in MB/s) for migrations. Value 0 is no limit.

--name <string>
Set a name for the VM. Only used on the configuration web interface.

--nameserver <string>
cloud-init: Sets DNS server IP address for a container. Create will automatically use the setting from the host if neither searchdomain nor nameserver are set.

--net[n] [model=]<enum> [,bridge=<bridge>] [,firewall=<1|0>]
[,host-tunnel=<1|0>] [,link_down=<1|0>]
[,macaddr=<XX:XX:XX:XX:XX:XX>] [,mtu=<integer>] [,queues=<integer>]
[,rate=<number>] [,tag=<integer>] [,trunks=<vlanid[;vlanid...]>]
[,<model>=<macaddr>]
Specify network devices.

--numa <boolean> (***default =*** **0**)
Enable/disable NUMA.

--numa[n] cpus=<id[-id];...> [,hostnodes=<id[-id];...>]
[,memory=<number>] [,policy=<preferred|bind|interleave>]
NUMA topology.

--onboot <boolean> (***default =*** **0**)
Specifies whether a VM will be started during system bootup.

--ostype <l24 | l26 | other | solaris | w2k | w2k3 | w2k8 | win10 |
win11 | win7 | win8 | wvista | wxp> (***default =*** **other**)
Specify guest operating system.

--parallel[n] /dev/parport\d+|/dev/usb/lp\d+
Map host parallel devices (n is 0 to 2).

--protection <boolean> (***default =*** **0**)
Sets the protection flag of the VM. This will disable the remove VM and remove disk operations.

--reboot <boolean> (***default =*** **1**)
Allow reboot. If set to *0* the VM exit on reboot.

--revert <string>
Revert a pending change.

--rng0 [source=]</dev/urandom|/dev/random|/dev/hwrng>
[,max_bytes=<integer>] [,period=<integer>]
Configure a VirtIO-based Random Number Generator.

**--sata[n] [file=]<volume> [,aio=<native|threads|io_uring>]
[,backup=<1|0>] [,bps=<bps>] [,bps_max_length=<seconds>]
[,bps_rd=<bps>] [,bps_rd_max_length=<seconds>] [,bps_wr=<bps>]
[,bps_wr_max_length=<seconds>] [,cache=<enum>]
[,detect_zeroes=<1|0>] [,discard=<ignore|on>] [,format=<enum>]
[,import-from=<source volume>] [,iops=<iops>] [,iops_max=<iops>]
[,iops_max_length=<seconds>] [,iops_rd=<iops>]
[,iops_rd_max=<iops>] [,iops_rd_max_length=<seconds>]
[,iops_wr=<iops>] [,iops_wr_max=<iops>]
[,iops_wr_max_length=<seconds>] [,mbps=<mbps>] [,mbps_max=<mbps>]
[,mbps_rd=<mbps>] [,mbps_rd_max=<mbps>] [,mbps_wr=<mbps>]
[,mbps_wr_max=<mbps>] [,media=<cdrom|disk>] [,replicate=<1|0>]
[,rerror=<ignore|report|stop>] [,serial=<serial>] [,shared=<1|0>]
[,size=<DiskSize>] [,snapshot=<1|0>] [,ssd=<1|0>] [,werror=<enum>]
[,wwn=<wwn>]**

Use volume as SATA hard disk or CD-ROM (n is 0 to 5). Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

**--scsi[n] [file=]<volume> [,aio=<native|threads|io_uring>]
[,backup=<1|0>] [,bps=<bps>] [,bps_max_length=<seconds>]
[,bps_rd=<bps>] [,bps_rd_max_length=<seconds>] [,bps_wr=<bps>]
[,bps_wr_max_length=<seconds>] [,cache=<enum>]
[,detect_zeroes=<1|0>] [,discard=<ignore|on>] [,format=<enum>]
[,import-from=<source volume>] [,iops=<iops>] [,iops_max=<iops>]
[,iops_max_length=<seconds>] [,iops_rd=<iops>]
[,iops_rd_max=<iops>] [,iops_rd_max_length=<seconds>]
[,iops_wr=<iops>] [,iops_wr_max=<iops>]
[,iops_wr_max_length=<seconds>] [,iothread=<1|0>] [,mbps=<mbps>]
[,mbps_max=<mbps>] [,mbps_rd=<mbps>] [,mbps_rd_max=<mbps>]
[,mbps_wr=<mbps>] [,mbps_wr_max=<mbps>] [,media=<cdrom|disk>]
[,product=<product>] [,queues=<integer>] [,replicate=<1|0>]
[,rerror=<ignore|report|stop>] [,ro=<1|0>] [,scsiblock=<1|0>]
[,serial=<serial>] [,shared=<1|0>] [,size=<DiskSize>]
[,snapshot=<1|0>] [,ssd=<1|0>] [,vendor=<vendor>] [,werror=<enum>]
[,wwn=<wwn>]**

Use volume as SCSI hard disk or CD-ROM (n is 0 to 30). Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

**--scsihw <lsi | lsi53c810 | megasas | pvscsi | virtio-scsi-pci |
virtio-scsi-single> (*default* = lsi)**

SCSI controller model

--searchdomain <string>

cloud-init: Sets DNS search domains for a container. Create will automatically use the setting from the host if neither searchdomain nor nameserver are set.

--serial[n] (/dev/[^,]+|socket)
Create a serial device inside the VM (n is 0 to 3)

--shares <integer> (0 - 50000) (*default =* 1000)
Amount of memory shares for auto-ballooning. The larger the number is, the more memory this VM gets. Number is relative to weights of all other running VMs. Using zero disables auto-ballooning. Auto-ballooning is done by pvestatd.

--skiplock <boolean>
Ignore locks - only root is allowed to use this option.

--smbios1 [base64=<1|0>] [,family=<Base64 encoded string>] [,manufacturer=<Base64 encoded string>] [,product=<Base64 encoded string>] [,serial=<Base64 encoded string>] [,sku=<Base64 encoded string>] [,uuid=<UUID>] [,version=<Base64 encoded string>]
Specify SMBIOS type 1 fields.

--smp <integer> (1 - N) (*default =* 1)
The number of CPUs. Please use option -sockets instead.

--sockets <integer> (1 - N) (*default =* 1)
The number of CPU sockets.

--spice_enhancements [foldersharing=<1|0>] [,videostreaming=<off|all|filter>]
Configure additional enhancements for SPICE.

--sshkeys <filepath>
cloud-init: Setup public SSH keys (one key per line, OpenSSH format).

--startdate (now | YYYY-MM-DD | YYYY-MM-DDTHH:MM:SS) (*default =* now)
Set the initial date of the real time clock. Valid format for date are:'now' or *2006-06-17T16:01:21* or *2006-06-17*.

--startup `[[order=]\d+] [,up=\d+] [,down=\d+] `
Startup and shutdown behavior. Order is a non-negative number defining the general startup order. Shutdown in done with reverse ordering. Additionally you can set the *up* or *down* delay in seconds, which specifies a delay to wait before the next VM is started or stopped.

--tablet <boolean> (*default =* 1)
Enable/disable the USB tablet device.

--tags <string>
Tags of the VM. This is only meta information.

--tdf <boolean> (*default =* 0)
Enable/disable time drift fix.

--template <boolean> (*default =* 0)
Enable/disable Template.

--tpmstate0 [file=]<volume> [,format=<raw|qcow2|vmdk>]
[,import-from=<source volume>] [,size=<DiskSize>]
[,version=<v1.2|v2.0>]
Configure a Disk for storing TPM state. The format is fixed to *raw*. Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Note that SIZE_IN_GiB is ignored here and 4 MiB will be used instead. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

--unused[n] [file=]<volume>
Reference to unused volumes. This is used internally, and should not be modified manually.

--usb[n] [[host=]<HOSTUSBDEVICE|spice>] [,mapping=<mapping-id>]
[,usb3=<1|0>]
Configure an USB device (n is 0 to 4, for machine version >= 7.1 and ostype l26 or windows > 7, n can be up to 14).

--vcpus <integer> (1 - N) (*default =* 0)
Number of hotplugged vcpus.

--vga [[type=]<enum>] [,clipboard=<vnc>] [,memory=<integer>]
Configure the VGA hardware.

--virtio[n] [file=]<volume> [,aio=<native|threads|io_uring>]
[,backup=<1|0>] [,bps=<bps>] [,bps_max_length=<seconds>]
[,bps_rd=<bps>] [,bps_rd_max_length=<seconds>] [,bps_wr=<bps>]
[,bps_wr_max_length=<seconds>] [,cache=<enum>]
[,detect_zeroes=<1|0>] [,discard=<ignore|on>] [,format=<enum>]
[,import-from=<source volume>] [,iops=<iops>] [,iops_max=<iops>]
[,iops_max_length=<seconds>] [,iops_rd=<iops>]
[,iops_rd_max=<iops>] [,iops_rd_max_length=<seconds>]
[,iops_wr=<iops>] [,iops_wr_max=<iops>]
[,iops_wr_max_length=<seconds>] [,iothread=<1|0>] [,mbps=<mbps>]
[,mbps_max=<mbps>] [,mbps_rd=<mbps>] [,mbps_rd_max=<mbps>]
[,mbps_wr=<mbps>] [,mbps_wr_max=<mbps>] [,media=<cdrom|disk>]
[,replicate=<1|0>] [,rerror=<ignore|report|stop>] [,ro=<1|0>]
[,serial=<serial>] [,shared=<1|0>] [,size=<DiskSize>]
[,snapshot=<1|0>] [,werror=<enum>]
Use volume as VIRTIO hard disk (n is 0 to 15). Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume. Use STORAGE_ID:0 and the *import-from* parameter to import from an existing volume.

--virtiofs[n] [dirid=]<mapping-id> [,cache=<enum>]
[,direct-io=<1|0>] [,expose-acl=<1|0>] [,expose-xattr=<1|0>]
Configuration for sharing a directory between host and guest using Virtio-fs.

--vmgenid <UUID> (*default =* 1 (autogenerated))
Set VM Generation ID. Use *1* to autogenerate on create or update, pass *0* to disable explicitly.

--vmstatestorage <storage ID>
Default storage for VM state volumes/files.

--watchdog [[model=]<i6300esb>] [,action=<enum>]
Create a virtual hardware watchdog device.

qm showcmd <vmid> [OPTIONS]

Show command line which is used to start the VM (debug info).

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--pretty <boolean> (*default =* 0)
Puts each option on a new line to enhance human readability

--snapshot <string>
Fetch config values from given snapshot.

qm shutdown <vmid> [OPTIONS]

Shutdown virtual machine. This is similar to pressing the power button on a physical machine. This will send an ACPI event for the guest OS, which should then proceed to a clean shutdown.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--forceStop <boolean> (*default =* 0)
Make sure the VM stops.

--keepActive <boolean> (*default =* 0)
Do not deactivate storage volumes.

--skiplock <boolean>
Ignore locks - only root is allowed to use this option.

--timeout <integer> (0 - N)
Wait maximal timeout seconds.

qm snapshot <vmid> <snapname> [OPTIONS]

Snapshot a VM.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<snapname>: <string>
The name of the snapshot.

--description <string>
A textual description or comment.

--vmstate <boolean>
Save the vmstate

qm start <vmid> [OPTIONS]

Start virtual machine.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--force-cpu <string>
Override QEMU's -cpu argument with the given string.

--machine [[type=]<machine type>] [,aw-bits=<number>]
[,enable-s3=<1|0>] [,enable-s4=<1|0>] [,viommu=<intel|virtio>]
Specify the QEMU machine.

--migratedfrom <string>
The cluster node name.

--migration_network <string>
CIDR of the (sub) network that is used for migration.

--migration_type <insecure | secure>
Migration traffic is encrypted using an SSH tunnel by default. On secure, completely private networks this can be disabled to increase performance.

--nets-host-mtu net\d+=\d+(,net\d+=\d+)*
Used for migration compat. List of VirtIO network devices and their effective host_mtu setting according to the QEMU object model on the source side of the migration. A value of 0 means that the host_mtu parameter is to be avoided for the corresponding device.

--skiplock <boolean>
Ignore locks - only root is allowed to use this option.

--stateuri <string>
Some command save/restore state from this location.

--sync-time-on-resume <boolean>
Override the *sync-time-on-resume* setting from the VM's guest agent (QGA) config for this start only. Controls whether the guest's clock is synchronized when starting a hibernated VM. No effect on a regular start.

--targetstorage <string>
Mapping from source to target storages. Providing only a single storage ID maps all source storages to that storage. Providing the special value *1* will map each source storage to itself.

--timeout <integer> (0 - N) (*default =* max(30, vm memory in GiB))
Wait maximal timeout seconds.

--with-conntrack-state <boolean> (*default =* 0)
Whether to migrate conntrack entries for running VMs.

qm status <vmid> [OPTIONS]

Show VM status.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--verbose <boolean>
Verbose output format

qm stop <vmid> [OPTIONS]

Stop virtual machine. The qemu process will exit immediately. This is akin to pulling the power plug of a running computer and may damage the VM data.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--keepActive <boolean> (*default =* 0)
Do not deactivate storage volumes.

--migratedfrom <string>
The cluster node name.

--overrule-shutdown <boolean> (*default =* 0)
Try to abort active *qmshutdown* tasks before stopping.

--skiplock <boolean>
Ignore locks - only root is allowed to use this option.

--timeout <integer> (0 - N)
Wait maximal timeout seconds.

qm suspend `<vmid> [OPTIONS]`

Suspend virtual machine.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--skiplock <boolean>
Ignore locks - only root is allowed to use this option.

--statestorage <storage ID>
The storage for the VM state

> **Note**
> Requires option(s): `todisk`

--todisk <boolean> (*default =* 0)
If set, suspends the VM to disk. Will be resumed on next VM start.

qm template `<vmid> [OPTIONS]`

Create a Template.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--disk <efidisk0 | ide0 | ide1 | ide2 | ide3 | sata0 | sata1 | sata2 | sata3 | sata4 | sata5 | scsi0 | scsi1 | scsi10 | scsi11 | scsi12 | scsi13 | scsi14 | scsi15 | scsi16 | scsi17 | scsi18 | scsi19 | scsi2 | scsi20 | scsi21 | scsi22 | scsi23 | scsi24 | scsi25 | scsi26 | scsi27 | scsi28 | scsi29 | scsi3 | scsi30 | scsi4 | scsi5 | scsi6 | scsi7 | scsi8 | scsi9 | tpmstate0 | virtio0 | virtio1 | virtio10 | virtio11 | virtio12 | virtio13 | virtio14 | virtio15 | virtio2 | virtio3 | virtio4 | virtio5 | virtio6 | virtio7 | virtio8 | virtio9>
If you want to convert only 1 disk to base image.

qm terminal `<vmid> [OPTIONS]`

Open a terminal using a serial device (The VM need to have a serial device configured, for example *serial0: socket*)

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--escape <string> (*default =* ^O)
Escape character.

--iface <serial0 | serial1 | serial2 | serial3>
Select the serial device. By default we simply use the first suitable device.

qm unlink

An alias for *qm disk unlink*.

qm unlock <vmid>

Unlock the VM.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

qm vncproxy <vmid>

Proxy VM VNC traffic to stdin/stdout

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

qm wait <vmid> [OPTIONS]

Wait until the VM is stopped.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--timeout <integer> (1 - N)
Timeout in seconds. Default is to wait forever.

A.10 qmrestore - Restore QemuServer `vzdump` Backups

qmrestore help

qmrestore <archive> <vmid> [OPTIONS]

Restore QemuServer vzdump backups.

<archive>: <string>
The backup file. You can pass - to read from standard input.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--allow-identity-mismatch <boolean> (*default =* 0)
Allow overwriting an existing guest with a backup of another guest, as detected by a different *uid* in *meta*. The guest then keeps its own uid. Not needed to restore a backup again over a guest that an unfinished restore of that backup left behind.

--bwlimit <number> (0 - N)
Override I/O bandwidth limit (in KiB/s).

--force <boolean>
Allow to overwrite existing VM.

--ha-managed <boolean> (*default =* 0)
Add the VM as a HA resource after it was restored.

--live-restore <boolean>
Start the VM immediately from the backup and restore in background. PBS only.

--pool <string>
Add the VM to the specified pool.

--start <boolean> (*default =* 0)
Start VM after it was restored successfully.

--storage <storage ID>
Default storage.

--unique <boolean>
Assign a unique random ethernet address and do not adopt the guest uid of the backup.

A.11 pct - Proxmox Container Toolkit

pct <COMMAND> [ARGS] [OPTIONS]

pct clone <vmid> <newid> [OPTIONS]

Create a container clone/copy

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<newid>: <integer> (100 - 999999999)
VMID for the clone.

--bwlimit <number> (0 - N) (*default =* clone limit from datacenter or storage config)
Override I/O bandwidth limit (in KiB/s).

--description <string>
Description for the new CT.

--full <boolean>
Create a full copy of all disks. This is always done when you clone a normal CT. For CT templates, we try to create a linked clone by default.

--hostname <string>
Set a hostname for the new CT.

--pool <string>
Add the new CT to the specified pool.

--snapname <string>
The name of the snapshot.

--storage <storage ID>
Target storage for full clone.

--target <string>
Target node. Only allowed if the original VM is on shared storage.

pct config <vmid> [OPTIONS]

Get container configuration.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--current <boolean> (*default =* 0)
Get current values (instead of pending values).

--snapshot <string>
Fetch config values from given snapshot.

pct console <vmid> [OPTIONS]

Launch a console for the specified container.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--escape \^?[a-z] (*default =* ^a)
Escape sequence prefix. For example to use <Ctrl+b q> as the escape sequence pass *^b*.

pct cpusets

Print the list of assigned CPU sets.

pct create <vmid> <ostemplate> [OPTIONS]

Create or restore a container.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<ostemplate>: <string>
The OS template or backup file.

--allow-identity-mismatch <boolean> (*default =* 0)
Allow overwriting an existing guest with a backup of another guest, as detected by a different *uid* in *meta*. The guest then keeps its own uid. Not needed to restore a backup again over a guest that an unfinished restore of that backup left behind. A restore from standard input over a container that has a uid always needs this option, as the backup cannot be checked beforehand.

Note
Requires option(s): `restore`

--arch <amd64 | arm64 | armhf | i386 | riscv32 | riscv64> (*default =* amd64)
OS architecture type.

--bwlimit <number> (0 - N) (*default =* restore limit from datacenter or storage config)
Override I/O bandwidth limit (in KiB/s).

--cmode <console | shell | tty> (*default =* tty)
Console mode. By default, the console command tries to open a connection to one of the available tty devices. By setting cmode to *console* it tries to attach to /dev/console instead. If you set cmode to *shell*, it simply invokes a shell inside the container (no login).

--console <boolean> (*default =* 1)
Attach a console device (/dev/console) to the container.

--cores <integer> (1 - 8192)
The number of cores assigned to the container. A container can use all available cores by default.

--cpulimit <number> (0 - 8192) (*default =* 0)
Limit of CPU usage.

Note
If the computer has 2 CPUs, it has a total of *2* CPU time. Value *0* indicates no CPU limit.

--cpuunits <integer> (0 - 500000) (*default =* cgroup v1: 1024, cgroup v2: 100)
CPU weight for a container, will be clamped to [1, 10000] in cgroup v2.

--debug <boolean> (*default =* 0)
Try to be more verbose. For now this only enables debug log-level on start.

--description <string>
Description for the Container. Shown in the web-interface CT's summary. This is saved as comment inside the configuration file.

--dev[n] [[path=]<Path>] [,deny-write=<1|0>] [,gid=<integer>] [,mode=<Octal access mode>] [,uid=<integer>]
Device to pass through to the container

--entrypoint (?^:[^\x00-\x08\x0a-\x1F\x7F]+\z) (*default =* /sbin/init)
Command to run as init, optionally with arguments; may start with an absolute path, relative path, or a binary in $PATH.

--env (?^:(?:\w+=[^\x00-\x08\x0a-\x1F\x7F]*)(?:\0\w+=[^\x00-\x08\x0a-\x1F\x7F]*)*

The container runtime environment as NUL-separated list. Replaces any lxc.environment.runtime entries in the config.

--features [force_rw_sys=<1|0>] [,fuse=<1|0>] [,keyctl=<1|0>] [,mknod=<1|0>] [,mount=<fstype;fstype;...>] [,nesting=<1|0>]
Allow containers access to advanced features.

--force <boolean>
Allow to overwrite existing container.

--ha-managed <boolean> (*default =* 0)
Add the CT as a HA resource after it was created.

--hookscript <string>
Script that will be executed during various steps in the containers lifetime.

--hostname <string>
Set a host name for the container.

--ignore-unpack-errors <boolean>
Ignore errors when extracting the template.

--lock <backup | create | destroyed | disk | fstrim | migrate | mounted | rollback | snapshot | snapshot-delete>
Lock/unlock the container.

--memory <integer> (16 - N) (*default =* 512)
Amount of RAM for the container in MB.

--mp[n] [volume=]<volume> ,mp=<Path> [,acl=<1|0>] [,backup=<1|0>]
[,idmap=<type:container:disk:range-size[;type:container:disk:range-size;...
[,keepattrs=<1|0>] [,mountoptions=<opt[;opt...]>] [,quota=<1|0>]
[,replicate=<1|0>] [,ro=<1|0>] [,shared=<1|0>] [,size=<DiskSize>]
Use volume as container mount point. Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume.

--nameserver <string>
Comma-separated list of IP addresses. Sets the addresses of the DNS servers of the container. Create will automatically use the setting from the host if you neither set searchdomain nor nameserver.

--net[n] name=<string> [,bridge=<bridge>] [,firewall=<1|0>]
[,gw=<GatewayIPv4>] [,gw6=<GatewayIPv6>] [,host-managed=<1|0>]
[,hwaddr=<XX:XX:XX:XX:XX:XX>] [,ip=<(IPv4/CIDR|dhcp|manual)>]
[,ip6=<(IPv6/CIDR|auto|dhcp|manual)>] [,link_down=<1|0>]
[,mtu=<integer>] [,rate=<mbps>] [,tag=<integer>]
[,trunks=<vlanid[;vlanid...]>] [,type=<veth>]
Specifies network interfaces for the container.

--onboot <boolean> (*default =* 0)
Specifies whether a container will be started during system bootup.

--ostype <alpine | archlinux | centos | debian | devuan | fedora |
gentoo | nixos | opensuse | ubuntu | unmanaged>
OS type. This is used to setup configuration inside the container, and corresponds to lxc setup scripts in /usr/share/lxc/config/<ostype>.common.conf. Value *unmanaged* can be used to skip and OS specific setup.

--password <password>
Sets root password inside container.

--pool <string>
Add the VM to the specified pool.

--protection <boolean> (*default =* 0)
Sets the protection flag of the container. This will prevent the CT or CT's disk remove/update operation.

--restore <boolean>
Mark this as restore task.

--rootfs [volume=]<volume> [,acl=<1|0>]
[,idmap=<type:container:disk:range-size[;type:container:disk:range-size;...
[,mountoptions=<opt[;opt...]>] [,quota=<1|0>] [,replicate=<1|0>]
[,ro=<1|0>] [,shared=<1|0>] [,size=<DiskSize>]
Use volume as container root.

--searchdomain <string>
Sets DNS search domains for a container. Create will automatically use the setting from the host if you neither set searchdomain nor nameserver.

--ssh-public-keys <filepath>
Setup public SSH keys (one key per line, OpenSSH format).

--start <boolean> (*default =* 0)
Start the CT after its creation finished successfully.

--startup `[[order=]\d+] [,up=\d+] [,down=\d+] `
Startup and shutdown behavior. Order is a non-negative number defining the general startup order. Shutdown in done with reverse ordering. Additionally you can set the *up* or *down* delay in seconds, which specifies a delay to wait before the next VM is started or stopped.

--storage <storage ID> (*default =* local)
Default Storage.

--swap <integer> (0 - N) (*default =* 512)
Amount of SWAP for the container in MB.

--tags <string>
Tags of the Container. This is only meta information.

--template <boolean> (*default =* 0)
Enable/disable Template.

--timezone <string>
Time zone to use in the container. If option isn't set, then nothing will be done. Can be set to *host* to match the host time zone, or an arbitrary time zone option from /usr/share/zoneinfo/zone.tab

--tty <integer> (0 - 6) (*default =* 2)
Specify the number of tty available to the container

--unique <boolean>
Assign a unique random ethernet address and do not adopt the guest uid of the backup.

Note
Requires option(s): `restore`

--unprivileged <boolean> (*default =* 0)
Makes the container run as unprivileged user. For creation, the default is 1. For restore, the default is the value from the backup. (Should not be modified manually.)

--unused[n] [volume=]<volume>
Reference to unused volumes. This is used internally, and should not be modified manually.

pct delsnapshot <vmid> <snapname> [OPTIONS]

Delete a LXC snapshot.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<snapname>: <string>
The name of the snapshot.

--force <boolean>
For removal from config file, even if removing disk snapshots fails.

pct destroy <vmid> [OPTIONS]

Destroy the container (also delete all uses files).

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--destroy-unreferenced-disks <boolean>
If set, destroy additionally all disks with the VMID from all enabled storages which are not referenced in the config.

--force <boolean> (*default =* 0)
Force destroy, even if running.

--purge <boolean> (*default =* 0)
Remove container from all related configurations. For example, backup jobs, replication jobs or HA. Related ACLs and Firewall entries will **always** be removed.

pct df <vmid>

Get the container's current disk usage.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

pct enter <vmid> [OPTIONS]

Launch a shell for the specified container.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--keep-env <boolean> (*default =* 1)
Keep the current environment. This option will disabled by default with PVE 9. If you rely on a preserved environment, please use this option to be future-proof.

pct exec <vmid> [<extra-args>] [OPTIONS]

Launch a command inside the specified container.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<extra-args>: <array>
Extra arguments as array

--keep-env <boolean> (*default =* 1)
Keep the current environment. This option will disabled by default with PVE 9. If you rely on a preserved environment, please use this option to be future-proof.

pct fsck <vmid> [OPTIONS]

Run a filesystem check (fsck) on a container volume.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--device **<mp0 | mp1 | mp10 | mp100 | mp101 | mp102 | mp103 | mp104 | mp105 | mp106 | mp107 | mp108 | mp109 | mp11 | mp110 | mp111 | mp112 | mp113 | mp114 | mp115 | mp116 | mp117 | mp118 | mp119 | mp12 | mp120 | mp121 | mp122 | mp123 | mp124 | mp125 | mp126 | mp127 | mp128 | mp129 | mp13 | mp130 | mp131 | mp132 | mp133 | mp134 | mp135 | mp136 | mp137 | mp138 | mp139 | mp14 | mp140 | mp141 | mp142 | mp143 | mp144 | mp145 | mp146 | mp147 | mp148 | mp149 | mp15 | mp150 | mp151 | mp152 | mp153 | mp154 | mp155 | mp156 | mp157 | mp158 | mp159 | mp16 | mp160 | mp161 | mp162 | mp163 | mp164 | mp165 | mp166 | mp167 | mp168 | mp169 | mp17 | mp170 | mp171 | mp172 | mp173 | mp174 | mp175 | mp176 | mp177 | mp178 | mp179 | mp18 | mp180 | mp181 | mp182 | mp183 | mp184 | mp185 | mp186 | mp187 | mp188 | mp189 | mp19 | mp190 | mp191 | mp192 | mp193 | mp194 | mp195 | mp196 | mp197 | mp198 | mp199 | mp2 | mp20 | mp200 | mp201 | mp202 | mp203 | mp204 | mp205 | mp206 | mp207 | mp208 | mp209 | mp21 | mp210 | mp211 | mp212 | mp213 | mp214 | mp215 | mp216 | mp217 | mp218 | mp219 | mp22 | mp220 | mp221 | mp222 | mp223 | mp224 | mp225 | mp226 | mp227 | mp228 | mp229 | mp23 | mp230 | mp231 | mp232 | mp233 | mp234 | mp235 | mp236 | mp237 | mp238 | mp239 | mp24 | mp240 | mp241 | mp242 | mp243 | mp244 | mp245 | mp246 | mp247 | mp248 | mp249 | mp25 | mp250 | mp251 | mp252 | mp253 | mp254 | mp255 | mp26 | mp27 | mp28 | mp29 | mp3 | mp30 | mp31 | mp32 | mp33 | mp34 | mp35 | mp36 | mp37 | mp38 | mp39 | mp4 | mp40 | mp41 | mp42 | mp43 | mp44 | mp45 | mp46 | mp47 | mp48 | mp49 | mp5 | mp50 | mp51 | mp52 | mp53 | mp54 | mp55 | mp56 | mp57 | mp58 | mp59 | mp6 | mp60 | mp61 | mp62 | mp63 | mp64 | mp65 | mp66 | mp67 | mp68 | mp69 | mp7 | mp70 | mp71 | mp72 | mp73 | mp74 | mp75 | mp76 | mp77 | mp78 | mp79 | mp8 | mp80 | mp81 | mp82 | mp83 | mp84 | mp85 | mp86 | mp87 | mp88 | mp89 | mp9 | mp90 | mp91 | mp92 | mp93 | mp94 | mp95 | mp96 | mp97 | mp98 | mp99 | rootfs>**

A volume on which to run the filesystem check

--force **<boolean>** **(*default =* 0)**

Force checking, even if the filesystem seems clean

pct fstrim `<vmid> [OPTIONS]`

Run fstrim on a chosen CT and its mountpoints, except bind or read-only mountpoints.

<vmid>: <integer> (100 - 999999999)

The (unique) ID of the VM.

--ignore-mountpoints **<boolean>**

Skip all mountpoints, only do fstrim on the container root.

pct help `[OPTIONS]`

Get help about specified command.

--extra-args <array>
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
Verbose output format.

pct list

LXC container index (per node).

pct listsnapshot <vmid>

List all snapshots.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

pct migrate <vmid> <target> [OPTIONS]

Migrate the container to another node. Creates a new migration task.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<target>: <string>
Target node.

--bwlimit <number> (0 - N) (*default =* migrate limit from datacenter or storage config)
Override I/O bandwidth limit (in KiB/s).

--online <boolean>
Use online/live migration.

--restart <boolean>
Use restart migration

--skip-config-check <boolean> (*default =* 0)
For intra-cluster migration. Skip checking if the configuration can be parsed successfully by the target. Using this flag can lead to dropped or ignored configuration options if the target is too old to parse them.

--target-storage <string>
Mapping from source to target storages. Providing only a single storage ID maps all source storages to that storage. Providing the special value *1* will map each source storage to itself.

--timeout <integer> (*default =* 180)
Timeout in seconds for shutdown for restart migration

pct mount <vmid>

Mount the container's filesystem on the host. This will hold a lock on the container and is meant for emergency maintenance only as it will prevent further operations on the container other than start and stop.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

pct move-volume <vmid> <volume> [<storage>] [<target-vmid>] [<target-volume>] [OPTIONS]

Move a rootfs-/mp-volume to a different storage or to a different container.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

```
<volume>: <mp0 | mp1 | mp10 | mp100 | mp101 | mp102 | mp103 | mp104
| mp105 | mp106 | mp107 | mp108 | mp109 | mp11 | mp110 | mp111 |
mp112 | mp113 | mp114 | mp115 | mp116 | mp117 | mp118 | mp119 |
mp12 | mp120 | mp121 | mp122 | mp123 | mp124 | mp125 | mp126 |
mp127 | mp128 | mp129 | mp13 | mp130 | mp131 | mp132 | mp133 |
mp134 | mp135 | mp136 | mp137 | mp138 | mp139 | mp14 | mp140 |
mp141 | mp142 | mp143 | mp144 | mp145 | mp146 | mp147 | mp148 |
mp149 | mp15 | mp150 | mp151 | mp152 | mp153 | mp154 | mp155 |
mp156 | mp157 | mp158 | mp159 | mp16 | mp160 | mp161 | mp162 |
mp163 | mp164 | mp165 | mp166 | mp167 | mp168 | mp169 | mp17 |
mp170 | mp171 | mp172 | mp173 | mp174 | mp175 | mp176 | mp177 |
mp178 | mp179 | mp18 | mp180 | mp181 | mp182 | mp183 | mp184 |
mp185 | mp186 | mp187 | mp188 | mp189 | mp19 | mp190 | mp191 |
mp192 | mp193 | mp194 | mp195 | mp196 | mp197 | mp198 | mp199 | mp2
| mp20 | mp200 | mp201 | mp202 | mp203 | mp204 | mp205 | mp206 |
mp207 | mp208 | mp209 | mp21 | mp210 | mp211 | mp212 | mp213 |
mp214 | mp215 | mp216 | mp217 | mp218 | mp219 | mp22 | mp220 |
mp221 | mp222 | mp223 | mp224 | mp225 | mp226 | mp227 | mp228 |
mp229 | mp23 | mp230 | mp231 | mp232 | mp233 | mp234 | mp235 |
mp236 | mp237 | mp238 | mp239 | mp24 | mp240 | mp241 | mp242 |
mp243 | mp244 | mp245 | mp246 | mp247 | mp248 | mp249 | mp25 |
mp250 | mp251 | mp252 | mp253 | mp254 | mp255 | mp26 | mp27 | mp28
| mp29 | mp3 | mp30 | mp31 | mp32 | mp33 | mp34 | mp35 | mp36 |
mp37 | mp38 | mp39 | mp4 | mp40 | mp41 | mp42 | mp43 | mp44 | mp45
| mp46 | mp47 | mp48 | mp49 | mp5 | mp50 | mp51 | mp52 | mp53 |
mp54 | mp55 | mp56 | mp57 | mp58 | mp59 | mp6 | mp60 | mp61 | mp62
| mp63 | mp64 | mp65 | mp66 | mp67 | mp68 | mp69 | mp7 | mp70 |
mp71 | mp72 | mp73 | mp74 | mp75 | mp76 | mp77 | mp78 | mp79 | mp8
| mp80 | mp81 | mp82 | mp83 | mp84 | mp85 | mp86 | mp87 | mp88 |
mp89 | mp9 | mp90 | mp91 | mp92 | mp93 | mp94 | mp95 | mp96 | mp97
| mp98 | mp99 | rootfs | unused0 | unused1 | unused10 | unused100 |
unused101 | unused102 | unused103 | unused104 | unused105 |
unused106 | unused107 | unused108 | unused109 | unused11 |
unused110 | unused111 | unused112 | unused113 | unused114 |
unused115 | unused116 | unused117 | unused118 | unused119 |
unused12 | unused120 | unused121 | unused122 | unused123 |
unused124 | unused125 | unused126 | unused127 | unused128 |
unused129 | unused13 | unused130 | unused131 | unused132 |
unused133 | unused134 | unused135 | unused136 | unused137 |
unused138 | unused139 | unused14 | unused140 | unused141 |
unused142 | unused143 | unused144 | unused145 | unused146 |
unused147 | unused148 | unused149 | unused15 | unused150 |
unused151 | unused152 | unused153 | unused154 | unused155 |
unused156 | unused157 | unused158 | unused159 | unused16 |
unused160 | unused161 | unused162 | unused163 | unused164 |
unused165 | unused166 | unused167 | unused168 | unused169 |
unused17 | unused170 | unused171 | unused172 | unused173 |
unused174 | unused175 | unused176 | unused177 | unused178 |
unused179 | unused18 | unused180 | unused181 | unused182 |
unused183 | unused184 | unused185 | unused186 | unused187 |
unused188 | unused189 | unused19 | unused190 | unused191 |
unused192 | unused193 | unused194 | unused195 | unused196 |
unused197 | unused198 | unused199 | unused2 | unused20 | unused200
```

Volume which will be moved.

<storage>: <storage ID>
Target Storage.

<target-vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

```
<target-volume>: <mp0 | mp1 | mp10 | mp100 | mp101 | mp102 | mp103 |
mp104 | mp105 | mp106 | mp107 | mp108 | mp109 | mp11 | mp110 |
mp111 | mp112 | mp113 | mp114 | mp115 | mp116 | mp117 | mp118 |
mp119 | mp12 | mp120 | mp121 | mp122 | mp123 | mp124 | mp125 |
mp126 | mp127 | mp128 | mp129 | mp13 | mp130 | mp131 | mp132 |
mp133 | mp134 | mp135 | mp136 | mp137 | mp138 | mp139 | mp14 |
mp140 | mp141 | mp142 | mp143 | mp144 | mp145 | mp146 | mp147 |
mp148 | mp149 | mp15 | mp150 | mp151 | mp152 | mp153 | mp154 |
mp155 | mp156 | mp157 | mp158 | mp159 | mp16 | mp160 | mp161 |
mp162 | mp163 | mp164 | mp165 | mp166 | mp167 | mp168 | mp169 |
mp17 | mp170 | mp171 | mp172 | mp173 | mp174 | mp175 | mp176 |
mp177 | mp178 | mp179 | mp18 | mp180 | mp181 | mp182 | mp183 |
mp184 | mp185 | mp186 | mp187 | mp188 | mp189 | mp19 | mp190 |
mp191 | mp192 | mp193 | mp194 | mp195 | mp196 | mp197 | mp198 |
mp199 | mp2 | mp20 | mp200 | mp201 | mp202 | mp203 | mp204 | mp205
| mp206 | mp207 | mp208 | mp209 | mp21 | mp210 | mp211 | mp212 |
mp213 | mp214 | mp215 | mp216 | mp217 | mp218 | mp219 | mp22 |
mp220 | mp221 | mp222 | mp223 | mp224 | mp225 | mp226 | mp227 |
mp228 | mp229 | mp23 | mp230 | mp231 | mp232 | mp233 | mp234 |
mp235 | mp236 | mp237 | mp238 | mp239 | mp24 | mp240 | mp241 |
mp242 | mp243 | mp244 | mp245 | mp246 | mp247 | mp248 | mp249 |
mp25 | mp250 | mp251 | mp252 | mp253 | mp254 | mp255 | mp26 | mp27
| mp28 | mp29 | mp3 | mp30 | mp31 | mp32 | mp33 | mp34 | mp35 |
mp36 | mp37 | mp38 | mp39 | mp4 | mp40 | mp41 | mp42 | mp43 | mp44
| mp45 | mp46 | mp47 | mp48 | mp49 | mp5 | mp50 | mp51 | mp52 |
mp53 | mp54 | mp55 | mp56 | mp57 | mp58 | mp59 | mp6 | mp60 | mp61
| mp62 | mp63 | mp64 | mp65 | mp66 | mp67 | mp68 | mp69 | mp7 |
mp70 | mp71 | mp72 | mp73 | mp74 | mp75 | mp76 | mp77 | mp78 | mp79
| mp8 | mp80 | mp81 | mp82 | mp83 | mp84 | mp85 | mp86 | mp87 |
mp88 | mp89 | mp9 | mp90 | mp91 | mp92 | mp93 | mp94 | mp95 | mp96
| mp97 | mp98 | mp99 | rootfs | unused0 | unused1 | unused10 |
unused100 | unused101 | unused102 | unused103 | unused104 |
unused105 | unused106 | unused107 | unused108 | unused109 |
unused11 | unused110 | unused111 | unused112 | unused113 |
unused114 | unused115 | unused116 | unused117 | unused118 |
unused119 | unused12 | unused120 | unused121 | unused122 |
unused123 | unused124 | unused125 | unused126 | unused127 |
unused128 | unused129 | unused13 | unused130 | unused131 |
unused132 | unused133 | unused134 | unused135 | unused136 |
unused137 | unused138 | unused139 | unused14 | unused140 |
unused141 | unused142 | unused143 | unused144 | unused145 |
unused146 | unused147 | unused148 | unused149 | unused15 |
unused150 | unused151 | unused152 | unused153 | unused154 |
unused155 | unused156 | unused157 | unused158 | unused159 |
unused16 | unused160 | unused161 | unused162 | unused163 |
unused164 | unused165 | unused166 | unused167 | unused168 |
unused169 | unused17 | unused170 | unused171 | unused172 |
unused173 | unused174 | unused175 | unused176 | unused177 |
unused178 | unused179 | unused18 | unused180 | unused181 |
unused182 | unused183 | unused184 | unused185 | unused186 |
unused187 | unused188 | unused189 | unused19 | unused190 |
unused191 | unused192 | unused193 | unused194 | unused195 |
unused196 | unused197 | unused198 | unused199 | unused2 | unused20
```

The config key the volume will be moved to. Default is the source volume key.

--bwlimit <number> (0 - N) (*default =* clone limit from datacenter or storage config)
Override I/O bandwidth limit (in KiB/s).

--delete <boolean> (*default =* 0)
Delete the original volume after successful copy. By default the original is kept as an unused volume entry.

--digest <string>
Prevent changes if current configuration file has different SHA1 " . "digest. This can be used to prevent concurrent modifications.

--target-digest <string>
Prevent changes if current configuration file of the target " . "container has a different SHA1 digest. This can be used to prevent " . "concurrent modifications.

pct move_volume

An alias for *pct move-volume*.

pct mtunnel

For internal use by intra-cluster migration only.

pct pending <vmid>

Get container configuration, including pending changes.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

pct pull <vmid> <path> <destination> [OPTIONS]

Copy a file from the container to the local system.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<path>: <string>
Path to a file inside the container to pull.

<destination>: <string>
Destination

--group <string>
Owner group name or id.

--perms <string>
File permissions to use (octal by default, prefix with *0x* for hexadecimal).

--user <string>
Owner user name or id.

pct push <vmid> <file> <destination> [OPTIONS]

Copy a local file to the container.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<file>: <string>
Path to a local file.

<destination>: <string>
Destination inside the container to write to.

--group <string>
Owner group name or id. When using a name it must exist inside the container.

--perms <string>
File permissions to use (octal by default, prefix with *0x* for hexadecimal).

--user <string>
Owner user name or id. When using a name it must exist inside the container.

pct reboot <vmid> [OPTIONS]

Reboot the container by shutting it down, and starting it again. Applies pending changes.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--timeout <integer> (0 - N)
Wait maximal timeout seconds for the shutdown.

pct remote-migrate <vmid> [<target-vmid>] <target-endpoint> --target-bridge <str
--target-storage <string> [OPTIONS]

Migrate container to a remote cluster. Creates a new migration task. EXPERIMENTAL feature!

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<target-vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<target-endpoint>: apitoken=<PVEAPIToken=user@realm!token=SECRET> ,host=<ADDRESS> [,fingerprint=<FINGERPRINT>] [,port=<PORT>]
Remote target endpoint

--allow-new-uid <boolean> (*default =* 0)
Allow the migration if another guest in the target cluster already has the uid of this guest. The migrated guest then gets a new uid.

--bwlimit <integer> (0 - N) (*default =* migrate limit from datacenter or storage config)
Override I/O bandwidth limit (in KiB/s).

--delete <boolean> (*default =* 0)
Delete the original CT and related data after successful migration. By default the original CT is kept on the source cluster in a stopped state.

--online <boolean>
Use online/live migration.

--restart <boolean>
Use restart migration

--target-bridge <string>
Mapping from source to target bridges. Providing only a single bridge ID maps all source bridges to that bridge. Providing the special value *1* will map each source bridge to itself.

--target-storage <string>
Mapping from source to target storages. Providing only a single storage ID maps all source storages to that storage. Providing the special value *1* will map each source storage to itself.

--timeout <integer> (*default =* 180)
Timeout in seconds for shutdown for restart migration

pct rescan [OPTIONS]

Rescan all storages and update disk sizes and unused disk images.

--dryrun <boolean> (*default =* 0)
Do not actually write changes to the configuration.

--vmid <integer> (100 - 999999999)
The (unique) ID of the VM.

pct resize <vmid> <disk> <size> [OPTIONS]

Resize a container mount point.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<disk>: <mp0 | mp1 | mp10 | mp100 | mp101 | mp102 | mp103 | mp104 | mp105 | mp106 | mp107 | mp108 | mp109 | mp11 | mp110 | mp111 | mp112 | mp113 | mp114 | mp115 | mp116 | mp117 | mp118 | mp119 | mp12 | mp120 | mp121 | mp122 | mp123 | mp124 | mp125 | mp126 | mp127 | mp128 | mp129 | mp13 | mp130 | mp131 | mp132 | mp133 | mp134 | mp135 | mp136 | mp137 | mp138 | mp139 | mp14 | mp140 | mp141 | mp142 | mp143 | mp144 | mp145 | mp146 | mp147 | mp148 | mp149 | mp15 | mp150 | mp151 | mp152 | mp153 | mp154 | mp155 | mp156 | mp157 | mp158 | mp159 | mp16 | mp160 | mp161 | mp162 | mp163 | mp164 | mp165 | mp166 | mp167 | mp168 | mp169 | mp17 | mp170 | mp171 | mp172 | mp173 | mp174 | mp175 | mp176 | mp177 | mp178 | mp179 | mp18 | mp180 | mp181 | mp182 | mp183 | mp184 | mp185 | mp186 | mp187 | mp188 | mp189 | mp19 | mp190 | mp191 | mp192 | mp193 | mp194 | mp195 | mp196 | mp197 | mp198 | mp199 | mp2 | mp20 | mp200 | mp201 | mp202 | mp203 | mp204 | mp205 | mp206 | mp207 | mp208 | mp209 | mp21 | mp210 | mp211 | mp212 | mp213 | mp214 | mp215 | mp216 | mp217 | mp218 | mp219 | mp22 | mp220 | mp221 | mp222 | mp223 | mp224 | mp225 | mp226 | mp227 | mp228 | mp229 | mp23 | mp230 | mp231 | mp232 | mp233 | mp234 | mp235 | mp236 | mp237 | mp238 | mp239 | mp24 | mp240 | mp241 | mp242 | mp243 | mp244 | mp245 | mp246 | mp247 | mp248 | mp249 | mp25 | mp250 | mp251 | mp252 | mp253 | mp254 | mp255 | mp26 | mp27 | mp28 | mp29 | mp3 | mp30 | mp31 | mp32 | mp33 | mp34 | mp35 | mp36 | mp37 | mp38 | mp39 | mp4 | mp40 | mp41 | mp42 | mp43 | mp44 | mp45 | mp46 | mp47 | mp48 | mp49 | mp5 | mp50 | mp51 | mp52 | mp53 | mp54 | mp55 | mp56 | mp57 | mp58 | mp59 | mp6 | mp60 | mp61 | mp62 | mp63 | mp64 | mp65 | mp66 | mp67 | mp68 | mp69 | mp7 | mp70 | mp71 | mp72 | mp73 | mp74 | mp75 | mp76 | mp77 | mp78 | mp79 | mp8 | mp80 | mp81 | mp82 | mp83 | mp84 | mp85 | mp86 | mp87 | mp88 | mp89 | mp9 | mp90 | mp91 | mp92 | mp93 | mp94 | mp95 | mp96 | mp97 | mp98 | mp99 | rootfs>
The disk you want to resize.

<size>: \+?\d+(\.\d+)?[KMGT]?
The new size. With the *+* sign the value is added to the actual size of the volume and without it, the value is taken as an absolute one. Shrinking disk size is not supported.

--digest <string>
Prevent changes if current configuration file has different SHA1 digest. This can be used to prevent concurrent modifications.

pct restore <vmid> <ostemplate> [OPTIONS]

Create or restore a container.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<ostemplate>: <string>
The OS template or backup file.

--allow-identity-mismatch <boolean> (*default =* 0)
Allow overwriting an existing guest with a backup of another guest, as detected by a different *uid* in *meta*. The guest then keeps its own uid. Not needed to restore a backup again over a guest that an unfinished restore of that backup left behind. A restore from standard input over a container that has a uid always needs this option, as the backup cannot be checked beforehand.

> **Note**
> Requires option(s): `restore`

--arch <amd64 | arm64 | armhf | i386 | riscv32 | riscv64> (*default =* amd64)
OS architecture type.

--bwlimit <number> (0 - N) (*default =* restore limit from datacenter or storage config)
Override I/O bandwidth limit (in KiB/s).

--cmode <console | shell | tty> (*default =* tty)
Console mode. By default, the console command tries to open a connection to one of the available tty devices. By setting cmode to *console* it tries to attach to /dev/console instead. If you set cmode to *shell*, it simply invokes a shell inside the container (no login).

--console <boolean> (*default =* 1)
Attach a console device (/dev/console) to the container.

--cores <integer> (1 - 8192)
The number of cores assigned to the container. A container can use all available cores by default.

--cpulimit <number> (0 - 8192) (*default =* 0)
Limit of CPU usage.

> **Note**
> If the computer has 2 CPUs, it has a total of *2* CPU time. Value *0* indicates no CPU limit.

--cpuunits <integer> (0 - 500000) (*default =* cgroup v1: 1024, cgroup v2: 100)
CPU weight for a container, will be clamped to [1, 10000] in cgroup v2.

--debug <boolean> (*default =* 0)
Try to be more verbose. For now this only enables debug log-level on start.

--description <string>
Description for the Container. Shown in the web-interface CT's summary. This is saved as comment inside the configuration file.

--dev[n] [[path=]<Path>] [,deny-write=<1|0>] [,gid=<integer>] [,mode=<Octal access mode>] [,uid=<integer>]
Device to pass through to the container

--entrypoint (?^:[^\x00-\x08\x0a-\x1F\x7F]+\z) (*default =* /sbin/init)
Command to run as init, optionally with arguments; may start with an absolute path, relative path, or a binary in $PATH.

--env
(?^:(?:\w+=[^\x00-\x08\x0a-\x1F\x7F]*)(?:\0\w+=[^\x00-\x08\x0a-\x1F\x7F]*)*

The container runtime environment as NUL-separated list. Replaces any lxc.environment.runtime entries in the config.

--features [force_rw_sys=<1|0>] [,fuse=<1|0>] [,keyctl=<1|0>] [,mknod=<1|0>] [,mount=<fstype;fstype;...>] [,nesting=<1|0>]
Allow containers access to advanced features.

--force <boolean>
Allow to overwrite existing container.

--ha-managed <boolean> (*default =* 0)
Add the CT as a HA resource after it was created.

--hookscript <string>
Script that will be executed during various steps in the containers lifetime.

--hostname <string>
Set a host name for the container.

--ignore-unpack-errors <boolean>
Ignore errors when extracting the template.

--lock <backup | create | destroyed | disk | fstrim | migrate | mounted | rollback | snapshot | snapshot-delete>
Lock/unlock the container.

--memory <integer> (16 - N) (*default =* 512)
Amount of RAM for the container in MB.

--mp[n] [volume=]<volume> ,mp=<Path> [,acl=<1|0>] [,backup=<1|0>]
[,idmap=<type:container:disk:range-size[;type:container:disk:range-size;...
[,keepattrs=<1|0>] [,mountoptions=<opt[;opt...]>] [,quota=<1|0>]
[,replicate=<1|0>] [,ro=<1|0>] [,shared=<1|0>] [,size=<DiskSize>]
Use volume as container mount point. Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume.

--nameserver <string>
Comma-separated list of IP addresses. Sets the addresses of the DNS servers of the container. Create will automatically use the setting from the host if you neither set searchdomain nor nameserver.

--net[n] name=<string> [,bridge=<bridge>] [,firewall=<1|0>]
[,gw=<GatewayIPv4>] [,gw6=<GatewayIPv6>] [,host-managed=<1|0>]
[,hwaddr=<XX:XX:XX:XX:XX:XX>] [,ip=<(IPv4/CIDR|dhcp|manual)>]
[,ip6=<(IPv6/CIDR|auto|dhcp|manual)>] [,link_down=<1|0>]
[,mtu=<integer>] [,rate=<mbps>] [,tag=<integer>]
[,trunks=<vlanid[;vlanid...]>] [,type=<veth>]
Specifies network interfaces for the container.

--onboot <boolean> (*default =* 0)
Specifies whether a container will be started during system bootup.

--ostype <alpine | archlinux | centos | debian | devuan | fedora |
gentoo | nixos | opensuse | ubuntu | unmanaged>
OS type. This is used to setup configuration inside the container, and corresponds to lxc setup scripts in /usr/share/lxc/config/<ostype>.common.conf. Value *unmanaged* can be used to skip and OS specific setup.

--password <password>
Sets root password inside container.

--pool <string>
Add the VM to the specified pool.

--protection <boolean> (*default =* 0)
Sets the protection flag of the container. This will prevent the CT or CT's disk remove/update operation.

--rootfs [volume=]<volume> [,acl=<1|0>]
[,idmap=<type:container:disk:range-size[;type:container:disk:range-size;...
[,mountoptions=<opt[;opt...]>] [,quota=<1|0>] [,replicate=<1|0>]
[,ro=<1|0>] [,shared=<1|0>] [,size=<DiskSize>]
Use volume as container root.

--searchdomain <string>
Sets DNS search domains for a container. Create will automatically use the setting from the host if you neither set searchdomain nor nameserver.

--ssh-public-keys <filepath>
Setup public SSH keys (one key per line, OpenSSH format).

--start <boolean> (*default =* 0)
Start the CT after its creation finished successfully.

--startup `[[order=]\d+] [,up=\d+] [,down=\d+] `
Startup and shutdown behavior. Order is a non-negative number defining the general startup order. Shutdown in done with reverse ordering. Additionally you can set the *up* or *down* delay in seconds, which specifies a delay to wait before the next VM is started or stopped.

--storage <storage ID> (*default =* local)
Default Storage.

--swap <integer> (0 - N) (*default =* 512)
Amount of SWAP for the container in MB.

--tags <string>
Tags of the Container. This is only meta information.

--template <boolean> (*default =* 0)
Enable/disable Template.

--timezone <string>
Time zone to use in the container. If option isn't set, then nothing will be done. Can be set to *host* to match the host time zone, or an arbitrary time zone option from /usr/share/zoneinfo/zone.tab

--tty <integer> (0 - 6) (*default =* 2)
Specify the number of tty available to the container

--unique <boolean>
Assign a unique random ethernet address and do not adopt the guest uid of the backup.

Note
Requires option(s): `restore`

--unprivileged <boolean> (*default =* 0)
Makes the container run as unprivileged user. For creation, the default is 1. For restore, the default is the value from the backup. (Should not be modified manually.)

--unused[n] [volume=]<volume>
Reference to unused volumes. This is used internally, and should not be modified manually.

pct resume `<vmid>`

Resume the container.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

pct rollback <vmid> <snapname> [OPTIONS]

Rollback LXC state to specified snapshot.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<snapname>: <string>
The name of the snapshot.

--start <boolean> (*default =* 0)
Whether the container should get started after rolling back successfully

pct set <vmid> [OPTIONS]

Set container options.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--arch <amd64 | arm64 | armhf | i386 | riscv32 | riscv64> (*default =* amd64)
OS architecture type.

--cmode <console | shell | tty> (*default =* tty)
Console mode. By default, the console command tries to open a connection to one of the available tty devices. By setting cmode to *console* it tries to attach to /dev/console instead. If you set cmode to *shell*, it simply invokes a shell inside the container (no login).

--console <boolean> (*default =* 1)
Attach a console device (/dev/console) to the container.

--cores <integer> (1 - 8192)
The number of cores assigned to the container. A container can use all available cores by default.

--cpulimit <number> (0 - 8192) (*default =* 0)
Limit of CPU usage.

> **Note**
> If the computer has 2 CPUs, it has a total of *2* CPU time. Value *0* indicates no CPU limit.

--cpuunits <integer> (0 - 500000) (*default* = cgroup v1: 1024, cgroup v2: 100)
CPU weight for a container, will be clamped to [1, 10000] in cgroup v2.

--debug <boolean> (*default* = 0)
Try to be more verbose. For now this only enables debug log-level on start.

--delete <string>
A list of settings you want to delete.

--description <string>
Description for the Container. Shown in the web-interface CT's summary. This is saved as comment inside the configuration file.

--dev[n] [[path=]<Path>] [,deny-write=<1|0>] [,gid=<integer>] [,mode=<Octal access mode>] [,uid=<integer>]
Device to pass through to the container

--digest <string>
Prevent changes if current configuration file has different SHA1 digest. This can be used to prevent concurrent modifications.

--entrypoint (?^:[^\x00-\x08\x0a-\x1F\x7F]+\z) (*default* = /sbin/init)
Command to run as init, optionally with arguments; may start with an absolute path, relative path, or a binary in $PATH.

--env
(?^:(?:\w+=[^\x00-\x08\x0a-\x1F\x7F]*)(?:\0\w+=[^\x00-\x08\x0a-\x1F\x7F]*)*

The container runtime environment as NUL-separated list. Replaces any lxc.environment.runtime entries in the config.

--features [force_rw_sys=<1|0>] [,fuse=<1|0>] [,keyctl=<1|0>] [,mknod=<1|0>] [,mount=<fstype;fstype;...>] [,nesting=<1|0>]
Allow containers access to advanced features.

--hookscript <string>
Script that will be executed during various steps in the containers lifetime.

--hostname <string>
Set a host name for the container.

--lock <backup | create | destroyed | disk | fstrim | migrate | mounted | rollback | snapshot | snapshot-delete>
Lock/unlock the container.

--memory <integer> (16 - N) (*default =* 512)
Amount of RAM for the container in MB.

--mp[n] [volume=]<volume> ,mp=<Path> [,acl=<1|0>] [,backup=<1|0>]
[,idmap=<type:container:disk:range-size[;type:container:disk:range-size;...
[,keepattrs=<1|0>] [,mountoptions=<opt[;opt...]>] [,quota=<1|0>]
[,replicate=<1|0>] [,ro=<1|0>] [,shared=<1|0>] [,size=<DiskSize>]
Use volume as container mount point. Use the special syntax STORAGE_ID:SIZE_IN_GiB to allocate a new volume.

--nameserver <string>
Comma-separated list of IP addresses. Sets the addresses of the DNS servers of the container. Create will automatically use the setting from the host if you neither set searchdomain nor nameserver.

--net[n] name=<string> [,bridge=<bridge>] [,firewall=<1|0>]
[,gw=<GatewayIPv4>] [,gw6=<GatewayIPv6>] [,host-managed=<1|0>]
[,hwaddr=<XX:XX:XX:XX:XX:XX>] [,ip=<(IPv4/CIDR|dhcp|manual)>]
[,ip6=<(IPv6/CIDR|auto|dhcp|manual)>] [,link_down=<1|0>]
[,mtu=<integer>] [,rate=<mbps>] [,tag=<integer>]
[,trunks=<vlanid[;vlanid...]>] [,type=<veth>]
Specifies network interfaces for the container.

--onboot <boolean> (*default =* 0)
Specifies whether a container will be started during system bootup.

--ostype <alpine | archlinux | centos | debian | devuan | fedora |
gentoo | nixos | opensuse | ubuntu | unmanaged>
OS type. This is used to setup configuration inside the container, and corresponds to lxc setup scripts in /usr/share/lxc/config/<ostype>.common.conf. Value *unmanaged* can be used to skip and OS specific setup.

--protection <boolean> (*default =* 0)
Sets the protection flag of the container. This will prevent the CT or CT's disk remove/update operation.

--revert <string>
Revert a pending change.

--rootfs [volume=]<volume> [,acl=<1|0>]
[,idmap=<type:container:disk:range-size[;type:container:disk:range-size;...
[,mountoptions=<opt[;opt...]>] [,quota=<1|0>] [,replicate=<1|0>]
[,ro=<1|0>] [,shared=<1|0>] [,size=<DiskSize>]
Use volume as container root.

--searchdomain <string>
Sets DNS search domains for a container. Create will automatically use the setting from the host if you neither set searchdomain nor nameserver.

--startup `[[order=]\d+] [,up=\d+] [,down=\d+] `
Startup and shutdown behavior. Order is a non-negative number defining the general startup order. Shutdown in done with reverse ordering. Additionally you can set the *up* or *down* delay in seconds, which specifies a delay to wait before the next VM is started or stopped.

--swap <integer> (0 - N) (*default* = 512)
Amount of SWAP for the container in MB.

--tags <string>
Tags of the Container. This is only meta information.

--template <boolean> (*default* = 0)
Enable/disable Template.

--timezone <string>
Time zone to use in the container. If option isn't set, then nothing will be done. Can be set to *host* to match the host time zone, or an arbitrary time zone option from /usr/share/zoneinfo/zone.tab

--tty <integer> (0 - 6) (*default* = 2)
Specify the number of tty available to the container

--unprivileged <boolean> (*default* = 0)
Makes the container run as unprivileged user. For creation, the default is 1. For restore, the default is the value from the backup. (Should not be modified manually.)

--unused[n] [volume=]<volume>
Reference to unused volumes. This is used internally, and should not be modified manually.

pct shutdown <vmid> [OPTIONS]

Shutdown the container. This will trigger a clean shutdown of the container, see lxc-stop(1) for details.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--forceStop <boolean> (*default* = 0)
Make sure the Container stops.

--timeout <integer> (0 - N) (*default* = 60)
Wait maximal timeout seconds.

pct snapshot <vmid> <snapname> [OPTIONS]

Snapshot a container.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<snapname>: <string>
The name of the snapshot.

--description <string>
A textual description or comment.

pct start <vmid> [OPTIONS]

Start the container.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--debug <boolean> (*default =* 0)
If set, enables very verbose debug log-level on start.

--skiplock <boolean>
Ignore locks - only root is allowed to use this option.

pct status <vmid> [OPTIONS]

Show CT status.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--verbose <boolean>
Verbose output format

pct stop <vmid> [OPTIONS]

Stop the container. This will abruptly stop all processes running in the container.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

--overrule-shutdown <boolean> (*default =* 0)
Try to abort active *vzshutdown* tasks before stopping.

--skiplock <boolean>
Ignore locks - only root is allowed to use this option.

pct suspend <vmid>

Suspend the container. This is experimental.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

pct template <vmid>

Create a Template.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

pct unlock <vmid>

Unlock the VM.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

pct unmount <vmid>

Unmount the container's filesystem.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

A.12 pveam - Proxmox VE Appliance Manager

pveam <COMMAND> [ARGS] [OPTIONS]

pveam available [OPTIONS]

List available templates.

--section <mail | system | turnkeylinux>
Restrict list to specified section.

pveam download <storage> <template>

Download appliance templates.

<storage>: <storage ID>
The storage where the template will be stored

<template>: <string>
The template which will downloaded

pveam help [OPTIONS]

Get help about specified command.

--extra-args <array>
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
Verbose output format.

pveam list <storage>

Get list of all templates on storage

<storage>: <storage ID>
Only list templates on specified storage

pveam remove <template_path>

Remove a template.

<template_path>: <string>
The template to remove.

pveam update

Update Container Template Database.

A.13 pvecm - Proxmox VE Cluster Manager

pvecm <COMMAND> [ARGS] [OPTIONS]

pvecm add <hostname> [OPTIONS]

Adds the current node to an existing cluster.

<hostname>: <string>
Hostname (or IP) of an existing cluster member.

--fingerprint ([A-Fa-f0-9]{2}:){31}[A-Fa-f0-9]{2}
Certificate SHA 256 fingerprint.

--force <boolean>
Do not throw error if node already exists.

--link[n] [address=]<IP> [,priority=<integer>]
Address and priority information of a single corosync link. (up to 8 links supported; link0..link7)

--nodeid <integer> (1 - N)
Node id for this node.

--use_ssh <boolean>
Always use SSH to join, even if peer may do it over API.

--votes <integer> (0 - N)
Number of votes for this node

pvecm addnode <node> [OPTIONS]

Adds a node to the cluster configuration. This call is for internal use.

<node>: <string>
The cluster node name.

--apiversion <integer>
The JOIN_API_VERSION of the new node.

--force <boolean>
Do not throw error if node already exists.

--link[n] [address=]<IP> [,priority=<integer>]
Address and priority information of a single corosync link. (up to 8 links supported; link0..link7)

--new_node_ip <string>
IP Address of node to add. Used as fallback if no links are given.

--nodeid <integer> (1 - N)
Node id for this node.

--votes <integer> (0 - N)
Number of votes for this node

pvecm apiver

Return the version of the cluster join API available on this node.

pvecm ca rotate

Replace the cluster CA with a new key and certificate, for example after the key got exposed, and issue new node certificates on all online nodes.

pvecm create <clustername> [OPTIONS]

Generate new cluster configuration. If no links given, default to local IP address as link0.

<clustername>: <string>
The name of the cluster.

--link[n] [address=]<IP> [,priority=<integer>]
Address and priority information of a single corosync link. (up to 8 links supported; link0..link7)

--nodeid <integer> (1 - N)
Node id for this node.

--token-coefficient <integer> (0 - N) (*default* = 125)
Coefficient used to determine Corosync's token timeout. See the corosync.conf(5) manual for more details.

--votes <integer> (1 - N)
Number of votes for this node.

pvecm delnode <node>

Removes a node from the cluster configuration.

<node>: <string>
The cluster node name.

pvecm expected <expected>

Tells corosync a new value of expected votes.

<expected>: <integer> (1 - N)
Expected votes

pvecm help [OPTIONS]

Get help about specified command.

--extra-args <array>
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
Verbose output format.

pvecm keygen <filename>

Generate new cryptographic key for corosync.

<filename>: <string>
Output file name

pvecm mtunnel [<extra-args>] [OPTIONS]

Used by VM/CT migration - do not use manually.

<extra-args>: <array>
Extra arguments as array

--get_migration_ip <boolean> (*default =* 0)
return the migration IP, if configured

--migration_network <string>
the migration network used to detect the local migration IP

--run-command <boolean>
Run a command with a tcp socket as standard input. The IP address and port are printed via this command's stdandard output first, each on a separate line.

pvecm nodes

Displays the local view of the cluster nodes.

pvecm qdevice remove

Remove a configured QDevice

pvecm qdevice setup `<address> [OPTIONS]`

Setup the use of a QDevice

<address>: <string>
Specifies the network address of an external corosync QDevice

--force <boolean>
Do not throw error on possible dangerous operations.

--network <string>
The network which should be used to connect to the external qdevice

pvecm status

Displays the local view of the cluster status.

pvecm updatecerts `[OPTIONS]`

Update node certificates (and generate all needed files/directories).

--force <boolean>
Force generation of new SSL certificate.

--silent <boolean>
Ignore errors (i.e. when cluster has no quorum).

--unmerge-known-hosts <boolean> (*default =* 0)
Unmerge legacy SSH known hosts.

A.14 pvesr - Proxmox VE Storage Replication

pvesr `<COMMAND> [ARGS] [OPTIONS]`

pvesr create-local-job `<id> <target> [OPTIONS]`

Create a new replication job

<id>: [1-9][0-9]{2,8}-\d{1,9}
Replication Job ID. The ID is composed of a Guest ID and a job number, separated by a hyphen, i.e. *<GUEST>-<JOBNUM>*.

<target>: <string>
Target node.

--comment <string>
Description.

--disable <boolean>
Flag to disable/deactivate the entry.

--rate <number> (1 - N)
Rate limit in mbps (megabytes per second) as floating point number.

--remove_job <full | local>
Mark the replication job for removal. The job will remove all local replication snapshots. When set to *full*, it also tries to remove replicated volumes on the target. The job then removes itself from the configuration file.

--schedule <string> (*default =* */15)
Storage replication schedule. The format is a subset of `systemd` calendar events.

--skip-freeze-fs <boolean> (*default =* 0)
Whether to skip freezing and thawing the guest's filesystems for consistency during replication.

--source <string>
For internal use, to detect if the guest was stolen.

pvesr delete `<id> [OPTIONS]`

Mark replication job for removal.

<id>: [1-9][0-9]{2,8}-\d{1,9}
Replication Job ID. The ID is composed of a Guest ID and a job number, separated by a hyphen, i.e. *<GUEST>-<JOBNUM>*.

--force <boolean> (*default =* 0)
Will remove the jobconfig entry, but will not cleanup.

--keep <boolean> (*default =* 0)
Keep replicated data at target (do not remove).

pvesr disable <id>

Disable a replication job.

<id>: [1-9][0-9]{2,8}-\d{1,9}
Replication Job ID. The ID is composed of a Guest ID and a job number, separated by a hyphen, i.e. *<GUEST>-<JOBNUM>*.

pvesr enable <id>

Enable a replication job.

<id>: [1-9][0-9]{2,8}-\d{1,9}
Replication Job ID. The ID is composed of a Guest ID and a job number, separated by a hyphen, i.e. *<GUEST>-<JOBNUM>*.

pvesr finalize-local-job <id> [<extra-args>] [OPTIONS]

Finalize a replication job. This removes all replications snapshots with timestamps different than <last_sync>.

<id>: [1-9][0-9]{2,8}-\d{1,9}
Replication Job ID. The ID is composed of a Guest ID and a job number, separated by a hyphen, i.e. *<GUEST>-<JOBNUM>*.

<extra-args>: <array>
The list of volume IDs to consider.

--last_sync <integer> (0 - N)
Time (UNIX epoch) of last successful sync. If not specified, all replication snapshots gets removed.

pvesr help [OPTIONS]

Get help about specified command.

--extra-args <array>
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
Verbose output format.

pvesr list

List replication jobs.

pvesr prepare-local-job <id> [<extra-args>] [OPTIONS]

Prepare for starting a replication job. This is called on the target node before replication starts. This call is for internal use, and return a JSON object on stdout. The method first test if VM <vmid> reside on the local node. If so, stop immediately. After that the method scans all volume IDs for snapshots, and removes all replications snapshots with timestamps different than <last_sync>. It also removes any unused volumes. Returns a hash with boolean markers for all volumes with existing replication snapshots.

<id>: [1-9][0-9]{2,8}-\d{1,9}
Replication Job ID. The ID is composed of a Guest ID and a job number, separated by a hyphen, i.e. *<GUEST>-<JOBNUM>*.

<extra-args>: <array>
The list of volume IDs to consider.

--force <boolean> (*default =* 0)
Allow to remove all existion volumes (empty volume list).

--last_sync <integer> (0 - N)
Time (UNIX epoch) of last successful sync. If not specified, all replication snapshots get removed.

--parent_snapname <string>
The name of the snapshot.

--scan <string>
List of storage IDs to scan for stale volumes.

pvesr read <id>

Read replication job configuration.

<id>: [1-9][0-9]{2,8}-\d{1,9}
Replication Job ID. The ID is composed of a Guest ID and a job number, separated by a hyphen, i.e. *<GUEST>-<JOBNUM>*.

pvesr run [OPTIONS]

This method is called by the systemd-timer and executes all (or a specific) sync jobs.

--id [1-9][0-9]{2,8}-\d{1,9}
Replication Job ID. The ID is composed of a Guest ID and a job number, separated by a hyphen, i.e. *<GUEST>-<JOBNUM>*.

--mail <boolean> (*default =* 0)
Send an email notification in case of a failure.

--verbose <boolean> (*default =* 0)
Print more verbose logs to stdout.

pvesr schedule-now <id>

Schedule replication job to start as soon as possible.

<id>: [1-9][0-9]{2,8}-\d{1,9}
Replication Job ID. The ID is composed of a Guest ID and a job number, separated by a hyphen, i.e. *<GUEST>-<JOBNUM>*.

pvesr set-state <vmid> <state>

Set the job replication state on migration. This call is for internal use. It will accept the job state as ja JSON obj.

<vmid>: <integer> (100 - 999999999)
The (unique) ID of the VM.

<state>: <string>
Job state as JSON decoded string.

pvesr status [OPTIONS]

List status of all replication jobs on this node.

--guest <integer> (100 - 999999999)
Only list replication jobs for this guest.

pvesr update <id> [OPTIONS]

Update replication job configuration.

<id>: [1-9][0-9]{2,8}-\d{1,9}
Replication Job ID. The ID is composed of a Guest ID and a job number, separated by a hyphen, i.e. *<GUEST>-<JOBNUM>*.

--comment <string>
Description.

--delete <string>
A list of settings you want to delete.

--digest <string>
Prevent changes if current configuration file has a different digest. This can be used to prevent concurrent modifications.

--disable <boolean>
Flag to disable/deactivate the entry.

--rate <number> (1 - N)
Rate limit in mbps (megabytes per second) as floating point number.

--remove_job <full | local>
Mark the replication job for removal. The job will remove all local replication snapshots. When set to *full*, it also tries to remove replicated volumes on the target. The job then removes itself from the configuration file.

--schedule <string> (*default =* */15)
Storage replication schedule. The format is a subset of `systemd` calendar events.

--skip-freeze-fs <boolean> (*default =* 0)
Whether to skip freezing and thawing the guest's filesystems for consistency during replication.

--source <string>
For internal use, to detect if the guest was stolen.

A.15 pveum - Proxmox VE User Manager

pveum `<COMMAND> [ARGS] [OPTIONS]`

pveum acl delete `<path> --roles <string> [OPTIONS]`

Update Access Control List (add or remove permissions).

<path>: <string>
Access control path

--groups <string>
List of groups.

--propagate <boolean> (*default =* 1)
Allow to propagate (inherit) permissions.

--roles <string>
List of roles.

--tokens <string>
List of API tokens.

--users <string>
List of users.

pveum acl list `[FORMAT_OPTIONS]`

Get Access Control List (ACLs).

pveum acl modify `<path> --roles <string> [OPTIONS]`

Update Access Control List (add or remove permissions).

<path>: <string>
Access control path

--groups <string>
List of groups.

--propagate <boolean> (*default* = 1)
Allow to propagate (inherit) permissions.

--roles <string>
List of roles.

--tokens <string>
List of API tokens.

--users <string>
List of users.

pveum acldel

An alias for *pveum acl delete*.

pveum aclmod

An alias for *pveum acl modify*.

pveum group add `<groupid> [OPTIONS]`

Create new group.

<groupid>: <string>
no description available

--comment <string>
no description available

pveum group delete `<groupid>`

Delete group.

<groupid>: <string>
no description available

pveum group list `[FORMAT_OPTIONS]`

Group index.

pveum group modify `<groupid> [OPTIONS]`

Update group data.

`<groupid>`: `<string>`
no description available

`--comment` `<string>`
no description available

pveum groupadd

An alias for *pveum group add*.

pveum groupdel

An alias for *pveum group delete*.

pveum groupmod

An alias for *pveum group modify*.

pveum help `[OPTIONS]`

Get help about specified command.

`--extra-args` `<array>`
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

`--verbose` `<boolean>`
Verbose output format.

pveum passwd `<userid> [OPTIONS]`

Change user password.

`<userid>`: `<string>`
Full User ID, in the `name@realm` format.

`--confirmation-password` `<string>`
The current password of the user performing the change.

pveum pool add `<poolid> [OPTIONS]`

Create new pool.

`<poolid>`: `<string>`
no description available

--comment <string>
no description available

pveum pool delete <poolid>

Delete pool.

<poolid>: <string>
no description available

pveum pool list [OPTIONS] [FORMAT_OPTIONS]

List pools or get pool configuration.

--poolid <string>
no description available

--type <lxc | network | qemu | storage>
no description available

> **Note**
> Requires option(s): poolid

pveum pool modify <poolid> [OPTIONS]

Update pool.

<poolid>: <string>
no description available

--allow-move <boolean> (***default =*** 0)
Allow adding a guest even if already in another pool. The guest will be removed from its current pool and added to this one.

--comment <string>
no description available

--delete <boolean> (***default =*** 0)
Remove the passed VMIDs, storage IDs and/or network resources instead of adding them.

--network vnet/<zone>/<vnet>[/<tag>|/*]
List of network resources to add or remove from this pool. *vnet/<zone>/<vnet>* allows network devices on the VNet without VLAN tag or trunks, a trailing */<tag>* allows that VLAN tag, and */** allows the VNet with or without any VLAN tag. This only controls the network device configuration, a device without VLAN tag can still carry tagged guest traffic on a VLAN-aware VNet.

--storage <string>
List of storage IDs to add or remove from this pool.

--vms <string>
List of guest VMIDs to add or remove from this pool.

pveum realm add <realm> --type <string> [OPTIONS]

Add an authentication server.

<realm>: <string>
Authentication domain ID

--acr-values ^[^\x00-\x1F\x7F <>#"]*$
Specifies the Authentication Context Class Reference values that theAuthorization Server is being requested to use for the Auth Request.

--audiences ^[^\x00-\x1F\x7F <>#"]*$
A list of audiences that the OpenID Issuer may include that are accepted in addition to *client-id*.

--autocreate <boolean> (*default =* 0)
Automatically create users if they do not exist.

--base_dn <string>
LDAP base domain name

--bind_dn <string>
LDAP bind domain name

--capath <string> (*default =* /etc/ssl/certs)
Path to the CA certificate store

--case-sensitive <boolean> (*default =* 1)
username is case-sensitive

--cert <string>
Path to the client certificate

--certkey <string>
Path to the client certificate key

--check-connection <boolean> (*default =* 0)
Check bind connection to the server.

--client-id <string>
OpenID Client ID

--client-key <string>
OpenID Client Key

--comment <string>
Description.

--default <boolean>
Use this as default realm

--domain \S+
AD domain name

--filter <string>
LDAP filter for user sync.

--group_classes <string> (***default =*** **groupOfNames, group, univentionGroup, ipausergroup**)
The objectclasses for groups.

--group_dn <string>
LDAP base domain name for group sync. If not set, the base_dn will be used.

--group_filter <string>
LDAP filter for group sync.

--group_name_attr <string>
LDAP attribute representing a groups name. If not set or found, the first value of the DN will be used as name.

--groups-autocreate <boolean> (***default =*** 0)
Automatically create groups if they do not exist.

--groups-claim (?^:[A-Za-z0-9\.\-_]+)
OpenID claim used to retrieve groups with.

--groups-overwrite <boolean> (***default =*** 0)
All groups will be overwritten for the user on login.

--issuer-url <string>
OpenID Issuer Url

--mode <ldap | ldap+starttls | ldaps> (***default =*** **ldap**)
LDAP protocol mode.

--password <string>
LDAP bind password. Will be stored in */etc/pve/priv/realm/<REALM>.pw*.

--port <integer> (1 - 65535)
Server port.

--prompt (?:none|login|consent|select_account|\S+)
Specifies whether the Authorization Server prompts the End-User for reauthentication and consent.

--query-userinfo <boolean> (*default =* 1)
Enables querying the userinfo endpoint for claims values.

--scopes <string> (*default =* email profile)
Specifies the scopes (user details) that should be authorized and returned, for example *email* or *profile*.

--secure <boolean>
Use secure LDAPS protocol. DEPRECATED: use *mode* instead.

--server1 <string>
Server IP address (or DNS name)

--server2 <string>
Fallback Server IP address (or DNS name)

--sslversion <tlsv1 | tlsv1_1 | tlsv1_2 | tlsv1_3>
LDAPS TLS/SSL version. It's not recommended to use version older than 1.2!

--sync-defaults-options [enable-new=<1|0>] [,full=<1|0>] [,purge=<1|0>] [,remove-vanished=([acl];[properties];[entry])|none] [,scope=<users|groups|both>]
The default options for behavior of synchronizations.

--sync_attributes \w+=[^,]+(,\s*\w+=[^,]+)*
Comma separated list of key=value pairs for specifying which LDAP attributes map to which PVE user field. For example, to map the LDAP attribute *mail* to PVEs *email*, write *email=mail*. By default, each PVE user field is represented by an LDAP attribute of the same name.

--tfa type=<TFATYPE> [,digits=<COUNT>] [,id=<ID>] [,key=<KEY>] [,step=<SECONDS>] [,url=<URL>]
Use Two-factor authentication.

--type <ad | ldap | openid | pam | pve>
Realm type.

--user_attr \S{2,}
LDAP user attribute name

--user_classes <string> (*default =* inetorgperson, posixaccount, person, user)
The objectclasses for users.

--username-claim <string>
OpenID claim used to generate the unique username.

--verify <boolean> (*default =* 0)
Verify the server's SSL certificate

pveum realm delete <realm>

Delete an authentication server.

<realm>: <string>
Authentication domain ID

pveum realm list [FORMAT_OPTIONS]

Authentication domain index.

pveum realm modify <realm> [OPTIONS]

Update authentication server settings.

<realm>: <string>
Authentication domain ID

--acr-values ^[^\x00-\x1F\x7F <>#"]*$
Specifies the Authentication Context Class Reference values that theAuthorization Server is being requested to use for the Auth Request.

--audiences ^[^\x00-\x1F\x7F <>#"]*$
A list of audiences that the OpenID Issuer may include that are accepted in addition to *client-id*.

--autocreate <boolean> (*default =* 0)
Automatically create users if they do not exist.

--base_dn <string>
LDAP base domain name

--bind_dn <string>
LDAP bind domain name

--capath <string> (*default =* /etc/ssl/certs)
Path to the CA certificate store

--case-sensitive <boolean> (*default =* 1)
username is case-sensitive

--cert <string>
Path to the client certificate

--certkey <string>
Path to the client certificate key

--check-connection <boolean> (*default =* 0)
Check bind connection to the server.

--client-id <string>
OpenID Client ID

--client-key <string>
OpenID Client Key

--comment <string>
Description.

--default <boolean>
Use this as default realm

--delete <string>
A list of settings you want to delete.

--digest <string>
Prevent changes if current configuration file has a different digest. This can be used to prevent concurrent modifications.

--domain \S+
AD domain name

--filter <string>
LDAP filter for user sync.

--group_classes <string> (*default =* **groupOfNames, group, univentionGroup, ipausergroup**)
The objectclasses for groups.

--group_dn <string>
LDAP base domain name for group sync. If not set, the base_dn will be used.

--group_filter <string>
LDAP filter for group sync.

--group_name_attr <string>
LDAP attribute representing a groups name. If not set or found, the first value of the DN will be used as name.

--groups-autocreate <boolean> (*default =* 0)
Automatically create groups if they do not exist.

--groups-claim (?^:[A-Za-z0-9\.\-_]+)
OpenID claim used to retrieve groups with.

--groups-overwrite <boolean> (*default =* 0)
All groups will be overwritten for the user on login.

--issuer-url <string>
OpenID Issuer Url

--mode <ldap | ldap+starttls | ldaps> (*default =* ldap)
LDAP protocol mode.

--password <string>
LDAP bind password. Will be stored in */etc/pve/priv/realm/<REALM>.pw*.

--port <integer> (1 - 65535)
Server port.

--prompt (?:none|login|consent|select_account|\S+)
Specifies whether the Authorization Server prompts the End-User for reauthentication and consent.

--query-userinfo <boolean> (*default =* 1)
Enables querying the userinfo endpoint for claims values.

--scopes <string> (*default =* email profile)
Specifies the scopes (user details) that should be authorized and returned, for example *email* or *profile*.

--secure <boolean>
Use secure LDAPS protocol. DEPRECATED: use *mode* instead.

--server1 <string>
Server IP address (or DNS name)

--server2 <string>
Fallback Server IP address (or DNS name)

--sslversion <tlsv1 | tlsv1_1 | tlsv1_2 | tlsv1_3>
LDAPS TLS/SSL version. It's not recommended to use version older than 1.2!

--sync-defaults-options [enable-new=<1|0>] [,full=<1|0>] [,purge=<1|0>] [,remove-vanished=([acl];[properties];[entry])|none] [,scope=<users|groups|both>]
The default options for behavior of synchronizations.

--sync_attributes \w+=[^,]+(,\s*\w+=[^,]+)*
Comma separated list of key=value pairs for specifying which LDAP attributes map to which PVE user field. For example, to map the LDAP attribute *mail* to PVEs *email*, write *email=mail*. By default, each PVE user field is represented by an LDAP attribute of the same name.

--tfa type=<TFATYPE> [,digits=<COUNT>] [,id=<ID>] [,key=<KEY>] [,step=<SECONDS>] [,url=<URL>]
Use Two-factor authentication.

--user_attr \S{2,}
LDAP user attribute name

--user_classes <string> (*default =* inetorgperson, posixaccount, person, user)
The objectclasses for users.

--verify <boolean> (*default =* 0)
Verify the server's SSL certificate

pveum realm sync `<realm> [OPTIONS]`

Syncs users and/or groups from the configured LDAP to user.cfg. NOTE: Synced groups will have the name *name-$realm*, so make sure those groups do not exist to prevent overwriting.

<realm>: <string>
Authentication domain ID

--dry-run <boolean> (*default =* 0)
If set, does not write anything.

--enable-new <boolean> (*default =* 1)
Enable newly synced users immediately.

--full <boolean>
DEPRECATED: use *remove-vanished* instead. If set, uses the LDAP Directory as source of truth, deleting users or groups not returned from the sync and removing all locally modified properties of synced users. If not set, only syncs information which is present in the synced data, and does not delete or modify anything else.

--purge <boolean>
DEPRECATED: use *remove-vanished* instead. Remove ACLs for users or groups which were removed from the config during a sync.

--remove-vanished ([acl];[properties];[entry])|none (*default =* none)
A semicolon-separated list of things to remove when they or the user vanishes during a sync. The following values are possible: *entry* removes the user/group when not returned from the sync. *properties* removes the set properties on existing user/group that do not appear in the source (even custom ones). *acl* removes acls when the user/group is not returned from the sync. Instead of a list it also can be *none* (the default).

--scope <both | groups | users>
Select what to sync.

pveum role add <roleid> [OPTIONS]

Create new role.

<roleid>: <string>
no description available

--privs <string>
no description available

pveum role delete <roleid>

Delete role.

<roleid>: <string>
no description available

pveum role list [FORMAT_OPTIONS]

Role index.

pveum role modify <roleid> [OPTIONS]

Update an existing role.

<roleid>: <string>
no description available

--append <boolean>
no description available

> **Note**
> Requires option(s): privs

--privs <string>
no description available

pveum roleadd

An alias for *pveum role add*.

pveum roledel

An alias for *pveum role delete*.

pveum rolemod

An alias for *pveum role modify*.

pveum ticket <username> [OPTIONS]

Create or verify authentication ticket.

<username>: <string>
User name

--new-format <boolean> (*default =* 1)
This parameter is now ignored and assumed to be 1.

--otp <string>
One-time password for Two-factor authentication.

--path <string>
Verify ticket, and check if user have access *privs* on *path*

> **Note**
> Requires option(s): `privs`

--privs <string>
Verify ticket, and check if user have access *privs* on *path*

> **Note**
> Requires option(s): `path`

--realm <string>
You can optionally pass the realm using this parameter. Normally the realm is simply added to the username <username>@<realm>.

--tfa-challenge <string>
The signed TFA challenge string the user wants to respond to.

pveum user add `<userid> [OPTIONS]`

Create new user.

<userid>: <string>
Full User ID, in the `name@realm` format.

--comment <string>
no description available

--email <string>
no description available

--enable <boolean> (*default =* 1)
Enable the account (default). You can set this to *0* to disable the account

--expire <integer> (0 - N)
Account expiration date (seconds since epoch). *0* means no expiration date.

--firstname <string>
no description available

--groups <string>
no description available

--keys [0-9a-zA-Z!=]{0,4096}
Keys for two factor auth (yubico).

--lastname <string>
no description available

--password <string>
Initial password.

pveum user delete <userid>

Delete user.

<userid>: <string>
Full User ID, in the name@realm format.

pveum user list [OPTIONS] [FORMAT_OPTIONS]

User index.

--enabled <boolean>
Optional filter for enable property.

--full <boolean> (*default =* 0)
Include group and token information.

pveum user modify <userid> [OPTIONS]

Update user configuration.

<userid>: <string>
Full User ID, in the name@realm format.

--append <boolean>
no description available

Note
Requires option(s): groups

--comment <string>
no description available

--email <string>
no description available

--enable <boolean> (*default* = 1)
Enable the account (default). You can set this to *0* to disable the account

--expire <integer> (0 - N)
Account expiration date (seconds since epoch). *0* means no expiration date.

--firstname <string>
no description available

--groups <string>
no description available

--keys [0-9a-zA-Z!=]{0,4096}
Keys for two factor auth (yubico).

--lastname <string>
no description available

pveum user permissions `[<userid>] [OPTIONS] [FORMAT_OPTIONS]`

Retrieve effective permissions of given user/token.

<userid>:
(?^:^(?^:[^\s:/]+)\@(?^:[A-Za-z][A-Za-z0-9\.\-_]+)(?:!(?^:[A-Za-z][A-Za-z0-

User ID or full API token ID

--path <string>
Only dump this specific path, not the whole tree.

pveum user tfa delete `<userid> [OPTIONS]`

Delete TFA entries from a user.

<userid>: <string>
Full User ID, in the `name@realm` format.

--id <string>
The TFA ID, if none provided, all TFA entries will be deleted.

pveum user tfa list `[<userid>]`

List TFA entries.

<userid>: <string>
Full User ID, in the `name@realm` format.

pveum user tfa unlock `<userid>`

Unlock a user's TFA authentication.

<userid>: <string>
Full User ID, in the `name@realm` format.

pveum user token add `<userid> <tokenid> [OPTIONS] [FORMAT_OPTIONS]`

Generate a new API token for a specific user. NOTE: returns API token value, which needs to be stored as it cannot be retrieved afterwards!

<userid>: <string>
Full User ID, in the `name@realm` format.

<tokenid>: (?^:[A-Za-z][A-Za-z0-9\.\-_]+)
User-specific token identifier.

--comment <string>
no description available

--expire <integer> (0 - N) (*default* = same as user)
API token expiration date (seconds since epoch). *0* means no expiration date, or the maximum lifetime if the datacenter token policy sets *default-to-max-lifetime*.

--privsep <boolean> (*default* = 1)
Restrict API token privileges with separate ACLs (default), or give full privileges of corresponding user.

pveum user token delete `<userid> <tokenid> [FORMAT_OPTIONS]`

Remove API token for a specific user.

<userid>: <string>
Full User ID, in the `name@realm` format.

<tokenid>: (?^:[A-Za-z][A-Za-z0-9\.\-_]+)
User-specific token identifier.

pveum user token list `<userid> [FORMAT_OPTIONS]`

Get user API tokens.

<userid>: <string>
Full User ID, in the `name@realm` format.

pveum user token modify `<userid> <tokenid> [OPTIONS] [FORMAT_OPTIONS]`

Update API token for a specific user. NOTE: when *regenerate* is set, the returned token value needs to be stored as it cannot be retrieved afterwards!

<userid>: <string>
Full User ID, in the `name@realm` format.

<tokenid>: (?^:[A-Za-z][A-Za-z0-9\.\-_]+)
User-specific token identifier.

--comment <string>
no description available

--delete <string>
A list of settings you want to delete.

--expire <integer> (0 - N) (*default =* same as user)
API token expiration date (seconds since epoch). *0* means no expiration date.

--privsep <boolean> (*default =* 1)
Restrict API token privileges with separate ACLs (default), or give full privileges of corresponding user.

--regenerate <boolean> (*default =* 0)
Regenerate the token's secret value. All users of the previous secret will lose access after this operation.

pveum user token permissions `<userid> <tokenid> [OPTIONS] [FORMAT_OPTIONS]`

Retrieve effective permissions of given token.

<userid>: <string>
Full User ID, in the `name@realm` format.

<tokenid>: (?^:[A-Za-z][A-Za-z0-9\.\-_]+)
User-specific token identifier.

--path <string>
Only dump this specific path, not the whole tree.

pveum user token remove

An alias for *pveum user token delete*.

pveum useradd

An alias for *pveum user add*.

pveum userdel

An alias for *pveum user delete*.

pveum usermod

An alias for *pveum user modify*.

A.16 vzdump - Backup Utility for VMs and Containers

vzdump `help`

vzdump `{<vmid>} [OPTIONS]`

Create backup.

<vmid>: <string>
The ID of the guest system you want to backup.

--all <boolean> (*default =* 0)
Backup all known guest systems on this host.

--bwlimit <integer> (0 - N) (*default =* 0)
Limit I/O bandwidth (in KiB/s).

--compress <0 | 1 | gzip | lzo | zstd> (*default =* 0)
Compress dump file.

--dumpdir <string>
Store resulting files to specified directory.

--exclude <string>
Exclude specified guest systems (assumes --all)

--exclude-path <array>
Exclude certain files/directories (shell globs). Paths starting with / are anchored to the container's root, other paths match relative to each subdirectory.

--fleecing [[enabled=]<1|0>] [,storage=<storage ID>]
Options for backup fleecing (VM only).

--ionice <integer> (0 - 8) (*default =* 7)
Set IO priority when using the BFQ scheduler. For snapshot and suspend mode backups of VMs, this only affects the compressor. A value of 8 means the idle priority is used, otherwise the best-effort priority is used with the specified value.

--job-id \S+
The ID of the backup job. If set, the *backup-job* metadata field of the backup notification will be set to this value. Only root@pam can set this parameter.

--lockwait <integer> (0 - N) (*default* = 180)
Maximal time to wait for the global lock (minutes).

--mailnotification <always | failure> (*default* = always)
Deprecated: use notification targets/matchers instead. Specify when to send a notification mail

--mailto <string>
Deprecated: Use notification targets/matchers instead. Comma-separated list of email addresses or users that should receive email notifications.

--mode <snapshot | stop | suspend> (*default* = snapshot)
Backup mode.

--node <string>
Only run if executed on this node.

--notes-template <string>
Template string for generating notes for the backup(s). It can contain variables which will be replaced by their values. Currently supported are {\{\cluster}}, {\{\guestname}}, {\{\node}}, {\{\uid}}, and {\{\vmid}}, but more might be added in the future. Needs to be a single line, newline and backslash need to be escaped as *\n* and \\ respectively.

Note
Requires option(s): `storage`

--notification-mode <auto | legacy-sendmail | none | notification-system> (*default* = auto)
Determine which notification system to use. If set to *legacy-sendmail*, vzdump will consider the mailto/-mailnotification parameters and send emails to the specified address(es) via the *sendmail* command. If set to *notification-system*, a notification will be sent via PVE's notification system, and the mailto and mailnotification will be ignored. If set to *auto* (default setting), an email will be sent if mailto is set, and the notification system will be used if not. If set to *none*, no notification will be sent.

--pbs-change-detection-mode <data | legacy | metadata>
PBS mode used to detect file changes and switch encoding format for container backups.

--performance [max-workers=<integer>] [,pbs-entries-max=<integer>]
Other performance-related settings.

--pigz <integer> (*default* = 0)
Use pigz instead of gzip when N>0. N=1 uses half of cores, N>1 uses N as thread count.

--pool <string>
Backup all known guest systems included in the specified pool.

--protected <boolean>
If true, mark backup(s) as protected.

> **Note**
> Requires option(s): `storage`

--prune-backups [keep-all=<1|0>] [,keep-daily=<N>] [,keep-hourly=<N>] [,keep-last=<N>] [,keep-monthly=<N>] [,keep-weekly=<N>] [,keep-yearly=<N>] (*default =* keep-all=1)
Use these retention options instead of those from the storage configuration.

--quiet <boolean> (*default =* 0)
Be quiet.

--remove <boolean> (*default =* 1)
Prune older backups according to *prune-backups*.

--script <string>
Use specified hook script.

--stdexcludes <boolean> (*default =* 1)
Exclude temporary files and logs.

--stdout <boolean>
Write tar to stdout, not to a file.

--stop <boolean> (*default =* 0)
Stop running backup jobs on this host.

--stopwait <integer> (0 - N) (*default =* 10)
Maximal time to wait until a guest system is stopped (minutes).

--storage <storage ID>
Store resulting file to this storage.

--tmpdir <string>
Store temporary files to specified directory.

--zstd <integer> (*default =* 1)
Zstd threads. N=0 uses half of the available cores, if N is set to a value bigger than 0, N is used as thread count.

A.17 ha-manager - Proxmox VE HA Manager

ha-manager `<COMMAND> [ARGS] [OPTIONS]`

ha-manager add `<sid> [OPTIONS]`

Create a new HA resource.

<sid>: <type>:<name>
HA resource ID. This consists of a resource type followed by a resource specific name, separated with colon (example: vm:100 / ct:100). For virtual machines and containers, you can simply use the VM or CT id as a shortcut (example: 100).

--auto-rebalance <boolean> (*default =* 1)
HA resource may be migrated during automatic rebalancing

--comment <string>
Description.

--failback <boolean> (*default =* 1)
Automatically migrate HA resource to the node with the highest priority according to their node affinity rules, if a node with a higher priority than the current node comes online.

--group <string>
The HA group identifier.

--max_relocate <integer> (0 - N) (*default =* 1)
Maximal number of resource relocate tries when a resource fails to start.

--max_restart <integer> (0 - N) (*default =* 1)
Maximal number of tries to restart the resource on a node after its start failed. When reached, the HA manager will try to relocate the resource to an eligible node.

--state <disabled | enabled | ignored | started | stopped> (*default =* started)
Requested resource state.

--type <ct | vm>
Resource type.

ha-manager config `[OPTIONS]`

List HA resources.

--type <ct | vm>
Only list resources of specific type

ha-manager crm-command arm-ha

Request re-arming the HA stack after it was disarmed.

ha-manager crm-command disarm-ha `<resource-mode>`

Request disarming the HA stack, releasing all watchdogs cluster-wide.

`<resource-mode>`: `<freeze | ignore>`
Controls how HA managed resources are handled while disarmed. The current state of resources is not affected. *freeze*: new commands and state changes are not applied. *ignore*: resources are removed from HA tracking and can be managed as if they were not HA managed.

ha-manager crm-command migrate `<sid> <node> [OPTIONS]`

Request resource migration (online) to another node.

`<sid>`: `<type>:<name>`
HA resource ID. This consists of a resource type followed by a resource specific name, separated with colon (example: vm:100 / ct:100). For virtual machines and containers, you can simply use the VM or CT id as a shortcut (example: 100).

`<node>`: `<string>`
Target node.

`--resource-type <ct | vm>`
The resource type. Automatically determined from the service ID.

ha-manager crm-command node-maintenance disable `<node>`

Change the node-maintenance request state.

`<node>`: `<string>`
The cluster node name.

ha-manager crm-command node-maintenance enable `<node>`

Change the node-maintenance request state.

`<node>`: `<string>`
The cluster node name.

ha-manager crm-command relocate `<sid> <node>`

Request resource relocation to another node. This stops the service on the old node, and restarts it on the target node.

<sid>: <type>:<name>
HA resource ID. This consists of a resource type followed by a resource specific name, separated with colon (example: vm:100 / ct:100). For virtual machines and containers, you can simply use the VM or CT id as a shortcut (example: 100).

<node>: <string>
Target node.

ha-manager crm-command stop `<sid> <timeout>`

Request the service to be stopped.

<sid>: <type>:<name>
HA resource ID. This consists of a resource type followed by a resource specific name, separated with colon (example: vm:100 / ct:100). For virtual machines and containers, you can simply use the VM or CT id as a shortcut (example: 100).

<timeout>: <integer> (0 - N)
Timeout in seconds. If set to 0 a hard stop will be performed.

ha-manager groupadd `<group> --nodes <string> [OPTIONS]`

Create a new HA group. (deprecated in favor of HA rules)

<group>: <string>
The HA group identifier.

--comment <string>
Description.

--nodes <node>[:<pri>]{,<node>[:<pri>]}*
List of cluster node names with optional priority.

--nofailback <boolean> (*default =* 0)
The CRM tries to run services on the node with the highest priority. If a node with higher priority comes online, the CRM migrates the service to that node. Enabling nofailback prevents that behavior.

--restricted <boolean> (*default =* 0)
Resources bound to restricted groups may only run on nodes defined by the group.

--type <group>
Group type.

ha-manager groupconfig

Get HA groups. (deprecated in favor of HA rules)

ha-manager groupremove `<group>`

Delete ha group configuration. (deprecated in favor of HA rules)

<group>: <string>
The HA group identifier.

ha-manager groupset <group> [OPTIONS]

Update ha group configuration. (deprecated in favor of HA rules)

<group>: <string>
The HA group identifier.

--comment <string>
Description.

--delete <string>
A list of settings you want to delete.

--digest <string>
Prevent changes if current configuration file has a different digest. This can be used to prevent concurrent modifications.

--nodes <node>[:<pri>]{,<node>[:<pri>]}*
List of cluster node names with optional priority.

--nofailback <boolean> (***default =*** 0)
The CRM tries to run services on the node with the highest priority. If a node with higher priority comes online, the CRM migrates the service to that node. Enabling nofailback prevents that behavior.

--restricted <boolean> (***default =*** 0)
Resources bound to restricted groups may only run on nodes defined by the group.

ha-manager help [OPTIONS]

Get help about specified command.

--extra-args <array>
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
Verbose output format.

ha-manager migrate

An alias for *ha-manager crm-command migrate*.

ha-manager relocate

An alias for *ha-manager crm-command relocate*.

ha-manager remove <sid> [OPTIONS]

Delete resource configuration.

<sid>: <type>:<name>
HA resource ID. This consists of a resource type followed by a resource specific name, separated with colon (example: vm:100 / ct:100). For virtual machines and containers, you can simply use the VM or CT id as a shortcut (example: 100).

--purge <boolean> (*default =* 1)
Remove this resource from rules that reference it, deleting the rule if this resource is the only resource in the rule

ha-manager rules add `<type> <rule> --resources <string> [OPTIONS]`

Create HA rule.

<type>: <node-affinity | resource-affinity>
HA rule type.

<rule>: <string>
HA rule identifier.

--comment <string>
HA rule description.

--disable <boolean>
Whether the HA rule is disabled.

--resources <type>:<name>{,<type>:<name>}*
List of HA resource IDs. This consists of a list of resource types followed by a resource specific name separated with a colon (example: vm:100,ct:101).

`Conditional options:`

--affinity <negative | positive> (*default =* positive)
Describes whether the HA resources are supposed to be placed on the given nodes (*positive*), or are supposed to be placed on any but the given nodes (*negative*).

`[type=node-affinity]`

--affinity <negative | positive>
Describes whether the HA resources are supposed to be kept on the same node (*positive*), or are supposed to be kept on separate nodes (*negative*).

`[type=resource-affinity]`

--nodes <node>[:<pri>]{,<node>[:<pri>]}*
List of cluster node names with optional priority.

`[type=node-affinity]`

--strict <boolean> (*default =* 0)
Describes whether the node affinity rule is strict or non-strict.
[type=node-affinity]

ha-manager rules config [OPTIONS] [FORMAT_OPTIONS]

Get HA rules.

--resource <string>
Limit the returned list to rules affecting the specified resource.

--type <node-affinity | resource-affinity>
Limit the returned list to the specified rule type.

ha-manager rules list [OPTIONS] [FORMAT_OPTIONS]

Get HA rules.

--resource <string>
Limit the returned list to rules affecting the specified resource.

--type <node-affinity | resource-affinity>
Limit the returned list to the specified rule type.

ha-manager rules remove <rule>

Delete HA rule.

<rule>: <string>
HA rule identifier.

ha-manager rules set <type> <rule> [OPTIONS]

Update HA rule.

<type>: <node-affinity | resource-affinity>
HA rule type.

<rule>: <string>
HA rule identifier.

--comment <string>
HA rule description.

--delete <string>
A list of settings you want to delete.

--digest <string>
Prevent changes if current configuration file has a different digest. This can be used to prevent concurrent modifications.

--disable <boolean>
Whether the HA rule is disabled.

--resources <type>:<name>{,<type>:<name>}*
List of HA resource IDs. This consists of a list of resource types followed by a resource specific name separated with a colon (example: vm:100,ct:101).

Conditional options:

--affinity <negative | positive> (*default =* positive)
Describes whether the HA resources are supposed to be placed on the given nodes (*positive*), or are supposed to be placed on any but the given nodes (*negative*).

[type=node-affinity]

--affinity <negative | positive>
Describes whether the HA resources are supposed to be kept on the same node (*positive*), or are supposed to be kept on separate nodes (*negative*).

[type=resource-affinity]

--nodes <node>[:<pri>]{,<node>[:<pri>]}*
List of cluster node names with optional priority.

[type=node-affinity]

--strict <boolean> (*default =* 0)
Describes whether the node affinity rule is strict or non-strict.

[type=node-affinity]

ha-manager set <sid> [OPTIONS]

Update resource configuration.

<sid>: <type>:<name>
HA resource ID. This consists of a resource type followed by a resource specific name, separated with colon (example: vm:100 / ct:100). For virtual machines and containers, you can simply use the VM or CT id as a shortcut (example: 100).

--auto-rebalance <boolean> (*default =* 1)
HA resource may be migrated during automatic rebalancing

--comment <string>
Description.

--delete <string>
A list of settings you want to delete.

--digest <string>
Prevent changes if current configuration file has a different digest. This can be used to prevent concurrent modifications.

--failback <boolean> (*default =* 1)
Automatically migrate HA resource to the node with the highest priority according to their node affinity rules, if a node with a higher priority than the current node comes online.

--group <string>
The HA group identifier.

--max_relocate <integer> (0 - N) (*default =* 1)
Maximal number of resource relocate tries when a resource fails to start.

--max_restart <integer> (0 - N) (*default =* 1)
Maximal number of tries to restart the resource on a node after its start failed. When reached, the HA manager will try to relocate the resource to an eligible node.

--state <disabled | enabled | ignored | started | stopped> (*default = started*)
Requested resource state.

ha-manager status [OPTIONS]

Display HA manager status.

--verbose <boolean> (*default =* 0)
Verbose output. Include complete CRM and LRM status (JSON).

Appendix B

Service Daemons

B.1 pve-firewall - Proxmox VE Firewall Daemon

pve-firewall `<COMMAND> [ARGS] [OPTIONS]`

pve-firewall compile

Compile and print firewall rules. This is useful for testing.

pve-firewall help `[OPTIONS]`

Get help about specified command.

--extra-args <array>
: Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
: Verbose output format.

pve-firewall localnet

Print information about local network.

pve-firewall restart

Restart the Proxmox VE firewall service.

pve-firewall simulate `[OPTIONS]`

Simulate firewall rules. This does not simulates the kernel *routing* table, but simply assumes that routing from source zone to destination zone is possible.

--dest <string>
: Destination IP address.

--dport <integer>
: Destination port.

--from (host|outside|vm\d+|ct\d+|([a-zA-Z][a-zA-Z0-9]{0,9})/(\S+)) **(*default =* outside)**
Source zone.

--protocol (tcp|udp) (*default =* tcp)
Protocol.

--source <string>
Source IP address.

--sport <integer>
Source port.

--to (host|outside|vm\d+|ct\d+|([a-zA-Z][a-zA-Z0-9]{0,9})/(\S+)) **(*default =* host)**
Destination zone.

--verbose <boolean> (*default =* 0)
Verbose output.

pve-firewall start [OPTIONS]

Start the Proxmox VE firewall service.

--debug <boolean> (*default =* 0)
Debug mode - stay in foreground

pve-firewall status

Get firewall status.

pve-firewall stop

Stop the Proxmox VE firewall service. Note, stopping actively removes all Proxmox VE related iptable rules rendering the host potentially unprotected.

B.2 pvedaemon - Proxmox VE API Daemon

pvedaemon <COMMAND> [ARGS] [OPTIONS]

pvedaemon help [OPTIONS]

Get help about specified command.

--extra-args <array>
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
Verbose output format.

pvedaemon restart

Restart the daemon (or start if not running).

pvedaemon start [OPTIONS]

Start the daemon.

--debug <boolean> (*default =* 0)
Debug mode - stay in foreground

pvedaemon status

Get daemon status.

pvedaemon stop

Stop the daemon.

B.3 pveproxy - Proxmox VE API Proxy Daemon

pveproxy <COMMAND> [ARGS] [OPTIONS]

pveproxy help [OPTIONS]

Get help about specified command.

--extra-args <array>
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
Verbose output format.

pveproxy restart

Restart the daemon (or start if not running).

pveproxy start [OPTIONS]

Start the daemon.

--debug <boolean> (*default =* 0)
Debug mode - stay in foreground

pveproxy status

Get daemon status.

pveproxy stop

Stop the daemon.

B.4 pvestatd - Proxmox VE Status Daemon

pvestatd `<COMMAND> [ARGS] [OPTIONS]`

pvestatd help `[OPTIONS]`

Get help about specified command.

`--extra-args <array>`
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

`--verbose <boolean>`
Verbose output format.

pvestatd restart

Restart the daemon (or start if not running).

pvestatd start `[OPTIONS]`

Start the daemon.

`--debug <boolean>` (*default =* 0)
Debug mode - stay in foreground

pvestatd status

Get daemon status.

pvestatd stop

Stop the daemon.

B.5 spiceproxy - SPICE Proxy Service

spiceproxy `<COMMAND> [ARGS] [OPTIONS]`

spiceproxy help `[OPTIONS]`

Get help about specified command.

`--extra-args <array>`
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

`--verbose <boolean>`
Verbose output format.

spiceproxy restart

Restart the daemon (or start if not running).

spiceproxy start [OPTIONS]

Start the daemon.

--debug <boolean> (*default =* 0)
Debug mode - stay in foreground

spiceproxy status

Get daemon status.

spiceproxy stop

Stop the daemon.

B.6 pmxcfs - Proxmox Cluster File System

pmxcfs [OPTIONS]

Help Options:

-h, --help
Show help options

Application Options:

-d, --debug
Turn on debug messages

-f, --foreground
Do not daemonize server

-l, --local
Force local mode (ignore corosync.conf, force quorum)

This service is usually started and managed using systemd toolset. The service is called *pve-cluster*.

```
systemctl start pve-cluster

systemctl stop pve-cluster

systemctl status pve-cluster
```

B.7 pve-ha-crm - Cluster Resource Manager Daemon

pve-ha-crm <COMMAND> [ARGS] [OPTIONS]

pve-ha-crm help [OPTIONS]

Get help about specified command.

--extra-args <array>
: Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
: Verbose output format.

pve-ha-crm start [OPTIONS]

Start the daemon.

--debug <boolean> (*default =* 0)
: Debug mode - stay in foreground

pve-ha-crm status

Get daemon status.

pve-ha-crm stop

Stop the daemon.

B.8 pve-ha-lrm - Local Resource Manager Daemon

pve-ha-lrm <COMMAND> [ARGS] [OPTIONS]

pve-ha-lrm help [OPTIONS]

Get help about specified command.

--extra-args <array>
: Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
: Verbose output format.

pve-ha-lrm start [OPTIONS]

Start the daemon.

--debug <boolean> (*default =* 0)
Debug mode - stay in foreground

pve-ha-lrm status

Get daemon status.

pve-ha-lrm stop

Stop the daemon.

B.9 pvescheduler - Proxmox VE Scheduler Daemon

pvescheduler <COMMAND> [ARGS] [OPTIONS]

pvescheduler help [OPTIONS]

Get help about specified command.

--extra-args <array>
Shows help for a specific command. Its arguments can follow, to only list the options of the type they select.

--verbose <boolean>
Verbose output format.

pvescheduler restart

Restart the daemon (or start if not running).

pvescheduler start [OPTIONS]

Start the daemon.

--debug <boolean> (*default =* 0)
Debug mode - stay in foreground

pvescheduler status

Get daemon status.

pvescheduler stop

Stop the daemon.

Appendix C

Configuration Files

C.1 General

Most configuration files in Proxmox VE reside on the shared cluster file system mounted at `/etc/pve`. There are exceptions, like the node-specific configuration file for backups in `/etc/vzdump.conf`.

Usually, the properties in a configuration file are derived from the JSON Schema that is also used for the associated API endpoints.

C.1.1 Casing of Property Names

Historically, longer properties (and sub-properties) often used `snake_case`, or were written as one word. This can likely be attributed to the Proxmox VE stack being developed mostly in the programming language Perl, where access to properties using `kebab-case` requires additional quotes, as well as less style enforcement during early development, so different developers used different conventions.

For new properties, `kebab-case` is the preferred way and it is planned to introduce aliases for existing `snake_case` properties, and in the long term, switch over to `kebab-case` for the API, CLI and in-use configuration files while maintaining backwards-compatibility when restoring a configuration.

C.2 Datacenter Configuration

The file `/etc/pve/datacenter.cfg` is a configuration file for Proxmox VE. It contains cluster wide default values used by all nodes.

C.2.1 File Format

The file uses a simple colon separated key/value format. Each line has the following format:

```
OPTION: value
```

Blank lines in the file are ignored, and lines starting with a # character are treated as comments and are also ignored.

C.2.2 Options

bwlimit: **[clone=<LIMIT>] [,default=<LIMIT>] [,migration=<LIMIT>] [,move=<LIMIT>] [,restore=<LIMIT>]**
Set I/O bandwidth limit for various operations (in KiB/s).

clone=<LIMIT>
bandwidth limit in KiB/s for cloning disks

default=<LIMIT>
default bandwidth limit in KiB/s

migration=<LIMIT>
bandwidth limit in KiB/s for migrating guests (including moving local disks)

move=<LIMIT>
bandwidth limit in KiB/s for moving disks

restore=<LIMIT>
bandwidth limit in KiB/s for restoring guests from backups

consent-text: **[A-Za-z0-9+/]*={0,2}**
Consent text that is displayed before logging in. Needs to be base64 encoded.

console: **<applet | html5 | vv | xtermjs>**
Select the default Console viewer. You can either use the builtin java applet (VNC; deprecated and maps to html5), an external virt-viewer comtatible application (SPICE), an HTML5 based vnc viewer (noVNC), or an HTML5 based console client (xtermjs). If the selected viewer is not available (e.g. SPICE not activated for the VM), the fallback is noVNC.

crs: **[ha=<basic|static|dynamic>] [,ha-auto-rebalance=<1|0>] [,ha-auto-rebalance-hold-duration=<number>] [,ha-auto-rebalance-margin=<number>] [,ha-auto-rebalance-method=<bruteforce|topsis>] [,ha-auto-rebalance-threshold=<number>] [,ha-rebalance-on-start=<1|0>]**
Cluster resource scheduling settings.

ha=<basic | dynamic | static> **(*default =* basic)**
Configures how the HA Manager should select nodes to start or recover services:

- with *basic*, only the number of services is used,
- with *static*, static CPU and memory configuration of services are considered,
- with *dynamic*, static and dynamic CPU and memory usage of services are considered.

ha-auto-rebalance=<boolean> **(*default =* 0)**
Whether to use CRS for balancing HA resources automatically depending on the current node imbalance.

ha-auto-rebalance-hold-duration=<number> (0 - N) (*default =* 3)
The number of HA rounds for which the cluster node imbalance threshold must be exceeded before triggering an automatic resource balancing migration.

Note
Requires option(s): `ha-auto-rebalance`

ha-auto-rebalance-margin=<number> (0 - 100) (*default =* 10)
The minimum relative improvement in cluster node imbalance, in percent, to commit to a resource balancing migration.

Note
Requires option(s): `ha-auto-rebalance`

ha-auto-rebalance-method=<bruteforce | topsis> (*default =* bruteforce)
The method to use for the scoring of balancing migrations.

Note
Requires option(s): `ha-auto-rebalance`

ha-auto-rebalance-threshold=<number> (0 - 100) (*default =* 30)
The cluster node imbalance, in percent, which will trigger the automatic resource balancing system if exceeded.

Note
Requires option(s): `ha-auto-rebalance`

ha-rebalance-on-start=<boolean> (*default =* 0)
Set to use CRS for selecting a suited node when a HA services request-state changes from stop to start.

description: <string>
Datacenter description. Shown in the web-interface datacenter notes panel. This is saved as comment inside the configuration file.

email_from: <string>
Specify email address to send notification from (default is root@$hostname)

fencing: <both | hardware | watchdog> (*default =* watchdog)
Set the fencing mode of the HA cluster. Hardware mode needs a valid configuration of fence devices in /etc/pve/ha/fence.cfg. With both all two modes are used.



Warning
hardware and *both* are EXPERIMENTAL & WIP

ha: shutdown_policy=<enum>
Cluster wide HA settings.

shutdown_policy=<conditional | failover | freeze | migrate>
(*default* = conditional)
Describes the policy for handling HA services on poweroff or reboot of a node. Freeze will always freeze services which are still located on the node on shutdown, those services won't be recovered by the HA manager. Failover will not mark the services as frozen and thus the services will get recovered to other nodes, if the shutdown node does not come up again quickly (< 1min). *conditional* chooses automatically depending on the type of shutdown, i.e., on a reboot the service will be frozen but on a poweroff the service will stay as is, and thus get recovered after about 2 minutes. Migrate will try to move all running services to another node when a reboot or shutdown was triggered. The poweroff process will only continue once no running services are located on the node anymore. If the node comes up again, the service will be moved back to the previously powered-off node, at least if no other migration, reloaction or recovery took place.

http_proxy: http://.*
Specify external http proxy which is used for downloads (example: *http://username:password@host:port/*)

keyboard: <da | de | de-ch | en-gb | en-us | es | fi | fr | fr-be | fr-ca | fr-ch | hu | is | it | ja | lt | mk | nl | no | pl | pt | pt-br | sl | sv | tr>
Default keybord layout for vnc server.

language: <ar | ca | da | de | en | es | eu | fa | fr | he | hr | it | ja | ka | kr | nb | nl | nn | pl | pt_BR | ru | sl | sv | tr | ukr | zh_CN | zh_TW>
Default GUI language.

location: latitude=<number> ,longitude=<number> [,name=<name>]
The location of the cluster.

latitude=<number> (-90 - 90)
The latitude of the nodes location in degrees.

longitude=<number> (-180 - 180)
The longitude of the nodes location in degrees.

name=<name>
The name of the location of this node

mac_prefix: <string> (*default* = BC:24:11)
Prefix for the auto-generated MAC addresses of virtual guests. The default BC:24:11 is the Organizationally Unique Identifier (OUI) assigned by the IEEE to Proxmox Server Solutions GmbH for a MAC Address Block Large (MA-L). You're allowed to use this in local networks, i.e., those not directly reachable by the public (e.g., in a LAN or NAT/Masquerading).

Note that when you run multiple cluster that (partially) share the networks of their virtual guests, it's highly recommended that you extend the default MAC prefix, or generate a custom (valid) one, to reduce the chance of MAC collisions. For example, add a separate extra hexadecimal to the Proxmox OUI for each cluster, like BC:24:11:0 for the first, BC:24:11:1 for the second, and so on. Alternatively, you can also separate the networks of the guests logically, e.g., by using VLANs.

+ For publicly accessible guests it's recommended that you get your own OUI from the IEEE registered or coordinate with your, or your hosting providers, network admins.

max_workers: <integer> (1 - N)
Defines how many workers (per node) are maximal started on actions like *stopall VMs* or task from the ha-manager.

migration: [type=]<secure|insecure> [,network=<CIDR>]
For cluster wide migration settings.

network=<CIDR>
CIDR of the (sub) network that is used for migration. Used as a fallback for replications jobs if the replication network setting is not set

type=<insecure | secure> (*default* = secure)
Migration traffic is encrypted using an SSH tunnel by default. On secure, completely private networks this can be disabled to increase performance.

migration_unsecure: <boolean>
Migration is secure using SSH tunnel by default. For secure private networks you can disable it to speed up migration. Deprecated, use the *migration* property instead!

next-id: [enforce=<1|0>] [,lower=<integer>] [,unique=<1|0>] [,upper=<integer>]
Control the range for the free VMID auto-selection pool.

enforce=<boolean> (*default* = 0)
Reject IDs for new guests outside of the configured *lower* and *upper* boundaries and, with *unique*, IDs that were used before.

lower=<integer> (*default* = 100)
Lower, inclusive boundary for free next-id API range.

unique=<boolean> (*default* = 0)
Only suggest guest IDs that are neither currently in use nor have previously been used.

upper=<integer> (***default =*** **1000000**)
Upper, exclusive boundary for free next-id API range.

notify: [fencing=<always|never>]
[,package-updates=<auto|always|never>]
[,replication=<always|never>] [,target-fencing=<TARGET>]
[,target-package-updates=<TARGET>] [,target-replication=<TARGET>]
Cluster-wide notification settings.

fencing=<always | never>
UNUSED - Use datacenter notification settings instead.

package-updates=<always | auto | never> (***default =*** **auto**)
DEPRECATED: Use datacenter notification settings instead. Control how often the daily update job should send out notifications:

- *auto* daily for systems with a valid subscription, as those are assumed to be production-ready and thus should know about pending updates.
- *always* every update, if there are new pending updates.
- *never* never send a notification for new pending updates.

replication=<always | never>
UNUSED - Use datacenter notification settings instead.

target-fencing=<TARGET>
UNUSED - Use datacenter notification settings instead.

target-package-updates=<TARGET>
UNUSED - Use datacenter notification settings instead.

target-replication=<TARGET>
UNUSED - Use datacenter notification settings instead.

registered-tags: <tag>[;<tag>...]
A list of tags that require a `Sys.Modify` on `/` to set and delete. Tags set here that are also in *user-tag-access* also require `Sys.Modify`.

replication: [type=]<secure|insecure> [,network=<CIDR>]
For cluster wide replication settings.

network=<CIDR>
CIDR of the (sub) network that is used for replication jobs.

type=<insecure | secure> (***default =*** **secure**)
Replication traffic is encrypted using an SSH tunnel by default. On secure, completely private networks this can be disabled to increase performance.

tag-style: [case-sensitive=<1|0>]
[,color-map=<tag>:<hex-color>[:<hex-color-for-text>][;<tag>=...]]
[,ordering=<config|alphabetical>] [,shape=<enum>]

Tag style options.

case-sensitive=<boolean> (*default =* 0)

Controls if filtering for unique tags on update should check case-sensitive.

color-map=<tag>:<hex-color>[:<hex-color-for-text>][;<tag>=...]

Manual color mapping for tags (semicolon separated).

ordering=<alphabetical | config> (*default =* alphabetical)

Controls the sorting of the tags in the web-interface and the API update.

shape=<circle | dense | full | none> (*default =* circle)

Tag shape for the web ui tree. *full* draws the full tag. *circle* draws only a circle with the background color. *dense* only draws a small rectancle (useful when many tags are assigned to each guest).*none* disables showing the tags.

token-policy: [allow-extension-on-regenerate=<1|0>]
[,default-to-max-lifetime=<1|0>] [,disallow-expiry-extension=<1|0>]
[,max-lifetime=<seconds>] [,require-expiry=<1|0>]
[,require-privilege-separation=<1|0>]

Cluster-wide policy for creating and updating API tokens, for example to enforce an expiration date or privilege separation.

allow-extension-on-regenerate=<boolean> (*default =* 0)

Allow extending the expiration date of an existing API token when its secret is regenerated in the same request, despite *disallow-expiry-extension*. The maximum lifetime still applies.

default-to-max-lifetime=<boolean> (*default =* 0)

Give API tokens created without an expiration date the maximum lifetime instead of rejecting them, for example for tools unaware of the policy. Has no effect without *max-lifetime*.

disallow-expiry-extension=<boolean> (*default =* 0)

Disallow moving the expiration date of existing API tokens later or removing it, so that *max-lifetime* cannot be circumvented by extending tokens repeatedly. Shortening the expiration date or setting one on a token that has none remains possible, and tokens can still be deleted and recreated.

max-lifetime=<seconds>

Maximum lifetime of API tokens in seconds, counted from when the expiration date is set, that is on creation or when an update changes it. Implies *require-expiry*.

require-expiry=<boolean> (*default =* 0)

Require an expiration date for new API tokens and when changing the expiration date of existing ones.

require-privilege-separation=<boolean> (***default =*** 0)
Require privilege separation for new API tokens and when changing that setting on existing ones, that is, disallow tokens with the full privileges of their user.

u2f: [appid=<APPID>] [,origin=<URL>]
u2f

appid=<APPID>
U2F AppId URL override. Defaults to the origin.

origin=<URL>
U2F Origin override. Mostly useful for single nodes with a single URL.

user-tag-access: [user-allow=<enum>]
[,user-allow-list=<tag>[;<tag>...]]
Privilege options for user-settable tags

user-allow=<existing | free | list | none> (***default =*** **free**)
Controls which tags can be set or deleted on resources a user controls (such as guests). Users with the `Sys.Modify` privilege on `/` are alwaysunrestricted.

- *none* no tags are usable.
- *list* tags from *user-allow-list* are usable.
- *existing* like list, but already existing tags of resources are also usable.
- *free* no tag restrictions.

user-allow-list=<tag>[;<tag>...]
List of tags users are allowed to set and delete (semicolon separated) for *user-allow* values *list* and *existing*.

webauthn: [allow-subdomains=<1|0>] [,id=<DOMAINNAME>]
[,origin=<URL>] [,rp=<RELYING_PARTY>]
webauthn configuration

allow-subdomains=<boolean> (***default =*** 1)
Whether to allow the origin to be a subdomain, rather than the exact URL.

id=<DOMAINNAME>
Relying party ID. Must be the domain name without protocol, port or location. Changing this **will** break existing credentials.

origin=<URL>
Site origin. Must be a `https://` URL (or `http://localhost`). Should contain the address users type in their browsers to access the web interface. Changing this **may** break existing credentials.

rp=<RELYING_PARTY>
Relying party name. Any text identifier. Changing this **may** break existing credentials.

Appendix D

Calendar Events

D.1 Schedule Format

Proxmox VE has a very flexible scheduling configuration. It is based on the systemd time calendar event format.[1] Calendar events may be used to refer to one or more points in time in a single expression.

Such a calendar event uses the following format:

```
[WEEKDAY] [[YEARS-]MONTHS-DAYS] [HOURS:MINUTES[:SECONDS]]
```

This format allows you to configure a set of days on which the job should run. You can also set one or more start times. It tells the replication scheduler the moments in time when a job should start. With this information we, can create a job which runs every workday at 10 PM: `'mon,tue,wed,thu,fri 22'` which could be abbreviated to: `'mon..fri 22'`, most reasonable schedules can be written quite intuitive this way.

Note
Hours are formatted in 24-hour format.

To allow a convenient and shorter configuration, one or more repeat times per guest can be set. They indicate that replications are done on the start-time(s) itself and the start-time(s) plus all multiples of the repetition value. If you want to start replication at 8 AM and repeat it every 15 minutes until 9 AM you would use: `'8:00/15'`

Here you see that if no hour separation (`:`), is used the value gets interpreted as minute. If such a separation is used, the value on the left denotes the hour(s), and the value on the right denotes the minute(s). Further, you can use `*` to match all possible values.

To get additional ideas look at more Examples below.

D.2 Detailed Specification

[1] see `man 7 systemd.time` for more information

weekdays

Days are specified with an abbreviated English version: `sun, mon, tue, wed, thu, fri and sat`. You may use multiple days as a comma-separated list. A range of days can also be set by specifying the start and end day separated by "..", for example `mon..fri`. These formats can be mixed. If omitted `'*'` is assumed.

time-format

A time format consists of hours and minutes interval lists. Hours and minutes are separated by `':'`. Both hour and minute can be list and ranges of values, using the same format as days. First are hours, then minutes. Hours can be omitted if not needed. In this case `'*'` is assumed for the value of hours. The valid range for values is `0-23` for hours and `0-59` for minutes.

Note

You can use `systemd-analyze calendar` to see whether a given calendar event specification is valid and when it would be triggered next. By passing the `--iterations=<N>` flag you can also let it output the next `<N>` times the calendar event would trigger (you need to replace `<N>` with a valid integer).

D.2.1 Examples:

There are some special values that have a specific meaning:

Table D.1: Special Values

Value	Syntax
`minutely`	`*-*-* *:*:00`
`hourly`	`*-*-* *:00:00`
`daily`	`*-*-* 00:00:00`
`weekly`	`mon *-*-* 00:00:00`
`monthly`	`*-*-01 00:00:00`
`yearly` or `annually`	`*-01-01 00:00:00`
`quarterly`	`*-01,04,07,10-01 00:00:00`
`semiannually` or `semi-annually`	`*-01,07-01 00:00:00`

Table D.2: Schedule Examples

Schedule String	Alternative	Meaning
mon,tue,wed,thu,fri	mon..fri	Every working day at 0:00
sat,sun	sat..sun	Only on weekends at 0:00
mon,wed,fri	—	Only on Monday, Wednesday and Friday at 0:00
12:05	12:05	Every day at 12:05 PM
*/5	0/5	Every five minutes

Table D.2: (continued)

Schedule String	Alternative	Meaning
mon..wed 30/10	mon,tue,wed 30/10	Monday, Tuesday, Wednesday 30, 40 and 50 minutes after every full hour
mon..fri 8..17,22:0/15	—	Every working day every 15 minutes between 8 AM and 6 PM and between 10 PM and 11 PM
fri 12..13:5/20	fri 12,13:5/20	Friday at 12:05, 12:25, 12:45, 13:05, 13:25 and 13:45
12,14,16,18,20,22:5	12/2:5	Every day starting at 12:05 until 22:05, every 2 hours
*	*/1	Every minute (minimum interval)
*-05	—	On the 5th day of every Month
Sat *-1..7 15:00	—	First Saturday each Month at 15:00
2015-10-21	—	21st October 2015 at 00:00

Appendix E

QEMU vCPU List

E.1 Introduction

This is a list of AMD and Intel x86-64/amd64 CPU types as defined in QEMU, going back to 2007.

E.2 Intel CPU Types

Intel processors

- *Nahelem* : 1st generation of the Intel Core processor
- *Nahelem-IBRS (v2)* : add Spectre v1 protection (*+spec-ctrl*)
- *Westmere* : 1st generation of the Intel Core processor (Xeon E7-)
- *Westmere-IBRS (v2)* : add Spectre v1 protection (*+spec-ctrl*)
- *SandyBridge* : 2nd generation of the Intel Core processor
- *SandyBridge-IBRS (v2)* : add Spectre v1 protection (*+spec-ctrl*)
- *IvyBridge* : 3rd generation of the Intel Core processor
- *IvyBridge-IBRS (v2)*: add Spectre v1 protection (*+spec-ctrl*)
- *Haswell* : 4th generation of the Intel Core processor
- *Haswell-noTSX (v2)* : disable TSX (*-hle*, *-rtm*)
- *Haswell-IBRS (v3)* : re-add TSX, add Spectre v1 protection (*+hle*, *+rtm*, *+spec-ctrl*)
- *Haswell-noTSX-IBRS (v4)* : disable TSX (*-hle*, *-rtm*)
- *Broadwell*: 5th generation of the Intel Core processor
- *Skylake*: 1st generation Xeon Scalable server processors
- *Skylake-IBRS (v2)* : add Spectre v1 protection, disable CLFLUSHOPT (*+spec-ctrl*, *-clflushopt*)

- *Skylake-noTSX-IBRS (v3)* : disable TSX (*-hle*, *-rtm*)
- *Skylake-v4*: add EPT switching (*+vmx-eptp-switching*)
- *Cascadelake*: 2nd generation Xeon Scalable processor
- *Cascadelake-v2* : add arch_capabilities msr (*+arch-capabilities*, *+rdctl-no*, *+ibrs-all*, *+skip-l1dfl-vmentry*, *+mds-no*)
- *Cascadelake-v3* : disable TSX (*-hle*, *-rtm*)
- *Cascadelake-v4* : add EPT switching (*+vmx-eptp-switching*)
- *Cascadelake-v5* : add XSAVES (*+xsaves*, *+vmx-xsaves*)
- *Cooperlake* : 3rd generation Xeon Scalable processors for 4 & 8 sockets servers
- *Cooperlake-v2* : add XSAVES (*+xsaves*, *+vmx-xsaves*)
- *Icelake*: 3rd generation Xeon Scalable server processors
- *Icelake-v2* : disable TSX (*-hle*, *-rtm*)
- *Icelake-v3* : add arch_capabilities msr (*+arch-capabilities*, *+rdctl-no*, *+ibrs-all*, *+skip-l1dfl-vmentry*, *+mds-no*, *+pschange-mc-no*, *+taa-no*)
- *Icelake-v4* : add missing flags (*+sha-ni*, *+avx512ifma*, *+rdpid*, *+fsrm*, *+vmx-rdseed-exit*, *+vmx-pml*, *+vmx-eptp-switching*)
- *Icelake-v5* : add XSAVES (*+xsaves*, *+vmx-xsaves*)
- *Icelake-v6* : add "5-level EPT" (*+vmx-page-walk-5*)
- *SapphireRapids* : 4th generation Xeon Scalable server processors

E.3 AMD CPU Types

AMD processors

- *Opteron_G3* : K10
- *Opteron_G4* : Bulldozer
- *Opteron_G5* : Piledriver
- *EPYC* : 1st generation of Zen processors
- *EPYC-IBPB (v2)* : add Spectre v1 protection (*+ibpb*)
- *EPYC-v3* : add missing flags (*+perfctr-core*, *+clzero*, *+xsaveerptr*, *+xsaves*)
- *EPYC-Rome* : 2nd generation of Zen processors
- *EPYC-Rome-v2* : add Spectre v2, v4 protection (*+ibrs*, *+amd-ssbd*)
- *EPYC-Milan* : 3rd generation of Zen processors
- *EPYC-Milan-v2* : add missing flags (*+vaes*, *+vpclmulqdq*, *+stibp-always-on*, *+amd-psfd*, *+no-nested-data-bp*, *+lfence-always-serializing*, *+null-sel-clr-base*)

Appendix F

Firewall Macro Definitions

Amanda Amanda Backup

Action	proto	dport	sport
PARAM	udp	10080	
PARAM	tcp	10080	

Auth Auth (identd) traffic

Action	proto	dport	sport
PARAM	tcp	113	

BGP Border Gateway Protocol traffic

Action	proto	dport	sport
PARAM	tcp	179	

BitTorrent BitTorrent traffic for BitTorrent 3.1 and earlier

Action	proto	dport	sport
PARAM	tcp	6881:6889	
PARAM	udp	6881	

BitTorrent32 BitTorrent traffic for BitTorrent 3.2 and later

Action	proto	dport	sport
PARAM	tcp	6881:6999	
PARAM	udp	6881	

CVS Concurrent Versions System pserver traffic

Action	proto	dport	sport
PARAM	tcp	2401	

Ceph Ceph Storage Cluster traffic (Ceph Monitors, OSD & MDS Daemons)

Action	proto	dport	sport
PARAM	tcp	6789	
PARAM	tcp	3300	
PARAM	tcp	6800:7300	

Citrix Citrix/ICA traffic (ICA, ICA Browser, CGP)

Action	proto	dport	sport
PARAM	tcp	1494	
PARAM	udp	1604	
PARAM	tcp	2598	

DAAP Digital Audio Access Protocol traffic (iTunes, Rythmbox daemons)

Action	proto	dport	sport
PARAM	tcp	3689	
PARAM	udp	3689	

DCC Distributed Checksum Clearinghouse spam filtering mechanism

Action	proto	dport	sport
PARAM	tcp	6277	

DHCPfwd Forwarded DHCP traffic

Action	proto	dport	sport
PARAM	udp	67:68	67:68

DHCPv6 DHCPv6 traffic

Action	proto	dport	sport
PARAM	udp	546:547	546:547

DNS Domain Name System traffic (upd and tcp)

Action	proto	dport	sport
PARAM	udp	53	
PARAM	tcp	53	

Distcc Distributed Compiler service

Action	proto	dport	sport
PARAM	tcp	3632	

FTP File Transfer Protocol

Action	proto	dport	sport
PARAM	tcp	21	

Finger Finger protocol (RFC 742)

Action	proto	dport	sport
PARAM	tcp	79	

GNUnet GNUnet secure peer-to-peer networking traffic

Action	proto	dport	sport
PARAM	tcp	2086	
PARAM	udp	2086	
PARAM	tcp	1080	
PARAM	udp	1080	

GRE Generic Routing Encapsulation tunneling protocol

Action	proto	dport	sport
PARAM	47		

Git Git distributed revision control traffic

Action	proto	dport	sport
PARAM	tcp	9418	

HKP OpenPGP HTTP key server protocol traffic

Action	proto	dport	sport
PARAM	tcp	11371	

HTTP Hypertext Transfer Protocol (WWW)

Action	proto	dport	sport
PARAM	tcp	80	

HTTPS Hypertext Transfer Protocol (WWW) over SSL

Action	proto	dport	sport
PARAM	tcp	443	

ICPV2 Internet Cache Protocol V2 (Squid) traffic

Action	proto	dport	sport
PARAM	udp	3130	

ICQ AOL Instant Messenger traffic

Action	proto	dport	sport
PARAM	tcp	5190	

IMAP Internet Message Access Protocol

Action	proto	dport	sport
PARAM	tcp	143	

IMAPS Internet Message Access Protocol over SSL

Action	proto	dport	sport
PARAM	tcp	993	

IPIP IPIP capsulation traffic

Action	proto	dport	sport
PARAM	94		

IPsec IPsec traffic

Action	proto	dport	sport
PARAM	udp	500	500
PARAM	50		

IPsecah IPsec authentication (AH) traffic

Action	proto	dport	sport
PARAM	udp	500	500
PARAM	51		

IPsecnat IPsec traffic and Nat-Traversal

Action	proto	dport	sport
PARAM	udp	500	
PARAM	udp	4500	
PARAM	50		

IRC Internet Relay Chat traffic

Action	proto	dport	sport
PARAM	tcp	6667	

Jetdirect HP Jetdirect printing

Action	proto	dport	sport
PARAM	tcp	9100	

L2TP Layer 2 Tunneling Protocol traffic

Action	proto	dport	sport
PARAM	udp	1701	

LDAP Lightweight Directory Access Protocol traffic

Action	proto	dport	sport
PARAM	tcp	389	

LDAPS Secure Lightweight Directory Access Protocol traffic

Action	proto	dport	sport
PARAM	tcp	636	

MDNS Multicast DNS

Action	proto	dport	sport
PARAM	udp	5353	

MSNP Microsoft Notification Protocol

Action	proto	dport	sport
PARAM	tcp	1863	

MSSQL Microsoft SQL Server

Action	proto	dport	sport
PARAM	tcp	1433	

Mail Mail traffic (SMTP, SMTPS, Submission)

Action	proto	dport	sport
PARAM	tcp	25	
PARAM	tcp	465	
PARAM	tcp	587	

Munin Munin networked resource monitoring traffic

Action	proto	dport	sport
PARAM	tcp	4949	

MySQL MySQL server

Action	proto	dport	sport
PARAM	tcp	3306	

NNTP NNTP traffic (Usenet).

Action	proto	dport	sport
PARAM	tcp	119	

NNTPS Encrypted NNTP traffic (Usenet)

Action	proto	dport	sport
PARAM	tcp	563	

NTP Network Time Protocol (ntpd)

Action	proto	dport	sport
PARAM	udp	123	

NeighborDiscovery IPv6 neighbor solicitation, neighbor and router advertisement

Action	proto	dport	sport
PARAM	icmpv6	router-solicitation	
PARAM	icmpv6	router-advertisement	
PARAM	icmpv6	neighbor-solicitation	
PARAM	icmpv6	neighbor-advertisement	

OSPF OSPF multicast traffic

Action	proto	dport	sport
PARAM	89		

OpenVPN OpenVPN traffic

Action	proto	dport	sport
PARAM	udp	1194	

PCA Symantec PCAnywere (tm)

Action	proto	dport	sport
PARAM	udp	5632	
PARAM	tcp	5631	

PMG Proxmox Mail Gateway web interface

Action	proto	dport	sport
PARAM	tcp	8006	

POP3 POP3 traffic

Action	proto	dport	sport
PARAM	tcp	110	

POP3S Encrypted POP3 traffic

Action	proto	dport	sport
PARAM	tcp	995	

PPtP Point-to-Point Tunneling Protocol

Action	proto	dport	sport
PARAM	47		
PARAM	tcp	1723	

Ping ICMP echo request

Action	proto	dport	sport
PARAM	icmp	echo-request	

PostgreSQL PostgreSQL server

Action	proto	dport	sport
PARAM	tcp	5432	

Printer Line Printer protocol printing

Action	proto	dport	sport
PARAM	tcp	515	

RDP Microsoft Remote Desktop Protocol traffic

Action	proto	dport	sport
PARAM	tcp	3389	

RIP Routing Information Protocol (bidirectional)

Action	proto	dport	sport
PARAM	udp	520	

RNDC BIND remote management protocol

Action	proto	dport	sport
PARAM	tcp	953	

Razor Razor Antispam System

Action	proto	dport	sport
PARAM	tcp	2703	

Rdate Remote time retrieval (rdate)

Action	proto	dport	sport
PARAM	tcp	37	

Rsync Rsync server

Action	proto	dport	sport
PARAM	tcp	873	

SANE SANE network scanning

Action	proto	dport	sport
PARAM	tcp	6566	

SMB Microsoft SMB traffic

Action	proto	dport	sport
PARAM	udp	135,445	
PARAM	udp	137:139	
PARAM	udp	1024:65535	137
PARAM	tcp	135,139,445	

SMBswat Samba Web Administration Tool

Action	proto	dport	sport
PARAM	tcp	901	

SMTP Simple Mail Transfer Protocol

Action	proto	dport	sport
PARAM	tcp	25	

SMTPS Encrypted Simple Mail Transfer Protocol

Action	proto	dport	sport
PARAM	tcp	465	

SNMP Simple Network Management Protocol

Action	proto	dport	sport
PARAM	udp	161:162	
PARAM	tcp	161	

SPAMD Spam Assassin SPAMD traffic

Action	proto	dport	sport
PARAM	tcp	783	

SPICEproxy Proxmox VE SPICE display proxy traffic

Action	proto	dport	sport
PARAM	tcp	3128	

SSH Secure shell traffic

Action	proto	dport	sport
PARAM	tcp	22	

SVN Subversion server (svnserve)

Action	proto	dport	sport
PARAM	tcp	3690	

SixXS SixXS IPv6 Deployment and Tunnel Broker

Action	proto	dport	sport
PARAM	tcp	3874	
PARAM	udp	3740	
PARAM	41		
PARAM	udp	5072,8374	

Squid Squid web proxy traffic

Action	proto	dport	sport
PARAM	tcp	3128	

Submission Mail message submission traffic

Action	proto	dport	sport
PARAM	tcp	587	

Syslog Syslog protocol (RFC 5424) traffic

Action	proto	dport	sport
PARAM	udp	514	
PARAM	tcp	514	

TFTP Trivial File Transfer Protocol traffic

Action	proto	dport	sport
PARAM	udp	69	

Telnet Telnet traffic

Action	proto	dport	sport
PARAM	tcp	23	

Telnets Telnet over SSL

Action	proto	dport	sport
PARAM	tcp	992	

Time RFC 868 Time protocol

Action	proto	dport	sport
PARAM	tcp	37	

Trcrt Traceroute (for up to 30 hops) traffic

Action	proto	dport	sport
PARAM	udp	33434:33524	
PARAM	icmp	echo-request	

VNC VNC traffic for VNC display's 0 - 99

Action	proto	dport	sport
PARAM	tcp	5900:5999	

VNCL VNC traffic from Vncservers to Vncviewers in listen mode

Action	proto	dport	sport
PARAM	tcp	5500	

Web WWW traffic (HTTP and HTTPS)

Action	proto	dport	sport
PARAM	tcp	80	
PARAM	tcp	443	

Webcache Web Cache/Proxy traffic (port 8080)

Action	proto	dport	sport
PARAM	tcp	8080	

Webmin Webmin traffic

Action	proto	dport	sport
PARAM	tcp	10000	

Whois Whois (nicname, RFC 3912) traffic

Action	proto	dport	sport
PARAM	tcp	43	

Appendix G

Markdown Primer

> Markdown is a text-to-HTML conversion tool for web writers. Markdown allows you to write using an easy-to-read, easy-to-write plain text format, then convert it to structurally valid XHTML (or HTML).
>
> — John Gruber *https://daringfireball.net/projects/markdown/*

The Proxmox VE web interface has support for using Markdown to rendering rich text formatting in node and virtual guest notes.

Proxmox VE supports CommonMark with most extensions of GFM (GitHub Flavoured Markdown), like tables or task-lists.

G.1 Markdown Basics

Note that we only describe the basics here, please search the web for more extensive resources, for example on https://www.markdownguide.org/

G.1.1 Headings

```
# This is a Heading h1
## This is a Heading h2
##### This is a Heading h5
```

G.1.2 Emphasis

Use `*text*` or `_text_` for emphasis.

Use `**text**` or `__text__` for bold, heavy-weight text.

Combinations are also possible, for example:

```
_You **can** combine them_
```

G.1.3 Links

You can use automatic detection of links, for example, `https://forum.proxmox.com/` would transform it into a clickable link.

You can also control the link text, for example:

```
Now, [the part in brackets will be the link text](https://forum.proxmox.com ↩
   /).
```

G.1.4 Lists

Unordered Lists

Use * or − for unordered lists, for example:

```
* Item 1
* Item 2
* Item 2a
* Item 2b
```

Adding an indentation can be used to created nested lists.

Ordered Lists

```
1. Item 1
1. Item 2
1. Item 3
  1. Item 3a
  1. Item 3b
```

Note
The integer of ordered lists does not need to be correct, they will be numbered automatically.

Task Lists

Task list use a empty box `[ ]` for unfinished tasks and a box with an `X` for finished tasks.

For example:

```
- [X] First task already done!
- [X] Second one too
- [ ] This one is still to-do
- [ ] So is this one
```

G.1.5 Tables

Tables use the pipe symbol | to separate columns, and − to separate the table header from the table body, in that separation one can also set the text alignment, making one column left-, center-, or right-aligned.

```
| Left columns  | Right columns |  Some  | More | Cols.| Centering Works  ↩
   Too
| -------------  ↩
   |--------------:|--------|------|------|:------------------:|
| left foo      | right foo     | First  | Row  | Here | >center<  ↩
             |
| left bar      | right bar     | Second | Row  | Here | 12345  ↩
                |
| left baz      | right baz     | Third  | Row  | Here | Test  ↩
                 |
| left zab      | right zab     | Fourth | Row  | Here |  ↩
   &#x2601;&#xfe0f;&#x2601;&#xfe0f;&#x2601;&#xfe0f;              |
| left rab      | right rab     | And    | Last | Here | The End  ↩
              |
```

Note that you do not need to align the columns nicely with white space, but that makes editing tables easier.

G.1.6 Block Quotes

You can enter block quotes by prefixing a line with >, similar as in plain-text emails.

```
> Markdown is a lightweight markup language with plain-text-formatting  ↩
   syntax,
> created in 2004 by John Gruber with Aaron Swartz.
>
>> Markdown is often used to format readme files, for writing messages in  ↩
   online discussion forums,
>> and to create rich text using a plain text editor.
```

G.1.7 Code and Snippets

You can use backticks to avoid processing for a few word or paragraphs. That is useful for avoiding that a code or configuration hunk gets mistakenly interpreted as markdown.

Inline code

Surrounding part of a line with single backticks allows to write code inline, for examples:

```
This hosts IP address is `10.0.0.1`.
```

Whole blocks of code

For code blocks spanning several lines you can use triple-backticks to start and end such a block, for example:

```
# This is the network config I want to remember here
auto vmbr2
iface vmbr2 inet static
        address 10.0.0.1/24
        bridge-ports ens20
        bridge-stp off
        bridge-fd 0
        bridge-vlan-aware yes
        bridge-vids 2-4094
```

Appendix H

GNU Free Documentation License

Version 1.3, 3 November 2008

Copyright (C) 2000, 2001, 2002, 2007, 2008 Free Software Foundation, Inc.
<http://fsf.org/>
Everyone is permitted to copy and distribute verbatim copies
of this license document, but changing it is not allowed.

0. PREAMBLE

The purpose of this License is to make a manual, textbook, or other functional and useful document "free" in the sense of freedom: to assure everyone the effective freedom to copy and redistribute it, with or without modifying it, either commercially or noncommercially. Secondarily, this License preserves for the author and publisher a way to get credit for their work, while not being considered responsible for modifications made by others.

This License is a kind of "copyleft", which means that derivative works of the document must themselves be free in the same sense. It complements the GNU General Public License, which is a copyleft license designed for free software.

We have designed this License in order to use it for manuals for free software, because free software needs free documentation: a free program should come with manuals providing the same freedoms that the software does. But this License is not limited to software manuals; it can be used for any textual work, regardless of subject matter or whether it is published as a printed book. We recommend this License principally for works whose purpose is instruction or reference.

1. APPLICABILITY AND DEFINITIONS

This License applies to any manual or other work, in any medium, that contains a notice placed by the copyright holder saying it can be distributed under the terms of this License. Such a notice grants a worldwide, royalty-free license, unlimited in duration, to use that work under the conditions stated herein. The "Document", below, refers to any such manual or work. Any member of the public is a licensee, and is addressed as "you". You accept the license if you copy, modify or distribute the work in a way requiring permission under copyright law.

A "Modified Version" of the Document means any work containing the Document or a portion of it, either copied verbatim, or with modifications and/or translated into another language.

A "Secondary Section" is a named appendix or a front-matter section of the Document that deals exclusively with the relationship of the publishers or authors of the Document to the Document's overall subject (or to related matters) and contains nothing that could fall directly within that overall subject. (Thus, if the Document is in part a textbook of mathematics, a Secondary Section may not explain any mathematics.) The relationship could be a matter of historical connection with the subject or with related matters, or of legal, commercial, philosophical, ethical or political position regarding them.

The "Invariant Sections" are certain Secondary Sections whose titles are designated, as being those of Invariant Sections, in the notice that says that the Document is released under this License. If a section does not fit the above definition of Secondary then it is not allowed to be designated as Invariant. The Document may contain zero Invariant Sections. If the Document does not identify any Invariant Sections then there are none.

The "Cover Texts" are certain short passages of text that are listed, as Front-Cover Texts or Back-Cover Texts, in the notice that says that the Document is released under this License. A Front-Cover Text may be at most 5 words, and a Back-Cover Text may be at most 25 words.

A "Transparent" copy of the Document means a machine-readable copy, represented in a format whose specification is available to the general public, that is suitable for revising the document straightforwardly with generic text editors or (for images composed of pixels) generic paint programs or (for drawings) some widely available drawing editor, and that is suitable for input to text formatters or for automatic translation to a variety of formats suitable for input to text formatters. A copy made in an otherwise Transparent file format whose markup, or absence of markup, has been arranged to thwart or discourage subsequent modification by readers is not Transparent. An image format is not Transparent if used for any substantial amount of text. A copy that is not "Transparent" is called "Opaque".

Examples of suitable formats for Transparent copies include plain ASCII without markup, Texinfo input format, LaTeX input format, SGML or XML using a publicly available DTD, and standard-conforming simple HTML, PostScript or PDF designed for human modification. Examples of transparent image formats include PNG, XCF and JPG. Opaque formats include proprietary formats that can be read and edited only by proprietary word processors, SGML or XML for which the DTD and/or processing tools are not generally available, and the machine-generated HTML, PostScript or PDF produced by some word processors for output purposes only.

The "Title Page" means, for a printed book, the title page itself, plus such following pages as are needed to hold, legibly, the material this License requires to appear in the title page. For works in formats which do not have any title page as such, "Title Page" means the text near the most prominent appearance of the work's title, preceding the beginning of the body of the text.

The "publisher" means any person or entity that distributes copies of the Document to the public.

A section "Entitled XYZ" means a named subunit of the Document whose title either is precisely XYZ or contains XYZ in parentheses following text that translates XYZ in another language. (Here XYZ stands for a specific section name mentioned below, such as "Acknowledgements", "Dedications", "Endorsements", or "History".) To "Preserve the Title" of such a section when you modify the Document means that it remains a section "Entitled XYZ" according to this definition.

The Document may include Warranty Disclaimers next to the notice which states that this License applies to the Document. These Warranty Disclaimers are considered to be included by reference in this License, but only as regards disclaiming warranties: any other implication that these Warranty Disclaimers may have is void and has no effect on the meaning of this License.

2. VERBATIM COPYING

You may copy and distribute the Document in any medium, either commercially or noncommercially, provided that this License, the copyright notices, and the license notice saying this License applies to the Document are reproduced in all copies, and that you add no other conditions whatsoever to those of this License. You may not use technical measures to obstruct or control the reading or further copying of the copies you make or distribute. However, you may accept compensation in exchange for copies. If you distribute a large enough number of copies you must also follow the conditions in section 3.

You may also lend copies, under the same conditions stated above, and you may publicly display copies.

3. COPYING IN QUANTITY

If you publish printed copies (or copies in media that commonly have printed covers) of the Document, numbering more than 100, and the Document's license notice requires Cover Texts, you must enclose the copies in covers that carry, clearly and legibly, all these Cover Texts: Front-Cover Texts on the front cover, and Back-Cover Texts on the back cover. Both covers must also clearly and legibly identify you as the publisher of these copies. The front cover must present the full title with all words of the title equally prominent and visible. You may add other material on the covers in addition. Copying with changes limited to the covers, as long as they preserve the title of the Document and satisfy these conditions, can be treated as verbatim copying in other respects.

If the required texts for either cover are too voluminous to fit legibly, you should put the first ones listed (as many as fit reasonably) on the actual cover, and continue the rest onto adjacent pages.

If you publish or distribute Opaque copies of the Document numbering more than 100, you must either include a machine-readable Transparent copy along with each Opaque copy, or state in or with each Opaque copy a computer-network location from which the general network-using public has access to download using public-standard network protocols a complete Transparent copy of the Document, free of added material. If you use the latter option, you must take reasonably prudent steps, when you begin distribution of Opaque copies in quantity, to ensure that this Transparent copy will remain thus accessible at the stated location until at least one year after the last time you distribute an Opaque copy (directly or through your agents or retailers) of that edition to the public.

It is requested, but not required, that you contact the authors of the Document well before redistributing any large number of copies, to give them a chance to provide you with an updated version of the Document.

4. MODIFICATIONS

You may copy and distribute a Modified Version of the Document under the conditions of sections 2 and 3 above, provided that you release the Modified Version under precisely this License, with the Modified Version filling the role of the Document, thus licensing distribution and modification of the Modified Version to whoever possesses a copy of it. In addition, you must do these things in the Modified Version:

A. Use in the Title Page (and on the covers, if any) a title distinct from that of the Document, and from those of previous versions (which should, if there were any, be listed in the History section of the Document). You may use the same title as a previous version if the original publisher of that version gives permission.

B. List on the Title Page, as authors, one or more persons or entities responsible for authorship of the modifications in the Modified Version, together with at least five of the principal authors of the Document (all of its principal authors, if it has fewer than five), unless they release you from this requirement.

C. State on the Title page the name of the publisher of the Modified Version, as the publisher.

D. Preserve all the copyright notices of the Document.

E. Add an appropriate copyright notice for your modifications adjacent to the other copyright notices.

F. Include, immediately after the copyright notices, a license notice giving the public permission to use the Modified Version under the terms of this License, in the form shown in the Addendum below.

G. Preserve in that license notice the full lists of Invariant Sections and required Cover Texts given in the Document's license notice.

H. Include an unaltered copy of this License.

I. Preserve the section Entitled "History", Preserve its Title, and add to it an item stating at least the title, year, new authors, and publisher of the Modified Version as given on the Title Page. If there is no section Entitled "History" in the Document, create one stating the title, year, authors, and publisher of the Document as given on its Title Page, then add an item describing the Modified Version as stated in the previous sentence.

J. Preserve the network location, if any, given in the Document for public access to a Transparent copy of the Document, and likewise the network locations given in the Document for previous versions it was based on. These may be placed in the "History" section. You may omit a network location for a work that was published at least four years before the Document itself, or if the original publisher of the version it refers to gives permission.

K. For any section Entitled "Acknowledgements" or "Dedications", Preserve the Title of the section, and preserve in the section all the substance and tone of each of the contributor acknowledgements and/or dedications given therein.

L. Preserve all the Invariant Sections of the Document, unaltered in their text and in their titles. Section numbers or the equivalent are not considered part of the section titles.

M. Delete any section Entitled "Endorsements". Such a section may not be included in the Modified Version.

N. Do not retitle any existing section to be Entitled "Endorsements" or to conflict in title with any Invariant Section.

O. Preserve any Warranty Disclaimers.

If the Modified Version includes new front-matter sections or appendices that qualify as Secondary Sections and contain no material copied from the Document, you may at your option designate some or all of these sections as invariant. To do this, add their titles to the list of Invariant Sections in the Modified Version's license notice. These titles must be distinct from any other section titles.

You may add a section Entitled "Endorsements", provided it contains nothing but endorsements of your Modified Version by various parties—for example, statements of peer review or that the text has been approved by an organization as the authoritative definition of a standard.

You may add a passage of up to five words as a Front-Cover Text, and a passage of up to 25 words as a Back-Cover Text, to the end of the list of Cover Texts in the Modified Version. Only one passage of Front-Cover Text and one of Back-Cover Text may be added by (or through arrangements made by) any one entity. If the Document already includes a cover text for the same cover, previously added by you or by arrangement

made by the same entity you are acting on behalf of, you may not add another; but you may replace the old one, on explicit permission from the previous publisher that added the old one.

The author(s) and publisher(s) of the Document do not by this License give permission to use their names for publicity for or to assert or imply endorsement of any Modified Version.

5. COMBINING DOCUMENTS

You may combine the Document with other documents released under this License, under the terms defined in section 4 above for modified versions, provided that you include in the combination all of the Invariant Sections of all of the original documents, unmodified, and list them all as Invariant Sections of your combined work in its license notice, and that you preserve all their Warranty Disclaimers.

The combined work need only contain one copy of this License, and multiple identical Invariant Sections may be replaced with a single copy. If there are multiple Invariant Sections with the same name but different contents, make the title of each such section unique by adding at the end of it, in parentheses, the name of the original author or publisher of that section if known, or else a unique number. Make the same adjustment to the section titles in the list of Invariant Sections in the license notice of the combined work.

In the combination, you must combine any sections Entitled "History" in the various original documents, forming one section Entitled "History"; likewise combine any sections Entitled "Acknowledgements", and any sections Entitled "Dedications". You must delete all sections Entitled "Endorsements".

6. COLLECTIONS OF DOCUMENTS

You may make a collection consisting of the Document and other documents released under this License, and replace the individual copies of this License in the various documents with a single copy that is included in the collection, provided that you follow the rules of this License for verbatim copying of each of the documents in all other respects.

You may extract a single document from such a collection, and distribute it individually under this License, provided you insert a copy of this License into the extracted document, and follow this License in all other respects regarding verbatim copying of that document.

7. AGGREGATION WITH INDEPENDENT WORKS

A compilation of the Document or its derivatives with other separate and independent documents or works, in or on a volume of a storage or distribution medium, is called an "aggregate" if the copyright resulting from the compilation is not used to limit the legal rights of the compilation's users beyond what the individual works permit. When the Document is included in an aggregate, this License does not apply to the other works in the aggregate which are not themselves derivative works of the Document.

If the Cover Text requirement of section 3 is applicable to these copies of the Document, then if the Document is less than one half of the entire aggregate, the Document's Cover Texts may be placed on covers that bracket the Document within the aggregate, or the electronic equivalent of covers if the Document is in electronic form. Otherwise they must appear on printed covers that bracket the whole aggregate.

8. TRANSLATION

Translation is considered a kind of modification, so you may distribute translations of the Document under the terms of section 4. Replacing Invariant Sections with translations requires special permission from their

copyright holders, but you may include translations of some or all Invariant Sections in addition to the original versions of these Invariant Sections. You may include a translation of this License, and all the license notices in the Document, and any Warranty Disclaimers, provided that you also include the original English version of this License and the original versions of those notices and disclaimers. In case of a disagreement between the translation and the original version of this License or a notice or disclaimer, the original version will prevail.

If a section in the Document is Entitled "Acknowledgements", "Dedications", or "History", the requirement (section 4) to Preserve its Title (section 1) will typically require changing the actual title.

9. TERMINATION

You may not copy, modify, sublicense, or distribute the Document except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, or distribute it is void, and will automatically terminate your rights under this License.

However, if you cease all violation of this License, then your license from a particular copyright holder is reinstated (a) provisionally, unless and until the copyright holder explicitly and finally terminates your license, and (b) permanently, if the copyright holder fails to notify you of the violation by some reasonable means prior to 60 days after the cessation.

Moreover, your license from a particular copyright holder is reinstated permanently if the copyright holder notifies you of the violation by some reasonable means, this is the first time you have received notice of violation of this License (for any work) from that copyright holder, and you cure the violation prior to 30 days after your receipt of the notice.

Termination of your rights under this section does not terminate the licenses of parties who have received copies or rights from you under this License. If your rights have been terminated and not permanently reinstated, receipt of a copy of some or all of the same material does not give you any rights to use it.

10. FUTURE REVISIONS OF THIS LICENSE

The Free Software Foundation may publish new, revised versions of the GNU Free Documentation License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns. See http://www.gnu.org/copyleft/.

Each version of the License is given a distinguishing version number. If the Document specifies that a particular numbered version of this License "or any later version" applies to it, you have the option of following the terms and conditions either of that specified version or of any later version that has been published (not as a draft) by the Free Software Foundation. If the Document does not specify a version number of this License, you may choose any version ever published (not as a draft) by the Free Software Foundation. If the Document specifies that a proxy can decide which future versions of this License can be used, that proxy's public statement of acceptance of a version permanently authorizes you to choose that version for the Document.

11. RELICENSING

"Massive Multiauthor Collaboration Site" (or "MMC Site") means any World Wide Web server that publishes copyrightable works and also provides prominent facilities for anybody to edit those works. A public wiki that anybody can edit is an example of such a server. A "Massive Multiauthor Collaboration" (or "MMC") contained in the site means any set of copyrightable works thus published on the MMC site.

"CC-BY-SA" means the Creative Commons Attribution-Share Alike 3.0 license published by Creative Commons Corporation, a not-for-profit corporation with a principal place of business in San Francisco, California, as well as future copyleft versions of that license published by that same organization.

"Incorporate" means to publish or republish a Document, in whole or in part, as part of another Document.

An MMC is "eligible for relicensing" if it is licensed under this License, and if all works that were first published under this License somewhere other than this MMC, and subsequently incorporated in whole or in part into the MMC, (1) had no cover texts or invariant sections, and (2) were thus incorporated prior to November 1, 2008.

The operator of an MMC Site may republish an MMC contained in the site under CC-BY-SA on the same site at any time before August 1, 2009, provided the MMC is eligible for relicensing.